



p/n 88-017137-01 B

6K Series Programmer's Guide

Effective: March 3, 2003



IMPORTANT

User Information



WARNING



6K Series products are used to control electrical and mechanical components of motion control systems. You should test your motion system for safety under all potential conditions. Failure to do so can result in damage to equipment and/or serious injury to personnel.

6K Series products and the information in this user guide are the proprietary property of Parker Hannifin Corporation or its licensors, and may not be copied, disclosed, or used for any purpose not expressly authorized by the owner thereof.

Since Parker Hannifin constantly strives to improve all of its products, we reserve the right to change this user guide and software and hardware mentioned therein at any time without notice.

In no event will the provider of the equipment be liable for any incidental, consequential, or special damages of any kind or nature whatsoever, including but not limited to lost profits arising from or in any way connected with the use of the equipment or this user guide.

© 1998-2003 Parker Hannifin Corporation
All Rights Reserved

Motion Planner and Servo Tuner are trademarks of Parker Hannifin Corporation.
Microsoft and MS-DOS are registered trademarks, and Windows, Visual Basic, and Visual C++ are trademarks of Microsoft Corporation.

Technical Assistance Contact your local automation technology center (ATC) or distributor, or ...

North America and Asia:

Compumotor Division of Parker Hannifin
5500 Business Park Drive
Rohnert Park, CA 94928
Telephone: (800) 358-9070 or (707) 584-7558
Fax: (707) 584-3793
e-mail: cmr_help@parker.com
Internet: <http://www.compumotor.com>

Europe (non-German speaking):

Parker Digiplan
21 Balena Close
Poole, Dorset
England BH17 7DX
Telephone: +44 (0)1202 69 9000
Fax: +44 (0)1202 69 5750

Germany, Austria, Switzerland:

HAUSER Elektronik GmbH
Postfach: 77607-1720
Robert-Bosch-Str. 22
D-77656 Offenburg
Telephone: +49 (0)781 509-0
Fax: +49 (0)781 509-176



Technical Support

E-mail: cmr_help@parker.com

Change Summary

Revision B Changes

March 3, 2003

This document, 88-020680-01B, supercedes 88-020680-1A. Changes associated with 6K Series Programmer's Guide revisions, and document clarifications and corrections are as follows:

Topic	Description
Memory Allocation	Correction: Updated the memory allocation table. See page 11.
COMEXS	Added a table to help illustrate stop conditions. See page 16.
Variables	Clarifications: Can store message strings of 50 characters or less. Also, enhancements in the OS for string variables as of revision 5.1.0. See page 18. Better explanation for assigning and using binary variables. See page 22.
Error Handling	Added description of error bit 22. See pages 30 and 31.
System Performance	Clarification: Added explanation of "SYSTEM UPDATE OVERRUN, USE SYSPER4" error message. See page 34.
Memory Allocation	Changed cautionary message about issuing MEMORY command. See page 45.
Drive Type Selection	Added DSTALL to the list of Servo Only Commands. See page 46.
Drive Stall Detection	Added description of DSTALL command. See page 47.
Step Pulse	Correction: Maximum pulse width misstated as 16µs. Corrected to 8µs. See page 47.
Velocity Scaling	Correction: Added PVF command to commands that are multiplied by the SCLD command value. See page 50.
Distance Scaling	Correction: Added PVF command to commands that are multiplied by the SCLD command value. See page 51.

Topic	Description
End-of-Travel Limits	Correction: Added <code>ERROR</code> command to the list of related commands. See page 57.
Homing	Correction: Misstated that <code>HOMLVL</code> defines the active level of the home limit input. Corrected to <code>LIMLVL</code> . See page 59.
Homing Using Channel Z	Correction: Home profile attributes for Figure O misstated that Backup to Home is disabled (<code>HOMBAC0</code>). Corrected to enabled (<code>HOMBAC1</code>). See page 63.
Stall Detection & Kill-on-Stall	Correction: Added note that the encoder count reference must be enabled (<code>ENCCNT1</code>). See page 64.
Encoder Setup Example	Correction: Added <code>ENCCNT1111</code> to code example. See page 65.
Encoder Failure Detection	Enhancement: Added note to use <code>EFAIL</code> command only with differential encoders. See page 66.
Programmable Inputs and Outputs	Correction: Reference to analog outputs. Added PLC scan mode to table of programmed events. Clarified the results of “Kill on I/O Disconnect” mode with <code>KIOEN0</code> . See page 75.
Expansion I/O Bricks	Correction: Added <code>ANIRNG</code> and <code>TIO</code> commands to table. See page 78.
Input Status	Correction: The description for the status assignment/comparison operator for trigger inputs and digital inputs on expansion I/O has changed. See page 80.
Stop Input	Enhancement: Clarified how <code>COMEXS2</code> functions on receiving a stop input. See page 83.
Output Active Level	Enhancement: Added a table describing onboard output settings, states, factory defaults, external power supplies, and statuses. Expanded discussion about outputs on expansion I/O bricks. See page 91.
PLC Scan Mode	Correction: Clarified discussion about the PLC Scan Mode and scan time. See page 104.
To implement a PLC program	Clarification: Added <code>HALT</code> , <code>BREAK</code> , <code>TIMST</code> , and <code>TIMSTP</code> commands to list of allowed commands. See page 104.
Technical Notes about PLC Programs	Enhancement: Controller status bit 3 is set when a PLC program is executed during scan mode. See page 105.
Programming Example	Clarification: Corrected when the “Pause Scan” begins in the graphic. See page 106.

Topic	Description
Linear Interpolation	Correction: Removed references to <code>PSCLA</code> and <code>PSCLV</code> . See page 123 . Also removed first two lines of code from code sample. See 123 .
Path Definition	Correction: Correct total memory 300,000; default allocation (program,compiled) <code>MEMORY150000,150000</code> ; maximum allocation for compiled profiles <code>MEMORY1000,299000</code> . See page 124 .
Path Final Velocity	Enhancement: Added discussion about line or arc segment termination with a final segment velocity (PVF). See page 126 .
Conditional Path Execution	Enhancement: Added discussion about end-points for lines or arcs. See page 127 .
Compiled Motion Profiling	Correction: Correct total memory 300,000; default allocation (program,compiled) <code>MEMORY150000,150000</code> ; maximum allocation for compiled profiles <code>MEMORY1000,299000</code> . See page 136 .
Status Commands	Correction: Added the <code>TASF</code> , <code>TAS</code> , and <code>AS</code> commands. See page 137 .
Rules for Using Velocity in Preset Compiled Motion	Enhancement: Replaces the section titled <code>Lst Motion Segment Must End At Zero Velocity</code> . See page 138 .
Dwells and Direction Changes	Correction: Removed from sample code use of incremental position mode <code>MA0</code> . See page 141 .
On-the-Fly Motion	Correction: Removed from sample code the disable scaling <code>SCALE0</code> . See page 151 .
OTF Error Conditions	Enhancement: Clarified discussion about On-the-Fly error conditions. See page 152 .
How to Set up a Registration Move	Clarification: Cannot configure the master trigger input. Removed See page 155 .
Registration-Sample Application 2	Clarification: Removed from the sample code the reference to deceleration (<code>AD.5</code>). See page 158 .
GOWHEN Syntax	Correction: Added <code>LIM</code> to list of right operands in the Relation Expression Syntax. See page 160 .
Following Status	Clarification: Bit number 26 identifies if the the Following move profile is being limited by the <code>FMAXS</code> or <code>FMAXV</code> commands. See page 167 .
Ratio Following Setup Parameters	Clarification: Master source axis number—If the master source is “8” (<code>VARI</code>), this represents the integer variable (<code>VARI</code>) number. Master source selection—Added source 8 <code>VARI</code> variable to the list. See page 168 .

Topic	Description
Following an Integer Variable	Enhancement: Added discussion of an axis using to follow an integer variable. See page 172 .
Repeatability of the Trigger Inputs and Sensors	Correction: Repeatability is dependant on trigger input position capture and your sensor accuracy. See page 194 .
Multi-Tasking Application Example	Correction: Corrections to solution. See page 219 .
Status Commands	Enhancements: <code>TASF</code> —Added bit 29 <code>GOWHEN</code> error, and bit 31 Executing Profile. <code>TASXF</code> —Added bit 7 Drive Stall Active. <code>TFSF</code> — Added bit 26 Following profile is limited (<code>FMAXA/FMAXV</code>) <code>TERF</code> — Added bit 5 Stop or Kill Issued, 19 Option Card Fault, and 22 Etherer Failure. Other status commands— <code>TSCF</code> and <code>TNT</code> . See page 226 .
List of all Status Commands	Enhancement: Added <code>TANO</code> , <code>TNT</code> , and <code>TSC</code> to list of commands. See page 230 .
Error Messages	Enhancement: Added error messages for <code>MASTER</code> , <code>SLAVE DISTANCE MISMATCH</code> ; <code>OUTPUT BIT USED AS OUTFNC</code> ; and <code>SYSTEM UPDATE OVERRUN</code> , USE <code>SYSPER4</code> . See page 232 .
Breakpoints	Enhancement: Added discussion on use of program breakpoints (<code>BP</code>). See page 238 .

Table of Contents

Revision B Changes	iii
February, 2000	iii

OVERVIEW

About This Manual	i
<i>Organization of This Manual</i>	i
<i>Programming Examples</i>	ii
<i>Reference Documentation</i>	ii
<i>Assumptions of Technical Experience</i>	ii
Before You Begin	iii
Motion Planner — programming support software.....	iii
Technical Support	iv

CHAPTER 1. PROGRAMMING FUNDAMENTALS

Motion Planner Programming Environment	2
Command Syntax	3
<i>Introduction</i>	3
<i>Description of Syntax Letters and Symbols</i>	5
<i>General Guidelines for Syntax</i>	6
<i>Command Value Substitutions</i>	7
<i>Assignment and Comparison Operators</i>	7
<i>Programmable Inputs and Outputs Bit Patterns</i>	9
Creating Programs	9
<i>Program Example</i>	10
<i>Use the Wizards in Motion Planner</i>	10
Storing Programs	11
<i>Memory Allocation</i>	11
<i>Checking Memory Status</i>	12
Executing Programs (options).....	13
Creating and Executing a Setup Program	13
Program Security	14
Controlling Execution of Programs and the Command Buffer	15
<i>COMEXC (Continuous Command Execution)</i>	15
<i>COMEXL (Save Command Buffer on Limit)</i>	15
<i>COMEXR (Effect of Pause/Continue Input)</i>	16
<i>COMEXS (Save Command Buffer on Stop)</i>	16
Restricted Commands During Motion	17
Variables	18
<i>Converting Between Binary and Numeric Variables</i>	18
<i>Using Numeric (VAR and VARI) Variables</i>	19
<i>Using Binary Variables</i>	22
Program Flow Control	23
<i>Unconditional Looping and Branching</i>	23
<i>Conditional Looping and Branching</i>	25
Program Interrupts (ON Conditions).....	29
Error Handling	30
<i>Enabling Error Checking</i>	30
<i>Defining the Error Program</i>	30
<i>Canceling the Branch to the Error Program</i>	31
<i>Error Program Set-up Example</i>	32
Non-Volatile Memory.....	33
System Performance	34

CHAPTER 2. COMMUNICATION

Communication Options	36
Motion Planner Communication Features.....	36
Serial Communication	37
<i>Controlling Multiple Serial Ports</i>	37
<i>RS-232C Daisy-Chaining</i>	38

<i>Daisy-Chaining and RP240s</i>	41
<i>RS-485 Multi-Drop</i>	41

CHAPTER 3. BASIC OPERATIONS SETUP

Before You Begin	44
<i>Setup Parameters Discussed in this Chapter</i>	44
<i>Using a Setup Program</i>	45
<i>Resetting the Controller</i>	45
Memory Allocation.....	45
Drive Setup.....	46
<i>Drive Type Selection</i>	46
<i>Drive Fault Input</i>	46
<i>Drive Stall Detection (stepper axes only)</i>	47
<i>Drive Resolution (stepper axes only)</i>	47
<i>Step Pulse (stepper axes only)</i>	47
<i>Disable Drive On Kill (servo axes only)</i>	48
Scaling	48
<i>Units of Measure without Scaling</i>	48
<i>What is Scaling?</i>	49
<i>When Should I Define Scaling Factors?</i>	49
<i>Acceleration & Deceleration Scaling (SCLA)</i>	50
<i>Velocity Scaling (SCLV)</i>	50
<i>Distance Scaling (SCLD and SCLMAS)</i>	51
Positioning Modes	53
<i>But first, a word about basic motion</i>	53
<i>Preset and Continuous Modes</i>	54
<i>Preset Positioning Mode</i>	55
<i>Continuous Positioning Mode</i>	56
End-of-Travel Limits	57
Homing (Using the Home Inputs).....	59
Encoder-Based Stepper Operation (stepper axes only).....	64
<i>Encoder Resolution</i>	64
<i>Stall Detection & Kill-on-Stall</i>	64
<i>Encoder Set Up Example</i>	65
<i>Encoder Polarity</i>	65
<i>Encoder Count/Capture Referencing</i>	66
<i>Encoder Failure Detection</i>	66
<i>Commanded Direction Polarity</i>	66
Servo Setup (servo axes only).....	67
<i>Basic Tuning Process</i>	68
<i>Encoder Polarity</i>	70
<i>Commanded Direction Polarity</i>	71
<i>DAC Output Limits</i>	72
<i>Servo Control Signal Offset</i>	72
<i>Servo Setup Example</i>	72
Target Zone Mode (move completion criteria—servo axes only).....	74
Programmable Inputs and Outputs (onboard and external inputs & outputs).....	75
<i>Programmable I/O Bit Patterns</i>	76
<i>Onboard Programmable I/O</i>	76
<i>Expansion I/O Bricks</i>	78
<i>Input Functions</i>	79
<i>Output Functions</i>	90

CHAPTER 4. PRODUCT CONTROL OPERATIONS

Variable Arrays (teaching variable data).....	94
<i>Basics of Teach-Data Applications</i>	94
<i>Summary of Related 6K Series Commands</i>	96
<i>Teach-Data Application Example</i>	96
Safety Features	100

Options Overview	101
Stand-Alone Interface Options	101
Programmable Logic Controller	101
Host Computer Interface	101
Programmable I/O Devices	102
Programmable I/O Functions	102
Thumbwheels	103
PLCs	103
PLC Scan Mode	104
RP240 Remote Operator Panel	107
Configuration	107
Operator Interface Features	108
Using the Default Menus	109
Joystick Control, Analog Inputs	114
Joystick Control	114
Analog Input Interface	117
Host Computer Interface	118

CHAPTER 5. CUSTOM PROFILING

S-Curve Profiling	120
S-Curve Programming Requirements	120
Determining the S-Curve Characteristics	120
Programming Example	121
Calculating Jerk	122
Linear Interpolation	123
Contouring (Circular Interpolation)	124
Path Definition	124
Participating Axes	125
Path Acceleration, Deceleration, and Velocity	126
Conditional Path Execution	127
Segment End-point Coordinates	128
Line Segments	129
Arc Segments	129
Segment Boundary	131
Using the C Axis (products with ≥ 4 axes)	131
Using the P Axis (products with ≥ 4 axes)	132
Outputs Along the Path	132
Paths Built Using 6K Series Commands	132
Compiling the Path	133
Executing the Path	133
Possible Programming Errors	133
Programming Examples	134
Compiled Motion Profiling	136
Compiled Following Profiles	139
Dwells and Direction Changes	141
Compiled Motion Versus On-The-Fly Motion	142
Related Commands	142
Compiled Motion — Sample Application 1	143
Compiled Motion — Sample Application 2	145
Compiled Motion — Sample Application 3	147
Compiled Motion — Sample Application 4	148
On-the-Fly Motion (pre-emptive GOs)	151
OTF Error Conditions	152
On-The-Fly Motion — Sample Application	153
Registration	155
How to Set up a Registration Move	155
Registration Move Accuracy(see also Registration Move Status below)	155
Preventing Unwanted Registration Moves (methods)	156
Registration Move Status & Error Handling	156
Registration — Sample Application 1	157
Registration — Sample Application 2	158
Registration — Sample Application 3	159
Synchronizing Motion (GOWHEN and TRGFN operations)	159
Conditional “GO”s (GOWHEN)	159
Trigger Functions (TRGFN)	162

CHAPTER 6. FOLLOWING

Ratio Following – Introduction	166
What can be a master?	166
Following Status (TFSE, TFS & FS Commands)	167
Implementing Ratio Following	168

Ratio Following Setup Parameters	168
Follower vs. Master Move Profiles	173
Performing Phase Shifts	176
Geared Advance Following	178
Summary of Ratio Following Commands	179
Electronic Gearbox Application for Ratio Following	180
Trackball Application for Ratio Following Motion	181
Master Cycle Concept	183
Master Cycle Commands	183
Summary of Master Cycle and Wait Commands	186
Continuous Cut-to-Length Application	187
Technical Considerations for Following	189
Performance Considerations	189
Master Position Prediction	190
Master Position Filtering	190
Following Error	191
Maximum Velocity and Acceleration (Stepper Axes Only)	192
Factors Affecting Following Accuracy	192
Preset vs. Continuous Following Moves	194
Master and Follower Distance Calculations	195
Using Other Features with Following	197
Troubleshooting for Following (also see Chapter 8)	199
Error Messages	199
Following Commands	200

CHAPTER 7. MULTI-TASKING

Introduction to Multi-Tasking	204
Using Multi-Tasking to Run Programs	204
Interaction Between Tasks	208
Axes & Tasks	210
How a “Kill” Works While Multi-Tasking	212
Using 6K Resources While Multi-Tasking	213
Associating Axes with Tasks	213
Sharing Common Resources Between Multiple Tasks	214
Locking Resources to a Specific Task	214
How Multi-tasking and the % Prefix Affect Commands and Responses	215
Input and Output Functions and Multi-tasking	216
Multi-Tasking Performance Issues	217
When is a Task Active?	217
Task Swapping	218
Task Execution Speed	218
Multi-Tasking Application Example	219
One machine multi-tasking application	219

CHAPTER 8 TROUBLESHOOTING

Troubleshooting Basics	222
Solutions to Common Problems	222
Program Debug Tools	225
Status Commands	226
Error Messages	232
Trace Mode	236
Single-Step Mode	237
Breakpoints	238
Simulating I/O Activation	238
Simulating Analog Input Channel Voltages	240
Motion Planner’s Panel Gallery	240
Technical Support	241
Operating System Upgrades	241
Product Return Procedure	241

INDEX

242

OVERVIEW

About This Manual

This manual is designed to help you implement the 6K Series Product's features in your application. Detailed feature descriptions are provided, including application scenarios and programming examples. For details on each 6K command, see the *6K Series Command Reference*.

Organization of This Manual

Chapter	Information
Chapter 1. <i>Programming Fundamentals</i>	Discussion of essential programming guidelines and standard programming features such as branching, variables, interrupts, error handling, etc.
Chapter 2. <i>Communication</i>	Communication considerations, such as using Motion Planner, alert event handling, communication server and fast status control, RS-232 daisy-chains and RS-485 multi-drops, etc.
Chapter 3. <i>Basic Operation Setup</i>	General operation setup conditions, such as number of axes, scaling factors, feedback device setup, programmable input and output functions, end-of-travel limits, homing, etc.
Chapter 4. <i>Product Control Options</i>	Considerations for implementing various product control methods, such as programmable I/O, a joystick, an RP240, custom GUI, etc.
Chapter 5. <i>Custom Profiling</i>	Descriptions of custom profiling features such as S-Curves, linear and circular interpolation, compiled profiles, on-the-fly motion profiling, registration, and synchronized motion.
Chapter 6. <i>Following</i>	Feature descriptions and application examples for using Following features.
Chapter 7. <i>Multi-Tasking</i>	Feature descriptions and application examples for using multi-tasking in your application.
Chapter 8. <i>Troubleshooting</i>	Methods for isolating and resolving hardware and software problems.

Programming Examples

Programming examples are provided in this document to demonstrate how the 6K product's features can be implemented. These examples are somewhat generalized, due to the diverse nature of the family of 6K Series products and their application; consequently, some attributes, such as the number of axes used or the I/O bit pattern referenced, can differ from those available with your particular 6K product.

HINT: From the Help menu in Motion Planner and from our web site (www.compumotor.com), you can access the online version of the *6K Series Command Reference*. You can copy the programming examples from this online document and paste them into Motion Planner's Program Editor. Then you can edit the code for your application requirements and download the program to the product.

Reference Documentation

This document is intended to accompany the printed and online documents listed below, as part of the 6K product user documentation set.

	Reference Document	Description
ONLINE ACCESS	<i>6K Series Hardware Installation Guide</i>	Hardware-related information specific to the 6K Series product: <ul style="list-style-type: none">•Product hardware specifications•Installation instructions•Troubleshooting procedures•Servo tuning instructions
Online versions of this Programmer's Guide and the Command Reference are available on the included compact disc.		
INTERNET ACCESS	<i>6K Series Command Reference</i>	Provides detailed descriptions of all 6K Series Programming Language commands. In addition, it includes quick-reference tables.
You can also view and print these documents our website at www.compumotor.com	<i>Com6srvr User's Guide for Gemini& 6K Series Products</i>	Provides information about the Com6srvr, and detailed descriptions of its properties and methods.
	<i>Motion Planner Online Help</i>	Online instructional aids: <ul style="list-style-type: none">•Step-by-step programming coaches•Conceptual overviews•Specifications on each 6K Series command

Assumptions of Technical Experience

To effectively use the information in this manual, you should have a fundamental understanding of the following:

- Electronics concepts such as voltage, switches, current, etc.
- Motion control concepts such as motion profiles, torque, velocity, distance, force, etc.
- Programming skills in a high-level language such as C, BASIC, or Pascal is helpful
- Ethernet communication protocol (if using the Ethernet port)
- If you are new to the 6K Series Programming Language, read Chapter 1 thoroughly.

Before You Begin

Before you begin to implement the 6K controller's features in your application you should complete the items listed below.

- Complete all the installation and test procedures provided in your *6K Series Hardware Installation Guide*.
- If you are controlling any servo axes, complete the servo tuning procedures. Be sure to use Motion Planner's built-in tuning utility to easily tune the axis and integrate the gains into your motion program. Tuning instructions are provide on page 67, with conceptual material provided in an appendix to the *6K Series Hardware Installation Guide*.
- Keep the *6K Series Command Reference* close at hand to answer questions about specific 6K Series commands (the contents are also available online from the Motion Planner interface). If you are new to the 6K Series Programming Language, read Chapter 1 (*Programming Fundamentals*) thoroughly.

Motion Planner — programming support software

Motion Planner is a Windows-based graphical interface that assists you with programming and tuning your 6K Series product. Motion Planner is provided in your ship kit. The Motion Planner interface allows you to:

- Create, edit, download, and upload programs (or code modules).
- Tune your servo system.
- Test & debug programs and controller operation with customizable displays.
- Organize all of your programs and resource files for your programming project.

PERFORMANCE SUPPORT. To help you program with speed and efficiency, Motion Planner provides these "performance support" features:

- **Ergonomic Interface:** In addition to the menus and toolbar buttons, the main part of the interface is designed with tabbed windows to give you easy access to all the tools you need. With one click, you can switch between editor, terminal emulator, files organizer, and online help system. In addition, each tabbed window has its own set of utility buttons and right mouse click menu commands for easy access to common tasks specific to what you're working on.
- **Programming Help with Wizards:** Wizards are available to speed up your programming tasks and minimize your need to learn the details of the programming language. Wizards are included for such tasks as overall program structure, setup programming, error programming, compiled motion, multi-tasking setup, servo tuning, etc.
- **Smart Editor:** The smart editor is the focal point for your programming tasks: The smart editor watches over your shoulder and provides syntax checking on the fly (as you type). To get detailed information on the command you're using, just press the F1 key. At any point, you can check the entire program file for logic flow and syntax errors.

Technical Support

For solutions to your questions about implementing 6K product software features, first look in this manual. Other aspects of the product (command descriptions, hardware specs, I/O connections, graphical user interfaces, etc.) are discussed in the respective manuals or Online Help systems listed above in *Reference Documentation* (see page ii).

If you cannot find the answer in this documentation, contact your local Automation Technology Center (ATC) or distributor for assistance.

If you need to talk to our in-house application engineers, please contact us at the numbers listed on the inside cover of this manual. (The phone numbers are also provided when you issue the `HELP` command to the 6K controller.)

CHAPTER ONE

Programming Fundamentals

IN THIS CHAPTER

This chapter is a guide to general 6K programming tasks. It is divided into these main topics:

• Motion Planner programming environment	2	• Restricted commands during motion	17
• Command syntax	3	• Using Variables	18
• Creating programs	9	• Program flow control	23
• Storing programs	10	• Program interrupts	29
• Executing programs	13	• Error handling	30
• Creating and executing a set-up program	13	• Non-volatile memory	33
• Program Security	14	• System performance considerations	34
• Controlling execution – programs & command buffer	15		


Motion Planner Programming Environment

Every 6K Series controller is shipped with Motion Planner, a Windows-based programming tool designed to simplify your programming efforts. The Motion Planner interface allows you to:

- Create, edit, download, and upload programs (or code modules).
- Tune your system to optimize performance.
- Test & debug programs and controller operation with customizable displays.
- Organize all of your programs and resource files for your programming project.

PROGRAMMING SUPPORT. To help you program with speed and efficiency, Motion Planner provides these “performance support” features:

- **Smart Editor:** The smart editor is the focal point for your programming tasks: The smart editor watches over your shoulder and provides syntax checking on the fly (as you type). To get detailed information on the command you’re using, just press the F1 key. At any point, you can check the entire program file for logic flow and syntax errors.
- **Programming Help with Wizards:** While you are working in the Editor, you can use the wizards to speed up your programming tasks and minimize your need to learn the details of the programming language. Wizards are available for general program structure, general system setup (including servo tuning), error programming, and a host of other programming tasks.



Command Syntax

Introduction

The 6K programming language accommodates a wide range of needs by providing basic motion control building blocks, as well as sophisticated motion and program flow constructs.

The language comprises simple ASCII mnemonic commands, with each command separated by a command delimiter (carriage return, colon, or line feed). The command delimiter signals the 6K product that a command is ready for processing.


Upon receiving a command followed by a command delimiter, the 6K controller places the command in its internal command buffer, or queue. Here the command is executed in the order in which it is received. To make the command execute immediately, place an exclamation point (!) in front of it (e.g., The `TAS` command will be executed after all commands ahead of it in the command buffer are executed; but `!TAS` will execute before any other commands in the command buffer).

Sample program, as viewed in an editor:

```

; *****
; This is a program that executes a trapezoidal motion
; profile on axes 1 and 2
; *****
DEL motion      ; (a precaution) Delete program called
                "motion"
DEF motion      ; Begin definition of program called "motion"
DRIVE11        ; Enable drives on axes 1 and 2
MC00           ; Set position mode to preset on both axes
A20,10         ; Set accel on axis 1 to 20 units/sec/sec, and
                ; Set accel on axis 2 to 10 units/sec/sec
V8,5           ; Set velocity on axis 1 to 8 units/sec, and
                ; Set velocity on axis 2 to 5 units/sec
D100000,75000  ; Set distance to 100,000 counts on axis 1,
                and
                ; Set distance to 75,000 counts on axis 2
; *****
    
```

These are command line comments, comprising a semi-colon and text. The comments are separated from the command by a tab. A carriage return is placed at the end of each command line.




```

; *****
; This is a program that executes a trapezoidal motion
; profile on axes 1 and 2
; *****
    
```

```

DEL motion
DEF motion
DRIVE11
    
```



```

MC00
A20,10

V8,5

D100000,75000

GO11
END
    
```

```

; (a precaution) Delete program called "motion"
; Begin definition of program called "motion"
; Enable drives on axes 1 and 2
; Set position mode to preset on both axes
; Set accel on axis 1 to 20 units/sec/sec, and
; Set accel on axis 2 to 10 units/sec/sec
; Set velocity on axis 1 to 8 units/sec, and
; Set velocity on axis 2 to 5 units/sec
; Set distance to 100,000 counts on axis 1, and
; Set distance to 75,000 counts on axis 2
; Execute motion on axes 1 and 2
; End definition of program called "motion"
    
```

Spaces and tabs within a command are processed as neutral characters. Comments can be specified with the semicolon (;) character — all characters following the semicolon and before the command delimiter are considered program comments.

Some commands contain one or more data fields in which you enter numeric or binary values or text:

- **Numeric data fields.** For example, `A20,10` is an acceleration (A) command that sets the acceleration for axes 1 and 2 to 20 units/sec² and 10 units/sec², respectively.
- **Binary fields.** For example, `DRIVE1011` is a drive enable (DRIVE) command that enables axes 1, 3 and 4 and disables axis 2.
- **Text fields.** For example, `STARTPpowrup` is a startup program assignment (STARTP) command that assigns the program called “powrup” as the startup program to be executed automatically when the 6K product is power up or reset.
- To check what the data field settings are for a particular command, simply type in the command without the data fields. The 6K will display the command settings. For example, after executing the `A20,10` noted above, you could type in the `A` command by itself and the 6K controller would respond with `A20,10`.
- **Shortcuts.** Most 6K language commands supply axis-related data, and have one field per axis, separated by commas. Each command field correlates, left to right, to the physical axis. For example, to specify a velocity of 10 on axes 6 and 8, the command “`V , , , , ,10, ,10`” would be used. As can be seen from the example, the required number of commas can be awkward, and could be a potential source of typographical error. The 6K products allow an axis specifier to be placed in front of a command with axis fields to identify the starting axis number for the fields in that command. For example, the above `V` command could be given as “`6V10, ,10`”. If the velocity were to be given to axis 6 only, the command would simply be “`6V10`”. An axis identifier placed in front of a data command without parameters (e.g. `6V`) will report the value for that axis only.

Description of Syntax Letters and Symbols


The command descriptions provided within the *6K Series Command Reference* use alphabetic letters and ASCII symbols within the **Syntax** description to represent different parameter requirements (see `INEN` example below).

INEN		Input Enable		Product	Rev
Type	Inputs; Program Debug Tools			6K	5.0
Syntax	<code><!>INEN<d><d><d>...<d></code>				
Units	d = Ø, 1, E, or X				
Range	Ø = off, 1 = on, E = enable, X = don't change				
Default	E				
Response	INEN: *INENEEEE_EEEE_EEEE_EEEE_E				
See Also	[IN], INFNC, INLVL, INPLC, INSTW, TIN, TIO				

Letter/Symbol	Description
a	Represents an axis specifier, numeric value from 1 to 8.
B	Represents the number of the product's I/O brick. External I/O bricks are represented by numbers 1 through n (to connect external I/O bricks, see your product's <i>Installation Guide</i>). On-board I/O are address at brick location zero (Ø). If the brick identifier is omitted from the command, the controller assumes the command is supposed to affect the onboard I/O.
b*	Represents the values 1, 0, X or x; does not require field separator between values.
c	Represents a character (A to Z, or a to z)
d	Represents the values 1, 0, X or x, E or e ; does not require field separator between values. E or e enables a specific command field. X or x leaves the specific command field unchanged or ignored. In the <code>ANIEN</code> command, the "d" symbol can also represent a real numeric value.
i	Represents a numeric value that cannot contain a decimal point (integer values only). The numeric range varies by command. Field separator required.
r	Represents a numeric value that can contain a decimal point, but is not required to have a decimal point. The numeric range varies by command. Field separator required.
t	Represents a string of alpha numeric characters from 1 to 6 characters in length. The string must start with a alpha character.
!	Represents an immediate command. Changes a buffered command to an immediate command. Immediate commands are processed immediately, even before previously entered buffered commands.
%	(Multitasking Only) Represents a task identifier. To address the command to a specific task, prefix the command with "i%", where "i" is the task number. For example, the <code>4%<i>CUT</i></code> command uses task 4 to execute the program called " <i>CUT</i> ".
,	(comma) Represents a field separator. Commands with the symbol <code>r</code> or <code>i</code> in their Syntax description require field separators. Commands with the symbol <code>b</code> or <code>d</code> in their Syntax description <u>do not</u> require field separators (but they can be included). See <i>General Guidelines</i> table below.
@	Represents a global specifier, where only one field need be entered. Applicable to all commands with multiple command fields. (e.g., <code>@V1</code> sets velocity on all axes to 1 rps).
< >	Indicates that the item contained within the < > is optional, not required by that command. NOTE: Do not confuse with <code><cr></code> , <code><sp></code> , and <code><lf></code> , which refer to the ASCII characters corresponding to a carriage return, space, and line feed, respectively.
[]	Indicates that the command between the [] must be used in conjunction with another command, and cannot be used by itself.

* The ASCII character `b` can also be used within a command to precede a binary number. When the `b` is used in this context, it is not to be replaced with a 0, 1, X, or x. Examples are assignments such as `VARB1=b10001`, and comparisons such as `IF(3IN=b1001X1)`.

Order of Precedence for Command Prefix Characters (from left to right):



General Guidelines for Syntax

Guideline Topic	Guideline	Examples
Neutral Characters <ul style="list-style-type: none"> Space (<sp>) Tab (<tab>) 	Using neutral characters anywhere within a command will not affect the command. (In the examples on the right, a space is represented by <sp>, a tab is <tab>), and a carriage return is <cr>)	Set velocity on axis 1 to 10 rps and axis 2 to 25 rps: V<sp>10,<sp>25,,<cr> Add a comment to the command: V 10, 25,,<tab> ;set accel <cr>
Command Delimiters: <ul style="list-style-type: none"> Carriage rtn (<cr>) Line feed (<lf>) Colon (:) 	All commands must be separated by a command delimiter. A carriage return is the most commonly used delimiter. To use a line in a live terminal emulator session, press ctrl/J. The colon (:) delimiter allows you to place multiple commands on one line of code, but only if you add it in the program editor (not during a live terminal emulator session).	Set acceleration on axis 2 to 10 rev/sec/sec: A,10,,<cr> A,10,,<lf> A,10,, : V,25,, : D,25000,, : @GO<cr>
Case Sensitivity	There is no case sensitivity. Use upper or lower case letters within commands.	Initiate motion on axes 1, 3 and 4: GO1011 go1011
Comment Delimiter (;)	All text between a comment delimiter and a command delimiter is considered <i>program comments</i> .	Add a comment to the command: V10<tab> ;set velocity
Field Separator (,)	Commands with the symbol <i>r</i> or <i>i</i> in their Syntax description require field separators. Commands with the symbol <i>b</i> or <i>d</i> in their Syntax description do not require field separators (but they can be included). Axes not participating in the command need not be specified; however, field separators that are normally required must be specified (unless the axis prefix is used).	Set velocity on axes 1 - 4 to 10 rps, 25 rps, 5 rps and 10 rps, respectively: V10,25,5,10 Initiate motion on axes 1, 3 and 4: GO1011 GO1,0,1,1 Set velocity on axes 4 and 6 to 5 rps: V,,,5,,5 Alternative is to use the axis prefix: 4V5,,5
Global Command Identifier (@)	When you wish to set the command value equal on all axes, add the @ symbol at the beginning of the command (enter only the value for one command field). The @ symbol is also useful for checking the status of all axes, or all inputs or outputs on all I/O bricks.	Set velocity on all axes to 10 rps: @V10 Check the status of all digital outputs (onboard, and on external I/O bricks): @OUT
Bit Select Operator (.)	The bit select operator allows you to affect one binary bit without having to enter all the preceding bits in the command. Syntax for setup commands: [command name].[bit #]-[binary value] Syntax for conditional expressions: [command name].[bit #]=[binary value]	Enable error-checking bit 9: ERROR.9-1 IF statement based on value of axis status bit 12 for axis 1: IF(1AS.12=b1)
Left-to-right Math	All mathematical operations assume left-to-right precedence.	VAR1=5+3*2 Result: Variable 1 is assigned the value of 16 (8*2), not 11 (5+6).
Binary and hexadecimal values	When making assignments with or comparisons against binary or hexadecimal values, you must precede the binary value with the letter "b" or "B", and the hex value with "h" or "H". In the binary syntax, an "x" simply means the status of that bit is ignored.	Binary: IF(IN=b1x01) ↑ Hexadecimal: IF(IN=h7F) ↑
Multi-tasking Task Identifier (%)	Use the % command prefix to identify the command with a specific task.	Launch the "move1" program in Task 1: 1%move1 Check the error status for Task 3: 3%TER Check the system status for Task 3: 3%TSS

NOTE: The command line is limited to 100 characters (excluding spaces).

Command Value Substitutions

Many commands can substitute one or more of its command field values with one of these substitution items (demonstrated in the programming example below):

VAR.....Places current value of the numeric variable in the corresponding command field.
VARBUses the value of the binary variable to establish all the command fields.
VARIPlaces current value of the integer variable in the corresponding command field.
READInformation is requested at the time the command is executed.
DREAD.....Reads the RP240's numeric keypad into the corresponding command field.
DREADF...Reads the RP240's function keypad into the corresponding command field.
TW.....Places the current value set on the thumbwheels in the corresponding command field.
DAT.....Places the current value of the data program (DATP) in the corresponding command field.

Programming Example: (NOTE: The substitution item must be enclosed in parentheses.)

```
VAR1=15           ; Set variable 1 to 15
A5,(VAR1),4,4     ; Set acceleration to 5,15,4,4 for axes 1-4, respectively
VARB1=b1101XX1   ; Set binary variable 1 to 1101XX1 (bits 5 & 6 not affected)
GO(VARB1)         ; Initiate motion on axes 1, 2 & 4 (value of binary
                  ; variable 1 makes it equivalent to the GO1101 command)
OUT(VARB1)        ; Turn on outputs 1, 2, 4, and 7
VARS1="Enter Velocity" ; Set string variable 1 to the message "Enter Velocity"
V2,(READ1)        ; Set the velocity to 2 on axis 1. Read in the velocity for
                  ; axis 2, output variable string 1 as the prompting message
                  ; 1. Operator sees "ENTER VELOCITY" displayed on the
                  ; screen.
                  ; 2. Operator enters velocity prefixed by '!' (e.g., '!20').
HOMV2,1,(TW1)     ; Set homing velocity to 2 and 1 on axes 1 and 2,
                  ; respectively.
                  ; Read in the home velocity for axis 3 from thumbwheel set 1
HOMV2,1,(DAT1)    ; Set homing velocity to 2 and 1 on axes 1 and 2,
                  ; respectively.
                  ; Read home velocity for axis 3 from data program 1.
VARI1=2*3         ; Set integer variable 1 to 6 (2 multiplied by 3)
D(VARI2),,(VARI3) ; Set the distance of axis 1 equal to the value of
                  ; integer variable 2, and the distance of axis 3 equal to
                  ; the value of integer variable 3.
```

RULE OF THUMB

Not all of the commands allow command field substitutions. In general, commands with a binary command field (in the command syntax) will accept the VARB substitution. Commands with a real or integer command field (<r> or <i> in the command syntax) will accept VAR, VARI, READ, DREAD, DREADF, TW or DAT.

Assignment and Comparison Operators

Comparison and assignment operators are used in command arguments for various functions such as variable assignments, conditional branches, wait statements, conditional GOs, etc. Some examples are listed below:

- Assign to numeric variable 6 the value of the encoder position on axis 3 (uses the PE operator): VAR6=3PE
- Wait until onboard inputs 3 & 6 become active (uses the IN operator): WAIT(IN=bxxlxx1)
- Continue until the value of numeric variable 2 is less than 36: UNTIL(VAR2<36)
- IF condition based on if a target zone timeout occurs on axis 2 (uses the AS axis status operator, where status bit 25 is set if a target zone timeout occurs): IF(2AS.25=b1)

The available comparison and assignment operators are listed below. For full descriptions, see the *6K Series Command Reference* (be sure to refer only to the commands in brackets—e.g., A is the acceleration setup command, but [A] is the acceleration assignment/comparison operator).

* denotes operators that have a correlated status display command.
(e.g., To see a full-text description of each axis status bit accessed with the AS operator, send the TASF command to the 6K controller.)
See page 226.

A Acceleration
AD Deceleration
ANI Voltage at the analog inputs on an expansion I/O brick (see page 76 for bit patterns) *
ANO Voltage at the analog outputs on an expansion I/O brick (see page 76 for bit patterns) *
AS Axis status *
ASX Extended axis status (additional axis status items) *
D Distance
DAC Digital-to-analog converter (output voltage) value *
DAT Data program number
DKEY Value of RP240 Key
DPTR Data pointer location *
DREAD Data from the numeric keypad on the RP240
DREADF Data from the function keypad on the RP240
ER Error status *
FB Position of current selected feedback sources *
FS Following status *
IN Input status (input bit patterns, see page 76) *
INO “Other” input status (ENABLE input reported with bit 6) *
LIM Limit status (end-of-travel limits and home limits) *
MOV Axis moving status
NMCY Current master cycle number *
OUT Output status (output bit patterns, see page 76) *
PANI Position of analog input, at 205 counts/volts unless otherwise scaled (servo axes) *
PC Commanded position *
PCC Captured commanded position *
PCE Captured encoder position *
PCME Captured master encoder position *
PCMS Captured master cycle position *
PER Position error (servo axes only) *
PME Current master encoder position *
PMAS Current master cycle position *
PE Position of master encoder *
PSHF Net position shift since constant Following ratio *
PSLV Current commanded position of the slave axis *
READ Read a numeric value to a numeric variable (VAR)
SC Controller status *
SCAN Runtime of the last scanned PLC program *
SEG Number of segments available in Compiled Profile memory *
SS System status *
SWAP Current active status of tasks *
TASK Number of the controlling task *
TIM Timer value *
TRIG Trigger interrupt status *
TW Thumbwheel data read
US User status *
V Velocity (programmed)
VAR Numeric variable substitution
VARI Integer variable substitution
VARB Binary variable substitution
VEL Velocity (commanded by the controller) *
VELA Velocity (actual, as measured by a position feedback device) *
VMAS Current velocity of the master axis *

Bit Select Operator

The bit select operator (.) makes it easier to base a command argument on the condition of one specific status bit. For example, if you wish to base an IF statement on the condition that a user fault input is activated (error status bit 7 is a binary status bit that is “1” if a user fault occurred and “Ø” if it has not occurred), you could use this command: IF (ER=bxxxxxx1) . Using a bit select operator, you could instead use this command: IF (ER. 7=b1) .

NOTE: You can use a bit select operator to set a particular status bit (e.g., to turn on onboard programmable output 5, you would type the OUT . 5-1 command; to enable error-checking bit 4 to check for drive faults, you would type the ERROR . 4-1 command). You can also check specific status bits (e.g., to check axis 2’s axis status bit 25 to see if a target zone timeout

occurred, type the `2TAS.25` command and observe the response).

Binary and Hex Values

When making assignments with or comparisons against binary or hexadecimal values, you must precede the binary value with the letter “b” or “B”, and the hex value with “h” or “H”. Examples: `IF (IN=b1x01)` and `IF (IN=h7F)`. In the binary syntax, an “x” simply means the status of that bit is ignored. Refer also to *Using Binary Variables* (page 22).

Related Operator Symbols

Command arguments include special operator symbols (e.g., +, /, &, ', >=, etc.) to perform bitwise, mathematical, relational, logical, and other special functions. These operators are described in detail, along with programming examples, at the beginning of the *Command Descriptions* section of the *6K Series Command Reference*.

Programmable Inputs and Outputs Bit Patterns

I/O pin outs, specifications, and circuit drawings are provided in each 6K Series Hardware Installation Guide.

The 6K product has programmable inputs and outputs. The total number of onboard inputs and outputs (trigger inputs, limit inputs, digital outputs) depends on the product. The total number of expansion inputs and outputs (analog inputs, digital inputs and digital outputs) depends on your configuration of expansion I/O bricks connected to the “EXPANSION I/O” connector.

These programmable I/O are represented by binary bit patterns, and it is the bit pattern that you reference when programming and checking the status of specific inputs and outputs. The bit pattern is referenced in commands like `WAIT (IN.4=b1)`, which means wait until onboard programmable input 4 (TRG-2B) becomes active. To ascertain your product’s I/O offering and bit patterns, see Chapter 3 (page 76).

Creating Programs

Debugging Programs: Refer to page 225 for methods to isolate and resolve programming problems.


A *program* is a series of commands. These commands are executed in the order in which they are programmed. Immediate commands (commands that begin with an exclamation point [!]) cannot be stored in a program. Only buffered commands can be used in a program. Refer to the program example below.

A *subroutine* is defined the same as a program, but it is executed with an unconditional branch command, such as `GOSUB`, `GOTO`, or `JUMP`, from another program (see page 23 for details about unconditional branching). Subroutines can be nested up to 16 levels deep. **NOTE:** The 6K family does not support recursive calling of subroutines.

Compiled profiles & PLC programs are defined like programs, using the `DEF` and `END` commands, but are compiled with the `PCOMP` command and executed with the `PRUN` command (PLC programs are usually launched in PLC Scan Mode with the `SCANP` command). Compiled profiles and PLC programs also affect a different part of the product’s memory, called *compiled memory*. A compiled *profile* could be a multi-axis contour (a series of arcs and lines), an individual axis profile (a series of `GOBUF` commands), or a compound profile (combination of multi-axis contours and individual axis profiles). A compiled *PLC program* is a pre-compiled program that mimics PLC functionality by scanning through the I/O faster than in normal program execution. For information on contouring, see page 124; for information on compiled individual axis profiles, see page 136; and for information on PLC programs, see page 104.

Program Example

The illustration below identifies the elements that comprise the general structure of a program.



Use the Wizards in Motion Planner

Motion Planner provides wizards that make it easy to create your program. Below is a partial list of the wizards available.

- Application Wizards (for program structure guidance)
 - Standard Application
 - Multitasking Application
- Program Wizards
 - Setup Program
 - Main Program
 - User Program
 - Error Program
- Setup Wizards
 - Drive
 - Feedback
 - Scaling
 - Limit
 - Servo Tuner
 - On-board I/O
 - Expansion I/O
 - Jogging
 - Joystick
 - Variable
- Action Wizards
 - Motion
 - Home
 - Output
 - If
 - Loop
 - Wait
 - Assignment
 - Target Zone
 - Registration

Storing Programs

After a program or compiled program/profile is defined (DEF) or downloaded to the 6K controller, it is automatically stored in non-volatile memory (battery-backed RAM). Information on controlling memory allocation is provided below (Memory Allocation, see page 11).

Memory Allocation

Your controller's memory has two partitions: one for storing *programs* and one for storing *compiled profiles & PLC programs*. The allocation of memory to these two areas is controlled with the MEMORY command.

“Programs” vs. “Compiled Profiles & PLC Programs”

Programs are defined with the DEF and END commands, as demonstrated in the *Program Example* on page 10.

Compiled Profiles & PLC Programs are defined like programs, using the DEF and END commands, but are compiled with the PCOMP command and executed with the PRUN command (PLC programs are usually executed in PLC Scan Mode with the SCANP). A compiled profile could be a multi-axis *contour* (a series of arcs and lines), an *individual axis profile* (a series of GOBUF commands), or a *compound profile* (combination of multi-axis contours and individual axis profiles). A PLC program is a pre-compiled program that mimics PLC functionality by scanning through the I/O faster than in normal program execution.

Programs intended to be compiled are stored in program memory. After they are compiled with the PCOMP command, they remain in program memory and the *segments* (see diagram below) from the compiled program are stored in compiled memory. The TDIR report indicates which programs are compiled as compiled profiles (“COMPILED AS A PATH”) and which programs are compiled as PLC programs (“COMPILED AS A PLC PROGRAM”).

For information on contouring, see page 124; for information on compiled individual axis profiles, see page 136; and for information on PLC programs, see page 104.

MEMORY
command
syntax
(example)

MEMORY150000,150000

Memory allocation for Programs (bytes). Storage requirements depend on the number of ASCII characters in the program.

Memory allocation for Compiled Profiles & Programs (bytes). Storage requirements depend on the number of *segments* (1 segment consumes 76 bytes). A segment could be one of these commands:

Contouring:	Compiled Motion:	PLC (PLCP) Program:
PARCM	GOBUF *	IF **
PARCOM	PLOOP	ELSE
PARCOP	GOWHEN	NIF
PARCP	TRGFN	L
PLIN	POUTA	LN
	POUTB	OUT
	POUTC	ANO
	POUTD	EXE
	POUTE	PEXE
	POUTF	VARI **
	POUTG	VARB **
	POUTH	

* GOBUF commands may require up to 4 segments.

** IF statement require at least 2 segments, each AND or OR compound requires an additional segment. VARI and VARB each require 2 segments.

The table below identifies memory allocation defaults and limits for all 6K Series products. When specifying the memory allocation, use only even numbers. The minimum storage capacity for one partition area (program or compiled) is 1,000 bytes.

Feature	All Other Products
Total memory (bytes)	300,000
Default allocation (program,compiled)	150000,150000
Maximum allocation for programs	299000,1000
Maximum allocation for compiled profiles & PLC programs	1000,299000
Maximum No. of programs	400
Maximum No. of labels	600
Maximum No. of compiled profiles & PLC programs	300
Maximum No. of compiled profile segments	2069
Maximum No. of numeric variables (VAR)	225
Maximum No. of integer variables (VARI)	225
Maximum No. of binary variables (VARB)	125
Maximum No. of string variables (VARS)	25

When teaching variable data to a data program (DATP), be aware that the memory required for each data statement of four data points (43 bytes) is taken from the memory allocation for program storage (see *Variable Arrays* in Chapter 3, page 94, for details).

CAUTION

Using a memory allocation command (e.g., MEMORY200000,100000) will erase all existing programs and compiled profile segments & PLC programs. However, issuing the MEMORY command without parameters (i.e., type MEMORY <cr> to request the status of how the memory is allocated) will not affect existing programs or compiled segments/programs.

Checking Memory Status

To find out what programs reside in your controller's memory, and how much of the available memory is allocated for programs and compiled profile segments, issue the TDIR command (see example response below). Entering the TMEM command or the MEMORY command (without parameters) will also report the available memory for programs and compiled profile segments.

Sample response to
TDIR command

```
*1 - SETUP USES 345 BYTES
*2 - PIKPRT USES 333 BYTES
*149322 OF 150000 BYTES (98%) PROGRAM MEMORY REMAINING
*1973 OF 1973 SEGMENTS (100%) COMPILED MEMORY REMAINING
```

Two system status bits (reported with the TSS and SS commands) are available to check when compiled profile segment storage is 75% full or 100% full. System status bit 29 is set when segment storage reaches 75% of capacity; bit 30 indicates when segment storage is 100% full.

Executing Programs (options)

Following is a list of the primary options for executing programs stored in your controller:

Method	Description	See Also
Execute from a terminal emulator	Type in the name of the program and press enter; or write a program to prompt the operator to select a program from the terminal.	-----
Execute as a subroutine from a "main" program	Use a branch (<code>GOTO</code> , <code>GOSUB</code> , or <code>JUMP</code>) from the main program to execute another stored program.	Page 23
Execute automatically when the controller is powered up	Assign a specific program as a startup program with the <code>STARTP</code> command. When you <code>RESET</code> or cycle power to the controller, the startup program is automatically executed.	Page 13
Execute from a PLC program	Write a PLC program that executes a program (using <code>EXE</code> or <code>PEXE</code>) based on a specific condition (e.g., input state). Use the <code>SCANP</code> command to launch the PLC program in the PLC Scan Mode.	Page 104
Execute a specific program with BCD weighted inputs	Define programmable inputs to function as BCD select inputs, each with a BCD weight. A specific program (identified by its number) is executed based on the combination of active BCD inputs. Related commands: <code>INSELP</code> and <code>INFNCi-B</code> or <code>LIMFNCi-B</code> .	Page 82
Execute a specific program with a dedicated input	Define a programmable input to execute a specific program (by number). Related commands: <code>INSELP</code> and <code>INFNCi-IP</code> or <code>LIMFNCi-P</code> .	Page 88
"Call" from a high-level program	Using a programming language such as BASIC or C, write a program that enables the computer to monitor processes and orchestrate motion and I/O by executing stored programs (or individual commands) in the controller.	Page 118
Execute from an RP240 (remote operator interface)	Execute a stored program from the <code>RUN</code> menu in the RP240's standard menu system.	Page 111
Execute from your own custom Windows program	Use a programming language (e.g., Visual Basic, Visual C++, etc.) and the 6K Communications Server (provided on the Motion Planner CD) to create your own windows application to control the 6K product.	-----

Creating and Executing a Setup Program

The intent of the Setup program is to place the 6K controller in a ready state for subsequent motion control. The setup program must be called from the "main" program for your application; or you can designate (with `STARTP`) the setup program as the program to be automatically executed when the 6K product is powered up or when the `RESET` command is executed. The setup program typically contains elements such as feedback device configuration, tuning gain selections, programmable I/O definitions, scaling, homing configuration, variable initialization, etc. (more detail on these "basic" features is provided in Chapter 3, *Basic Operation Setup*).

The basic process of creating a setup program is:

1. Create a program to be used as the setup program.
2. Save the program and download it to the 6K product.
3. Execute the `STARTP` command to assign your new program as the "start-up" program (e.g., `STARTP setup` assigns the program called "setup" as the start-up program). The next time the controller is powered up or reset, the assigned `STARTP` program will be executed.

Or call the setup program from the main program for your application.

Use **Motion Planner's Setup wizard** to help you create the basic configuration program. By simply responding to a series of dialog boxes, a program is created with a specific name (as if you created it in the usual process with the `DEF` and `END` commands). You can further edit this program in Motion Planner's Editor if you wish. Use the following procedure:

1. From the main Editor window, click the "Standard Application" wizard button (located on the right-hand side of the screen under Application Wizards) and select "Setup" and "Main" from the dialog. When you click "Finish", Motion Planner places a Setup program icon and a Main program icon in the Editor window.
2. Double-click the Setup program icon to launch the wizard. Complete the wizard dialogs and click "Finish" to complete the wizard. (The next time you open the icon, you will see a program editor with the code resulting from the setup wizard.) Setup elements include:
 - Product selection
 - Drives
 - Feedback (encoder, analog input)
 - Scaling
 - Hardware end-of-travel limits
 - Servo tuning
3. Double-click the Main program icon to launch the wizard. Select this program as the program to launch when the 6K controller is reset or powered up (this is equivalent to the `STARTP` command function). In the dialog for selecting the Setup Program, select the program developed in step 2 above.
4. Save the Editor files.
5. Download the files to the 6K controller.

Program Security

Issuing the `INFNCi-Q` or `LIMFNCi-Q` command enables the *Program Security* feature and assigns the *Program Access* function to the specified programmable input. The "i" represents the number of the programmable input to which you wish to assign the function (see page 76 programmable input bit patterns for your product).

The program security feature denies you access to the `DEF`, `DEL`, `ERASE`, `MEMORY`, `INFNC`, and `LIMFNC` commands until you activate the program access input. Being denied access to these commands effectively restricts altering the user memory allocation. If you try to use these commands when program security is active (program access input is not activated), you will receive the error message `*ACCESS DENIED`.

For example, once you issue the `INFNC5-Q` command, onboard input 5 is assigned the program access function and access to the `DEF`, `DEL`, `ERASE`, `MEMORY`, `INFNC`, and `LIMFNC` commands will be denied until you activate onboard input 5.

NOTE: To regain access to these commands without the use of the program access input, you must issue the `INEN` command to disable the program security input, make the required user memory changes, and then issue the `INEN` command to re-enable the input. For example, if input 3 on I/O brick 2 is assigned as the Program Security input, use `2INEN.3=1` to disable the input and leave it activated, make the necessary user memory changes, and then use `2INEN.3=E` to re-enable the input.

Controlling Execution of Programs and the Command Buffer

The 6K controller command buffer is capable of storing 2000 characters waiting to be processed. (This is separate from the memory allocated for program storage – see Memory Allocation, page 11.) COMEXC affects command execution. Three additional commands, COMEXL, COMEXR and COMEXS, affect the execution of programs and the command buffer.

COMEXC (Continuous Command Execution)

The COMEXC1 command enables the Continuous Command Execution Mode (default is COMEXC0). This mode allows the program to continue to the next command before motion is complete. This is useful for:

- Monitoring other processes while motion is occurring
- Performing calculations in advance of motion completion
- Pre-emptive GOs — executing a new profile with new attributes (distance, accel/decel, velocity, positioning mode, and Following ratio) before motion is complete: The motion profile underway is pre-empted with a new profile when a new GO is issued. The new GO both constructs and launches the pre-empting profile. Pre-emptive GOs are appropriate when the desired motion parameters are not known until motion is already underway. For a detailed description, see On-The-Fly Motion on page 151.
- Pre-process the next move while the current move is in progress (see CAUTION). This reduces the processing time for the subsequent move to only a few microseconds.

CAUTION: Avoid executing moves prematurely

With continuous command execution enabled (COMEXC1), if you wish motion to stop before executing the subsequent move, place a WAIT (AS.1=b0) statement before the subsequent GO command. If you wish to ensure the load settles adequately before the next move, use the WAIT (AS.24=b1) command instead (this requires you to define end-of-move settling criteria — see Target Zone Mode on page 74 for details).

In the programming example below, by enabling the continuous command execution mode (COMEXC1), the controller is able to turn on output 3 after the encoder moves 4000 units of its 125000-unit move. Normally, with COMEXC disabled (COMEXC0), command processing would be temporarily stopped at the GO1 command until motion is complete.

Programming Example (portion of program only)

```
COMEXC1           ;Enable continuous command execution mode
D125000           ;Set distance
V2                ;Set velocity
A10               ;Set acceleration
GO1               ;Initiate motion on axis 1
WAIT(1PE>4000)   ;Wait for the encoder position to exceed 4000
OUTXX1            ;Turn on onboard programmable output 3
WAIT(AS.1=b0)     ;Wait for motion to complete on axis 1 (AS bit 1 = zero)
OUTXX0            ;Turn off onboard programmable output 3
```

COMEXL (Save Command Buffer on Limit)

The COMEXL command enables saving the command buffer and maintaining program execution when a hardware or software end-of-travel limit is encountered. COMEXL is axis specific (e.g., COMEXL1xx1xxx1 enables saving the buffer for axes 1, 4, and 8).

For more information
on end-of-travel limits,
see page 57.

- COMEXL0: (This is the default setting.) When a limit is hit, every command in the command buffer will be discarded and program execution will be terminated.
- COMEXL1: When a limit is hit, all remaining commands in the command buffer will remain in the command buffer (excluding the command being executed at the time the limit is hit).

COMEXR (Effect of Pause/Continue Input)

The COMEXR command affects whether a “Pause” input (i.e., an input configured as a pause/continue input with the INFNCi-E command or the LIMFNCi-E command) will pause only program execution or both program execution and motion.

COMEXR0: (This is the default setting.) Upon receiving a pause input, only program execution will be paused; any motion in progress will continue to its predetermined destination. Releasing the pause input or issuing a !C command will resume program execution.

COMEXR1: Upon receiving a pause input, both motion and program execution will be paused; the motion stop function is used to halt motion. *After motion has come to a stop (not during deceleration)*, you can release the pause input or issue a !C command to resume motion and program execution.

Other Ways to Pause

- Issue the PS command before entering a series of buffered commands (to cause motion, activate outputs, etc.), then issue the !C command to execute the commands.
- While program execution is in progress, issuing the !PS command stops program execution, but any move currently in progress will be completed. Resume program execution with the !C command.

COMEXS (Save Command Buffer on Stop)

The COMEXS command determines the impact on motion, program execution, and the command buffer when the 6K receives a Stop command (S, !S, S1, or !S1) or an external Stop input (an input assigned a stop function with INFNCi-D or LIMFNCi-D).

COMEXS0: Under factory default conditions (COMEXS0), when the 6K receives a stop command (S, !S, S1, or !S1) or a stop input (INFNCi-D or LIMFNCi-D), the following will happen:

- Motion decelerates to a stop, using the present AD and ADA deceleration values. The motion profile cannot be resumed.
- If S, !S or Stop input:
 - All commands in the 6K’s command buffer are discarded.
 - Program execution is terminated and cannot be resumed.
- If S1, or !S1 (an axis number is included in the command):
 - All commands in the 6K’s command buffer are retained.
 - Program execution continues.

COMEXS1: Using the COMEXS1 mode, the 6K allows more flexibility in responding to stop conditions, depending on the stop method (see table below).

Stop Method	What Stops?		Resume Motion Profile. (Allow resume with a !C command or a resume input *)	Resume Program. (Allow resume with a !C command or a resume input *)	Save Command Buffer. (Save the commands that were in the command buffer when the stop was commanded)
	Motion	Program			
!S or S	Yes	Yes	Yes	Yes	Yes
!S1 or S1	Yes	No	No	No	Yes
Stop input	Yes	Yes	No	Yes	Yes
Pause input * (if COMEXR1)	Yes	Yes	Yes	Yes	Yes
Pause input * (if COMEXR0)	No	Yes	No	Yes	Yes

* A Pause input is an input configured with the INFNCi-E command or the LIMFNCi-E command. This is also the Resume input that can be used to resume motion and program execution after motion is stopped.

COMEXS2: Using the COMEXS2 mode, the 6K responds as it does in the COMEXS0 mode, with the exception that you can still use the program-select inputs to select programs (INSELP value is retained). The program-select input functions are: BCD select (INFNCi-B or LIMFNCi-B), and one-to-one select (INFNCi-P or LIMFNCi-P).

Restricted Commands During Motion

When motion is in progress on a given axis (or task), some commands cannot have their parameters changed until motion is complete (see table below).

For the commands identified in the table, if the continuous command execution mode is enabled (COMEXC1) and you try to enter new command parameters, you will receive the error response MOTION IN PROGRESS. If the continuous command execution mode is disabled (COMEXC0), which is the default setting, you will receive the response MOTION IN PROGRESS only if you precede the command with the immediate (!) modifier (e.g., !V20); if you enter a command without the immediate modifier (e.g., V20), you will not receive an error response and the new parameter will be ignored and the old parameter will remain in effect.

Multi-Tasking

If you are using multi-tasking, the restriction on commands is applicable only for the task to which the command is direct. For example, suppose axes 1 and 2 are associated with Task 1 (TSKAX1, 2) and axes 3 and 4 are associated with Task 2 (TSKAX3, 4). If motion is in progress on axes 1 and 2, Task 1 is considered "in motion" and Task 1 cannot execute a command from the list below. However, while motion is in progress in Task 1 and not Task 2, Task 2 can execute these commands without encountering an error.

All of the commands in the table below, except for SCALE, are axis-dependent. That is, if one axis is moving you can change the parameters on the other axes, provided they are not in motion.

Command	Description
CMDDIR.....	Commanded Direction Polarity
DRES	Drive Resolution
DRIVE.....	Drive Shutdown
ENCPOL.....	Encoder Polarity
ERES	Encoder Resolution
FOLEN.....	Following Mode Enable
GOL	Initiate Linear Interpolated Motion
HOM	Go Home
HOMA	Home Acceleration
HOMAA.....	Average Home Acceleration
HOMAD.....	Home Deceleration
HOMADA.....	Average Home Deceleration
HOMV	Home Velocity
HOMVF.....	Home Final Velocity
JOG	Jog Mode Enable
JOGA	Jog Acceleration
JOGAA.....	Average Jog Acceleration
JOGAD.....	Jog Deceleration
JOGADA.....	Average Jog Deceleration
JOGVH.....	Jog Velocity High
JOGVL.....	Jog Velocity Low

Command	Description
JOY.....	Joystick Mode Enable
JOYA.....	Joystick Acceleration
JOYAA	Average Joystick Acceleration
JOYAD	Joystick Deceleration
JOYADA	Average Joystick Deceleration
JOYVH	Joystick Velocity High
JOYVL	Joystick Velocity Low
LHAD.....	Hard Limit Deceleration
LHADA	Average Hard Limit Deceleration
LSAD.....	Soft Limit Deceleration
LSADA	Average Soft Limit Deceleration
PSET.....	Establish Absolute Position
SCALE	Enable/Disable Scale Factors *
SCLA.....	Acceleration Scale Factor
SCLD.....	Distance Scale Factor
SCLV.....	Velocity Scale Factor

* If any axis is in motion, you will cause an error if you attempt to change this command's parameters.

Variables

6K Series controllers have four types of variables, each designated with a different command. All four types are automatically stored in non-volatile memory.

Type	Command	Quantity	Function
Numeric (real)	VAR	225	Store real numeric data (range is $\pm 999,999,999.99999999$). Can be used to perform mathematical (=, +, -, *, /, SQRT), trigonometric (ATAN, COS, PI, SIN, TAN), and Boolean (&, , ^, ~) operations. Can also be used to store ("teach") variable data in variable arrays (called <i>data programs</i>) and later use the stored data as a source for motion program parameters (see <i>Variable Arrays</i> on page 94 for details).
Integer	VARI	225	Store integer numeric data (range is $\pm 2,147,483,647$). Can be used to perform mathematical (=, +, -, *, /) and Boolean (&, , ^, ~) operations.
Binary	VARB	125	Store 32-bit binary or hexadecimal values. Can also store the binary status bits from status registers. Frequently used registers are: inputs (IN), outputs (OUT), limits (LIM), system (SS), Following (FS), axis (AS & ASX), and error (ER). For example, the VARB2=IN.3 command assigns the binary state of input 12 to binary variable 2. Also use to perform bitwise operations (&, , ^, ~, >>, <<).
String	VARS	25	Store message strings of 50 characters or less. These message strings can be predefined error messages, user messages, etc. The programming example in the <i>Command Value Substitutions</i> (page 7) demonstrates the use of a string variable. Enhancements as of OS revision 5.1.0: <ul style="list-style-type: none"> Copy one VARS variable to another VARS variable. VARSn=VARSm can be used, as well as variable substitutions for "n" and "m". VARS message string was increased from 20 to 50 characters.

NOTE: Variables do not share the same memory (e.g., VAR1, VARI1, VARB1, and VARS1 can all exist at the same time and operate separately).

Converting Between Binary and Numeric Variables

Using the Variable Type Conversion (VCVT) operator, you can convert numeric (VAR or VARI) values to binary (VARB) values, and vice versa. The operation is a signed operation as the binary value is interpreted as a two's complement number. Any *don't cares* (x) in a binary value is interpreted as a zero (∅).

If the mathematical statement's result is a numeric value, then VCVT converts binary values to numeric values. If the statement's result is a binary value, then VCVT converts numeric values to binary values.

Numeric to Binary

Example	Description/Response
VAR1=-5	Set numeric variable value = -5
VARB1=VCVT (VAR1)	Convert the numeric value to a binary value
VARB1	*VARB1=1101_1111_1111_1111_1111_1111_1111_1111

Binary to Numeric

Example	Description/Response
VARB1=b0010_0110_0000_0000_0000_0000_0000_0000	Set binary variable = +100.0
VAR1=VCVT (VARB1)	Convert binary value to numeric
VAR1	*VAR1=+100.0

Using Numeric (VAR and VARI) Variables

NOTES

- The examples below show the use of real numeric variables (VAR). Integer variables can be used in the same operations with these exceptions:
 - Values are truncated to nearest integer value
 - Operations using square root (SQRT) and trigonometric (ATAN, COS, PI, SIN, TAN) operators are not allowed
- Some numeric variable operations reduce precision. The following operations reduce the precision of the return value: Division and Trigonometric functions yield 5 decimal places; Square Root yields 3 decimal places; and Inverse Trigonometric functions yield 2 decimal places.

Mathematical Operations

The following examples demonstrate how to perform math operations with numeric variables. Operator precedence occurs from left to right (e.g., VAR1=1+1+1*3 sets VAR1 to 9, not 5).

Addition (+)

Example	Response
VAR1=5+5+5+5+5+5+5	
VAR1	*VAR1=35.0
VAR23=1000.565	
VAR11=VAR1+VAR23	
VAR11	*VAR11=+1035.565
VAR1=VAR1+5	
VAR1	*VAR1=+40.0

Subtraction (-)

Example	Response
VAR3=20-10	
VAR20=15.5	
VAR3=VAR3-VAR20	
VAR3	*VAR3=-5.5

Multiplication (*)

Example	Response
VAR3=10	
VAR3=VAR3*20	
VAR3	*VAR3=+200.0

Division (/)

Example	Response
VAR3=10	
VAR20=15.5	
VAR20	*+15.5
VAR3=VAR3/VAR20	
VAR3	*+0.64516
VAR30=75	
VAR30	*+75.0
VAR19=VAR30/VAR3	
VAR19	*+116.25023

Square Root (SQRT)

Example	Response
VAR3=75	
VAR20=25	
VAR3=SQRT (VAR3)	
VAR3	*+8.660
VAR20=SQRT (VAR20)+SQRT (9)	
VAR20	*+8.0

Trigonometric Operations

The examples below demonstrate how to perform trigonometric operations with numeric variables.

Sine

Example

```
RADIAN0
VAR1=SIN(0)
VAR1
VAR1=SIN(30)
VAR1
VAR1=SIN(45)
VAR1
VAR1=SIN(60)
VAR1
VAR1=SIN(90)
VAR1
RADIAN1
VAR1=SIN(0)
VAR1
VAR1=SIN(PI/6)
VAR1
VAR1=SIN(PI/4)
VAR1
VAR1=SIN(PI/3)
VAR1
VAR1=SIN(PI/2)
VAR1
```

Response

```
*VAR1=+0.0
*VAR1=+0.5
*VAR1=+0.70711
*VAR1=+0.86603
*VAR1=+1.0
*VAR1=+0.0
*VAR1=+0.5
*VAR1=+0.70711
*VAR1=+0.86603
*VAR1=+1.0
```

Cosine

Example

```
RADIAN0
VAR1=COS(0)
VAR1
VAR1=COS(30)
VAR1
VAR1=COS(45)
VAR1
VAR1=COS(60)
VAR1
VAR1=COS(90)
VAR1
RADIAN1
VAR1=COS(0)
VAR1
VAR1=COS(PI/6)
VAR1
VAR1=COS(PI/4)
VAR1
VAR1=COS(PI/3)
VAR1
VAR1=COS(PI/2)
VAR1
```

Response

```
*VAR1=+1.0
*VAR1=+0.86603
*VAR1=+0.70711
*VAR1=+0.5
*VAR1=+0.0
*VAR1=+1.0
*VAR1=+0.86603
*VAR1=+0.70711
*VAR1=+0.5
*VAR1=+0.0
```


Tangent	<p>Example</p> RADIANO VAR1=TAN(0) VAR1 VAR1=TAN(30) VAR1 VAR1=TAN(45) VAR1 VAR1=TAN(60) VAR1 RADIAN1 VAR1=TAN(0) VAR1 VAR1=TAN(PI/6) VAR1 VAR1=TAN(PI/4) VAR1 VAR1=TAN(PI/3) VAR1	<p>Response</p> *VAR1=+0.0 *VAR1=+0.57735 *VAR1=+1.0 *VAR1=+1.73205 *VAR1=+0.0 *VAR1=+0.57735 *VAR1=+1.0 *VAR1=+1.73205
Inverse Tangent (Arc Tangent)	<p>Example</p> RADIANO VAR1=SQRT(2) VAR1=ATAN(VAR1/2) VAR1 VAR1=ATAN(.57735) VAR1	<p>Response</p> *VAR1=+35.26 *VAR1=+30.0

Boolean Operations 6K Series products have the ability to perform Boolean operations with numeric variables. The following examples illustrate this capability. Refer to the *6K Series Command Reference* for more information on each operator (&, |, ^, and ~).

Boolean And (&)	<p>Example</p> VAR1=5 VAR2=-1 VAR3=VAR1 & VAR2 VAR3	<p>Response</p> *VAR3=+0.0
Boolean Or ()	<p>Example</p> VAR1=5 VAR2=-1 VAR3=VAR1 VAR2 VAR3	<p>Response</p> *VAR3=+1.0
Boolean Exclusive Or (^)	<p>Example</p> VAR1=5 VAR2=-1 VAR3=VAR1 ^ VAR2 VAR3	<p>Response</p> *VAR3=+1.0
Boolean Not (~)	<p>Example</p> VAR1=5 VAR3=~(VAR1) VAR3 VAR1=-1 VAR3=~(VAR1) VAR3	<p>Response</p> *VAR3=+0.0 *VAR3=+1.0

Using Binary Variables

The following examples illustrate the 6K Series product's ability to perform bitwise functions with binary variables.

Storing binary values. The 6K Series Language allows you to store binary numbers in the binary variables (VARB) command. The binary variables start at the left with the least significant bit, and increase to the right. For example, to set bit 1, 5, and 7 you would issue the command VARB1=b1xxx1x1. Notice that the letter b is required. When assigning a binary variable, any bit set to “x” remains “x” until set to “1” or “0”. Any bit that is unspecified is set to “x”. To change, or check, one bit without affecting the others, use the bit-select operator (e.g., use VARB1.3-1 to set only bit 3 of VARB1).

Example VARB1=b1101XX1	Response *VARB1=1101_XX1X_XXXX_XXXX_XXXX_XXXX_XXXX
----------------------------------	--

Storing hexadecimal values. Hexadecimal values can also be stored in binary variables (VARB). The hexadecimal value must be specified the same as the binary value—left is least significant byte, right is most significant. For example, to set bit 1, 5, and 7 you would issue the command VARB1=h15. Notice that the letter h is required. **NOTE:** When assigning a hexadecimal value to a binary variable, all unspecified bits are set to zero.

Example VARB1=h7FAD VARB1	Response *VARB1=1110_1111_0101_1011_0000_0000_0000_0000
--	---

Bitwise And (&)	Example VARB1=b1101 VARB1 VARB1=VARB1 & bXXX1 1101 VARB1 VARB1=h0032 FDA1 & h1234 VARB1	Response *VARB1=1101_XXXX_XXXX_XXXX_XXXX_XXXX_XXXX_XXXX *VARB1=XX01_XX0X_XXXX_XXXX_XXXX_XXXX_XXXX_XXXX 43E9 *VARB1=0000_0000_1100_0000_0010_1000_0101_1000
-----------------	--	---

Bitwise Or ()	Example VARB1=h32FD VARB1 VARB1=VARB1 bXXX1 1101 VARB1 VARB1=h0032 FDA1 h1234 VARB1	Response *VARB1=1100_0100_1111_1011_0000_0000_0000_0000 *VARB1=11X1_1101_1111_1X11_XXXX_XXXX_XXXX_XXXX 43E9 *VARB1=1000_0100_1100_0110_1111_1111_0111_1001
----------------	--	---

Bitwise Exclusive Or (^)	Example VARB1=h32FD ^ bXXX1 1101 VARB1 VARB1=h0032 FDA1 ^ h1234 VARB1	Response *VARB1=XXX1_1001_XXXX_XXXX_XXXX_XXXX_XXXX_XXXX 43E9 *VARB1=1000_0100_0000_0110_1101_0111_0010_0001
--------------------------	--	---

Bitwise Not (~)	Example VARB1=~(h32FD) VARB1 VARB1=~(b1010 XX11 0101) VARB1	Response *VARB1=0011_1011_0000_0100_1111_1111_1111_1111 *VARB1=0101_XX00_1010_XXXX_XXXX_XXXX_XXXX_XXXX
-----------------	--	---

Shift Left to Right (>>)	Example VARB1=h32FD >> h4 VARB1 VARB1=b1010 XX11 0101 >> b11 VARB1	Response *VARB1=0000_1100_0100_1111_1011_0000_0000_0000 b11 *VARB1=0001_010X_X110_101X_XXXX_XXXX_XXXX_XXXX
--------------------------	---	--

Shift Right to Left (<<)	Example VARB1=h32FD << h4 VARB1 VARB1=b1010 XX11 0101 << b11 VARB1	Response *VARB1=0100_1111_1011_0000_0000_0000_0000_0000 b11 *VARB1=0XX1_1010_1XXX_XXXX_XXXX_XXXX_XXXX_X000
--------------------------	---	--

Program Flow Control

Program flow refers to the order in which commands will be executed, and when or whether they will be executed at all. In general, commands are executed in the order in which they are received. However, certain commands can redirect the order in which commands will be processed.

You can affect program flow with:

- Unconditional Loops and Branches
- Conditional Loops and Branches

Unconditional Looping and Branching

Unconditional Looping

The Loop (L) command is an unconditional looping command. You can use this command to repeat the execution of a group of commands for a predetermined number of iterations. You can nest Loop commands up to 16 levels deep. The code sample (portion of a program) below demonstrates a loop of 5 iterations.

```
MA0      ; Sets unit to Incremental mode
A50      ; Sets acceleration to 50
V5       ; Sets velocity to 5
L5       ; Loops 5 times
D2000    ; Sets distance to 2,000
GO1      ; Executes the move (Go)
T2       ; Delays 2 seconds after the move
LN       ; Ends loop
```

Unconditional Branching

When an unconditional branch is processed, the flow of program execution (“control”) passes to the program or label specified in the branch command. Depending on the branch command used, processing may or may not return to the original program (the “calling” program). There are three ways to branch unconditionally:

GOSUB: The GOSUB command branches to the program name or label stated in the GOSUB command. After the called program or label is executed, processing returns to the calling program at the next command line after the GOSUB branch command.

GOTO: The GOTO command branches to the program name or label stated in the GOTO command. After the called program or label is executed, processing **does not** return to the calling program—instead, the program will end. This holds true unless the subroutine in which the GOTO resides was called with a GOSUB by another program; in this case, the END in the GOTO program will initiate a return to the calling program. For example, if processing flows from a GOSUB in program A to program B, and then a GOTO from program B to program C, when the END command is processed in program C, processing returns to program A at the command line after the GOSUB.

JUMP: The JUMP command branches to the program name or label stated in the JUMP command. All nested IFs, WHILEs, and REPEATs, loops (L), and subroutines are cleared; thus, the program or label that the JUMP initiates **will not** return control to the calling program; instead, the called program will end.

If an invalid program or label name is entered, the branch command will be ignored and processing will continue with the next line in the program.

6K Series products do not support recursive calling of subroutines.

Using labels: Labels, defined with the \$ command, provide a method of branching to specific locations within the same program. Labels can only be defined within a program and executed with a GOTO, GOSUB, or JUMP command from within the same program (see *Example B below*).

NOTE

Be careful about performing a GOTO within a loop or branch statement area (i.e., between L & LN, between IF & NIF, between REPEAT & UNTIL, or between WHILE & NWHILE). Branching to a different location within the same program will cause the next L, IF, REPEAT, or WHILE statement encountered to be nested within the previous L, IF, REPEAT, or WHILE statement area, unless an LN, NIF, UNTIL, or NWHILE command has already been encountered.

** To avoid this nesting situation, use the JUMP command instead of the GOTO command.

Example A

DESCRIPTION: The program cut1 is executed until it gets to the command GOSUB prompt. From there it branches unconditionally to the subroutine (actually a program) called prompt. The subroutine prompt queries the operator for the number of parts to process. After the part number is entered (e.g., operator enters the !'12 command to process 12 parts), the rest of the prompt subroutine is executed and control goes back to the cut1 program and resumes program execution with the next command after the GOSUB, which is MAØØ.

```
DEL cut1                ; Delete a program before defining it
DEF cut1                ; Begin definition of program cut1
HOM11                  ; Send axes 1 and 2 to the home position
WAIT(1AS=b0XXX1 AND 2AS=b0XXX1) ; Wait for axes 1 and 2 to come
                        ; to a halt at home
GOSUB prompt           ; Go to subroutine program called prompt
MA00                   ; Place axes 1 and 2 in the incremental mode
A10,30                 ; Set acceleration: axis 1 = 10, axis 2 = 30
AD5,12                 ; Set deceleration: axis 1 = 5, axis 2 = 12
V5,8                   ; Set velocity: axis 1 = 5, axis 2 = 8
D16000,100000         ; Set distance: axis 1 = 16,000; axis 2 = 100,000
OUT.3-1                ; Turn on onboard output number 3
T5                     ; Wait for 5 seconds
L(VAR2)                ; Begin loop (number of loops = value of VAR2)
  GO11                 ; Initiate moves on axes 1 and 2
  T3                   ; Wait for 3 seconds
LN                      ; End loop
OUT.3-0                ; Turn off onboard output number 3
END                     ; End definition of program cut1

DEF prompt              ; Begin definition of program prompt
VAR1="Enter part count >" ; Place message in string variable 1
VAR2=READ1              ; Prompt operator with string variable 1,
                        ; and read data into numeric variable 2
                        ; NOTE: Type !' before the part count number.
END                      ; End definition of program prompt
```

Example B

DESCRIPTION: This example demonstrates the use of labels (\$).

```
DEL pick                ; Delete a program before defining it
DEF pick                ; Begin definition of program pick
GO1100                 ; Initiate motion and axes 1 and 2
IF(VAR1=5)              ; If variable 1 = 5, then execute commands
                        ; between IF and ELSE. Otherwise, execute
                        ; commands between ELSE and NIF
  GOTO pick1            ; Goto label pick1
  ELSE                  ; Else part of IF statement
    GOTO pick2          ; Goto label pick2
NIF                     ; End of IF statement
$ pick1                 ; Define label for pick1
GO0011                 ; Initiate motion on axes 3 and 4
BREAK                  ; Break out of current subroutine or program
$ pick2                 ; Define label for pick2
GO1001                 ; Initiate motion on axes 1 and 4
END                     ; End definition of program pick
```

Conditional Looping and Branching

Conditional looping (REPEAT/UNTIL and WHILE/NWHILE) entails repeating a set of commands until or while a certain condition exists. In *conditional branching* (IF/ELSE/NIF), a specific set of commands is executed based on a certain condition. Both rely on the fulfillment of a conditional *expression*, a condition specified in the UNTIL, WHILE, or IF commands.

A wait command pauses command execution until a specific condition exists.

Flow Control Expression Examples

This section provides examples of expressions that can be used in conditional branching and looping commands (UNTIL, WHILE, and IF) and the wait command. These expressions can be constructed, in conjunction with relational and logical operators, with the following operands:

- Numeric variables and binary variables
- Inputs and outputs
- Current motion parameters and status
- Current commanded and actual position
- Error, axis, and system status
- Timer value
- Data read from the serial port
- Data read from the RP240
- Following conditions
- Multi-tasking conditions

Numeric and Binary Variables

A numeric variable (VAR or VARI) can be used within an expression if it is compared against another numeric variable, a value, or one of the comparison commands (see list on page 7). When comparing a variable against another value, variable, or comparison command, the relational operators (=, >, >=, <, <=, <>) and logical operators (AND, OR, NOT) are used.

Expression

(VAR1<VAR2)
 (VAR1>=2500)
 (VAR1=1AD)
 (VAR1<VAR2 AND VAR4>1PE)

Description

True expression if variable 1 is less than variable 2
 True expression if variable 1 is greater than or equal to 2500
 True expression if variable 1 is equal to the decel of axis 1
 True expression if variable 1 is less than variable 2 and variable 4 is greater than the value of encoder 1

A binary variable (VARB) can be used within an expression, if the variable is compared against another binary variable, or a value. When comparing a variable against another value or variable, the relational operators (=, >, >=, <, <=, <>) and logical operators (AND, OR, NOT) are used.

Expression

(VARB1<>VARB2)
 (VARB1=b1101 X111)
 (VARB1<VARB2 AND VARB4>hF)

Description

True expression if binary variable 1 is not equal to binary variable 2
 True expression if binary variable 1 is equal to 1101 X111
 True expression if binary variable 1 is less than binary variable 2 and binary variable 4 is greater than the hexadecimal value of F

Inputs and Outputs

An input or output operand (ANI, ANO, IN, INO, LIM, OUT, TRIG) can be used within an expression, if the operand is compared against a binary variable or a binary or hexadecimal value. When making the comparison, the relational operators (=, >, >=, <, <=, <>) and logical operators (AND, OR, NOT) are used.

Expression Description

(IN.3=b1) True expression if onboard input 3 is equal to 1
 (LIM>h3) True expression if limit status is greater than hexadecimal 3

Current Motion Parameters and Status

Motion parameters consist of A, AD, D, V, VEL, status MOV. The motion parameters can be used within an expression, if the operand is compared against a numeric variable or value. The motion status operand must be compared against a binary variable or a binary or hexadecimal value. When making the comparison, the relational operators (=, >, >=, <, <=, <>) and logical operators (AND, OR, NOT) are used. (Following conditions are addressed below.)

Expression	Description
(VAR1<1VEL)	True expression if the value of variable 1 is less than the commanded velocity of axis 1
(1AD=25000)	True expression if axis 1 deceleration equals 25000
(MOV=b00)	True expression if moving status equals 00 (axes 1 & 2 are not moving)

Current Commanded & Actual Position

The current commanded and actual positions (ANI, DAC, FB, PANI, PC, PCC, PCE, PCME, PCMS, PE, PER, PE, PMAS, PME, PSHF, PSLV) can be used within an expression, if the operand is compared against a numeric variable or value. When making the comparison, the relational operators (=, >, >=, <, <=, <>) and logical operators (AND, OR, NOT) are used.

Expression	Description
(VAR1<1FB)	True expression if the value of variable 1 is less than the actual position (position of the assigned feedback device) of axis 1
(2PC=4000)	True expression if axis 2 commanded position equals 4000
(VAR1<1PME)	True expression if VAR1 is < master encoder position of axis 1
(2PE=25000)	True expression if axis 2 encoder position equals 25000

Error, Axis, and System Status

The error status, axis status, and system status operands (ER, AS, ASX, SS) can be used within an expression, if the operand is compared against a binary variable or a binary or hexadecimal value. When making the comparison, the relational operators (=, >, >=, <, <=, <>) and logical operators (AND, OR, NOT) are used. Refer to page 226 for a list of status bit functions.

Expression	Description
(ER.12=b1)	True expression if error status bit 12 is equal to 1
(AS=h3FFD)	True expression if axis status is equal to hexadecimal 3FFD

Timer Value

The current timer value (TIM) can be used within an expression, if the operand is compared against a numeric variable or value. When making the comparison, the relational operators (=, >, >=, <, <=, <>) and logical operators (AND, OR, NOT) are used.

Expression	Description
(VAR1<TIM)	True expression if the value of variable 1 is less than the timer value

Data Read from the Communications Port

The READ command can be used to input data from a serial port or the Ethernet port into a numeric variable. After the data has been read into a numeric variable, that variable can be used in an expression.

Example	Description
VAR8="ENTER DATA"	Define message (string variable 8)
VAR2=READ8	Send message (string variable 8) and then wait for immediate data to be read (into numeric variable 2)
!'88.3	Immediate data input (must type '!' before the numeric value)
IF (VAR2<=100)	Evaluate expression to see if data read is < or equal to 100
.	
NIF	End of IF

Data Read from the RP240

The DREAD and DREADF commands can be used to input data from the RP240 into a numeric variable. DREAD reads a number from the RP240's numeric keypad. DREADF reads a number representing a RP240 function key. After the data has been read into a numeric variable, that variable can be used in an expression. The DKEY operator allows you to read the current state of the RP240 keypad (each key has a unique numeric value).

DCLEAR0	; Clear RP240 display
DWRITE"HIT F4"	; Send message to RP240 display
VAR3=DREADF	; Read data from a RP240 function key into numeric variable 3
IF (DKEY=24)	; Evaluate expression to see if function key F4 was hit
DCLEAR2	; Clear RP240 display line 2
DWRITE"TRY AGAIN"	; Send message to RP240 display
NIF	; End of IF

The DREADI1 command allows continual numeric or function key data entry from the RP240 (when used in conjunction with the DREAD and/or DREADF commands). In this immediate mode, program execution is not paused (waiting for data entry) when a DREAD or DREADF command is encountered. Refer to the DREAD and DREADF command descriptions for programming examples.

NOTES

- While in the Data Read Immediate Mode, data is read into numeric variables only (VAR).
- This feature is not designed to be used in conjunction with the RP240's standard menus; the RUN, JOG, and DJOG menus will disable the DREADI mode.
- Do not assign the same variable to read numeric data and function key data—pick only one.

Following Conditions

These Following conditions are available for conditional expressions: Axis status bit 26 (AS.26), Error status bit 14 (ER.14), Following status (FS), NMCY, PCME, PCMS, PMAS, PME, PSHF, PSLV, and VMAS.

Expression	Description
(2AS.26=b1)	True if a new motion profile on axis 2 is waiting for the GOWHEN condition to be true or a TRGFNC1xxxxxxx trigger.
(1ER.14=b1)	True if the GOWHEN condition on axis 1 is already true when the subsequent GO, GOL, FSHFC, or FSHFD command is executed.
(3FS.7=b0)	True if the master for follower axis 3 is in motion.
(2NMCY>200)	True if the master for axis 2 has moved through 200 cycles.
(1PMAS>12)	True if the master for axis 1 has traveled more than 12 units.
(1PSHF>1.5)	True if follower axis 1 has shifted more than 1.5 units.
(3PSLV>24)	True if follower axis 3's commanded position is more than 24 units.
(1VMAS<2)	True if the velocity of the master for axis 1 is less than 2 units/sec.

Multi-Tasking Conditions

These Multi-tasking conditions are available for conditional expressions: Status of which tasks are current active (SWAP), identity of the task in which the command is executed (TASK).

Expression	Description
(SWAP.3=b1)	True if Task 3 is active.
(TASK=3)	True if the task executing the conditional expression is Task 3.

Conditional Looping

The 6K controller supports two conditional looping structures—REPEAT/UNTIL and WHILE/NWHILE.

All commands between REPEAT and UNTIL are repeated until the expression contained within the parenthesis of the UNTIL command is true. The example below illustrates how a typical REPEAT/UNTIL conditional loop works. In this example, the REPEAT loop will execute 1 time, at which point the expression stated within the UNTIL command will be evaluated. If the expression is true, command processing will continue with the first command following the UNTIL command. If the expression is false, the REPEAT loop will be repeated.

```

VAR5=0           ; Initializes variable 5 to 0
DEL prog10      ; Delete a program before defining it
DEF prog10      ; Defines program prog10
INFNC1-A        ; Assign onboard input 1 as g.p. input for use with IN
INFNC2-A        ; Assign onboard input 2 as g.p. input for use with IN
INFNC3-A        ; Assign onboard input 3 as g.p. input for use with IN
INFNC4-A        ; Assign onboard input 4 as g.p. input for use with IN
OUTFNC1-A       ; Assign onboard output 1 is a general-purpose output
A50             ; Acceleration is 50
AD50            ; Deceleration is 50
V5             ; Sets velocity to 5
D25000         ; Distance is 25,000
REPEAT          ; Begins the REPEAT loop
  GO1           ; Executes the move (Go)
  VAR5=VAR5+1   ; Variable 5 counts up from 0
UNTIL(IN=b1110 OR VAR5>10) ; When inputs 1-4 are 1110, respectively, or
  
```

```

                                ; VAR5 is greater than 10, the loop will stop.
OUT1                             ; Turn on output 1 when finished with REPEAT loop
END                               ; End program definition
RUN prog10                        ; Initiate program prog10

```

All commands between WHILE and NWHILE are repeated as long as the WHILE condition is true. The following example illustrates how a typical WHILE/NWHILE conditional loop works. In this example, the WHILE loop will execute if the expression is true. If the expression is false, the WHILE loop will not execute.

```

VAR5=0                            ; Initializes variable 5 to 0
DEL prog10                        ; Delete a program before defining it
DEF prog10                        ; Defines program prog10
INFNC1-A                          ; Assign onboard input 1 as g.p. input for use with IN
INFNC2-A                          ; Assign onboard input 2 as g.p. input for use with IN
INFNC3-A                          ; Assign onboard input 3 as g.p. input for use with IN
INFNC4-A                          ; Assign onboard input 4 as g.p. input for use with IN
OUTFNC1-A                        ; Assign onboard output 1 is a general-purpose output
A50                               ; Acceleration is 50
AD50                              ; Deceleration is 50
V5                                ; Sets velocity to 5
D25000                           ; Distance is 25,000
WHILE(IN=b1110 OR VAR5>10)      ; While the inputs 1-4 are 1110, respectively
                                ; or VAR5 is greater than 10, the loop will continue.
    GO1                           ; Executes the move (Go)
    VAR5=VAR5+1                   ; Variable 5 counts up from 0
NWHILE                            ; End WHILE command
OUT1                             ; Turn on output 1 when finished with WHILE loop
END                               ; End program definition

; *****
; * To run prog10, execute the "RUN prog10" command *
; *****

```

Conditional Branching

You can use the IF command for conditional branching. All commands between IF and ELSE are executed if the expression contained within the parentheses of the IF command is true. If the expression is false, the commands between ELSE and NIF are executed. If the ELSE is not needed, it can be omitted. The commands between IF and NIF are executed if the expression is true. Examples of these commands are as follows.

```

DEL prog10                        ; Delete a program before defining it
DEF prog10                        ; Defines program prog10
INFNC1-A                          ; Assign onboard input 1 as g.p. input for use with IN
INFNC2-A                          ; Assign onboard input 2 as g.p. input for use with IN
INFNC3-A                          ; Assign onboard input 3 as g.p. input for use with IN
INFNC4-A                          ; Assign onboard input 4 as g.p. input for use with IN
A50                               ; Acceleration is 50
AD50                              ; Deceleration is 50
V5                                ; Sets velocity to 5
IF(VAR1>0)                        ; IF variable 1 is greater than zero
    D25000                        ; Distance is 25,000
    ELSE                          ; Else
    D50000                        ; Distance is 50,000
NIF                               ; End if command
IF(IN=b1110)                      ; If onboard inputs 1-4 are 1110, initiate axis 1 move
    GO1                           ; Executes the move (Go)
NIF                               ; End IF command
END                               ; End program definition

; *****
; * To run prog10, execute the "RUN prog10" command *
; *****

```


Program Interrupts (*ON Conditions*)

Multi-Tasking
 Each task has its own ONP program and its own set of ON conditions.

While executing a program, the 6K controller can interrupt the program based on several possible *ON conditions*: programmable input(s) status, user status, or the value of numeric variables 1 or 2. These ON conditions are enabled with the ONCOND command, and are defined with the commands listed below. After the ON conditions are enabled (with the ONCOND command), an ON condition interrupt can occur at any point in program execution. When an ON condition occurs, the controller performs a GOSUB to the program assigned as the ON program and then passes control back to the original program and resumes command execution at the command line from which the interruption occurred.

Within the ON program, the programmer is responsible for checking which ON condition caused the branch (if multiple ON conditions are enabled with the ONCOND command). Once a branch to the ON program occurs, the ON program will not be called again until after it has finished executing. After returning from the ON program, the condition that caused the branch must evaluate false before another branch to the ON program will be allowed.

SETUP FOR PROGRAM INTERRUPT (see programming example below)

1. Define a program to be used as the ON program to which the controller will GOSUB when an ON condition evaluates true.
2. Use the ONP command to assign the program as the ON program.
3. Use the ONCOND command to enable the ON conditions that you are using. The syntax for the ONCOND command is ONCOND, where the first is for the ONIN condition, the second for ONUS, the third for ONVARA, and the fourth for ONVARB.

ON conditions:

- ONIN Specify an input bit pattern that will cause a GOSUB to the program assigned as the ON program (see programming example below).
- ONUS Specify an user status bit pattern that will cause a GOSUB to the ON program. The user status bits are defined with the INDUST command.
- ONVARA Specify the range of numeric variable 1 (VAR1) that will cause a GOSUB to the ON program. For example, ONVARAØ, 2Ø establishes the condition that if the value of VAR1 is ≤0 or ≥20, the ON program will be called.
- ONVARB This is the same function as ONVARA, but for numeric variable 2 (VAR2)

Programming Example: Configures the controller to increment variable 1 when input 1 goes active. If input 1 does go active, control will be passed (GOSUB) to the ON program (onjump), the commands within the ON program will be executed, and control will then be passed back to the original program.

```

DEF onjump        ; Begin definition of program onjump

VAR1=VAR1+1      ; Increment variable 1
END               ; End definition of program onjump

VAR1=0            ; Initialize variable 1
ONIN1            ; When input 1 becomes active, branch to the ON program
ONP onjump       ; Assign the onjump program as the ON program
ONCOND1000       ; Enable only the ONIN function. Disable the ONUS,
                  ; ONVARA, and ONVARB functions, respectively
  
```

Situations in which ON conditions will not interrupt immediately

These are situations in which an ON condition does not immediately interrupt the program in progress. However, the fact that the ON condition evaluated true is retained, and when the condition listed below is no longer preventing the interrupt, the interrupt will occur.

- While motion is in progress due to GO, GOL, GOWHEN, HOM, JOY, JOG, or PRUN and the continuous command execution mode is disabled (COMEXCØ).
- While a WAIT statement is in progress
- While a time delay (T) is in progress
- While a program is being defined (DEF)
- While a pause (PS) is in progress
- While a data read (DREAD, DREADI, DREADF, or READ) is in progress

Error Handling

USE MOTION PLANNER

Motion Planner's editor provides an error handling wizard.

DEBUG TOOLS

For information on program debug tools, see page 225.

The 6K Series products have the ability to detect and recover the following error conditions:

- Error bit 1 Stepper axes only: Stall detected on any axis
- Error bit 2 Hardware end-of-travel limit encountered on any axis
- Error bit 3 Software end-of-travel limit encountered on any axis
- Error bit 4 Drive fault input activated any axis
- Error bit 5 Commanded kill or stop
- Error bit 6 Kill input activated
- Error bit 7 User fault input activated
- Error bit 8 Stop input activated
- Error bit 9 ENABLE input not grounded
- Error bit 10 Profile for a pre-emptive GO or a registration move is not possible
- Error bit 11 Servo Axes Only: Target zone settling timeout
- Error bit 12 Servo Axes Only: Allowable position error (SMPER) exceeded
- Error bit 14 GOWHEN condition already true when the subsequent GO, GOL, FSHFC, or FSHFD command was executed
- Error bit 16 Bad command is detected
- Error bit 17 Encoder failure is detected, if EFAIL1 mode is enabled
- Error bit 18 Expansion I/O brick cable is disconnected or powered down
- Error bit 22 Ethernet failed due to hardware disconnect or COM6SRVR server failure.

Enabling Error Checking

To detect and respond to the error conditions noted above, the corresponding error-checking bit(s) must be enabled with the `ERROR` command (see the *ERROR Bit* column in the table below). If an error condition occurs and the associated error-checking bit has been enabled with the `ERROR` command, the 6K controller will branch to the error program.

For example, if you wish the 6K controller to branch to the error program when a hardware end-of-travel limit is encountered (error bit 2) or when a drive fault occurs (error bit 4), you would issue the `ERRORØ1Ø1` command to enable error-checking bits 2 and 4.

MULTI-TASKING

If you are operating multiple tasks, be aware that you must enable error conditions (`ERROR`) and specify an error program (`ERRORP`) for each task (e.g., `2%ERROR.2-1` and `2%ERRORP FIX` for Task 2). Each task has its own error status register (reported with `ER`, `TER`, and `TERF`). Regarding axis-related error conditions (e.g., drive fault, end-of-travel limit, etc.), only errors on the task's associated (`TSKAX`) axes will cause a branch to the task's `ERRORP` program.

⇒ **Hint:** Within the structure of your error program, you can use the `IF` and `ER` commands to check which error caused the call to the `ERRORP` program and respond accordingly.

Defining the Error Program

The purpose of the error program is to provide a programmed response to certain error conditions (see list above) that can occur during the operation of your system. Programmed responses typically include actions such as shutting down the drive(s), activating or deactivating outputs, etc. Refer to the error program set-up example below.

Using the `ERRORP` command, you can assign any previously defined program as the error program. For example, to assign a previously defined program named `CRASH` as the error program, enter the `ERRORP CRASH` command. To un-assign a program from being the error program, issue the `ERRORP CLR` command (e.g., as in this example, it does not delete the `CRASH` program, but merely unlinks it from its assignment as the error program).

Canceling the Branch to the Error Program

NOTE: In addition to canceling the branch to the error program, you must also remedy the cause of the error; otherwise, the error program will be called again when you resume operation. Refer to the *How to Remedy the Error* column in the table below for details.

If an error condition occurs and the associated error-checking bit has been enabled with the ERROR command, the 6K controller will branch to the error program. The error program will be continuously called/repeated until you cancel the branch to the error program. (This is true for all cases except error condition number 9, ENABLE input activated, in which case the error program is called only once.)

There are three options for canceling the branch to the error program:

- Disable the error-checking bit with the ERROR.n-Ø command, where "n" is the number of the error-checking bit you wish to disable. For example, to disable error checking for the kill input activation (bit 6), issue the ERROR.6-Ø command. To re-enable the error-checking bit, issue the ERROR.n-1 command.
- Delete the program assigned as the ERRORP program (DEL <name of program>).
- Satisfy the *How to Remedy the Error* requirement identified in the table below.

ERROR Bit	Cause of the Error	Branch Type to Error Program	How to Remedy the Error
1	Stepper axes only: Stall detected (Stall Detection and Kill On Stall must be enabled first—see ESTALL and ESK, respectively).	Gosub	Issue a GO command.
2	Hard Limit Hit. (hard limits must be enabled first—see LH)	If COMEXLØ, then Goto; If COMEXL1, then Gosub	Change direction & issue GO command on the axis that hit the limit; or issue LHØ.
3	Soft Limit Hit. (soft limits must be enabled first—see LS)	If COMEXLØ, then Goto; If COMEXL1, then Gosub	Change direction & issue GO command on the axis that hit the limit; or issue LSØ.
4	Drive Fault (Detected only if you enable drive, DRIVE1, and drive fault input, DRFEN, and set correct drive fault level, DRFLVL; See page 46.)	Goto	Clear the fault condition at the drive, & issue a DRIVE1 command for the faulted axis.
5	Commanded Stop or Kill (whenever a K, !K, <ctrl>K, K, or !S command is sent). <div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 5px auto;">See note below entitled "Commanded Kill or Stop".</div>	If !K, then Goto; If !S & COMEXSØ, then Goto; If !S & COMEXS1, then Gosub, but need !C	No fault condition is present—there is no error to clear. If you want the program to stop, you must issue the !HALT command.
6	Kill Input Activated (see INFNCi-C or LIMFNCi-C)	Goto	Deactivate the kill input.
7	User Fault Input Activated (see INFNCi-F or LIMFNCi-F).	Goto	Deactivate the user fault input, or disable it by assigning it a different function.
8	Stop input activated (see INFNCi-D or LIMFNCi-C).	Goto	Deactivate the stop input, or disable it by assigning it a different function.
9	ENABLE input not grounded. (see "ESTOP" below)	Goto	Re-ground ENABLE input, and issue @DRIVE1.
10	Profile for pre-emptive GO or registration move not possible at the time of attempted execution.	Gosub	Issue another GO command.
11	Servo axes only: Target Zone Timeout (STRGTT value has been exceeded).	Gosub	Issue these commands in this order: STRGTEØ, DØ, GO, STRGTE1
12	Servo axes only: Exceeded Maximum Allowable Position Error (set with the SMPER command).	Gosub	Issue a DRIVE1 command to the axis that exceeded the allowable position error. Verify that feedback device is working properly.
14	GOWHEN condition was already true when the subsequent GO, GOL, FGADV, FSHFC, or FSHFD command was executed.	Goto	Issue another GOWHEN command; or issue a !K command and check the program logic (use the TRACE and STEP features if necessary).
16	Bad command was detected.	Gosub	Issue the TCMDEP command to I.D. the command.
17	Encoder failure detected (EFAIL1 must be enabled before this error can be detected).	Gosub	Reconnect the encoder while the axis is in the EFAIL1 mode.
18	Cable to an expansion I/O brick is disconnected, or power to the I/O brick is lost.	Goto	Reconnect I/O brick cable. Issue the ERROR.18-0 command and then the ERROR.18-1 command.
22	Ethernet connection failed (hardware disconnect or COM6SRVR communications server failure).	Gosub	Clear the error bit (ERROR.22-0), re-establish the Ethernet connection, and then issue ERROR.22-1.

Reserved Bits: Bits 13, 15, 19-21 and 23-32.

Branching Types: If the error condition calls for a GOSUB, then after the ERRORP program is executed, program control returns to the point at which the error occurred. To prevent a return to the point at which the error occurred, use the HALT command to end program execution or use the GOTO command to go to a different program. If the error condition calls for a GOTO, there is no way to return to the point at which the error occurred.

Commanded Kill or Stop: When error bit 5 is enabled (ERROR.5-1), a Stop (S or !S) or a Kill (K, !K or <ctrl>K) command will cause the controller to branch to the error program. Note, however, that this error condition does not set an error bit (ER), because there is no way to clear the error condition upon leaving the error program. Therefore, you should use the IF (ER=b00000000000000000000000000000000) statement in your error program to determine if the cause of the error was a commanded kill or stop (i.e., if no error bits are set).

If ESTOP (ENABLE input) also cuts power to drives: This note is for systems in which power to the drives (not the 6K) is cut if the ENABLE input is opened. If you enable ERROR bit 9: When the ENABLE input is opened (and power is cut to the drives), the ERRORP program is called. Because the drives have lost power, the 6K will detect drive faults, which in turn kills the ERRORP program. If the ENABLE input is still ungrounded, the ERRORP program will again be called and then killed because of the drive fault condition (causing an endless loop). The resolution is to place the @DRFEN0 command in the ERRORP program so that it can disable checking the drive fault input and thereby circumvent the endless loop of calling the ERRORP program. Be sure to later re-enable drive fault checking with @DRFEN1 after the ENABLE input is re-grounded.

Error Program Set-up Example

The following is an example of how to set up an error program. This particular example is for handling the occurrence of a user fault.

Step 1 Create a program file (in Motion Planner's Editor module) to set up the error program:

```
; *****  
; * Assign the user fault input function to onboard trigger input 1. *  
; * The purpose of the user fault input is to detect the occurrence *  
; * of a fault external to the 6K controller and the motor/drive. *  
; * This input will generate an error condition. *  
; *****  
INFNC1-F ; Define onboard trigger input 1 as a user fault input  
  
; *****  
; * Define a program to respond to the user fault (call the program *  
; * fault), and then assign that program as the error program. The *  
; * purpose of the fault program is to display a message to inform *  
; * the operator that the user fault input has been activated. *  
; *****  
DEL fault ; Delete a program before defining it (a precaution)  
DEF fault ; Begin definition of program fault  
IF(ER.7=b1) ; Check if error bit 7 equals 1  
; (which means the user fault input has been activated)  
WRITE"FAULT INPUT\10\13" ; Send the message FAULT INPUT  
T3 ; Wait 3 seconds  
NIF ; End IF command  
END ; End definition of program fault  
ERRORP fault ; Assign the program called fault as the error program  
  
; *****  
; * Enable the user fault error-checking bit by putting a "1" in *  
; * the seventh bit of the ERROR command. After enabling this *  
; * error-checking bit, the controller will branch to the error *  
; * program whenever the user fault input is activated. *  
; *****  
ERROR000001 ; Branch to error program upon user fault input (As an  
; alternative to the ERROR000001 command, you could also  
; enable bit 7 by issuing the ERROR.7-1 command.)
```

Step 2 Save the program file in the Editor module. Then, using the Terminal module, download the program file to the 6K controller.

Step 3 Test the error handling:

1. While in the terminal emulator, enter these four commands:


```

L                               ; Loop command
WRITE"IN LOOP\10\13"           ; Display the message "IN LOOP"
T2                               ; Wait 2 seconds
LN                               ; End the loop ("IN LOOP" will be displayed
                               ; once every 2 seconds)
      
```
2. While the loop (IN LOOP) is executing in the terminal emulator, enter the !INEN1 command. The !INEN1 command disables input 1 and forces it on for testing purposes. This simulates the physical activation of input 1. (Since the error program is called continuously until the branch to the error program is canceled, the message FAULT INPUT will be repeatedly displayed once every 3 seconds.)
3. While the FAULT INPUT loop is executing in the terminal emulator, enter the !INENE command. The !INENE command re-enables input 1. The message In loop will not be displayed again, because the user fault input error is a GOTO branch (not a GOSUB branch) to the error program.

Non-Volatile Memory

The items listed below are automatically stored in the 6K product's non-volatile memory (battery-backed RAM). Cycling power or issuing a RESET command will not affect these settings.

- Power-up program (STARTP)
- Programs (defined with DEF & END)
- Compiled profiles and PLC programs (PCOMP). Compiled contours and PLC programs are always saved in the Compiled portion of battery-backed RAM. However, compiled individual axis profiles (GOBUF profiles) are removed from Compiled memory if you run them with the PRUN command and later cycle power or reset the controller (you will have to re-compile them with the PCOMP command).
- Memory allocation (MEMORY)
- Axis type definition (AXSDEF)
- Variables: VAR, VARI, VARB, and VARS
- Scaling: SCALE, SCLA, SCLD, SCLV, SCLMAS
- Commanded direction polarity (CMDDIR)
- Encoder polarity (ENCPOL)
- Device address for RS-232 or RS-485 serial communication (ADDR)
- Baud rate for RS-232 or RS-485 serial communication (BAUD)
- Ethernet IP address (NTADDR)
- Ethernet network mask (NTMASK)
- RP240 check and serial port functionality (DRPCHK)
- RP240 password (DPASS)
- Servo gain sets (SGSET)

A checksum is calculated for the non-volatile memory area each time you power up or reset your 6K controller. A bad checksum indicates that the user memory has been corrupted (possibly due to electrical noise) or has been cleared (due to a spent battery). The controller will clear all user memory when a bad checksum is calculated on power up or reset, and bit 22 will be set in the TSS command response.

System Performance

Several commands (listed below), when enabled, will slow command processing. This degradation in performance will not be noticeable for most applications. But for some, it can be necessary to disable one or all of these commands.

- SCALE (enable/disable scaling)
- INDUSE (enable/disable user status updates)
- INFNC (trigger and extended input functions; excluding functions “A” and “H”)
- LIMFNC (limit input functions; excluding functions “A”, “R”, “S”, and “T”)
- OUTFNC (digital output functions; excluding function “A”)
- ONCOND (enable/disable ON conditions)

Servo Update Performance Slowdown

If the 6K displays the “SYSTEM UPDATE OVERRUN, USE SYSPER4” error message, execute the SYSPER4 command to change the 6K’s system update period. For details, see the SYSPER command description in the *Command Reference*.


CHAPTER TWO

Communication

IN THIS CHAPTER

- Motion Planner™ communication features 36
- Serial Communication:
 - Controlling multiple serial ports 37
 - RS-232C daisy-chaining 38
 - RS-485 multi-drop 41

Communication Options



USING MULTIPLE PORTS

You can communicate to either the Ethernet port or the RS-232 port (COM1) at any give time; the port that you communicate to first is the only one that is recognized until you cycle power.

You can communicate to the Ethernet port or the RS-232 port (COM1) while the 6K is also communicating with an RP240 via the RS-232/485 port (COM2).

Motion Planner Communication Features

Motion Planner provides easy direct communication links to the product:

- Communicate directly from any Motion Planner utility (Editor, Terminal, and Panels).
- Communication setup parameters (Ethernet and serial communication).
- Download the 6K product's soft operating system. The operating system is loaded at the factory, but can use this feature to download upgrades.
- Download motion programs to the controller, and upload motion programs from the controller.

Communications Server: Also available on the Motion Planner CD is a 32-bit OLE automation server for adding 6K communication capability to your custom applications created with programming languages such as Visual Basic or Visual C++. For details, see *Com6srvr User's Guide for Gemini & 6K Series Products*.

Serial Communication

In this section:

- Controlling Multiple Serial Ports
- RS-232 Daisy Chaining
- RS-485 Multi-Drop

Controlling Multiple Serial Ports

Every 6K Series product has two serial ports. The “RS-232” connector is referenced as the “COM1” serial port, and the “RS-232/485” connector is referenced as the “COM2” serial port.

XON/XOFF

The XON/XOFF command was created to enable or disable XON/XOFF ASCII handshaking. (XON/XOFF1 enables XON/XOFF, XON/XOFF0 disables XON/XOFF) Defaults: XON/XOFF1 for the COM1 port, XON/XOFF0 for the COM2 port.

Controllers on a multi-drop do not support XON/XOFF; to ensure that XON/XOFF is disabled for COM2, send the PORT2 command followed by the XON/XOFF0 command.

Configuring the COM Port

To control the applicable port for setting up serial communication and transmitting ASCII text strings, use the PORT command. PORT1 selects COM1 and PORT2 selects COM2.

- Serial communication setup commands (see list below) affect the COM port selected with the last PORT command. For example, to configure the COM2 port for 6K language commands only (e.g., to communicate to the 6K product over an RS-485 interface), execute the PORT2 command, then execute the DRPCHK0 command.

DRPCHK..... RP240 Check
E..... Enable Serial Communication
ECHO..... Enable Communication Echo
BOT..... Beginning of Transmission Characters
BAUD..... Serial Communication Baud Rate
EOT..... End of Transmission Characters
EOL..... End of Line Terminating Characters
ERRBAD..... Error Prompt
ERRDEF..... Program Definition Prompt
ERRLVL..... Error Detection Level
ERRORK..... Good Prompt
XON/XOFF..... Enable or disable XON/XOFF

- The PORT command also selects the COM port through which the WRITE and READ commands transmit ASCII text strings. If an RP240 is connected, the DWRITE command (and all other RP240 commands) will affect the RP240 regardless of the PORT command setting. If no RP240 is detected, the commands are sent to the COM2 port. DWRITE text strings are always terminated with a carriage return.

Setup for 6K Language or RP240

To configure the COM ports for use with 6K language commands or an RP240, use the DRPCHK command. The DRPCHK command affects the COM port selected with the last PORT command. The default for COM1 is DRPCHK0; the default for COM2 is DRPCHK3. The DRPCHK setting is automatically saved in non-volatile memory. **NOTE:** Only one COM port can be set to DRPCHK2 or DRPCHK3 at any given time.

- DRPCHKØ..... Use the COM port for 6K language commands only. This is the default setting for COM1, and if using RS-485 half duplex on COM2. Power-up messages appear on all ports set to DRPCHKØ.
- DRPCHK1..... Check for the presence of an RP240 at power-up/reset. If an RP240 is present, initialize the RP240. If an RP240 is not present, use the port only for 6K language commands. **NOTE:** RP240 commands will be sent at power-up and reset.
- DRPCHK2..... Check for the presence of an RP240 every 5-6 seconds. If an RP240 is plugged in, initialize the RP240.
- DRPCHK3..... Check for the presence of an RP240 at power-up/reset. If an RP240 is present, the initialize the RP240. If an RP240 is not present, use the COM port for DWRITE commands only, and ignore received characters. This is the default setting for COM2, unless you are using RS-485 multi-drop communication (in that case the default changes to DRPCHKØ).

RS-485 compatible products: If you are using RS-485 communication in a multi-drop (requires you to change an internal jumper to select half duplex), the default setting for COM2 is DRPCHKØ. If the internal jumper setting is left at full duplex, the default setting for COM2 is DRPCHK3.

Selecting a Destination Port for Transmitting from the Controller

To define the port (COM port) through which the 6K product sends its responses, you have 3 options:

- Do nothing different. The response will be sent to the COM port through which the request was made. If the command is in a stored program, the report will be sent to the COM port selected by the most recent PORT command.
- Prefix the command with [. This causes the response to be sent to both COM ports. (e.g., the [TFS command response will be sent through both COM ports)
- Prefix the command with]. This causes the response to be sent to the alternative COM port. For example, if a report back (e.g.,]TAS) is requested from COM1, the response is sent through COM2. If the command is in a stored program, the report will be sent out the alternate port from the one selected by the most recent PORT command.

RS-232C Daisy-Chaining

Up to ninety-nine stand-alone 6K Series products can be daisy-chained. There are two methods of daisy-chaining: one uses a computer or terminal as the controller in the chain; the other uses one 6K product as the master controller. Refer to your product's *Installation Guide* for daisy-chain connections.

Follow these steps to implement daisy-chaining:

Step 1

To enable and disable communications on a particular controller unit in the chain, you must use the Daisy-Chain Address (ADDR) command to establish a unique device address for each the unit. The ADDR command automatically configures unit addresses for daisy chaining. This command allows up to 99 units on a daisy chain to be uniquely addressed.

Sending ADDR_i to the first unit in the daisy chain sets its address to be (i). The first unit in turn transmits ADDR (i + 1) to the next unit to set its address to (i + 1). This continues down the daisy chain until the last unit of (n) daisy-chained units has its address set to (i + n).

Note that a controller with the default device address of zero (0) will send an initial power-up start message similar to the following:

```
*PARKER 6K MOTION CONTROLLER
*NO REMOTE PANEL
```

Step 2

Connect the daisy-chain with a terminal as the master (see diagram in the product's *Installation Guide*).

It is necessary to have the error level set to 1 for all units on the daisy-chain (ERRLVL1). When the error level is not set to 1, the controller sends ERROK or ERBAD prompts after each command, which makes daisy-chaining impossible. Send the ERRLVL1 command to each unit in the chain. (**NOTE:** To send a the ERRLVL1 command to one specific unit on the chain, prefix the command with the appropriate unit's device address and an underline.)

Commands

```
1_ ERRLVL1      ; Set error level to 1 for unit 1
2_ ERRLVL1      ; Set error level to 1 for unit 2
3_ ERRLVL1      ; Set error level to 1 for unit 3
```

After this has been accomplished, a carriage return sent from the terminal will not cause any controller to send a prompt. Verify this. Instructions below (step 3) show how to set the error level to 1 automatically on power-up by using the controller's power-up start program (highly recommended).

After the error level for all units has been set to ERRLVL1, send a 6K series command to all units on the daisy-chain by entering that command from the master terminal.

Commands

```
OUT1111        ; Turn on onboard outputs 1-4 on all units
A50,50         ; Set accel to 50 (all units, axes 1 & 2)
```

To send a 6K series command to one particular unit on the chain, prefix the command with the appropriate unit's device address and an underline:

Commands

```
2_ OUT0        ; Turn off onboard output 1 on unit 2
4_ OUT0        ; Turn off onboard output 1 on unit 4
```

To receive data from a particular controller on the chain, you **must** prefix the command with the appropriate unit's device address and an underline:

Commands

```
1_ A           ; Request acceleration information from unit 1
*A50,50        ; Response from unit 1
```

Use the E command to enable/disable RS-232C communications for an individual unit. If all 6K controller units on the daisy chain are enabled, commands without a device address identifier will be executed by all units. Because of the daisy-chain's serial nature, the commands will be executed approximately 1 ms per character later on each successive unit in the chain (assuming 9600 baud).

Units with the RS-232C disabled (EØ) will not respond to any commands, except E1; however, characters are still echoed to the next device in the daisy chain.

Commands

```
3_ E0          ; Disable RS-232C on unit 3
VAR1=1         ; Set variable 1 to 1 on all other units
3_ E1          ; Enable RS-232C on unit 3
3_ VAR1=5      ; Set variable 1 to 5 on unit 3
```

Verify communication to all units by using the techniques described above.

Step 3

Now that communication is established, programming of the units can begin (alternatively, units can be programmed individually by connecting the master terminal to one unit at a time). To allow daisy-chaining between multiple controllers, the ERRLVL1 command must be used to prevent units from sending error messages and command prompts. In every daisy-chained unit, the ERRLVL1 command should be placed in the program that is defined as the STARTP program:

```

Program
DEF chain          ; Begin definition of program chain
ERRLVL1          ; Set error level to 1
GOTO main        ; Go to program main
END              ; End definition of program chain
STARTP chain     ; Designates program chain as the power-up program

```

To define program main for unit 0:

```

Program
0_DEF main        ; Begin definition of program main on unit 0
0_GO             ; Start motion
0_END            ; End definition of program main on unit 0

```

Step 4

After all programming is completed, program execution can be controlled by either a master terminal, or by a 6K Series controller used as a master.

Daisy-Chaining from a Computer or Terminal

Controlling the daisy-chain from a master computer or terminal follows the examples above:

```

Commands
0_RUN main        ; Run program main on unit 0
1_RUN main        ; Run program main on unit 1
2_GO1            ; Start motion on unit 2 axis 1
3_2A             ; Get A command response from unit 3 axis 2

```

Daisy-Chaining from a Master 6K Controller

Controlling the daisy-chain from a master 6K controller (the first unit on the daisy-chain) requires the programs stored in the master controller to control program and command execution on the slave controllers. The example below demonstrates the use of the WRITE command to send commands to other units on the daisy chain.

NOTE

The last unit on the daisy-chain must have RS-232C echo disabled (ECHOØ command).

Master controller's main program:

```

Program
DEF main          ; Program main
L                ; Indefinite loop
  WHILE (IN.1 = b0) ; Wait for input 1 to go active
  NWHILE
  GOL            ; Initiate linear interpolated move
  WHILE (IN.1 = b1) ; Wait for input 1 to go inactive
  NWHILE
  WRITE"2_D2000,4000" ; Send message "2_D2000,4000" down daisy chain
  WRITE"2_ACK"       ; Send message "2_ACK" down the daisy chain
LN                ; End of loop
END              ; End of program main

```

Controller unit 2 ack program:

```

Program
DEF ack          ; Program ack
GO11            ; Start motion on both axes
END            ; End of program ack

```

Daisy-Chaining and RP240s

RP240s cannot be placed in the controller daisy chain; RP240s can only be connected to the designated RP240 port on a controller. It is possible to use only one RP240 with a controller daisy-chain to input data for multiple units on the chain. The example below (for the controller master with an RP240 connected) reads data from the RP240 into variables 1 (*data1*) & 2 (*data2*), then sends the messages 3_Ddata1, data2<CR> and 3_GO<CR>.

Sample portion of code:

```
L ; Indefinite loop
VAR1=DREAD ; Read RP240 data into variable 1
VAR2=DREAD ; Read RP240 data into variable 2
EOT0,0,0,0 ; Turn off <CR>
WRITE"3_D" ; Send message "3_D" down the daisy chain
WRVAR1 ; Send variable 1 data down the daisy chain
WRITE", " ; Send message ", " down the daisy chain
EOT13,0,0,0 ; Turn on <CR>
WRVAR2 ; Send variable 2 data down the daisy chain
WRITE"3_GO" ; Send message "3_GO" down the daisy chain
LN ; End of loop
```

RS-485 Multi-Drop

Up to 99 6K Series products can be multi-dropped. Refer to your product's *Installation Guide* for multi-drop connections.

To establish device addresses, using the ADDR command:

The ADDR command allows you to establish up to 99 unique addresses. To use the ADDR command, you must address each unit individually before it is connected on the multi drop. For example, given that each product is shipped configured with address zero, you could set up a 4-unit multi-drop with the commands below, and then connect them in a multi drop:

1. Connect the unit that is to be unit 1 and transmit the Ø_ADDR1 command to it.
2. Connect the unit that is to be unit 2 and transmit the Ø_ADDR2 command to it.
3. Connect the unit that is to be unit 3 and transmit the Ø_ADDR3 command to it.
4. Connect the unit that is to be unit 4 and transmit the Ø_ADDR4 command to it.

If you need to replace a unit in the multi drop, send the Ø_ADDRi command to it, where "i" is the address you wish the new unit to have.

To send a 6K command from the master unit to a specific unit in the multi-drop, prefix the command with the unit address and an underscore (e.g., 3_OUTØ turns off output 1 on unit 3). The master unit (if it is not a 6K product) can receive data from a multi-drop unit.

The ECHO command was enhanced with options 2 and 3. The purpose is to accommodate an RS-485 multi-drop configuration in which a host computer communicates to the "master" 6K controller over RS-232 (COM1 port) and the master 6K controller communicates over RS-485 (COM2 port) to the rest of the units on the multi-drop. For this configuration, the echo setup should be configured by sending to the master the following commands executed in the order shown. In this example, it is assumed that the master's device address is set to 1. Hence, each command is prefixed with "1_" to address only the master unit.

```
1_PORT2 ..... Subsequent command affects COM2, the RS-485 port
1_ECHO2 ..... Echo characters back through the other port, COM1
1_PORT1 ..... Subsequent command affects COM1, the RS-232 port
1_ECHO3 ..... Echo characters back through both ports, COM1 and COM2
```

NOTE

Controllers on a multi-drop do not support XON/XOFF. To ensure that XON/XOFF is disabled for COM2, send the PORT2 command followed by the XONOFFØ command.

CHAPTER THREE

Basic Operation Setup

IN THIS CHAPTER

This chapter will enable you to understand and implement these basic operation features:

- Before You Begin (setup programs, Motion Planner, resetting, etc.)..... 44
- Memory Allocation 45
- Drive Setup..... 46
- Scaling..... 48
- Positioning Modes..... 52
- End-of-Travel Limits..... 57
- Homing..... 59
- Encoder-Based Stepper Operation (stepper axes only) 64
- Servo Setup (servo axes only)..... 67
- Target Zone Mode (servo axes only)..... 74
- Programmable Inputs and Outputs (incl. triggers and auxiliary outputs)..... 75
- Variable Arrays (*teaching variable data*)..... 94

Before You Begin



WARNING



The 6K Product is used to control your system's electrical and mechanical components. Therefore, you should test your system for safety under all potential conditions. Failure to do so can result in damage to equipment and/or serious injury to personnel.

Setup Parameters Discussed in this Chapter

Below is a list of the setup parameters discussed in this chapter. You can check the status of each parameter setting by entering the respective setup command without any command fields (e.g., typing LIMFNC <cr> displays the current function and state of each limit input). Some setup parameters are also reported with the TSTAT and TASF status commands (these and other status commands are described on page 226).

Setup Parameter	Command	See Pg	Setup Parameter	Command	See Pg
Memory (status with TDIR & TMEM)	MEMORY.....	12 & 45	Programmable Input Functions		75
Drive Setup.....		46	Define input functions	INFNC & LIMFNC	
Drive type (servo/stepper) selection.....	AXSDEF		Input active level	INLVL & LIMLVL	
Drive fault input - enable.....	DRFEN		Input debounce	INDEB	
Drive fault input - active level	DRFLVL		Trigger interrupt - special functions	TRGFN	
Drive resolution (stepper only)	DRES		Trigger interrupt - lockout time.....	TRGLOT	
Step pulse width (stepper only)	PULSE		Virtual Inputs.....	IN	
Drive disable on kill (servo only).....	KDRIVE		Programmable Output Functions.....		75
Drive stall detection	DSTALL		Define output functions.....	OUTFNC	
Scaling.....		48	Output active level	OUTLVL	
Enable scaling factor	SCALE		End-of-travel limits.....		57
Acceleration scaling factor.....	SCLA		Limit function assignments	LIMFNC & INFNC	
Distance scaling factor	SCLD		Hardware – enabled	LH	
Velocity scaling factor.....	SCLV		Hardware – deceleration.....	LHAD	
Positioning Mode.....		52	Hardware – s-curve decel.....	LHADA	
Continuous or preset	MC		Hardware – active level of input.....	LIMLVL	
Preset: absolute or incremental.....	MA		Software – enabled	LS	
Encoder Based Stepper Operation (stepper only)		64	Software – deceleration	LSAD	
Encoder resolution.....	ERES		Software – s-curve decel	LSADA	
Encoder capture/counting enable.....	ENCNT		Software – negative direction limit	LSNEG	
Encoder polarity.....	ENCPOL		Software – positive direction limit	LSPOS	
Encoder failure detection.....	EFAIL		Homing		59
Commanded direction polarity.....	CMDDIR		Limit function assignments	LIMFNC & INFNC	
Stall detection	ESTALL		Acceleration	HOMA	
Kill when stall is detected	ESK		S-curve acceleration	HOMAA	
Stall deadband.....	ESDB		Deceleration.....	HOMAD	
Servo Setup (servo axes only)		67	S-curve deceleration.....	HOMADA	
Tuning parameters	(see page Error!		Backup to home.....	HOMBAC	
Bookmark not defined.)			Final approach direction	HOMDF	
Feedback source selection.....	SFB, ANIFB		Stopping edge of switch.....	HOMEDG	
Feedback source resolution	ERES, ANIRNG		Home switch active level	LIMLVL	
Encoder failure detection.....	EFAIL		Velocity	HOMV	
Maximum position error	SMPER		Velocity of final approach.....	HOMVF	
Encoder feedback polarity	ENCPOL		Home to Z channel input.....	HOMZ	
Commanded direction polarity.....	CMDDIR		Variable Arrays (<i>teaching</i> variable data)		94
DAC output limit, maximum	DACLIM		Initialize numeric variable for data	VAR or VARI	
Servo control signal offset	SOFFS		Define data program and program size	DATSIZ	
Target Zone end-of-move settling criteria (servo axes).....		74	Set data pointer & establish increment	DATPTR	
Target zone mode enable	STRGTE		Reset data pointer to specific location..	DATRST	
Target distance zone	STRGTD				
Target velocity zone	STRGTV				
Target settling timeout period	STRGTT				

Using a Setup Program

The features described in this chapter are configured with certain 6K Series commands, commonly referred to as “setup commands.” We recommend placing these commands (except MEMORY) into a special “setup program” that is executed to prepare the 6K Series product for subsequent controller operations. Further details about setup programming are provided in the *Creating and Executing a Setup Program* section, page 13.

USE THE SETUP WIZARD IN MOTION PLANNER

The easiest way to create your setup program is to use the Setup Wizard in Motion Planner’s editor.

Resetting the Controller

There are two primary ways to reset the 6K controller (listed below).

- Cycle power.
- Execute the RESET command.

When the controller is reset, most of the previously entered command parameters are returned to their original factory default values. All programs and variables, as well as certain command values, are retained in non-volatile memory (see page 33). If a start-up program is assigned with the STARTP command, resetting the controller will automatically execute that program. If you are using an RP240, the RESET function is available if you use the default menu system (see page 114).

Memory Allocation

For details about memory allocation, see *Storing Programs* on page 11.

CAUTION

Issuing a new MEMORY command (e.g., MEMORY200000, 100000) will erase all existing programs and compiled contouring path segments residing in the 6K product’s memory. To determine the status of memory allocation, use the TMEM command.

Do not place the MEMORY command in the program assigned as the startup (STARTP) program. Doing so would erase all programs and segments upon cycling power or issuing the RESET command.

Drive Setup

Drive Type Selection

6K products can control any combination of stepper and servo axes. To tell the 6K which type of drive you are using and a particular axis, use the `AXSDEF` command. Stepper drives receive their positioning information via step and direction signals. Servo drives receive their positioning commands via a ± 10 volt signal.

NOTE: If a drive is attached at the time you issue the `AXSDEF` command, the drive must be disabled (`DRIVE0`).

✍ Make your drive type selection before configuring other parameters that are relative to the drive type.

The value of `AXSDEF` disables command fields that are not appropriate for that type of drive. For example, an axis configured as a stepper cannot be affected by a Servo Proportional Gain (`SGP`) command. The report back of non-applicable commands contains “-” in the field for that axis.

AXSDEF0 — Stepper Only Commands:		AXSDEF1 — Servo Only Commands:			
DRES	FMAXA	ANIFB	DSTALL	KDRIVE	PER
ENCCNT	FMAXV	SFB	SGP	SGI	SGV
ESDB	PULSE	SGVF	SGAF	SGILIM	SOFFS
ESK		SMPER	SGSET	SGENB	STRGTD
ESTALL		STRGTE	STRGTT	STRGTV	TFB
		TGAIN	TPER	TSGSET	TSTLT

Drive Fault Input

Enable the Drive Fault Input

Use the `DRFEN` command to enable or disable checking the state of the drive fault input for each axis. The default condition is that the drive fault input is not checked (`DRFEN0`); therefore, a drive fault would not be detectable. Even with `DRFEN` enabled (`DRFEN1`), the controller will not respond to a drive fault condition until the respective axis is enabled with the `DRIVE1` command. The drive fault input must be enabled (`DRFEN1`) before you can use these functions (remember that the default power-up state is disabled):

- `AS`, `TAS`, and `TASF` (axis status) bit 14 reports if a drive fault occurred.
- `ERROR` bit 4 enables checking for the occurrence of a drive fault, and when it does, to branch to the `ERRORP` program.
- `ER`, `TER`, and `TERF` (error status) bit 4 reports if a drive fault occurred (if `ERROR` bit 4 is enabled).
- An output assigned the “Fault Indicator” function (`OUTFNi-F`) will turn on when a drive fault occurs or a user fault input (`INFNi-F` or `LIMFNi-F`) is activated.

Regardless of the state of the `DRFEN` command, the extended axis status bit 4 (reported with `ASX`, `TASX`, and `TASXF`) will accurately report the hardware state of the drive fault input.

Set the Drive Fault Input Active Level

The drive fault level (`DRFLVL`) should be set to “active high” or “active low” for each axis. The default setting is “active high” (`DRFLVL1`). The drive fault input schematic is shown in your 6K Series product installation guide. Use the table below as a guide.

Compumotor Product	Drive Fault Level
GEMINI, APEX, Dynaserv, LN, OEM Series, S, TQ, ZETA	Active High (<code>DRFLVL1</code>)
SV, BLH, L, LE, PDS, PK130	Active Low (<code>DRFLVL0</code>)

NOTE: If you are using a drive that does not have a drive fault output, set the drive fault level to active low (`DRFLVL0`).

NOTE

Once the drive fault level has been configured, you must enable the drive fault input with the `DRFEN1` command before the input is usable.

Checking Drive Fault Input Status (see table below): Axis status bit 14 (TASF, TAS or AS commands) indicates the drive fault input status, but only while the drive is enabled (DRIVE1) and the drive fault input is enabled (DRFEN1). If you need to monitor the drive fault input status regardless of the state of DRIVE and DRFEN, use the extended axis status bit 4 (TASXF, TASX, or ASX commands).

Drive Fault Level (DRFLVL)	Status of device driving the Fault input	Axis Status of Bit 14 (or Extended Axis Status Bit 4)
DRFLVL1 (active high)	OFF or not connected (not sinking current) ON (sinking current)	1 (drive fault has occurred) Ø
DRFLVLØ (active low)	OFF or not connected (not sinking current) ON (sinking current)	Ø 1 (drive fault has occurred)

When a drive fault occurs, motion will be stopped on all axes (stopped at the LHAD & LHADA deceleration values) and program execution will be terminated.

Drive Stall Detection (stepper axes only)

The DSTALL command determines if the Stall Input on pin 4 of the DRIVE connector will be checked as Drive Stall indicator.

The state of the Stall Input can be monitored at all times with Extended Axis Status bit 7 (reported with TASX, TASF, and the ASX assignment/comparison operand); if left unconnected, the input is low, and status bit 7 will be set (reports a “1”). If this input is enabled as a drive stall indicator with the DSTALL1 command, a low input will be interpreted as a Drive Stall.

When a Drive Stall is detected, the 6K responds as follows: (this response is the same as that for Encoder Stall Detection, which is enabled with the ESTALL command)

- The stall is reported with Axis Status bit 12 (reported with TAS, TASF, and AS).
- If ERROR error-checking bit 1 is enabled (ERROR.1-1):
 - The stall is reported with Error Status bit 1 (reported with TER, TERF, and ER).
 - The 6K branches to the assigned ERRORP program.
- If the Kill-on-Stall feature is enabled (ESK1), the 6K immediately stops pulses from being sent to the affected axis.

Drive Resolution (stepper axes only)


The drive resolution controls the number of steps the 6K controller considers as a full revolution for the motor drive. The controller's resolution is set with the DRES command (default is 4,000 steps/rev). Refer to the user documentation that accompanied your drive if you need to change its resolution.

IMPORTANT!

If the controller's resolution (set with the DRES command) does not match the drive's resolution, the motor will not move according to the programmed distance and velocity.

Step Pulse (stepper axes only)

The step output pulse width can be varied using the PULSE command. The pulse width can be 0.3 µs to 8 µs (default is 0.3 µs). The pulse width is the amount of time the step output signal is active (see illustration below). The step output pulse width should be configured to meet the minimum step input pulse width requirement of the motor drive you are using.



The pulse width does not vary as the motion profile is executed. The same pulse width is used during acceleration, constant velocity, and deceleration.

When the pulse width is changed from the default value of 0.3 μs , the maximum velocity range is reduced. The amount of reduction is directly proportional to the change in pulse width (see table below).

Pulse Width (PULSE) Setting	Actual Pulse Width	Maximum Velocity
DEFAULT \rightarrow 0.3 μs	0.244 μs	2.048 MHz
0.5 μs	0.484 μs	1.024 MHz
1.0 μs	0.976 μs	512 KHz
2.0 μs	1.953 μs	256 KHz
4.0 μs	3.906 μs	128 KHz
8.0 μs	7.812 μs	64 KHz

Disable Drive On Kill (servo axes only)

Normally, when you issue a Kill command (K , $!K$, or $\langle\text{ctrl}\rangle K$) or activate an input configured as a kill input (see INFNCi-C or LIMFNCi-C command), motion is stopped at the hard limit (LHAD/LHADA) deceleration setting and the drives are left in the enabled state (DRIVE1).

However, your application can require you to *disable (shut down or de-energize)* the drives in a Kill situation to, for example, prevent damage to the motors or other system mechanical components. If so, set the controller to the *Disable Drive on Kill* mode with the KDRIVE1 command. In this mode, a kill command or kill input will shut down the drives immediately, letting the motors *free wheel* (without control from the drives) to a stop.

Scaling

Units of Measure without Scaling

Scaling is disabled ($\text{SCALE}\emptyset$) as the factory default condition:

- Stepper axes: When scaling is disabled, all distance values entered are in commanded counts (sometimes referred to as *motor steps*), and all acceleration, deceleration and velocity values entered are internally multiplied by the DRES command value.

Motion Attribute	Units of Measure (per feedback source)	
	Encoder	ANI
Accel/Decel	Revs/sec/sec *	volts/sec/sec
Velocity	Revs/sec *	volts/sec
Distance	Counts (<i>steps</i>) **	Counts (<i>steps</i>) **

* All accel/decels & velocity values are multiplied by the ERES value.

** Distance is measured in the counts received from the feedback device.

Contouring & Linear Interpolated Motion: Path acceleration, velocity, and distance are based on the resolution (DRES for steppers, ERES for servos) of axis 1. If multi-tasking is used, path motion units are based on the resolution of the first (lowest number) axis associated with the task (TSKAX).

What is Scaling?

Scaling allows you to program acceleration, deceleration, velocity, and position values in units of measure that are appropriate for your application. The SCALE command is used to enable or disable scaling (SCALE1 to enable, SCALE0 to disable). The motion type(s) you are using in your application determines which scale factor commands you need to configure:

Type of Motion	Accel/Decel Scaling	Velocity Scaling	Distance Scaling
Standard Point-to-Point Motion	SCLA	SCLV	SCLD
Following	SCLA	SCLV	SCLD for follower distances SCLMAS for master distances
Contouring, Linear Interpolation	SCLD (used for all path motion scaling)		

When Should I Define Scaling Factors?

NOTE
All scaling parameters are saved in battery-backed RAM

Scaling calculations are performed when a program is defined or downloaded. Consequently, you must enable scaling (SCALE1) and define the scaling factors (SCLD, SCLA, SCLV, SCLMAS) *prior* to defining (DEF), uploading (TPROG), or running (RUN) the program.

RECOMMENDATION: Place the scaling commands at the beginning of your program file, *before* the location of any defined programs. This ensures that the motion parameters in subsequent programs in your program file are scaled correctly. When you use Motion Planner's Setup Generator wizard, the scaling commands are automatically placed in the appropriate location in your program file.

ALTERNATIVE: Scaling factors could be defined via a terminal emulator *just before* defining or downloading a program. Because scaling command values are saved in battery-backed RAM (remembered after you cycle power or issue a RESET command), all subsequent program definitions and downloads will be scaled correctly.

NOTES

- Scaling commands are not allowed in a program. If there are scaling commands in a program, the controller will report an error message ("COMMAND NOT ALLOWED IN PROGRAM") when the program is downloaded.
- If you intend to upload a program with scaled motion parameters, be sure to use Motion Planner. Motion Planner automatically uploads the scaling parameters and places them at the beginning of the program file containing the uploaded program from the controller. This ensures correct scaling when the program file is later downloaded.

Servo Axes

Scaling can be used with encoder or analog input feedback sources. When the scaling commands (SCLA, SCLD, etc.) are executed, they are specific only to the current feedback source selected with the last SFB command.

If your application requires switching between feedback sources for the same axis, then for each feedback source, you must select the feedback source with the appropriate SFB command and issue the scaling factors specific to operating with that feedback source.

For example, if you have two axes and will be switching between encoder and ANI feedback, you should include code similar to the following in your setup program:

```
SFB1,1      ; Select encoder feedback (subsequent scaling
             ; parameters are specific to encoder feedback)
SCLA4000,4000 ; Program accel/decel in revs/sec/sec
SCLV4000,4000 ; Program velocity in revs/sec
SCLD4000,4000 ; Program distances in revs
SFB2,2      ; Select ANI feedback (subsequent scaling
             ; parameters are specific to ANI feedback)
SCLA205,205  ; Program accel/decel in volts/sec/sec
SCLV205,205  ; Program velocity in volts/sec
SCLD205,205  ; Program distances in volts
```

Acceleration & Deceleration Scaling (SCLA)

Stepper Axes: If scaling is enabled (SCALE1), all accel/decel values entered are internally multiplied by the acceleration scaling factor to convert user units/sec/sec to commanded counts/sec/sec. The scaled values are always in reference in commanded counts, regardless of the existence of an encoder.

Servo Axes: If scaling is enabled (SCALE1), all accel/decel values entered are internally multiplied by the acceleration scaling factor to convert user units/sec/sec to encoder or analog input counts/sec/sec.

All accel/decel commands for point-to-point motion (e.g., A, AA, AD, HOMA, HOMAD, JOGA, etc.) are multiplied by the SCLA command value. **NOTE:** All accel/decel commands for linear interpolated and contouring motion (e.g., PA, PAD, etc.) are multiplied by the SCLD command value.

As the accel/decel scaling factor (SCLA) changes, the resolution of the accel and decel values and the number of positions to the right of the decimal point also change (see table at right). An accel/decel value with greater resolution than allowed will be truncated (e.g., if scaling is set to SCLA10, the A9.9999 command would be truncated to A9.9).

SCLA value (steps/unit ²)	Decimal Places
1 - 9	0
10 - 99	1
100 - 999	2
1000 - 9999	3
10000 - 99999	4
100000 - 999999	5

Use the following equations to determine the range of acceleration and deceleration values for your product.

If the analog input voltage range is changed, the equations will change. See ANIRNG command for details.

Axis Type	Minimum Accel or Decel (resolution)	Maximum Accel or Decel
Stepper	$\frac{0.001 * DRES}{SCLA}$	$\frac{999.9999 * DRES}{SCLA}$
Servo	Encoder feedback: $\frac{0.001 * ERES}{SCLA}$	Encoder feedback: $\frac{999.9999 * ERES}{SCLA}$
	ANI feedback: $\frac{0.205}{SCLA}$	ANI feedback: $\frac{204799.9795}{SCLA}$

Velocity Scaling (SCLV)

Stepper Axes: If scaling is enabled (SCALE1), all velocity values entered are internally multiplied by the velocity scaling factor to convert user units/sec to commanded counts/sec. The scaled values are always in reference to commanded counts (sometimes referred to as “motor steps”).

Servo Axes: If scaling is enabled (SCALE1), all velocity values entered are internally multiplied by the velocity scaling factor to convert user units/sec to encoder or analog input counts/sec.

All velocity commands for point-to-point motion (e.g., V, HOMV, HOMVF, JOGVH, JOGVL, etc.) are multiplied by the SCLV command value. **NOTE:** The velocity commands for linear interpolated and contouring motion (PV and PVF) are multiplied by the SCLD command value.

As the velocity scaling factor (SCLV) changes, the velocity command's range and its decimal places also change (see table below). A velocity value with greater resolution than allowed will be truncated. For example, if scaling is set to SCLV10, the V9.9999 command would be truncated to V9.9.

SCLV Value (counts/unit)	Velocity Resolution (units/sec)	Decimal Places
1 - 9	1	0
10 - 99	0.1	1
100 - 999	0.01	2
1000 - 9999	0.001	3
10000 - 99999	0.0001	4
100000 - 999999	0.00001	5

Use the following equations to determine the maximum velocity range for your product type.

Maximum Velocity for Stepper Axes		Maximum Velocity for Servo Axes (determined by feedback source selected for axis 1)	
$\frac{6,500,000}{\text{SCLV}}$	$n = \text{maximum velocity as set by the PULSE command.}$	Encoder Feedback: $\frac{6,500,000}{\text{SCLV}}$	Equation changes if ANI voltage range is changed (see ANIRNG command).
		ANI Feedback: $\frac{1000 * 205}{\text{SCLV}}$	

Distance Scaling (SCLD and SCLMAS)

Stepper Axes: If scaling is enabled (SCALE1), all distance values entered are internally multiplied by the distance scaling factor to convert user units to commanded counts (“motor steps”).

Servo Axes: If scaling is enabled (SCALE1), all distance values entered are internally multiplied by the distance scaling factor to convert user units to encoder or analog input counts.

All distance commands for point-to-point motion (e.g., D, PSET, REG, SMPER) are multiplied by the SCLD command value. **NOTE:** Distance, accel/decel, and velocity commands for contouring and linear interpolated motion (e.g., PARCM, PARCOM, PARCOP, PARCP, PLC, PLIN, PRTOL, PWC, PV, PVF, PA, PAD, PAA, PADA) are also multiplied by the SCLD command value.

Scaling for Following Motion: The SCLD command defines the follower's distance scale factor, and the SCLMAS command defines the master's distance scale factor. The Following-related commands that are affected by SCLD and SCLMAS are listed in the table below.

Commands Affected by Master Scaling (SCLMAS)	Commands Affected by Follower Scaling (SCLD)
FMCLEN: <i>Master Cycle Length</i>	FOLRN: <i>Follower-to-Master Ratio (Numerator)</i>
FMCP: <i>Master Cycle Position Offset</i>	FSHFD: <i>Preset Phase Shift</i>
FOLMD: <i>Master Distance</i>	GOWHEN: <i>Conditional GO (left-hand variable ≠ PMAS)</i>
FOLRD: <i>Follower-to-Master Ratio (Denominator)</i>	TPSHF & [PSHF]: <i>Net Position Shift of Follower</i>
GOWHEN: <i>Conditional GO (left-hand variable is PMAS)</i>	TPSLV & [PSLV]: <i>Position of Follower Axis</i>
TPMAS & [PMAS]: <i>Position of Master Axis</i>	
TVMAS & [VMAS]: <i>Velocity of Master Axis</i>	

Scaling for Contouring Motion: All distance, accel/decel, and velocity is scaled by the SCLD value.

Fractional Step Truncation
If you are operating in the incremental mode (MAØ), or specifying master distance values with FOLMD, when the distance scaling factor (SCLD or SCLMAS) and the distance value are multiplied, a fraction of one step may be left over. This fraction is truncated when the distance value is used in the move algorithm. This truncation error can accumulate over a period of time, when performing incremental moves continuously in the same direction. To eliminate this truncation problem, set SCLD or SCLMAS to 1, or a multiple of 10.

As the SCLD or SCLMAS scaling factor changes, the distance command's range and its decimal places also change (see table below). A distance value with greater resolution than allowed will be truncated. For example, if scaling is set to SCLD400, the D105.2776 command would be truncated to D105.277.

SCLD or SCLMAS Value (counts/unit)	Distance Resolution (units)	Distance Range (units)	Decimal Places
1 - 9	1.0	0 - ±999999999	0
10 - 99	0.10	0.0 - ±99999999.9	1
100 - 999	0.010	0.00 - ±9999999.99	2
1000 - 9999	0.0010	0.000 - ±999999.999	3
10000 - 99999	0.00010	0.0000 - ±99999.9999	4
100000 - 999999	0.00001	0.00000 - ±9999.99999	5

Scaling Example — Stepper Axes

Axis 1 and axis 2 control 25,000 step/rev motor/drives attached to 5-pitch leadscrews. The user wants to program motion parameters in inches; therefore the scale factor calculation is: 25,000 steps/rev x 5 revs/inch = 125,000 steps/inch. For instance, with a scale factor of 125,000, the operator could enter a move distance value of 2.000 and the controller would send out 250,000 pulses, corresponding to two inches of travel.

```
SCALE1           ; Enable scaling
DRES25000,25000  ; Set drive resolution to 25,000 steps/rev on both axes
SCLD125000,125000 ; Allow entering distance in inches (both axes)
SCLV125000,125000 ; Allow entering velocity in inches/sec (both axes)
SCLA125000,125000 ; Allow entering accel/decel in inches/sec/sec
```

Scaling Example — Servo Axes

Axis 1 controls a 4,000 count/rev servo motor/drive system (using a 1000-line encoder) attached to a 5-pitch leadscrew. The user wants to position in inches; therefore, the scale factor calculation is 4,000 counts/rev x 5 revs/inch = 20,000 counts/inch. Half way through the motion process, axis 1 must switch to ANI feedback for the purpose of positioning to a voltage (scale factor is 205 counts/volt).

Axis 2 controls a 4,000 count/rev servo motor/drive system (using a 1000-line encoder) attached to a 10-pitch leadscrew. The user wants to position in inches (scale factor calculation: 4,000 counts/rev x 10 revs/inch = 40,000 counts/inch).

```
SFB1,1           ; Select encoder feedback for both axes
ERES4000         ; Set encoder resolution to 4000 steps/rev (post quadrature)
SCALE1           ; Enable scaling
SCLD20000,40000  ; Allow entering distance values in inches
SCLV20000,40000  ; Allow entering velocity values in inches/sec
SCLA20000,40000  ; Allow entering accel/decel values in inches/sec/sec
SFB2             ; Select ANI feedback for axis 1
SCALE1           ; Enable scaling
SCLD205          ; Allow entering distance values in volts
SCLV205          ; Allow entering velocity values in volts/sec
SCLA205          ; Allow entering accel/decel values in volts/sec/sec
SFB1,1           ; Select encoder feedback for both axes (prepare for motion)
```

Scaling Example — Following

Typically, the master and follower scale factors are programmed so that master and follower units are the same, but this is not required. Consider the scenario below as an example.

The master is a 1000-line encoder (4000 counts/rev post-quadrature) mounted to a 50 teeth/rev pulley attached to a 10 teeth/inch conveyor belt, resulting in 80 counts/tooth (4000 counts/50 teeth = 80 counts/tooth). To program in inches, you would set up the master scaling factor with the SCLMAS800 command (80 counts/tooth * 10 teeth/inch = 800 counts/inch).

The follower axis is a servo motor with position feedback from a 1000-line encoder (4000 counts/rev). The motor is mounted to a 4-pitch (4 revs/inch) leadscrew. Thus, to program in inches, you would set up the follower scaling factor with the SCLD16000 command (4000 counts/rev * 4 revs/inch = 16000 counts/inch).

```
SCALE1           ; Enable scaling
SCLMAS800        ; Master scaling:
                  ; (80 counts/tooth * 10 teeth/inch = 800 counts/inch)
SCLD16000        ; Follower scaling:
                  ; (4000 counts/rev * 4 revs/inch = 16000 counts/inch)
```

Scaling Example — Contouring and Linear Interpolation

This simple example uses 2 servo axes (axes 1 and 2) for contouring. Both axes use encoder feedback with a resolution (ERES) of 4000 counts/rev, axis 1 uses a 10-pitch (10 revs per inch) leadscrew and axis 2 uses a 5-pitch (5 revs per inch) lead screw, and you want to program in inches. For this application you would use the SCLD40000,20000 command to establish path motion units in inches: distance is inches, acceleration is inches/sec/sec, and velocity is inches/sec. **NOTE** that all path motion attributes are scaled by the SCLD value.

```
SCALE1           ; Enable scaling
SCLD40000,20000  ; Set scaling to program in inches:
                  ; Axis 1: 4000 counts/rev * 10 revs/inch = 40000 counts/inch
                  ; Axis 2: 4000 counts/rev * 5 revs/inch = 20000 counts/inch
PV5              ; Set path velocity to 5 inches/sec
PA50             ; Set path acceleration to 50 inches/sec/sec
PAD100           ; Set path deceleration to 100 inches/sec/sec
DEF prog1        ; Begin definition of path named prog1
PAXES1,2         ; Set axes 1 and 2 as the X and Y contouring axes
PABO             ; Set to incremental coordinates
PLIN1,1         ; Specify X-Y endpoint position to create a 45 degree
                  ; angle line segment
END              ; End definition of path prog1
PCOMP prog1      ; Compile path prog1
PRUN prog1       ; Execute path prog1
```


Positioning Modes

But first, a word about basic motion...

Accel, Decel,
Velocity, Distance

The basic motion profile comprises acceleration, deceleration, velocity, and distance commands (see table below). Motion is generally initiated with the GO command.

Parameter	Units (Unscaled), Stepper	Units (Unscaled), Servo	Unit Scaling Command *
Acceleration	revs/sec ²	encoder/resolver: revs/sec ² ANI: volts/sec ²	SCLA (or SCLD **)
Deceleration	revs/sec ²	encoder/resolver: revs/sec ² ANI: volts/sec ²	SCLA (or SCLD **)
Velocity	revs/sec	encoder/resolver: revs/sec ANI: volts/sec	SCLV (or SCLD **)
Distance	steps	counts	SCLD ***


* Scaling must first be enabled with the SCALE1 command. For details on scaling, refer to page 48.

** All Contouring and linear interpolated motion is scaled with SCLD (distance, accel/decel, and velocity).

*** An axis assigned as a master (for Following) is scaled by the SCLMAS command.

Example Program

Resulting Motion Profile:




The program below controls two axes of motion. Axis 1 produces a preset (incremental) 100,000-count move in a nominally trapezoidal profile. Axis 2 produces a preset 80,000-count move in a nominally trapezoidal profile.


```

DEL BASIC          ; Delete program called BASIC
DEF BASIC          ; Begin definition of program called BASIC
MC00              ; Use the preset positioning mode for axes 1 & 2
MA00              ; Use the incremental (preset) positioning mode
A20,10            ; Accelerate axis 1 at 20 revs/sec/sec, and axis 2 at 10
AD5,5             ; Decelerate axis 1 and axis 2 at 5 revs/sec/sec
V8,5              ; Set axis 1 velocity to 8 revs/sec, and axis 2 to 5
D100000,80000    ; Set distance to 100,000 counts
GO11              ; Execute the motion on both axes
END               ; End definition of BASIC
    
```

Axis 1 profile:




Axis 2 profile:



Direction of Motion
for Rotary Motors

Positive distance values (e.g., D20000) represent clockwise motion, negative values (e.g., D-20000) represent counter-clockwise motion. This assumes you connected the drive and motor (and feedback device for servo drives) according to the *Hardware Installation Guide* instructions.



Preset and Continuous Modes

The 6K controller can be programmed to position in either the preset (incremental or absolute) mode or the continuous mode. You should select the mode that will be most convenient for your application. For example, a repetitive cut-to-length application requires incremental positioning. X-Y positioning, on the other hand, is better served in the absolute mode. Continuous mode is useful for applications that require constant movement of the load based on internal conditions or inputs, not distance.

Positioning modes require acceleration, deceleration, velocity, and distance commands (*continuous mode does not require distance*). The table below identifies these commands and their units of measure, and which scaling command affects them.

Parameter	Units (Unscaled), Stepper	Units (Unscaled), Servo	Unit Scaling Command *
Acceleration	revs/sec ²	encoder/resolver: revs/sec ² ANI: volts/sec ²	SCLA (or SCLD **)
Deceleration	revs/sec ²	encoder/resolver: revs/sec ² ANI: volts/sec ²	SCLA (or SCLD **)
Velocity	revs/sec	encoder/resolver: revs/sec ANI: volts/sec	SCLV (or SCLD **)
Distance	steps	counts	SCLD ***

* Scaling must first be enabled with the `SCALE1` command. For details on scaling, see page 48.

** All Contouring and linear interpolated motion is scaled with `SCLD` (distance, accel/decel, and velocity).

*** An axis assigned as a master (for Following) is scaled by the `SCLMAS` command.

On-The-Fly (Pre-emptive Go) Motion Profiling

While motion is in progress (regardless of the positioning mode), you can change these motion parameters to affect a new profile:

- Acceleration (A) — s-curve acceleration not allowed during on-the-fly changes
- Deceleration (AD) — s-curve deceleration not allowed during on-the-fly changes
- Velocity (V)
- Distance (D)
- Preset or Continuous Positioning Mode Selection (MC)
- Incremental or Absolute Positioning Mode Selection (MA)
- Following Ratio Numerator and Denominator (FOLRN and FOLRD, respectively)

The motion parameters can be changed by sending the respective command (e.g., A, V, D, MC, etc.) followed by the `GO` command. If the continuous command execution mode is enabled (`COMEXC1`), you can execute buffered commands; otherwise, you must prefix each command with an immediate command identifier (e.g., !A, !V, !D, !MC, etc., followed by !GO). The new `GO` command pre-empts the motion profile in progress with a new profile based on the new motion parameter(s).

For more information, see *On-The-Fly Motion Profiling* on page 151.

Preset Positioning Mode

A *preset* move is a point-to-point move of a specified distance. You can select preset moves by putting the 6K controller into preset mode (canceling continuous mode) using the MCØ command. Preset moves allow you to position the motor/load in relation to the previous stopped position (*incremental mode*—enabled with the MAØ command) or in relation to a defined zero reference position (*absolute mode*—enabled with the MA1 command).

Incremental Mode Moves

The incremental mode is the controller's default power-up mode. When using the Incremental Mode (MAØ), a preset move moves the motor/load the specified distance from its starting position. For example, if you start at position *N*, executing the D6ØØØ command in the MAØ mode will move the motor/load 6,000 units from the *N* position. Executing the D6ØØØ command again will move the motor/load an additional 6,000 units, ending the move 12,000 units from position *N*.

You can specify the direction of the move by using the optional sign + or - (e.g., D+6ØØØ or D-6ØØØ). Whenever you do not specify the direction (e.g., D6ØØØ), the unit defaults to the positive (+) direction.

Example

```
SCALE0 ; Disable scaling
MA0 ; Set axis 1 to Incremental Position Mode
A2 ; Set axis 1 acceleration to 2 units/sec/sec
V5 ; Set axis 1 velocity to 5 units/sec
D4000 ; Set axis 1 distance to 4,000 positive units
GO1 ; Initiate motion on axis 1 (move 4,000 positive units)
GO1 ; Repeat the move
D-8000 ; Set distance to 8,000 negative units
; (return to original position)
GO1 ; Initiate motion on axis 1 (move 8,000 units in the negative
; direction and end at its original starting position)
```

Absolute Mode Moves

A preset move in the Absolute Mode (MA1) moves the motor/load the distance that you specify from the *absolute zero position*.

Establishing a Zero Position

One way to establish the zero position is to issue the PSET command when the load is at the location you would like to reference as absolute position zero (e.g., PSETØ, Ø defines the current position as absolute position zero for axes 1 and 2). Stepper axes with encoder feedback can use the PESET command set the absolute encoder position in ENCCNT1 mode.

The zero position is also established when the Go Home (HOM) command is issued, the absolute position register is automatically set to zero after reaching the home position, thus designating the home position as position zero.

The direction of an absolute preset move depends upon the motor's/load's position at the beginning of the move and the position you command it to move to. For example, if the motor/load is at absolute position +12,500, and you instruct it to move to position +5,000 (e.g., with the D5ØØØ command), it will move in the negative direction a distance of 7,500 steps to reach the absolute position of +5,000.

The 6K controller retains the absolute position, even while the unit is in the incremental mode. To ascertain the absolute position, use the TPC and PC commands.

Example

```
SCALE0 ; Disable scaling
MA1 ; Set the controller to the absolute positioning mode
PSET0 ; Set axis 1 current absolute position to zero
A5 ; Set axis 1 acceleration to 5 units/sec/sec
V3 ; Set axis 1 velocity to 3 units/sec
D4000 ; Set axis 1 move to absolute position 4,000 units
GO1 ; Initiate axis 1 move (move to absolute position +4,000)
D8000 ; Set axis 1 move to absolute position +8,000
GO1 ; Initiate axis 1 move (starting from position +4,000, move 4,000
; additional units in the positive direction to position +8,000)
D0 ; Set axis 1 move to absolute position zero
GO1 ; Initiate axis 1 move (starting at absolute position +8,000,
; move 8,000 units in the negative direction to position zero)
```

Continuous Positioning Mode

The Continuous Mode (MC1) is useful in these situations:

- Applications that require constant movement of the load
- Synchronize the motor to external events such as trigger input signals
- Changing the motion profile after a specified distance or after a specified time period (T command) has elapsed

You can manipulate the motor movement with either buffered or immediate commands. After you issue the GO command, buffered commands are not executed unless the continuous command execution mode (COMEXC1 command) is enabled. Once COMEXC1 is enabled, buffered commands are executed in the order in which they were programmed. More information on the COMEXC mode is provided on page 15.

The command can be specified as *immediate* by placing an exclamation mark (!) in front of the command. When a command is specified as immediate, it is placed at the front of the command queue and is executed immediately.

```
Example A  COMEXC1      ; Enable continuous command processing mode
           COMEXS1     ; Allow command execution to continue after stop
           MC1         ; Sets axis 1 mode to continuous
           A10         ; Sets axis 1 acceleration to 10
           V1          ; Sets axis 1 velocity to 1
           GO1         ; Initiates axis 1 move (Go)
           WAIT(LEVEL=1) ; Wait to reach continuous velocity
           T5          ; Time delay of 5 seconds
           S1          ; Initiate stop of axis 1 move
           WAIT(MOV=b0) ; Wait for motion to completely stop on axis 1
           COMEXC0     ; Disable continuous command processing mode
           ; When the move is executed, the load will accelerate to 1 unit/sec,
           ; continue at that rate for 5 seconds, and then decelerate to a stop.

Example B  DEF progr1   ; Begin definition of program progr1
           COMEXC1     ; Enable continuous command processing mode
           COMEXS1     ; Allow command execution to continue after stop
           MC1         ; Set axis 1 to continuous positioning mode
           A10         ; Set axis 1 acceleration to 10
           V1          ; Set axis 1 velocity to 1
           GO1         ; Initiate axis 1 move (Go)
           WAIT(LEVEL=1) ; Wait for motor to reach continuous velocity
           T3          ; Time delay of 3 seconds
           A50         ; Set axis 1 acceleration to 50
           V10         ; Set axis 1 velocity to 10
           GO1         ; Initiate acceleration and velocity changes on axis 1
           T5          ; Time delay of 5 seconds
           S1          ; Initiate stop of axis 1 move
           WAIT(MOV=b0) ; Wait for motion to completely stop on axis 1
           COMEXC0     ; Disable continuous command processing mode
           END         ; End definition of program progr1
```

While in continuous mode, motion can be stopped if:

- You issue an immediate Stop (!S) or Kill (!K or ctrl/K) command.
- The load trips an end-of-travel limit switch or encounters a software end-of-travel limit.
- The load trips a registration input (a trigger input configured with the INFNCi-H command to function as a registration input).
- The load trips an input configured as a kill input (INFNCi-C or LIMFNCi-C) or a stop input (INFNCi-D or LIMFNCi-D).

NOTE

While the axis is moving, you cannot change the parameters of some commands (such as DRIVE and HOM). This rule applies during the COMEXC1 mode and even if you prefix the command with an immediate command identifier (!). For more information, see *Restricted Commands During Motion* on page 17.

End-of-Travel Limits

Related Commands

LHHard limit enable
LHADHard limit decel
LHADAHard limit decel (s)
LIMLVLLimit switch polarity
LSSoft limit enable
LSADSoft limit decel
LSADASoft limit decel (s)
LSNEGSoft limit (negative)
LSPOSSoft limit (positive)
TLIMHard limit status
TASFBits 15-18 indicate if
hard or soft limit
was encountered
TERFBit 2: hard limit hit
Bit 3: soft limit hit
(must enable ERROR
checking bits 2 & 3)
ERRORBit 2 or 3 is enabled,
the 6K will branch to
the ERRORP program
if a hard or soft limit
is encountered

The 6K controller can respond to both hardware and software end-of-travel limits. The purpose of hardware and software end-of-travel limits is to prevent the motor's load from traveling past defined limits. Software and hardware limits are typically positioned in such a way that when the software limit is reached, the motor/load will start to decelerate toward the hardware limit, thus allowing for a much smoother stop at the hardware limit. Software limits can be used regardless of incremental or absolute positioning. When a hardware or software end-of-travel limit is reached, the 6K controller stops that axis using the respective hardware deceleration rate (set with LHAD & LHADA) or software limit deceleration rate (set with LSAD & LSADA).

How to set up hardware end-of-travel limits (for each axis):

1. Connect the end-of-travel limit inputs according to the instructions in your 6K product's *Installation Guide*. To help assure safety, connect normally-closed switches and leave the active level at default "active low" setting (set with the LIMLVL command).
2. (Optional) Define the inputs to be used as end-of-travel inputs for the respective axes.
NOTE: When the 6K product is shipped from the factory, the inputs on the "LIMITS/HOME" connectors are factory-configured with the LIMFNC command to function as end-of-travel and home limits for their respective axes. If you intend to use digital inputs on an external I/O brick as limit inputs:
 - a. Assign the limit function to the external input with the INFNC command. For example, 1 INFNC9-1R assigns the "axis 1 positive end-of-travel limit" function to the 1st input on SIM2 (I/O point 9) of I/O brick 1.
 - b. Reassign the respective "LIMITS/HOME" input to a non-limit function with the LIMFNC command. For example, LIMFNC1-A assigns the "general-purpose input" function to limit input 1 (normally assigned the "axis 1 positive end-of-travel limit" function).
3. Set the hard limit deceleration rate (LHAD & LHADA) to be used when the limit switch is activated. The LHADA command allows you to define an s-curve deceleration.
Stepper Axes: If your system is moving heavy loads or operating at high velocities, you can need to decrease the LHAD command value (deceleration rate) to prevent the motor from stalling (GEMINI and ZETA drives can compensate without reducing decel).

NOTES ON HARDWARE LIMITS

- 6K controllers are shipped from the factory with the hardware end-of-travel limits enabled, but not connected. Therefore, **motion will not be allowed until you do one of the following:**
 - Install limit switches or jumper the end-of-travel limit terminals to the GND terminal (see your product's *Installation Guide* for wiring instructions).
 - Disable the limits with the LH command (recommended only if the load is not coupled).
 - Reverse the active level of the limits by executing the LIMLVLO command for the respective axis.
- If you reverse the commanded direction polarity (CMDDIR1), you should swap the hardware end-of-travel switch connections to maintain a positive correlation with the commanded direction.

How to set up software end-of-travel limits (for each axis):

1. Use the LS command to enable the software end-of-travel limits for the appropriate axes (for example, LS1111 enables software limits for axes 1-4).
2. Define the positive-direction limit with the LSPOS command, and define the negative-direction limit with the LSNEG command. If you have scaling enabled (SCALE1), these limit values are scaled by the SCLD command. Both software limits can be defined with positive values (e.g., axis 2 in the example below)

NOTES ON SOFTWARE LIMITS

- The software limits (LSPOS & LSNEG) are referenced from a position of absolute zero. or negative values. *Care must be taken when performing incremental moves because the software limits are always defined in absolute terms.* They must be large enough to accommodate the moves, or a new zero reference position must be defined (using the PSET command) before each move.
- To ensure proper motion when using soft end-of-travel limits, be sure to set the LSPOS value to an absolute value greater than the LSNEG value.

Programming Example

In this sample of code (not a complete program), the hardware and software limits are enabled on axes 1 and 2, and disabled on axes 3 and 4. The distance scaling command (SCLD) is used to define software limit locations in revolutions from the absolute zero position (assumes a 4000 step/rev resolution). Deceleration rates are specified for both software and hardware limits. If a limit is encountered, the motors will decelerate to a stop.

```
; *****
; These scaling setup commands are downloaded before the
; limit setup commands are executed:
SCALE1      ; Enable scaling
@SCLD4000   ; Program soft limit distance in revs (all axes)
@SCLA4000   ; Program soft limit accel/decel in revs/sec/sec (all axes)
@ERES4000   ; Set encoder resolution to 4000 steps/rev (all axes)
; *****
LH3,3,0,0   ; Enable limits 1 and 2, disable limits 3 and 4
LHAD10,10   ; Set hard limit deceleration
LSAD5,10    ; Set soft limit deceleration
LSNEG0,2    ; Set negative direction soft limit
            ; (axis 1: 0 revs; axis2: 2 revs)
LSPOS10,20  ; Establish positive soft limit
            ; (axis 1: 10 revs; axis 1: 20 revs)
LS3,3,0,0   ; Enable soft limits 1 and 2, disable limits 3 and 4
```

Homing (Using the Home Inputs)

Refer to the product's *Installation Guide* for instructions to wire hardware home limit switches.

Homing Status:

Status of homing moves is stored in bit #5 of the axis status register (indicates whether or not the home operation was successful). To display the status, use the `TASF` command or the `TAS` command. To use the status in a conditional expression (e.g., for an `IF` statement), use the `AS` assignment/comparison operator.

The *homing operation* is a sequence of moves that position an axis using the Home Limit input and/or the Z Channel input of an incremental encoder. The goal of the homing operation is to return the load to a repeatable initial starting location.

Zero Reference After Homing: As soon as the homing operation is successfully completed, the absolute position register is reset to zero, thus establishing a zero reference position (for servo axes using analog input feedback, this applies also to the voltage register).


The homing operation has several potential homing functions you can customize to suit the needs of your application (illustrations of the effects of these commands are presented below):

Command	Homing Function (see respective command descriptions for further details)	Default
HOM.....	Initiate the homing move. To start the homing move in the positive direction, use <code>HOMØ</code> ; to home in the negative direction, use <code>HOM1</code> .	HOMx (do not home)
HOMA.....	Acceleration while homing.	HOMA1Ø (10 units/sec ²)
HOMAA.....	S-curve acceleration while homing.	HOMAA10 (10 units/sec ²)
HOMAD.....	Deceleration while homing.	HOMAD10 (10 units/sec ²)
HOMADA.....	S-curve deceleration while homing.	HOMADA10 (10 units/sec ²)
HOMBAC.....	Back up to home. The load will decelerate to a stop after encountering the active edge of the home region, and then will move in the opposite direction at the <code>HOMVF</code> velocity until the active edge of the home region is encountered. Allows the use of <code>HOMEDG</code> and <code>HOMDF</code> .	HOMBAC0 (function disabled)
HOMDF.....	Final approach direction—during backup to home (<code>HOMBAC</code>) or during homing to the Z channel input of an incremental encoder (<code>HOMZ</code>).	HOMDF0 (positive direction)
HOMEDG.....	Specify the side of the home switch on which to stop (either the positive-travel side or the negative-travel side).	HOMEGD0 (positive-travel side of switch)
LIMLVL.....	Define the home limit input active level (i.e., the state, high or low, which is to be considered an activation of the input). To use a normally-open switch, select active low (<code>LIMLVL0</code>); to use a normally-closed switch, select active high (<code>LIMLVL1</code>).	LIMLVL0 (active-low, use a normally-open switch)
HOMV.....	Velocity while seeking the home position (see also <code>HOMVF</code>).	HOMV1 (1 unit/sec)
HOMVF.....	Velocity while in final approach to home position—during backup to home (<code>HOMBAC</code>) or during homing to the Z channel input of an incremental encoder (<code>HOMZ</code>).	HOMVF.1 (0.1 unit/sec)
HOMZ.....	Home to the Z channel input from an incremental encoder. NOTE: The home limit input must be active prior to homing to the Z channel.	HOMZ0 (function disabled)

NOTES ABOUT HOMING

- Avoid using pause and resume functions during the homing operation. A pause command (`PS` or `!PS`) or pause/continue input (input configured with the `INFNCi-E` or `LIMFNCi-E` command) will pause the homing motion. However, when the subsequent resume command (`C` or `!C`) or pause/continue input occurs, motion will resume at the beginning of the homing motion sequence.

- Relevance of positive and negative direction:



- If an end-of-travel limit is encountered during the homing operation, the motion will be reversed and the home switch will be sought in the opposite direction. If a second limit is encountered, the homing operation will be terminated, stopping motion at the second limit.

Figures A and B show the homing operation when HOMBAC is not enabled. “CW” refers to the positive direction and “CCW” refers to the negative direction.

Figure A:





Figure B:



**Positive Homing,
Backup to Home
Enabled**


The seven steps below describe a sample homing operation when HOMBAC is enabled (see Figure C). The final approach direction (HOMDF) is CW and the home edge (HOMEDG) is the CW edge. “CW” refers to the positive direction and “CCW” refers to the negative direction.

NOTE

To better illustrate the direction changes in the backup-to-home operation, the illustrations in the remainder of this section show the backup-to-home movements with varied velocities. In reality, the backup-to-home movements are performed at the same velocity (HOMVF value).

- Step 1** A CW home move is started with the HOMØ command at the HOMA and HOMAA accelerations. Default HOMA is 10 revs (or volts or inches) per sec².
- Step 2** The HOMV velocity is reached (move continues at that velocity until home input goes active).
- Step 3** The CCW edge of the home input is detected, this means the home input is active. At this time the move is decelerated at the HOMAD and HOMADA command values. It does not matter if the home input becomes inactive during this deceleration.
- Step 4** After stopping, the direction is reversed and a second move with a peak velocity specified by the HOMVF value is started.
- Step 5** This move continues until the CCW edge of the home input is reached.
- Step 6** Upon reaching the CCW edge, the move is decelerated at the HOMAD and HOMADA command values, the direction is reversed, and another move is started in the CW direction at the HOMVF velocity.
- Step 7** As soon as the home input CW edge is reached, this last move is immediately terminated. The load is at home and the absolute position register is reset to zero.


Figure C:



- Home Profile Attributes (commands):
- Start home move in positive direction (HOM0)
 - Backup To Home enabled (HOMBAC1)
 - Final approach direction is positive (HOMDF0)
 - Stop on the positive-travel side of the home switch active region (HOMEDG0)


Figures D through F show the homing operation for different values of HOMDF and HOMEDG, when HOMBAC is enabled. “CW” refers to the positive direction and “CCW” refers to the negative direction.

Figure D:




- Home Profile Attributes (commands):
- Start home move in positive direction (HOM0)
 - Backup To Home enabled (HOMBAC1)
 - Final approach direction is positive (HOMDF0)
 - Stop on the negative-travel side of the home switch active region (HOMEDG1)

Figure E:



- Home Profile Attributes (commands):
- Start home move in positive direction (HOM0)
 - Backup To Home enabled (HOMBAC1)
 - Final approach direction is negative (HOMDF1)
 - Stop on the positive-travel side of the home switch active region (HOMEDG0)

Figure F:




- Home Profile Attributes (commands):
- Start home move in positive direction (HOM0)
 - Backup To Home enabled (HOMBAC1)
 - Final approach direction is negative (HOMDF1)
 - Stop on the negative-travel side of the home switch active region (HOMEDG1)

Negative Homing, Backup to Home Enabled

Figures G through J show the homing operation for different values of HOMDF and HOMEDG, when HOMBAC is enabled. "CW" refers to the positive direction and "CCW" refers to the negative direction.


Figure G:



Home Profile Attributes (commands):

- Start home move in negative direction (HOM1)
- Backup To Home enabled (HOMBAC1)
- Final approach direction is negative (HOMDF1)
- Stop on the negative-travel side of the home switch active region (HOMEDG1)


Figure H:



Home Profile Attributes (commands):

- Start home move in negative direction (HOM1)
- Backup To Home enabled (HOMBAC1)
- Final approach direction is negative (HOMDF1)
- Stop on the positive-travel side of the home switch active region (HOMEDG0)


Figure I:



Home Profile Attributes (commands):

- Start home move in negative direction (HOM1)
- Backup To Home enabled (HOMBAC1)
- Final approach direction is positive (HOMDF0)
- Stop on the negative-travel side of the home switch active region (HOMEDG1)

Figure J:




Home Profile Attributes (commands):

- Start home move in negative direction (HOM1)
- Backup To Home enabled (HOMBAC1)
- Final approach direction is positive (HOMDF0)
- Stop on the positive-travel side of the home switch active region (HOMEDG0)

Homing Using The Z-Channel

Figures K through O show the homing operation when homing to an encoder index pulse, or Z channel, is enabled (HOMZ1). The Z-channel will only be recognized after the home input is activated. It is desirable to position the Z channel within the home active region; this reduces the time required to search for the Z channel. “CW” refers to the positive direction and “CCW” refers to the negative direction.


Figure K:



Home Profile Attributes (commands):

- Z-Channel homing enabled (HOMZ1)
- Start home move in negative direction (HOM1)
- Backup To Home enabled (HOMBAC1)
- Final approach direction is negative (HOMDF1)
- Stop on the negative-travel side of the z-channel active region (HOMEDG1)


Figure L:



Home Profile Attributes (commands):

- Z-Channel homing enabled (HOMZ1)
- Start home move in negative direction (HOM1)
- Backup To Home enabled (HOMBAC1)
- Final approach direction is positive (HOMDF0)
- Stop on the positive-travel side of the z-channel active region (HOMEDG0)


Figure M:



Home Profile Attributes (commands):

- Z-Channel homing enabled (HOMZ1)
- Start home move in negative direction (HOM1)
- Backup To Home enabled (HOMBAC1)
- Final approach direction is positive (HOMDF0)
- Stop on the positive-travel side of the z-channel active region (HOMEDG0)


Figure N:



Home Profile Attributes (commands):

- Z-Channel homing enabled (HOMZ1)
- Start home move in positive direction (HOM0)
- Backup To Home disabled (HOMBAC0)
- Final approach direction is positive (HOMDF0)
- Stop on the positive-travel side of the z-channel active region (HOMEDG0)

Figure O:



Home Profile Attributes (commands):

- Z-Channel homing enabled (HOMZ1)
- Start home move in positive direction (HOM0)
- Backup To Home enabled (HOMBAC1)
- Final approach direction is positive (HOMDF0)
- Stop on the positive-travel side of the z-channel active region (HOMEDG0)

Encoder-Based Stepper Operation (stepper axes only)

When using an encoder in an stepper application, you can configure the following:

- Encoder resolution
- Stall Detection & Kill-on-Stall, Stall Deadband
- Encoder polarity
- Encoder-based position reference and position capture
- Encoder failure detection
- Commanded direction polarity

Encoder Resolution

You must specify the encoder resolution with the `ERES` command. The power-up default value for encoder resolution is 4,000 counts/rev. Listed below are the resolution values for Compumotor-supplied encoders.

- -RE, -RC, -EC, and -E Series Encoders:..... ERES4000
- -HJ Series Encoders:..... ERES2048
- Daedal Positioning Tables (encoder options):
 - E2 ERES42000
 - E3 ERES84000
 - E4 ERES420000
 - E5 ERES8400
- Dynaserv:

DR10xxB.....	ERES507904	DR5xxxA.....	ERES425894
DR1xxxE.....	ERES614400	DM10xxB.....	ERES655360
DR1xxxA.....	ERES819200	DM1xxxA.....	ERES1024000
DR5xxxB.....	ERES278528	DM1004x.....	ERES655360

Stall Detection & Kill-on-Stall

To detect stalls without an encoder, see *Drive Stall Detection* on page 47.

The `ESTALL1` command enables the controller to detect encoder-based stall conditions.

NOTE: Encoder count reference must be enabled (`ENCCNT1`) before stall detect (`ESTALL`) can be used.

If used with *Kill-on-Stall* enabled (`ESK1` command), the move in progress will be aborted upon detecting a stall. If queried with the `ER` or the `AS` commands, the user can branch to any other section of program when a stall is detected. Refer to the `ER`, and `AS` command descriptions in the *6K Series Command Reference* for more information.

Kill-on-Stall functions only if the stall detection is enabled (`ESTALL1`).



WARNING



Disabling the Kill-on-Stall function with the `ESK0` command will allow the controller to finish the move regardless of a stall detection, even if the load is jammed. **This can potentially damage user equipment and injure personnel.**

Stall Deadband

Another encoder set-up parameter is the Stall Backlash Deadband (`ESDB`) command. This command sets the number of commanded counts of error allowed, after a change in direction, before a stall will be detected. This is useful for situations in which backlash in a system can cause false stall situations.

Encoder Set Up Example

The example below illustrates the features discussed in the previous paragraphs. The DRES statement defines the motor resolutions. The ERES statement defines the number of encoder steps per encoder revolution. Standard 1000-line encoders are used on all axes that produce 4000 quadrature steps/rev. Encoder counting (ENCCNT), stall detect (ESTALL) and kill-on-stall (ESK1) are enabled. If a stall is detected, the motor's movement is killed. The ESDB statement defines the stall deadband.

*Examples for 4 Axes
(command line samples)*

```
DRES25000,25000,25000,200 ; Set drive resolution
ERES4000,4000,4000,4000 ; Set encoder resolution
ESK11111 ; Enable kill motion on stall
ENCCNT1111 ; Enable encoder counting (this is
; required for ESTALL to work)
ESTALL1111 ; Enable stall detection
ESDB0,0,10,10 ; Set stall deadband
```

Encoder Polarity

If the encoder input is counting in the wrong direction, you can reverse the polarity with the ENCPOL command. This allows you to reverse the counting direction without having to change the actual wiring to the encoder input. For example, if the encoder on axis 2 counted in the wrong direction, you could issue the ENCPOLx1 command to correct the polarity.

Immediately after issuing the ENCPOL command, the encoder will start counting in the opposite direction (including all encoder position registers).

NOTES

- Changing the feedback polarity effectively invalidates any existing offset position (PSET) setting; therefore, you will have to re-establish the PSET position.
- The ENCPOL command is automatically saved in non-volatile RAM.
- If you wish to reverse the commanded direction of motion, first make sure there is a direct correlation between commanded direction and encoder direction, then issue the appropriate CMDDIR command to reverse both the commanded direction and the encoder direction (see CMDDIR command description for full details).

*Programming
Scenario (as seen in a
terminal emulator)*

```
; This programming scenario assumes the encoder polarity is reversed
; from the commanded direction (e.g., commanding a move of +10 units,
; yields and encoder position of -10 units).
;
> PSET0 ; Define current position of axis 1 as position zero
> 1TPE ; Check the position of encoder 1
*1TPE+0 (response indicates encoder 1 is at position zero)

> MA0 ; Select incremental positioning mode
> D+8000 ; Set distance to 8,000 units in the positive direction
> GO1 ; Move axis 1 a distance of 8,000 units
> 1TPE ; Check the position of encoder 1
*1TPE-8000 (response shows that encoder 1 is at position -8000,
the minus sign indicates that the encoder is counting in the
wrong direction)

> DRIVE0 ; Disable the drive (disabled before changing polarity)
> ENCPOL1 ; Reverse encoder polarity on axis 1
> PSET0 ; Define current position of axis 1 as position zero
> DRIVE1 ; Enable the drive
> D+8000 ; Set distance to 8,000 units in the positive direction
> GO1 ; Move axis 1
> 1TPE ; Check the position of encoder 1
*1TPE+8000 (response shows encoder 1 has moved 8,000 units in the positive
direction, indicating that the encoder is now counting in the
correct direction)
```

Encoder Count/Capture Referencing

Use `ENCCNT` to configure stepper axes to reference either the encoder position or the commanded position when capturing the position (see `INFNCi-H`) and checking the encoder position (`PE` and `TPE`). When checking the actual velocity (`VELA` and `TVELA`), `ENCCNT` determines whether the velocity, in units of revs/sec, is derived with the encoder resolution (`ERES`) or the drive resolution (`DRES`). The default setting (`ENCCNT0`) references the commanded position.

Example

```
AXSDEF00 ; Axes 1 & 2 as steppers; axis 1 has encoder, axis 2 doesn't
INFNC1-H ; Configure trigger 1A as position capture input for axis 1
INFNC3-H ; Configure trigger 2A as position capture input for axis 2
ENCCNT10 ; Capture axis 1's encoder position when trigger 1A is
          ; activated. Capture axis 2's commanded position when
          ; trigger 2A is activated.
```

Encoder Failure Detection

The Encoder Failure Detect (`EFAIL`) command enables (1) or disables (0) the monitoring of the encoder signals to determine if the encoder is functioning properly (default is disabled). For example, the `EFAIL1111000` command enables encoder failure checking on axes 1-4, but not axes 5-8.

The 6K detects a failure if both channel A+ and channel A- are the same state (i.e., both high or both low). The B channel is not checked. A+ and A- are internally pulled to +5V; therefore, if the encoder is disconnected a failure is detected. A failure could occur if either A+ or A- are disconnected, it depends on whether the other signal was high or low at that time. The typical causes for the failure would be a disconnected encoder or a failed encoder.

If `EFAIL` is enabled for an axis, and an encoder failure is detected, then bit 5 of the extended axis status register (reported with `TASX`, `TASXF` and `ASX`) is set to 1. When `ERROR` bit 17 is set to 1, an encoder failure occurring on any axis will initiate a jump to the error program (`ERRORP`). The error condition is cleared by reconnecting the encoder while `EFAIL` is enabled for that particular axis.

DO NOT USE WITH SINGLE-ENDED ENCODERS

Use the `EFAIL` feature only with differential encoders. Do not attempt to use the `EFAIL` feature with single-ended encoders; because the A- terminal is not connected, the 6K will always detect an encoder failure if `EFAIL` is enabled.

Commanded Direction Polarity

The `CMDDIR` command allows you to reverse the direction that the controller considers to be the “positive” direction; this also reverses the polarity of the counts from the encoder. Thus, using the `CMDDIR` command, you can reverse the referenced direction of motion without the need to (a) change the connections to the drive and the encoder, or (b) change the sign of all the motion-related commands in your program.

NOTES

- The `CMDDIR` command cannot be executed while motion is in progress or while the drive is enabled. For example, you could wait for motion to be complete (indicated when `TAS` and `AS` bit 1 is a zero) and then use the `DRIVE` command to disable the appropriate axis before executing the `CMDDIR` command.
- Before changing the commanded direction polarity, make sure there is a direct correlation between the commanded direction and the direction of the encoder counts (i.e., a positive commanded direction from the controller must result in positive counts from the encoder).
- Once you change the commanded direction polarity, you should swap the end-of-travel limit connections to maintain a positive correlation with the commanded direction.
- The `CMDDIR` setting is automatically saved in non-volatile memory.

Servo Setup (servo axes only)


Use Motion Planner

Motion planner provides wizards and a tuning aide to create setup code for your servo product.


To assure optimum performance you should tune your servo system. The goal of the tuning process is to define the gain settings, servo performance, and feedback setup (see command list below) that you can incorporate into your application program. (Typically, these commands are placed into a setup program). Servo tuning should be performed as part of the application *setup process*, as described below. **To tune your servo system (4-step process):**

1. After starting Motion Planner, you will see the Editor window. Select the Servo Tuner tab. If a Servo Tuner session is not already open, on the File click New. Then select Servo Tuner and click Ok.
2. To send a pre-programmed step output to the drive, click Start. Notice that the graph display draws the commanded and actual velocity profiles so that you can graphically tune your servo system.

Optimize the proportional (SGP) and velocity (SGV) values by iteratively changing gains and viewing the results on the graph display. The object is to achieve a 1st order response (minimal overshoot and close position tracking). The typical process is illustrated in the flow diagram on the next page.



Basic Tuning Process




This figure outlines the basic process to achieve a 1st Order Response (minimal overshoot and close position tracking).

3. Repeat step 2 for each axis. Then write down the final gain settings.
4. When you have determined which tuning gains are best for your application's performance, insert the gain commands into your setup program:
 - (refer also to the illustration below)
 - a. Click the "Copy Gains" to Clipboard button. This copies the gain commands to your computer's clipboard.
 - b. Click the "Editor" tab to bring the program editor to the front.
 - c. Place the cursor at the location in your program where you wish to insert the gain commands (see note below).
 - d. Paste the gain commands at the location of the cursor.

NOTE

The tuning gains are specific to the feedback source selection in effect at the time the gain commands are executed. The factory default feedback source (selected with the SFB command) is encoder feedback. The illustration below demonstrates where to insert the gain commands relative to the SFB command.

If your application requires you to switch between feedback sources for the same axis, then for each feedback source you must select the source with the SFB command and then execute the tuning gain commands relevant to the feedback source (an example is provided in the illustration below).



Sample code generated by Motion Planner

Tuning-Related Commands (see 6K Series Command Reference for details)

Tuning Gains:	
SGP.....	Sets the proportional gain in the PIV&F servo algorithm.
SGI.....	Sets the integral gain in the PIV&F servo algorithm.
SGV.....	Sets the velocity gain in the PIV&F servo algorithm.
SGAF.....	Sets the acceleration feedforward gain in the PIV&F _a algorithm.
SGVF.....	Sets the velocity feedforward gain in the PIV&F _v algorithm.
SGILIM....	Sets a limit on the correctional control signal that results from the integral gain action trying to compensate for a position error that persists too long.
SGENB	Enables a previously-saved set of PIV&F gains. A set of gains (specific to the current feedback source selected with the SFB command) is saved using the SGSET command.
SGSET	Saves the presently-defined set of PIV&F gains as a <i>gain set</i> (specific to the current feedback source on each axis). Up to 5 gain sets can be saved and enabled at any point in a move profile, allowing different gains at different points in the profile.

Feedback Setup:	
SFB	Selects the servo feedback device (encoder or analog input). To use analog input feedback, you must first use the ANIFB command to configure the targeted analog input to be used for feedback. IMPORTANT: Parameters for scaling, tuning gains, max. position error (SMPER), and position offset (PSET) are specific to the feedback device selected (with the SFB command) at the time the parameters are entered (see programming examples in the 6K Programmer's Guide).
ERES	Encoder resolution.
SMPER.....	Sets the maximum allowable error between the commanded position and the actual position as measured by the feedback device. If the error exceeds this limit, the controller activates the Shutdown output and sets the DAC output to zero (plus any SOFFS offset). If there is no offset, the motor will freewheel to a stop. You can enable the ERROR command to continually check for this error condition (ERROR.12-1), and when it occurs to branch to a programmed response defined in the ERRORP program.

Encoder Polarity

To change the commanded and encoder polarity, use the CMDDIR command instead (see page 71 for details).

Servo stability requires a direct correlation between the commanded direction and the direction of the encoder counts (i.e., a positive commanded direction from the controller must result in positive counts from the encoder).

If the encoder is counting in the wrong direction, you can reverse the polarity with the ENCPOL command. This allows you to reverse the counting direction without having to change the actual wiring to the encoder. For example, if the encoder on axis 2 counted in the wrong direction, you could issue the ENCPOLx1 command to correct the polarity.

Immediately after issuing the ENCPOL command, the respective encoder will start counting in the opposite direction (including all the encoder position register, reported with TPE and PE). The polarity of the encoder is immediately changed whether or not the encoder is currently selected with the SFB command.

NOTES

- You cannot change the encoder on a specific axis while that axis is moving.
- Changing the encoder polarity effectively invalidates any existing offset position (PSET) setting; therefore, you will have to re-establish the PSET position.
- The ENCPOL command is automatically saved in non-volatile RAM.
- If you wish to reverse the commanded direction of motion, first make sure there is a direct correlation between commanded direction and encoder direction, then issue the appropriate CMDDIR command to reverse both the commanded direction and the encoder direction (see CMDDIR command description or page 71 for full details).

*Programming Scenario
(as seen when the
commands are typed
into a terminal
emulator)*

```
> SFB1          (Select encoder feedback for axis 1)
> SMPER100     (Set maximum position error to 100 units on axis 1)
> PSET0        (Define current position of axis 1 as position zero)
> 1TPE         (Check the position of encoder 1)
*1TPE+0        (response indicates encoder 1 is at position zero)

> MA0          (Select incremental positioning mode)
> D+8000       (Set distance to 8,000 units in the positive direction)
> GO1          (Move axis 1. If the encoder polarity is incorrect, the axis will be unstable and will stop -
               drive disabled - as soon as the maximum position error of 100 units is reached.)
> 1TPE         (Check the position of encoder 1)
*1TPE-100     (response should show that encoder 1 is approximately at position -100; the minus sign
               indicates that the encoder is counting in the wrong direction)

> ENCPOL1     (Reverse encoder polarity on axis 1)
> PSET0        (Define current position of axis 1 as position zero)
> DRIVE1      (Enable the drive - drive was disabled when the SMPER value was exceeded)
> D+8000       (Set distance to 8,000 units in the positive direction)
> GO1          (Move axis 1)
> 1TPE         (Check the position of encoder 1)
*1TPE+8000    (response shows encoder 1 has moved 8,000 units in the positive direction, indicating
               that the encoder is now counting in the correct direction)
```

Commanded Direction Polarity

EXAMPLE

The command to change the polarity for axis 2 is
`CMDDIR, 1`

The `CMDDIR` command allows you to reverse the direction that the controller considers to be the “positive” direction; this also reverses the polarity of the counts from the feedback devices. Thus, using the `CMDDIR` command, you can reverse the referenced direction of motion without the need to (a) change the connections to the drive/valve and the feedback device, or (b) change the sign of all the motion-related commands in your program.

NOTES

- The `CMDDIR` command cannot be executed while motion is in progress or while the drive/valve is enabled. For example, you could wait for motion to be complete (indicated when `TAS` and `AS` bit 1 is a zero) and then use the `DRIVE` command to disable the appropriate axis before executing the `CMDDIR` command.
- Before changing the commanded direction polarity, make sure there is a direct correlation between the commanded direction and the direction of the feedback source counts (i.e., a positive commanded direction from the controller must result in positive counts from the feedback device).
- Once you change the commanded direction polarity, you should swap the end-of-travel limit connections to maintain a positive correlation with the commanded direction.
- The `CMDDIR` command is automatically saved in non-volatile memory.

DAC Output Limits

If you will not be using the entire -10V to +10V range of the 6K controller's analog output, you can set up maximum (DACLIM) limits. For example, setting the DAC limit to 8.000V (DACLIM8.00) will clamp the DAC output range from -8.000 to +8.000.

Use the TDAC command to verify the voltage being commanded at the servo controller's analog output to the drive.

Servo Control Signal Offset

The SOFFS command provides a means of setting the controller's analog output to a known voltage value. This could be useful for these occasions:

- Testing motion in an open-loop configuration (all gains set to zero).
- If the commanded output is set to zero (motor is supposed to be stationary), but it keeps moving, you can impose an offset value to stop motion. *This is the same effect as the balance input on most analog servo drives.*

Use the TDAC command to check the voltage being commanded at the servo controller's analog output (the voltage displayed includes and offset in effect).

WARNING — Torque Drive Users

If there is little or no load attached, the SOFFS offset can cause an acceleration to a high speed.

Servo Setup Example

This section shows examples of how the servo setup commands might be incorporated into a setup program. The example shows that much of the feedback selection and scaling code is placed in the program file before the setup program definition; this program file structure is required because scaling parameters are not allowed in a program.

USE THE SETUP WIZARD IN MOTION PLANNER

Motion Planner automatically generates the setup code when you use the wizards in the Editor. More information on creating and executing setup programs is provided on page 10.

```

; SETUP FOR 2-AXIS CONTROLLER
;*****
;* Setup for encoder *
;* (will need to switch between encoder & ANI feedback) *
;*****
SFB1,1 ; Select encoder feedback for axis 1. Subsequent scaling,
; gains, SMPER & PSET parameters are specific to encoder feed-
; back. (accommodates switching between encoder & ANI feedback)
ERES4000,4000 ; Set encoder resolution to 4,000 counts/rev
SCLA4000,4000 ; Allow programming accel/decel in revs/sec/sec
SCLV4000,4000 ; Set scaling for programming velocity in revs/sec
SCLD4000,4000 ; Set scaling for programming distances in revs
SGP5,5 ; Set proportional feedback gain
SGI1,1 ; Set integral feedback gain
SGV1,1 ; Set velocity feedback gain
SMPER.001,.001 ; Set max. position error to 1/1000 of rev (4 encoder counts)
PSET0,0 ; Set current position as absolute position zero

;*****
;* setup for ANI *
;*****
ANIFB2-9,2-10 ; Select the 1st analog input on SIM 2 of I/O brick 2
; to be used as position feedback for axis 1, and
; select the 2nd analog input on SIM 2 of I/O brick 2
; to be used as position feedback for axis 2
SFB2,2 ; Select ANI (analog input) feedback for both axes
; (subsequent scaling, gains, SMPER, and PSET
; parameters are specific to ANI feedback)
2ANIRNG.9=4 ; Select voltage range of -10V to +10V for the 1st and
2ANIRNG.10=4 ; 2nd analog inputs on SIM 2 of I/O brick 2 (these
; are the inputs used for position feedback)
SCLA205,205 ; Allow programming accel/decel in volts/sec/sec
SCLV205,205 ; Allow programming velocity in volts/sec
SCLD205,205 ; Allow programming distances in volts
SGP1,1 ; Set proportional feedback gain
SGI0,0 ; Set integral feedback gain
SGV.5,.5 ; Set velocity feedback gain
SMPER.01,.01 ; Set max. position error to 1/50 of a volt (with a resolution
; of -10 to +10V, this is equivalent to 4 ANI counts)
PSET5,5 ; Set current position as absolute position 5


;*****
;* Below is the setup program *
;*****
DEF SETUP ; Begin definition of SETUP program
DRFEN11 ; Enable the drive fault input
DRFLVL11 ; Set drive fault level to active high
DRIVE00 ; Disable both drives
KDRIVE11 ; Invoke the Disable Drive On Kill feature, both axes
SFB1,1 ; Select encoder feedback for start of main program
Main ; Run the program called "main" (the main controlling
; program for this application)
END ; End definition of SETUP program

;*****
;* The following command (STARTP SETUP) is used to assign SETUP as the *
;* startup program to be automatically executed on power up or RESET. *
;*****
STARTP SETUP

```

Target Zone Mode (move completion criteria—servo axes only)

Under default operation (Target Zone Mode not enabled), the 6K product's move completion criteria is simply derived from the move trajectory. The 6K product considers the current preset move to be complete when the commanded trajectory has reached the desired target position; after that, subsequent commands/moves can be executed for that same axis. Consequently, the next move or external operation can begin before the actual position has settled to the commanded position (see diagram).




To prevent premature command execution before the actual position settles into the commanded position, use the *Target Zone Mode*. In this mode, enabled with the STRGTE command, the move cannot be considered complete until the actual position and actual velocity are within the *target zone* (that is, within the distance zone defined by STRGTD and less than or equal to the velocity defined by STRGTV). If the load does not settle into the target zone before the timeout period set with the STRGTT command, the 6K product detects a *timeout error* (see illustration below).

If the timeout error occurs, you can prevent subsequent command/move execution only if you enable the ERROR command to continually check for this error condition, and when it occurs to branch to a programmed response you can define in the ERRORP program. (Refer to the *Error Handling* section, page 30, for error program examples.)

As an example, setting the distance zone to ± 5 counts (STRGTD5), the velocity zone to ≤ 0.5 revs/sec (STRGTV0.5), and the timeout period to 1/2 second (STRGTT500), a move with a distance of 8,000 counts (D8000) must end up between position 7,995 and 8,005 and settle down to ≤ 0.5 rps within 500 ms (1/2 second) after the commanded profile is complete.

Damping is critical

To ensure that a move settles within the distance zone, it must be damped to the point that it will not move out of the zone in an oscillatory manner. This helps ensure the actual velocity falls within the target velocity zone set with the STRGTV command (see illustration below).



Checking the Settling Time

Checking the Actual Settling Time: Using the TSTLT command, you can display the actual time it took the last move to settle into the target zone (that is, within the distance zone defined by STRGTD and less than or equal to the velocity defined by STRGTV). The reported value represents milliseconds. The TSTLT command is usable whether or not the Target Zone Settling Mode is enabled with the STRGTE command.

Programmable Inputs and Outputs (onboard and external inputs & outputs)

Programmable inputs and outputs allow the controller to detect and respond to the state of switches, thumbwheels, electronic sensors, and outputs of other equipment such as drives and PLCs. The I/O that can be used as programmable inputs and outputs are:

- Onboard I/O:
 - Limit inputs on the “LIMITS/HOME” connectors
 - Trigger inputs on the “TRIGGERS/OUTPUTS” connectors (pins 9, 11, 13, 15, 17, 19, 21 & 23). A “master trigger” is available (see “MASTER TRIG” terminal on the connector on top of the 6K chassis).
 - Digital outputs on the “TRIGGERS/OUTPUTS” connectors (1, 3, 5 & 7)
- Expansion I/O located on I/O bricks connected to the 6K controller’s “EXPANSION I/O” connector. Each I/O brick can hold from 1 to 4 of these I/O SIM modules in any combination (each SIM module provides 8 inputs or outputs, for a total of 32 I/O points per I/O brick):
 - Digital inputs
 - Digital outputs
 - Analog inputs
 - Analog outputs

USING THE STATE OF I/O TO CONTROL PROGRAMMED EVENTS: Based on the binary state of the inputs and outputs (binary status can be used in assignment/comparison operations using the LIM, IN and OUT operators), the controller can make program flow decisions and assign values to binary variables for subsequent mathematical operations. These operations and the associated program flow, branching, and variable commands are listed below.

Operation based on I/O State	Associated Commands	See Also*
I/O state assigned to a binary variable	LIM, [IN], [OUT], VARB	Variables (page 18)
I/O state used as a basis for comparison in conditional branching & looping statements	LIM, [IN], [OUT], IF, ELSE, NIF, REPEAT, UNTIL, WAIT, WHILE, NWHILE	Program Flow Control (page 23)
Input state used as a basis for a conditional GO	[IN], GOWHEN, LIM	Synchronizing Motion (page 159)
I/O state used as a basis for a program interrupt (GOSUB) conditional statement	ONIN	Program Interrupts (page 29)
Mimic PLC functionality by scanning I/O states with a compiled program	PLCP, SCANP	PLC Scan Mode (page 104)

* Refer also to the respective command descriptions in the *6K Series Command Reference*.

I/O UPDATE RATE: The programmable inputs and outputs are sampled at the “system update rate,” which is every 2 ms. **EXPANSION I/O BRICKS:** If the I/O brick is disconnected or if it loses power, the controller will perform a kill (all tasks) and set error bit 18 (see ERROR). (If you disable the “Kill on I/O Disconnect” mode with KIOENØ, the 6K will not perform the kill.) The controller will remember the brick configuration (volatile memory) in effect at the time the disconnection occurred. When you reconnect the I/O brick, the controller checks to see if anything changed (SIM by SIM) from the state when it was disconnected. If an existing SIM slot is changed (different SIM, vacant SIM slot, or jumper setting), the controller will set the SIM to factory default INEN and OUTLVL settings. If a new SIM is installed where there was none before, the new SIM is auto-configured to factory defaults.

Programmable I/O Bit Patterns

The total number of onboard inputs and outputs (trigger inputs, limit inputs, digital outputs) depends on the product. The total number of expansion inputs and outputs (analog inputs, digital inputs and digital outputs) depends on your configuration of expansion I/O bricks.

These programmable I/O are represented by binary bit patterns, and it is the bit pattern that you reference when programming and checking the status of specific inputs and outputs. The bit pattern is referenced 1 to *n*, from left to right.

- **Onboard I/O.** For example, the status command to check all onboard trigger inputs is `TIN`.
An example response for the 6K8 is: `*TIN0100_0001_0000_0011_0.`


Bit 1 →
← Bit 17
- **Expansion I/O.** For example, the status command to check all digital inputs on I/O brick 2 is `2TIN`.
An example response for the 6K8 is: `*2TIN0010 0110_1100_0000_XXXX_XXXX_XXXX_XXXX.`

I/O Brick 2 →
← Bit 1
← Bit 32

Onboard Programmable I/O

I/O	Location	Programming	Status Report, Assignment
Limit Inputs	"LIMITS/HOME" connectors	LIMFNC, LIMEN, LIMLVL	TLIM, LIM
Trigger Inputs	"TRIGGERS/OUTPUTS" connectors (pins 9, 11, 13, 15, 17, 19, 21 & 23). Master Trigger is "MASTER TRIG" on connector on top of the 6K chassis	INFNC, INLVL, INEN, ONIN, INPLC, INSTW	TIN, IN
Outputs (digital)	"TRIGGERS/OUTPUTS" connectors (pins 1, 3, 5 & 7).	OUT, OUTFNC, OUTLVL, OUTEN, OUTALL, OUTPLC, OUTTW, POUT	TOUT, [OUT]

Limit Inputs ("LIMITS/HOME" connectors)



Input bit pattern for LIM, TLIM, LIMEN, LIMFNC, and LIMLVL:


Bit #	Pin #	Function *
1	23	Positive end-of-travel limit, axis 1.
2	21	Negative end-of-travel limit, axis 1.
3	19	Home limit, axis 1.
4	17	Positive end-of-travel limit, axis 2.
5	15	Negative end-of-travel limit, axis 2.
6	13	Home limit, axis 2.
7	11	Positive end-of-travel limit, axis 3.
8	9	Negative end-of-travel limit, axis 3.
9	7	Home limit, axis 3.
10	5	Positive end-of-travel limit, axis 4.
11	3	Negative end-of-travel limit, axis 4.
12	1	Home limit, axis 4.
13	23	Positive end-of-travel limit, axis 5.
14	21	Negative end-of-travel limit, axis 5.
15	19	Home limit, axis 5.
16	17	Positive end-of-travel limit, axis 6.
17	15	Negative end-of-travel limit, axis 6.
18	13	Home limit, axis 6.
19	11	Positive end-of-travel limit, axis 7.
20	9	Negative end-of-travel limit, axis 7.
21	7	Home limit, axis 7.
22	5	Positive end-of-travel limit, axis 8.
23	3	Negative end-of-travel limit, axis 8.
24	1	Home limit, axis 8.

* The functions listed are the factory default functions; other functions may be assigned with the LIMFNC command.


Sample response to TLIM (limit inputs status) command:

`*TLIM001_001_001_001_001_001_001_001`

Trigger Inputs ("TRIGGERS/OUTPUTS" connectors)



Outputs ("TRIGGERS/OUTPUTS" connectors)



Expansion I/O Bricks


The 6K product allows you to expand your system I/O by connecting up to 8 I/O bricks (see *Installation Guide* for connections). Expansion I/O bricks can be ordered separately (referred to as the “EVM32”). Each I/O brick can hold from 1 to 4 of these I/O SIM modules in any combination:

SIM Type	Programming	Status Report, Assignment
Digital Inputs SIM (8 inputs)	INFNC, INLVL, INEN, ONIN, INPLC, INSTW	TIN, IN, TIO
Digital Outputs SIM (8 outputs)	OUT, OUTFNC, OUTLVL, OUTEN, OUTALL, OUTPLC, OUTTW, POUT	TOUT, [OUT], TIO
Analog Inputs SIM (8 inputs)	<ul style="list-style-type: none"> • Enable/Disable: ANIEN. • Voltage range: ANIRNG. • Joystick setup: JOYAXH, JOYAXL, JOYCDB, JOYCTR, JOYEDB, JOYZ. • Servo feedback: ANIFB, SFB • Following master source: ANIMAS, FOLMAS 	<ul style="list-style-type: none"> • Voltage: TANI, ANI, TIO • Servo position: TPANI, PANI, FB, TFB
Analog Outputs SIM (8 outputs)	ANO	TANO, [ANO], TIO

Each I/O brick has a unique “brick address”, denoted with the “” symbol in the command syntax. The I/O bricks are connected in series to the “EXPANSION I/O” connector on the 6K. The 1st I/O brick has address 1, the next brick has address 2, and so on. (**NOTE:** If you leave out the brick address in the command, the 6K product assumes you are addressing the command to the onboard I/O.) Each I/O brick has 32 I/O addresses, referenced as absolute I/O point locations:

- SIM slot 1 = I/O points 1-8
- SIM slot 2 = I/O points 9-16
- SIM slot 3 = I/O points 17-24
- SIM slot 4 = I/O points 25-32

Example



The TIO command identifies the connected I/O bricks (and installed SIMs), including the status of each I/O point:

```

*BRICK 1:  SIM Type      Status      Function
           1-8: DIGITAL INPUTS  0000_0000  AAAA AAAA
           9-16: DIGITAL INPUTS  0000_0000  AAAA AAAA
           17-24: DIGITAL INPUTS  0000_0000  AAAA AAAA
           25-32: ANALOG INPUTS   0.000,0.000,0.000,0.000,0.000,0.000,0.000,0.000

*BRICK 2:  SIM Type      Status      Function
           1-8: DIGITAL OUTPUTS  0000_0000  AAAA AAAA  -- SINKING
           9-16: DIGITAL INPUTS  0000_0000  AAAA AAAA
           17-24: NO SIM PRESENT
           25-32: DIGITAL OUTPUTS  0000_0000  AAAA AAAA  -- SOURCING
  
```

Input Functions

Programmable input functions can be assigned to the onboard limit and trigger inputs, as well as to digital inputs on an expansion I/O brick connected to the 6K product. The appropriate input function command (LIMFNC or INFNC) depends on which input you are configuring:

- Onboard limit inputs (on the “LIMITS/HOME” connector) — use LIMFNC:

Syntax: LIMFNCi-<a>c

Number of the input. (see page 141 for input bit assignments) — points to 'i'

Axis number (optional). Some functions may be made specific to one axis. When shipped from the factory, all limit inputs are assigned the limit function for the respective axis. For example, limit input 1 is assigned the positive travel end-of-travel limit function for axis 1 (LIMFNC1-1R). — points to 'a'

Letter that selects the desired function (see list below). — points to 'c'

- Onboard trigger inputs (on the “TRIGGERS/OUTPUTS” connector) and digital inputs installed on an expansion I/O brick — use INFNC:

Syntax: INFNCi-<a>c

I/O Brick number. Trigger inputs are considered collectively as I/O brick 0 (zero), and are addressed of the I/O brick number is left off the command. — points to ''

Number of the input. (see page 143 for input bit assignments) — points to 'i'

Axis number (optional). Some functions may be made specific to one axis. For example, to assign the 2nd input on SIMM2 (I/O point #9) of I/O brick 1 to be the stop input for axis 2 only, use the 1INFNC9-2D command. — points to 'a'

Letter that selects the desired function (see list below). — points to 'c'

Virtual Inputs

Virtual Inputs provide programming input functionality for data or external events that are not ordinarily represented by inputs. The Virtual Input Override (IN) command allows you to substitute almost any 32-bit data operand as a virtual input brick of 32 inputs (integer values are converted to binary). Page 8 provides a list of the data operands; the only data operands that are not allowed are: SIN, COS, TAN, ATAN, VCVT, SQRT, VAR, TW, READ, DREAD, DREADF, DAT, DPTR, and PI.

The virtual inputs behave similar to real inputs in that they are affected by INEN and INLVL, and they affect INFNC, INPLC, INSTW, INDUST, ONIN, and GOWHEN (IN=b<bbbb>) commands. Unlike real inputs, virtual inputs are not affected by the INDEB debounce setting.

NOTE: A virtual input can only be defined for expansion I/O bricks that are not connected on the serial I/O network (remember that up to 8 I/O bricks are allowed). For example, if your 6K unit has two I/O bricks, you can designate I/O bricks 3-8 as virtual I/O bricks.

EXAMPLE: Suppose a PLC is sending binary data via the VARB1 command to the 6K. If the binary state of VARB1 is assigned to input brick 2 (2IN=VARB1), the 6K can respond based on programmable input functions set up with the INFNC command.

```

2TIN          ; Brick 2 is not connected; therefore, the 6K will
              ; respond with an error message: "*INCORRECT I/O BRICK"
2IN=VARB1     ; Map the binary state of VARB1 to be the input state
              ; of "virtual" input brick 2 (2IN)
VARB1=b1010000 ; Change "virtual" input brick 2IN to a new VARB1 value
2TIN          ; Check the input status. The response will be:
              ; "*2IN1010_0000_0000_0000_0000_0000_0000"
    
```

Letter Designator	Function
A.....	General-purpose input (<u>default function for triggers & inputs on I/O bricks</u>)
B.....	BCD program select
C.....	Kill
<a>D.....	Stop (axis designator "a" is optional)
E.....	Pause/Continue
F.....	User fault
G.....	<RESERVED>
H.....	Trigger Interrupt for position capture or registration (trigger inputs only). Special trigger functions can be assigned with the TRGFN command (see page 162).
I.....	Cause an "Alarm Event" over the Ethernet interface
aJ.....	Jog in the positive-counting direction (axis designator is required)
aK.....	Jog in the negative-counting direction (axis designator is required)
aL.....	Jog velocity select (axis designator is required)
M.....	Joystick release
N.....	Joystick axis select
O.....	Joystick velocity select
P.....	One-to-one program select
Q.....	Program security
aR.....	End-of-travel limit for positive-counting direction (axis designator is required) *
aS.....	End-of-travel limit for negative-counting direction (axis designator is required) *
aT.....	Home limit (axis designator is required) *

* Limit inputs (on the "LIMITS/HOME" connector) are factory-set to their respective end-of-travel or home limit function (see page 57).

NOTES

- **Multi-tasking:** If the LIMFNC or INFNC command does not include the task identifier (%) prefix, the function affects the task that executes the LIMFNC or INFNC command. The only functions that can be directed to a task with % are: C, D (without an axis specified), E, F, and P (e.g., 2%INFNC3-F assigns onboard input 3 as a user fault input for task 2). Multiple tasks can share the same input, but the input can only be assigned one function.
- **Limit of 32 functions per input group:** You can assign a maximum of 32 LIMFNC functions, and a maximum of 32 INFNC functions. For LIMFNC, this excludes functions A ("general-purpose") and R, S, and T (end-of-travel and home limit input functions). For INFNC, this excludes functions A ("general-purpose") and H ("trigger interrupt").

Input Status

* The purpose of the IN and LIM operators is to use the state of the inputs as a basis for conditional statements (IF, REPEAT, WHILE, GOWHEN, etc.) or for binary variable assignments (VARB). For examples, see the *Conditional Looping and Branching* section on page 25, and *Synchronizing Motion* on page 159.

Limit inputs (LIMFNC):

- Status display commands:
 - LIMFNC.....Active state and programmed function of all limit inputs
 - LIMFNCiSame as LIMFNC display, but only for the input number ("i")
 - TLIMHardware state of all limit inputs (binary report);
use TLIM.i to check the state of only one input ("i")
- Status assignment/comparison operator: *
 - LIM.....Hardware state (binary) of all limit inputs;
use LIM.i to check the state of only one input ("i")

Trigger inputs and digital inputs on expansion I/O bricks (INFNC):

- Status display commands:
 - TIO.....I/O brick configuration (which SIMs are present)
 - INFNC.....Active state and programmed function of all trigger inputs
 - INFNCi.....Same as INFNC display, but only for the trigger input number ("i")
 - INFNC.....Active state and programmed function of all inputs on I/O brick B
 - INFNCi.....Same as INFNC display, but only for the input number ("i") on brick B
 - TIN.....Hardware state of all onboard trigger inputs (binary report);
use TIN.i to check the state of only one input ("i")
 - TIN.....Hardware state of all digital inputs on I/O brick B (binary report);
use TIN.i to check the state of only one input ("i") on brick B
- Status assignment/comparison operator: *
 - INHardware state (binary) of triggers and expansion digital inputs;
use IN.i to check the state of only one input ("i") on brick B

Input Active Levels

Many people refer to a voltage level when referencing the state of programmable inputs and outputs. Using LIMLVL (for limit inputs) and INLVL (for triggers and I/O brick inputs), you can define the logic levels of the programmable inputs as positive or negative. The 6K product defaults to an input level of zero volts as its active level (referred to as “active low”); thus, a “1” will appear in a status command (TLIM & LIM, or TIN & IN) referencing an input state when the voltage level is zero volts.

Active Level Setting	State	LIM/TLIM or IN/TIN Report
Active Low, <u>the default setting</u> <ul style="list-style-type: none"> LIMLVLO for limits INLVLO for triggers/I/O bricks 	Grounded — sinking current (device drive the input is on)	1 (active)
	Not Grounded — not sinking current (device drive the input is off)	- 0 (inactive)
Active High <ul style="list-style-type: none"> LIMLVL1 for limits INLVL1 for triggers/I/O bricks 	Grounded — sinking current (device drive the input is on)	0 (inactive)
	Not Grounded — not sinking current (device drive the input is off)	- 1 (active)

Input Debounce Time

Using the INDEB command, you can change the input debounce time for programmable inputs. The debounce is the period of time that the input must be held in a certain state before the controller recognizes it. This directly affects the rate at which the inputs can change state and be recognized. The default setting is 4 ms. For example, to set the debounce for all digital inputs on I/O brick 2 to 5 ms, use the 2INDEB6 command.

Exception for Trigger Inputs: For trigger inputs that are assigned the “Trigger Interrupt” function (INFNCi-H), the debounce is instead governed by the TRGLOT setting. The TRGLOT setting applies to all trigger inputs defined as “Trigger Interrupt” inputs. The TRGLOT debounce time is the time required between a trigger’s initial active transition and its secondary active transition. This allows rapid recognition of a trigger, but prevents subsequent bouncing of the input from causing a false position capture. The default TRGLOT setting is 24 ms.

Limit Inputs. The limit inputs found on the “LIMITS/HOME” connectors are not normally debounced; however, if a limit is assigned a different function with the LIMFNC command (other than LIMFNCi-R, LIMFNCi-S, or LIMFNCi-T), the input is debounced using the INDEB setting for the on-board trigger inputs (I/O brick 0). If a I/O brick input or an onboard trigger input is assigned a limit input function (INFNCi-R, INFNCi-S, or INFNCi-T), the input will not be debounced.

“General Purpose”

- LIMFNCi-A
- INFNCi-A

This is the default function for INFNC inputs (triggers and I/O brick inputs). When an input is defined as a *General Purpose* input, the input is used as a standard input. You can then use this input to synchronize or trigger program events, through the use of the LIM or IN operator.

```

Example DEL prog1      ; Precaution: Delete a program before defining it
        DEF prog1     ; Begin definition of program prog1
        INFNC1-A      ; No function (general purpose) for trigger input 1
        INFNC2-A      ; No function (general purpose) for trigger input 2
        INFNC3-D      ; Trigger input 3 is a stop input (all axes)
        A10           ; Set acceleration
        V10           ; Set velocity
        D5            ; Set distance
        WAIT(IN=b1XX) ; Wait for onboard trigger input 1
        GO1           ; Initiate motion
        IF(IN=bX1)    ; If onboard trigger input 2
        1TFB         ; Transfer feedback device position for axis 1
        NIF           ; End IF statement
        END           ; End definition of program prog1
    
```

BCD Program Select

- LIMFNCi-B
- INFNCi-B

The *BCD program select* function allows you to execute defined programs by activating the program select inputs.

BCD program select inputs are assigned BCD weights, with the least weight on the smallest numbered input. The next BCD weight is assigned to the next input defined as a BCD input. For example, the table to the right shows the BCD weights if inputs 1-8 are configured as program select inputs.

Input No.	BCD Weight
Input 1	1
Input 2	2
Input 3	4
Input 4	8
Input 5	10
Input 6	20
Input 7	40
Input 8	80

To execute a particular program, you activate the combination of inputs to achieve the BCD weight that corresponds to the *number of the program* (see note below). For example, if inputs 1-8 are defined as BCD inputs (as in the example above), activating inputs 4 and 6 would execute program 28, activating inputs 1 and 4 would execute program 9, and so on.

Program Numbers

A program's number is determined by the order in which the program was downloaded to the controller. The number of each program stored in the controller's memory can be obtained through the TDIR command — refer to the number reported in front of each program name. When selecting programs with BCD Program Select inputs, a program is executed when the total BCD weight of the active BCD inputs equals the program's number. When selecting programs with One-to-One Program Select inputs, the program number is assigned to one specific input and is executed when that input is activated.

Before you can execute programs using the BCD program select inputs, you must first enable scanning with the INSELP1 command. Once enabled, the controller will continuously scan the BCD inputs and execute the program (by number) according to the weight of the currently active BCD inputs. After executing and completing the selected program, the controller will scan the inputs again. **NOTE:** To disable scanning, enter !INSELP0 or place INSELP0 in a program that can be selected.

The INSELP command also determines how long the BCD program select input level must be maintained before the controller executes the program. This delay is referred to as debounce time (but is not affected by the INDEB setting).

Example

```
RESET          ; Return controller to power-up conditions
ERASE          ; Erase all programs
DEF PROG1      ; Begin definition of program PROG1
TPE           ; Transfer position of encoders
END           ; End program
DEF PROG2      ; Begin definition of program PROG2
TREV          ; Transfer software revision
END           ; End program
DEF PROG3      ; Begin definition of program PROG3
TSTAT         ; Transfer statistics
END           ; End program
INFNC1-B       ; Assign onboard input 1 as a BCD program select input
INFNC2-B       ; Assign onboard input 2 as a BCD program select input
INSELP1,50    ; Enable scanning inputs, levels must be maintained for 50ms
TDIR          ; Display number and name of programs stored in memory
; response from TDIR should be similar to following:
; *1 - PROG1 USES 6 BYTES
; *2 - PROG2 USES 18 BYTES
; *3 - PROG3 USES 99 BYTES
; *32877 OF 33000 BYTES (98%) PROGRAM MEMORY REMAINING
; *500 OF 500 SEGMENTS (100%) COMPILED MEMORY REMAINING
```



The number in front of each program name is the BCD weight required to execute the program.

You can now execute the programs by activating the correct combination of inputs:

- Activate trigger input 1 (BCD weight of 1) to execute program 1 (PROG1)
- Activate trigger input 2 (BCD weight of 2) to execute program 2 (PROG2)
- Activate trigger inputs 1 & 2 (BCD weight of 3) to execute program 3 (PROG3)

Kill

- LIMFNCi-C
- INFNCi-C

When an input defined as a *Kill* input goes active:

- Motion stops on all axes (using the LHAD and LHADA decel rate).
- Program currently in progress is terminated.
- Commands currently in the command buffer are eliminated.
- Drives are left in the enabled state (@DRIVE1), unless the “disable drive on kill” function is enabled with the KDRIVE command (see description on page 48).
- If error-checking bit 6 is enabled (e.g., ERROR . 6-1), the error status is reported by bit 6 of the TERF, TER and ER commands and the error program (assigned with the ERRORP command) will be executed to respond to the error condition.

NOTE: Kill is not intended as a means to temporarily inhibit motion; use the *Pause/Continue* input function instead (LIMFNCi-E or INFNCi-E).

Stop

- LIMFNCi-<a>D
- INFNCi-<a>D

An input defined as a *Stop* input will stop motion on one or all axes (see examples below).

Deceleration is controlled by the programmed AD/ADA deceleration ramp. If error-checking bit 8 is enabled (e.g., ERROR . 8-1), the error status is reported by bit 8 of the TERF, TER and ER commands and the error program (assigned with the ERRORP command) will be executed to respond to the error condition.

After the Stop input is received, further program execution is dependent upon the COMEXS command setting:

COMEXS0: (default setting) Upon receiving a stop input, motion will stop, program execution will be terminated and cannot be resumed, and every command in the buffer will be discarded (exception: an axis-specific stop input does not dump the command buffer).

COMEXS1: Upon receiving a stop input, motion will stop, program execution will pause, and all commands following the command currently being executed will remain in the command buffer (*but the move in progress will not be saved*).

You can resume program execution (but not the move in progress) by issuing an immediate Continue (!C) command or by activating a pause/continue input (i.e., a general-purpose input configured as a pause/continue input with the INFNCi-E command—see below). *You cannot resume program execution while the move in progress is decelerating.*

COMEXS2: Upon receiving a stop input, the 6K responds as it does in the COMEXS0 mode, with the exception that you can still use the program-select inputs to select programs (INSELP value is retained). The program-select input functions are: BCD select (INFNCi-B or LIMFNCi-B; see page 82), and one-to-one select (INFNCi-P or LIMFNCi-P; see page 88). For further details on program selection with inputs, see INFNC (or LIMFNC) and INSELP.

Example 1 (stop all axes): The 3INFNC2-D command assigns the “stop” function to the 2nd input on SIM1 of I/O brick 3. When this input is activated, all axes will stop.

Example 2 (stop a specific axis): The 3INFNC2-4D command assigns the “stop” function to the 2nd input on SIM1 of I/O brick 3, but makes it specific only to the motion on axis 4. When this input is activated, only the motion on axis 4 axes will stop.

Pause/Continue

- LIMFNCi-E
- INFNCi-E

An input defined as a *Pause/Continue* input will affect motion and program execution depending on the COMEXR command setting, as described below. In both cases, when the input is activated, the current command being processed will be allowed to finish executing before the program is paused.

COMEXR0: Upon receiving a pause input, only program execution will be paused; any motion in progress will continue to its predetermined destination. Releasing the pause

input or issuing a !C command will resume program execution.

COMEXR1: Upon receiving a pause input, both motion and program execution will be paused; the motion stop function is used to halt motion. Releasing the pause input or issuing a !C command will resume motion and program execution. *You cannot resume program execution while the move in progress is decelerating.*

User Fault

- LIMFNCi-F
- INFNCi-F

An input defined as a *User Fault* input acts as an immediate Kill (!K) command, stopping motion on all axes and terminating program execution. Motion is stopped at the rate set with the hard limit (LHAD & LHADA) commands.

If error-checking bit 7 is enabled (e.g., ERROR. 7-1), then a user fault input will cause a branch to the ERRORP error program (for more information, see *Error Handling* on page 30) and the occurrence of a user fault input will be reported by error bit 7 (see TERF, TER and ER commands).

Trigger Interrupt (INFNCi-H)

This function is available only for onboard trigger inputs. Any trigger input can be defined as a Trigger Interrupt input and can be used for these functions:

- Position Capture (see below)
- Special trigger functions assigned with the TRGFN command (see below)
- Registration (see discussion on page 155)

Notes About Trigger Interrupt Inputs

- The trigger interrupt input is debounced for 24 ms (default) before another input on the same trigger is recognized. If your application requires a different debounce time, you can change it with the TRGLOT command (see *Input Debounce Time* on page 81).
- When configured as Trigger Interrupts, the triggers cannot be affected by the input enable (INEN) command.
- Status: Use the TTRIG and TRIG commands to ascertain if a trigger interrupt input has been activated. TTRIG displays the status as a binary report, and TRIG is an assignment/comparison operator for using the status information in a conditional expression (e.g., in an IF statement). Each TTRIG/TRIG bit is cleared when the respective captured position value is read with the PCC, PCE, PCME, PCMS, TPCC, TPCE, TPCME, or TPCMS commands, but the position information is still available from the respective register until it is overwritten by a subsequent position capture by the same trigger input.

Position Capture

Each axis has two dedicated trigger inputs, referred to as “TRIG-nA” and “TRIG-nB” (n = number of the axis). These trigger inputs are located on the 25-pin “TRIGGERS/OUTPUTS” connector. When either trigger input (TRIG-nA or TRIG-nB) for a particular axis is assigned the Trigger Interrupt function, activating the input performs a *hardware capture* of that axis’ position. If the axis is used as a follower in Following, activating the trigger also performs an *interpolated capture* of the associated master axis position.

An additional trigger, labeled “TRIG-M”, can be used to perform a hardware capture of the Master Encoder (the encoder connected to the “MASTER ENCODER” connector), as well as the position of all axes (encoder position on servo axes; commanded or encoder position for steppers, depending on the ENCCNT setting). To assign TRIG-M as a trigger interrupt input, use the INFNC17-H command.

When a Trigger Interrupt input is activated, the controller captures the relevant positions and stores them in registers that are available at the next system update (2 ms) through the use of these transfer and assignment/comparison commands:

Captured Information	Transfer	Assignment/Comparison	Offset *	Scale Factor **
Commanded position	TPCC	PCC	PSET	SCLD
Encoder position	TPCE	PCE	PSET	SCLD
Master encoder position	TPCME	PCME	PMESET	SCLMAS
Master cycle position	TPCMS	PCMS	PSET	SCLMAS

* Captured values are offset by any existing PSET or PMESET offset.


** If scaling is enabled, the captured position is scaled by SCLD or SCLMAS.

Notes About Position Capture

- **Hardware Capture:** The encoder position is captured within ± 1 encoder count. The commanded position capture accuracy is ± 1 count.
- **Interpolated Capture:** There is a time delay of up to 50 μ s between activating the trigger interrupt input and capturing the position; therefore, the accuracy of the captured position is equal to 50 μ s multiplied by the velocity of the axis at the time the input was activated.
- **Servo vs. Stepper.** The nature of the axis position captured with a Trigger Interrupt input can be different, depending on whether the axis is configured for servo or stepper operation (AXSDEF command setting). For servo axes, both the commanded and encoder position for the axis are captured. Analog input feedback cannot be captured. For stepper axes, if the ENCCNT command is set to ENCCNT0 (default condition), only the commanded position is captured. If ENCCNT1 mode is enabled, only the encoder position is captured.

Trigger Functions

The Trigger Functions command (TRGFN) allows you to assign additional functions to trigger inputs that have been defined as trigger interrupt inputs with the INFNCi-H command. These trigger functions are cleared once the function is triggered. Command syntax is:



- “Conditional GO” Function (aTRGFNc1x): Suspend execution of the next start-motion command until the specified trigger input goes active. Start-motion commands are:
 - GO (standard command to begin motion)
 - GOL (begin linear interpolated motion)
 - FSHFC (begin continuous shift – for Following motion)
 - FSHFD (begin preset shift – for Following motion)

Axis status bit 26 (reported with TASF, TAS, or AS) is set to one (1) when there is a pending “Conditional GO” condition initiated by a TRGFN command; this bit is cleared when the trigger is activated or when a stop command or a kill command is issued. If you need execution to be triggered by other factors (e.g., input state, master position, encoder position, etc.) use the GOWHEN command; see GOWHEN command or page 159 for details.

- “New Master Cycle” Function (aTRGFNcx1): This is equivalent to executing the FMCNEW command. When the specified trigger input goes active, the controller begins a new Following master cycle. Refer to the FMCNEW command or to page 184 for more on master cycles.

Code Examples

```
INFNC2-H      ; Assign trigger 1B (onboard input 2) to
              ; function as a trigger interrupt input.
1TRGFNBx1    ; When trigger 1B goes active, axis 1 will begin
              ; a new master cycle
2TRGFNB1     ; When trigger 2B goes active, axis 2 will execute
              ; the move commanded with the GO command.
GO01         ; The move on axis 2 is commanded, but will not
```

; execute until trigger 2B becomes active.

Registration

If registration is enabled (with the RE command), activating a trigger interrupt input will initiate registration move(s) defined with the REG command. Refer to page 155 for details on the Registration feature.

Alarm Event

- LIMFNCi-I
- INFNCi-I

An input specified as an *Alarm Even* input will cause the 6K controller to set an Alarm Event in the Communications Server over the Ethernet interface. You must first enable the Alarm checking bit for this input-driven alarm (INTHW. 23-1). For details on Communications Server features, see the *Com6srvr User's Guide for Gemini & 6K Series Products*.

Jogging the Motor

- LIMFNCi-aJ
- LIMFNCi-aK
- LIMFNCi-aL
- INFNCi-aJ
- INFNCi-aK
- INFNCi-aL

In some applications, you might want to manually move (*jog*) the load. You can configure these jog-related input functions:

“J”Jog in the positive counting direction when the input is active, stop when the input is inactive.

“K”Jog in the negative counting direction when the input is active, stop when the input is inactive.

“L”Select the high (JOGVH) or low (JOGVL) velocity setting for jog motion. Activating the input selects high velocity, deactivating the input selects low velocity.

The jog profile is defined with these commands listed below. **NOTE:** If scaling is enabled (SCALE1) the velocity is scaled by SCLV and accel/decel is scaled by SCLA.

JOGVHHigh velocity range for jogging. The high velocity is used when the jogging speed-select input (configured with INFNCi-aL) is active.

JOGVLLow velocity range for jogging. The low velocity is used when the jogging speed-select input (configured with INFNCi-aL) is inactive.

JOGA.....Jog acceleration

JOGAAJog acceleration (s-curve profile)

JOGADJog deceleration

JOGADA.....Jog deceleration (s-curve profile)

Once you set up the jog functions and move profile, you can attach a switch to the designated jog inputs and perform jogging. (Jog motion will not occur unless Jog Mode is enabled with the JOG command.) The example below shows you how to define a program to set up jogging.

Example

Step 1 Define program for jog setup:

```
DEF prog1      ; Begin definition of program prog1
JOGA25        ; Jog acceleration to 25 units/sec/sec
JOGAD25       ; Jog deceleration to 25 units/sec/sec
JOGVL.5       ; Low-speed jog velocity to 0.5 units/sec
JOGVH5        ; High-speed jog velocity to 5 units/sec
INFNC1-1J     ; Trigger input 1 is a positive-direction jog input, axis 1
INFNC2-1K     ; Trigger input 2 is a negative-direction jog input, axis 1
INFNC3-1L     ; Trigger input 3 is a speed-select input, axis 1
JOG1          ; Enable Jog function for axis 1
END           ; End program definition
```

Step 2 Download and run the prog1 program.

Step 3 Activate trigger input 1 to move the load on axis 1 in the positive direction at a velocity of 0.5 units/sec (until trigger input 1 is released). Deactivate the input to stop the axis.

- Step 4** Activate trigger input 2 to move the load on axis 1 in the negative direction at a velocity of 0.5 units/sec (until trigger input 2 is released). Deactivate the input to stop the axis.
- Step 5** Activate trigger input 3 to switch to high-speed jogging.
- Step 6** Repeat steps 3 and 4 to perform high-speed jogging at the JOGVH value (5 rps).

Joystick Functions

- LIMFNCi-M
- LIMFNCi-N
- LIMFNCi-O
- INFNCi-M
- INFNCi-N
- INFNCi-O

As part of the joystick setup process, you can configure programmable inputs to serve the joystick input functions listed below. Full details on joystick setup and operation are provided on page 114.

“M”The *Joystick Release* input signals the controller to end joystick operation and resume program execution with the next statement in your program. When the input is open (high, sinking current), the joystick mode is disabled (joystick mode can be enabled only if the input is closed, and only with the JOY command). When the input is closed (low, not sinking current), joystick mode can be enabled with the JOY command. The general process of using Joystick mode is:

1. Assign the “Joystick Release” input function to a programmable input.
2. At the appropriate place in the program, enable joystick control of motion (with the JOY command). (Joystick mode cannot be enabled unless the "Joystick Release" input is closed.) When the JOY command enables joystick mode for the affect axes, program execution stops on those axes (assuming the Continuous Command Execution Mode is disabled with the COMEXCØ command).
3. Use the joystick to move the axes as required.
4. When you are finished using the joystick, open the “Joystick Release” input to disable the joystick mode. This allows program execution to resume with the next statement after the initial JOY command that started the joystick mode.

“N”The *Joystick Axis Select* input allows you to control two pairs of axes with one joystick. Use the JOYAXH and JOYAXL commands to assign analog inputs to control specific axes. Opening the Axis Select input (input is high, sinking current) selects the JOYAXH configuration. Closing the Axis Select input (input is low, not sinking current) selects the JOYAXL configuration.

“O”The *Joystick Velocity Select* input allows you to select the velocity for joystick motion. The JOYVH and JOYVL commands establish the high-speed velocity and the low-speed velocity, respectively. Opening the Velocity Select input (input is high, sinking current) selects the JOYVH configuration. Closing the Velocity Select input (input is low, not sinking current) selects the JOYVL configuration. The high range could be used to quickly move to a location, the low range could be used for accurate positioning. **NOTE:** When this input is not connected, joystick motion always uses the JOYVL velocity setting.

One-to-One Program Select

- LIMFNCi-iP
- INFNCi-iP

An input defined as a *One-to-One Program Select* input is assigned to execute one specific program. The targeted program is reference by its *number* (see note).

Program Numbers

A program's number is determined by the order in which the program was downloaded to the controller. The number of each program stored in the controller's memory can be obtained through the TDIR command — refer to the number reported in front of each program name. When selecting programs with One-to-One Program Select inputs, the program number is assigned to one specific input and is executed when the input is activated (see example below).

Before you can execute programs using the One-to-One program select inputs, you must first enable scanning with the INSELP2 command. Once enabled, the controller will continuously scan the inputs and execute the program (by number) according to the program number assigned to the input. After executing and completing the selected program, the controller will scan the inputs again. **NOTE:** To disable scanning, enter !INSELPØ or place INSELPØ in a program that can be selected.

The INSELP command also determines how long the program select input level must be maintained before the controller executes the program. This delay is referred to as debounce time (but is not affected by the INDEB setting).

```
Example  RESET          ; Return controller to power-up default conditions
        DEF proga      ; Begin definition of program proga
        TFB           ; Transfer position of feedback devices
        END           ; End program
        DEF progb     ; Begin definition of program progB
        TREV          ; Transfer software revision
        END           ; End program
        DEF progC     ; Begin definition of program progC
        TSTAT         ; Transfer statistics
        END           ; End program
        TDIR          ; Response should show:  *1 - PROGA USES 36 BYTES
        ;                                           *2 - PROGB USES 70 BYTES
        ;                                           *3 - PROGC USES 133 BYTES
        INFNC4-1P     ; Trigger input 4 (TRIG-2B) will select proga
        INFNC5-2P     ; Trigger input 5 (TRIG-3A) will select progB
        INFNC6-3P     ; Trigger input 6 (TRIG-3B) will select progC
        INSELP2,50    ; Enable scanning of inputs with a strobe time of 50 ms
```

You can now execute programs by making a contact closure from an input to ground to activate the input:

- Activate trigger input 4 to execute program 1 (proga)
- Activate trigger input 5 to execute program 2 (progb)
- Activate trigger input 6 to execute program 3 (progC)

Program Security

- LIMFNCi-Q
- INFNCi-Q

Once an input is assigned the *Program Security* function, the Program Security feature is enabled. The program security feature denies you access to the DEF, DEL, ERASE, MEMORY, LIMFNC and INFNC commands until you activate the Program Security input. Being denied access to these commands effectively restricts altering the user memory allocation. If you try to use these commands when program security is active (program security input is not activated), you will receive the error message *ACCESS DENIED.

For example, once you issue the 2INFNC7-Q command, input 7 on I/O brick 2 (2IN.7) is assigned the program security function and access to the DEF, DEL, ERASE, MEMORY, LIMFNC and INFNC commands will be denied until you activate 2IN.7.

To regain access to the DEF, DEL, ERASE, MEMORY, LIMFNC or INFNC commands without the use of the program security input, you must issue the INEN command to disable the program security input, make the required user memory changes, and then issue the INEN command to re-enable the input. For example, if input 3 on brick 2 is assigned as the Program Security input, use 2INEN.3=1 to disable the input and leave it activated, make the necessary user memory changes, and then use 2INEN.3=E to re-enable the input.

NOTE: If you wish the Program Security feature to be enabled on power-up, place the INFNCi-Q or LIMFNCi-Q command in the start-up program (STARTP).

Limit Functions

- LIMFNCi-aR
- LIMFNCi-aS
- LIMFNCi-aT
- INFNCi-aR
- INFNCi-aS
- INFNCi-aT

The inputs on the “LIMITS/HOME” connectors are factory-configured with the LIMFNC command to function as end-of-travel and home limits for the respective axes (see illustration on page 76). The limit functions are:

“R” *Positive-Direction End-of-Travel Limit* input, axis specific.

“S” *Negative-Direction End-of-Travel Limit* input, axis specific.

“T” *Home Limit* input, axis specific.

If you intend to use digital inputs on an external I/O brick as limit inputs:


1. Assign the limit function to the external input with the INFNC command. For example, 1INFNC9-1R assigns the “axis 1 positive end-of-travel limit” function to the 1st input on SIM2 (I/O point 9) of I/O brick 1.
2. Reassign the respective “LIMITS” input to a non-limit function with the LIMFNC command. For example, LIMFNC1-A assigns the “general-purpose input” function to limit input 1 (normally assigned the “axis 1 positive end-of-travel limit” function).

NOTE: Once a trigger or I/O brick input is assigned a limit function, it is no longer debounced (INDEB has no effect), and it must be enabled/disabled with the LH command instead of the INEN command.

Output Functions

The 6K product provides programmable digital outputs, found on the “TRIGGERS/OUTPUTS” connect. Additional digital outputs can be installed on expansion I/O bricks (see example on page 78).

You can turn the controller's programmable outputs on and off with the Output (OUT, POUT or OUTALL) commands, or you can use the Output Function (OUTFNC) command to configure them to activate based on seven different situations. The OUTFNC syntax is as follows:



Letter Designator	Function
A.....	General-purpose output (default function)
<a>B.....	Moving/not moving (axis designator optional)
C.....	Program in progress
<a>D.....	Hardware or software end-of-travel limit encountered (axis designator optional)
<a>E.....	Stall indicator (axis designator optional) — stepper axes only
F.....	Fault indicator (indicates drive fault input or user fault input is active)
G.....	Position error exceeds maximum limit set with <code>SMPER</code> — servo axes only
H.....	Output on position

NOTES

- **Multi-tasking:** If the `OUTFNC` command does not include the task identifier (%) prefix, the function affects the task that executes the `OUTFNC` command. “Program in progress” (function C) is only function that can be directed to a specific task with %. Multiple tasks can share the same output, but the output can only be assigned one function.
- **Limit of 32 output functions:** You can assign a maximum of 32 `OUTFNC` functions. This excludes function A (“general-purpose”).

Output Status

Below is a list of the status commands you can use to ascertain the current state and/or defined function of the outputs.

- Status display commands:
 - `TIO`..... I/O brick configuration (which SIMs are present, including sinking/sourcing)
 - `OUTFNC`..... Active state and programmed function of all onboard outputs
 - `OUTFNCi` Same as `OUTFNC` display, but only for the output number (“i”)
 - `OUTFNC`..... Active state and programmed function of all outputs on I/O brick B
 - `OUTFNCi` Same as `OUTFNC` display, but only for the output number (“i”) on I/O brick B
 - `TOUT` Hardware state of all onboard outputs (binary report);
use `TOUT.i` to check the state of only one output (“i”)
 - `TOUT` Hardware state of all outputs (binary report) on I/O brick B;
use `TOUT.i` to check the state of only one output (“i”) on brick B

- Status assignment/comparison operator: *
 - OUTHardware state (binary) of all onboard outputs;
 - use OUT . i to check the state of only one output (“i”)
 - OUTHardware state (binary) of all outputs on I/O brick B;
 - use OUT . i to check the state of only one output (“i”) on I/O brick B
- * The purpose of the OUT operator is to use the state of the outputs as a basis for conditional statements (IF, REPEAT, WHILE, GOWHEN, etc.) or for binary variable assignments (VARB).

Output Active Levels

Using OUTLVL, you can define the logic levels of the programmable outputs as positive or negative. OUTLVL0 selects active low (default setting); OUTLVL1 selects active high.

Onboard Outputs (on the “TRIGGERS/OUTPUTS” connector):

OUTLVL Setting	OUT State *	Factory Default (use internal 24V)	Use an external supply at VINref	OUT/TOUT status
OUTLVL0 (default)	OUT1	Sinking current	Sinking current	1
OUTLVL0 (default)	OUT0	Sourcing 24V @ 0.7mA	Sourcing VINref	0
OUTLVL1	OUT1	Sourcing 24V @ 0.7mA	Sourcing VINref	1
OUTLVL1	OUT0	Sinking current	Sinking current	0

* The output is “active” when it is commanded by the OUT, OUTP, or POUT command (for example, OUTxx1 activates output 3).

Outputs on Expansion I/O Bricks:

- Sinking vs. Sourcing Outputs. On power up, the 6K controller auto-detects the type of output SIM installed on each external I/O brick, and automatically changes the OUTLVL setting accordingly. If sinking (NPN) outputs are detected, OUTLVL is set to active low (OUTLVL0); if sourcing (PNP) outputs are detected, OUTLVL is set to active high (OUTLVL1).
- Disconnect I/O Brick. If the I/O brick is disconnected (or if it loses power), the controller will perform a kill (all tasks) and set error bit 18. (If you disable the “Kill on I/O Disconnect” mode with KIOENØ, the 6K will not perform the kill.) The controller will remember the brick configuration (volatile memory) in effect at the time the disconnection occurred. When you reconnect the I/O brick, the controller checks to see if anything changed (SIM by SIM) from the state when it was disconnected. If an existing SIM slot is changed (different SIM, vacant SIM slot, or jumper setting), the controller will set the SIM to factory default INEN and OUTLVL settings. If a new SIM is installed where there was none before, the new SIM is auto-configured to factory defaults.
- Relationships:

Output Type	OUTLVL Setting	OUT State *	Current	OUT/TOUT status	LED
NPN (sinking)	OUTLVL0 (default)	OUT1	Sinking current	1	ON
NPN	OUTLVL0 (default)	OUT0	No current flow	0	OFF
NPN	OUTLVL1	OUT1	No current flow	1	OFF
NPN	OUTLVL1	OUT0	Sinking current	0	ON
PNP (sourcing)	OUTLVL0	OUT1	No current flow	1	OFF
PNP	OUTLVL0	OUT0	Sourcing current	0	ON
PNP	OUTLVL1 (default)	OUT1	Sourcing current	1	ON
PNP	OUTLVL1 (default)	OUT0	No current flow	0	OFF

* The output is “active” when it is commanded by the OUT, OUTP, or POUT command (for example, OUTxx1 activates output 3).

“General Purpose”
(OUTFNCi-A)

The default function for the outputs is *General Purpose*. As such, the output is used as a standard output, turning it on or off with the OUT, OUTP or OUTALL commands to affect processes external to the controller. To view the state of the outputs, use the TOUT command. To use the state of the outputs as a basis for conditional branching or looping statements (IF, REPEAT, WHILE, etc.), use the [OUT] command.

**Moving/Not Moving
(In Position)**
(OUTFNCi-<a>B)

When assigned the *Moving/Not Moving* function, the output will activate when the axis is commanded to move. As soon as the move is completed, the output will change to the opposite state.

Servo Axes: If the target zone mode is enabled (STRGTE1), the output will not change state until the move completion criteria set with the STRGTD and STRGTV commands has been met. (For more information, see the *Target Zone* section on page 74.) In this manner, the Moving/Not Moving output functions as an *In Position* output.

Example

The code example below defines onboard outputs 1 and 2 as *General Purpose* outputs and output 3 as a *Moving/Not Moving* output. Before the motor moves 4,000 steps, output 1 turns on and output 2 turns off. These outputs remain in this state until the move is completed, then output 1 turns off and output 2 turns on. While the motor/load is moving, output 3 remains on.

```
SCALE0      ; Disable scaling
MC0         ; Set axis 1 to preset positioning mode
MA0         ; Select incremental positioning mode
A10        ; Set axis 1 acceleration to 10
V5          ; Set axis 1 velocity to 5
D4000      ; Set axis 1 distance to 4,000 counts
OUTFNC1-A   ; Set onboard output 1 as a general purpose output
OUTFNC2-A   ; Set onboard output 2 as a general purpose output
OUTFNC3-1B  ; Set onboard output 3 as axis 1 Moving/Not Moving output
OUT10       ; Turn onboard output 1 on and output 2 off
GO1         ; Initiates axis 1 move
OUT01       ; Turn onboard output 1 off and output 2 on
```

**Program in
Progress**
(OUTFNCi-C)

When assigned the *Program in Progress* function, the output will activate when a program is being executed. After the program is finished, the output's state is reversed. The action of executing a program is also reported with system status bit 3 (see TSSF, TSS and SS commands).

Limit Encountered
(OUTFNCi-<a>D)

When assigned the *Limit Encountered* function, the output will activate when a hard or soft end-of-travel limit has been encountered.

If a hard or soft limit is encountered, you will not be able to move the motor/load in that same direction until you clear the limit by changing direction (D) and issuing a GO command. (An alternative is to disable the limits with the LHØ command, but this is recommended only if the motor is not coupled to the load.) The event of encountering an end-of-travel limit is also reported with axis status bits 15-18 (see TASF, TAS and AS commands, summary on page 226).

Stall Indicator
(OUTFNCi-<a>E)
Stepper Axis Only

When assigned the *Stall Indicator* function, the output will activate when a stall is detected. To detect a stall, you must first connect an encoder and enable stall detection with the ESTALL1 command. Refer to *Encoder-Based Stepper Operation* on page 64 for further discussion on stall detection.

Fault Output
(OUTFNCi-F)

When assigned the *Fault Output* function, the output will activate when either the user fault input or the drive fault input becomes active. The user fault input is a general-purpose input defined as a user fault input with the LIMFNCi-F or INFNCi-F command (see page 83).

Make sure the drive fault input is enabled (DRFEN) and the drive fault active level (DRFLVL) is appropriate for the drive you are using.

**Maximum Position
Error Exceeded**
(OUTFNCi-<a>G)
Servo Axes Only

When assigned the *Maximum Position Error Exceeded* function, the output will activate when the maximum allowable position error, as defined with the SMPER command, is exceeded.


The position error (TPER) is defined as the difference between the commanded position (TPC) and the actual position as measured by the feedback device (TFB). When the maximum position error is exceeded (usually due to lagging load, instability, or loss of position feedback), the controller shuts down the drive and sets error status bit 12 (reported by the TERF, TER and ER commands if bit 12 of the ERROR command is enabled).

NOTE

If the SMPER command is set to zero (SMPERØ — the default value), the position error is not monitored; thus, the *Maximum Position Error Exceeded* function will not be usable.

Output on Position (OUTFNCi-H)

The *Output on Position* feature activates the designated output when the axis has reached a specified position. To use this feature, you must first assign the Output on Position function to the respective output, and define the Output on Position characteristics with the `OUTP` command. The `OUTP` command correlates directly to a specific onboard programmable output and axis (e.g., `OUTPA` correlates to output 1 and axis 1, `OUTPB` correlates to output 2 and axis 2, and so on):



Sample Code for Setup

In this example, the user has a two-axis application and wants to turn on output when axis 1 (servo) reaches encoder position 50,000 and turn on another output when axis 2 (stepper) reaches commanded position 30,000. Both outputs must remain on for 50 milliseconds.

```
AXSDEF10           ; Define axis 1 as servo, axis 2 as stepper
SFB1              ; Select encoder feedback for axis 1
OUTFNC1-H         ; Define onboard output 1 as an "output on
                  ; position" output
OUTFNC2-H         ; Define onboard output 2 as an "output on
                  ; position" output
OUTPA1,0,+50000,50 ; Turn on onboard output 1 for 50 ms when the
                  ; encoder position of axis 1 is > or =
                  ; absolute position +50,000
OUTPB1,1,+30000,50 ; Turn on onboard output 2 for 50 ms when the
                  ; axis 2's commanded position reaches > or =
                  ; incremental position 30,000 (since the last GO)
```

Notes about Output On Position

- On servo axes, this feature can be used only with encoder feedback and is not operational with ANI (analog input) feedback.
 On stepper axes, this feature can be based on commanded position or encoder position, depending on the `ENCCNT` setting for the particular axis (default is `ENCCNT0`, which uses the commanded position).
- The output activates only during motion; thus, issuing a `PSET` command to set the absolute position counter to activate the output on position will not turn on the output until the next motion occurs.

Variable Arrays (*teaching* variable data)

More on variables:
see page 18.

Variable data arrays provide a method of storing (*teaching*) variable data and later using the stored data as a source for motion program parameters. The variable data can be any value that can be stored in a numeric (VAR or VARI) variable (e.g., position, acceleration, velocity, etc.). The variable data is stored into a *data program*, which is an array of *data elements* that have a specific address from which to write and read the variable data. Data programs do not contain 6K Series commands.

The information below describes the principles of using the data program in a teach-type application. Following that is an application example in which the joystick is used to teach position data to be used in a motion program.

Basics of Teach-Data Applications

The basic process of using a data program for data teaching applications is as follows:

1. Initialize a data program.
2. Teach (store/write) variable data into the data program.
3. Read the data elements from the data program into a motion program.

1. Initialize a Data Program

This is accomplished with the DATSIZ command. The DATSIZ command syntax is DATSIZ*i*<, *i*>. The first integer (*i*) represents the number of the data program (1 - 50). You can create up to 50 separate data programs. The data program is automatically given a specific program name (DATP*i*). The second integer represents the total number of data elements (up to 6,500) you want in the data program. Upon issuing the DATSIZ command, the data program is created with all the data elements initialized with a value of zero.

The data program has a tabular structure, where the data elements are stored 4 to a line. Each line of data elements is called a *data statement*. Each element is numbered in sequential order from left to right (1 - 4) and top to bottom (1 - 4, 5 - 8, 9 - 12, etc.). You can use the TPROG DATP*i* command (“*i*” represents the number of the data program) to display all the data elements of the data program.

For example, if you issue the DATSIZ1, 13 command, data program 1 (called DATP1) is created with 13 data elements initialized to zero. The response to the TPROG DATP1 command is depicted below. Each line (*data statement*) begins with DATA=, and each data element is separated with a comma.

```
*DATA=+0.0, +0.0, +0.0, +0.0
*DATA=+0.0, +0.0, +0.0, +0.0
*DATA=+0.0, +0.0, +0.0, +0.0
*DATA=+0.0
```

Each data statement, comprising four data elements, uses 43 bytes of memory. The memory for each data statement is subtracted from the memory allocated for user programs (see MEMORY command).

2. Teach the Data to the Data Program

The data that you wish to write to the data elements in the data program must first be placed into numeric variables (VAR). Once the data is stored into numeric variables, the data elements in the data program can be edited by using the Data Pointer (DATPTR) command to move the data pointer to that element, and then using the Data Teach (DATTECH) command to write the datum from the numeric variable into the element.

When the DATSIZ command is issued, the internal data pointer is automatically positioned to data element 1. Using the default settings for the DATPTR command, the numeric variable data is written to the data elements in sequential order, incrementing one by one. When the last data element in the data program is written, the data pointer is automatically set to data element 1 and a warning message (*WARNING: POINTER HAS WRAPPED AROUND TO DATA POINT 1) is displayed. The warning message does not interrupt program execution.

The DATPTR command syntax is `DATPTRi, i, i`. The first integer (i) represents the data program number (1 through 50). The second integer represents the number of the data element to point to (1 through 6500). The third integer represents the number of data elements by which the pointer will increment after writing each data element from the DATTECH command, or after recalling a data element with the DAT command.

The DATTECH command syntax is `DATTECHi<, i, i, i>`. Each integer (i) represents the number of a numeric variable. The value of the numeric variable will be stored into the data element(s) of the currently active data program (i.e., the program last specified with the last DATSIZ or DATPTR command). As indicated by the number of integers in the syntax, the maximum number of variable values that can be stored in the data program per DATTECH command is 4. Each successive value from the DATTECH command is stored to the data program according to the pattern established by the third integer of the DATPTR command.

As an example, suppose data program 1 is configured to hold 13 data elements (DATSIZ1, 13), the data pointer is configured to start at data element 1 and increment 1 data element after every value stored from the DATTECH command (DATPTR1, 1, 1), and the values of numeric variables 1 through 3 are already assigned (VAR1=2, VAR2=4, VAR3=8). If you then enter the DATTECH1, 2, 3 command, the values of VAR1 through VAR3 will be assigned respectively to the first three data elements in the data program, leaving the pointer pointing to data element 4. The response to the TPROG DATP1 command would be as follows (the text is highlighted to illustrate the final location of the data pointer after the DATTECH1, 2, 3 command is executed):

```
*DATA=+2.0, +4.0, +8.0, +0.0
*DATA=+0.0, +0.0, +0.0, +0.0
*DATA=+0.0, +0.0, +0.0, +0.0
*DATA=+0.0
```

If you had set the DATPTR command to increment 2 data elements after every value from the DATTECH command (DATPTR1, 1, 2), the data program would be filled differently and the data pointer would end up pointing to data element 7:

```
*DATA=+2.0, +0.0, +4.0, +0.0
*DATA=+8.0, +0.0, +0.0, +0.0
*DATA=+0.0, +0.0, +0.0, +0.0
*DATA=+0.0
```

3. Recall the Data from the Data Program

After storing (*teaching*) your variables to the data program, you can use the DATPTR command to point to the data elements and the DATi (“i” = data program number) data assignment command to read the stored variables to your motion program. *You cannot recall more than one data element at a time; therefore, if you want to recall the data in a one-by-one sequence, the third integer of the DATPTR command must be a 1 (this is the default setting).*

Summary of Related 6K Series Commands

- DATSIZ Establishes the number of data elements a specific data program is to contain. A new DATP_i program name is automatically generated according to the number of the data program (*i* = 1 through 50). The memory required for the data program is subtracted from the memory allocated for user programs (see MEMORY command).
- DATPTR Moves the data pointer to a specific data element in any data program. This command also establishes the number of data elements by which the pointer increments after writing each data element from the DATTCB command and after recalling each data element with the DAT command.
- DATTCB Stores the variable data into the data program specified with the last DATSIZ or DATPTR command. After the data is stored, the data pointer is incremented the number of times entered in the third integer of the DATPTR command. *The data must first be assigned to a numeric variable before it can be taught to the data program.*
- TDPTR Responds with a 3-integer status report (*i*, *i*, *i*): First integer is the number of the active data program (the program specified with the last DATSIZ or DATPTR command); Second integer is the location number of the data element to which the data pointer is currently pointing; Third integer is the increment set with the last DATPTR command.
- [DPTR] ... From the currently active data program, uses the number of the data pointer's location in a numeric variable assignment operation or a conditional statement operation.
- [DATP_i] . The name of the data program created after issuing the DATSIZ command. The integer (*i*) represents the number of the data program. Data programs can be deleted just like any other user program (e.g., DEL DATP1).
- [DAT_i] ... From the data program specified with *i*, assigns the numeric value of the data element (currently pointed to by the data pointer) to a specified variable parameter in a 6K series command (e.g., D (DAT3) , (DAT3)).

Teach-Data Application Example

In this example, 2 axes (axis 1 and axis 2) of a 6K Series controller are used to move a 2-axis stage. This example illustrates a common method of teaching a path by using the joystick to move the load into position, teach the position (triggered by the Joystick Release input), then move to the next position. Five positions will be taught from each axis (2 axes at one trigger), for a total of 10 data elements in the data program. After all 10 positions are taught to the data program, the controller will automatically move both axes to a home position, move to each position that was taught, and then return to the home position.

For the sake of brevity, this example is limited to teaching 10 position data points; however, in a typical application, many more points would be taught. Also, it is assumed that end-of-travel and home limits are wired and a homing move has been programmed.

What follows is a suggested method of programming the controller for this application. To accomplish the teach application, a program called MAIN is created, comprising three subroutines: SETUP (to set up for teaching data to the data program), TEACH (to teach the positions), and DOPATH (to implement a motion program based on the positions taught).

The joystick operation in this example is based on using an analog inputs (ANI) SIM on an expansion I/O brick. The ANI SIM is in slot 2 of I/O brick 1 and inputs 1 and 2 are used to control axes 1 and 2, respectively. A digital input SIM is installed in slot 1 of I/O brick 1, and input 1 on that SIM is assigned the Joystick Release function to trigger the position teach operation.

Step 1 Initialize a Data Program.

```
DEL DATP1          ; Delete data program 1 (DATP1) in preparation for
                  ; creating a new data program 1
DATSIZ1,10        ; Create data program 1 (named DATP1) with an
                  ; allocation of 10 data elements. Each element is
                  ; initialized to zero.
```

Step 2 Define the SETUP Subroutine. The SETUP subroutine need only run once.

```
DEF SETUP          ; Begin definition of the subroutine called SETUP
1INFNC1-M         ; Assign digital input 1 on SIM 2 (I/O point 1) of
                  ; I/O brick 1 to function as a "Joystick Release" input.
JOYVH3,3          ; Set the maximum velocity (3 units/sec) that axes 1
                  ; and 2 can achieve when the joystick is at full
                  ; deflection
JOYAXH1-9,1-10    ; Assign ANI input 1 on SIM 2 (I/O point 9) of I/O
                  ; brick 1 to control axis 1; assign ANI input 2 on
                  ; SIM 2 (I/O point 10) of I/O brick 1 to control
                  ; axis 1
VAR1=0            ; Initialize variable 1 equal to zero
VAR2=0            ; Initialize variable 2 equal to zero
DRIVE11          ; Enable the drives for both axes
MA11             ; Enable the absolute positioning mode for both axes
END              ; End definition of the subroutine called SETUP
```

Step 3 Define the TEACH Subroutine.

```
DEF TEACH          ; Begin definition of the subroutine called TEACH
HOM11             ; Home both axes (absolute position counter is set to
                  ; zero after the homing move)
DATPTR1,1,1       ; Select data program 1 (DATP1) as the current active
                  ; data program, and move the data pointer to the first
                  ; data element. After each DATTCH value is stored to
                  ; DATP1, increment the data pointer by 1 data element.
REPEAT           ; Set up a repeat/until loop
JOY11            ; Enable joystick mode on both axes. At this point,
                  ; you can start moving the axes into position with the
                  ; joystick. WHILE USING THE JOYSTICK, COMMAND PROCESSING
                  ; IS STOPPED HERE UNTIL YOU ACTIVATE THE JOYSTICK
                  ; RELEASE INPUT. Activating the joystick release input
                  ; disables the joystick mode and allows the subsequent
                  ; commands to be executed (assign the current positions
                  ; to the variables and then store the positions in the
                  ; data program).
VAR1=1PM         ; Set variable 1 equal to the position of motor 1
VAR2=2PM         ; Set variable 2 equal to the position of motor 2
DATTCH1,2        ; Store variable 1 and variable 2 into consecutive
                  ; data elements. (The first time through the
                  ; repeat/until
                  ; loop, variable 1 is stored into data element 1 and
                  ; variable 2 is stored into data element 2. The data
                  ; pointer is automatically incremented once after each
                  ; data element and ends up pointing to the third data
                  ; element in anticipation of the next DATTCH command.)
WAIT(1IN.1=b1)   ; Wait for the joystick release input to be de-activated
UNTIL(DPTR=1)    ; Repeat the loop until the data pointer wraps around
                  ; to data element 1 (data program full)
END              ; End definition of the subroutine called TEACH
```

Step 4 Define the DOPATH Subroutine.

```
DEF DOPATH          ; Begin definition of the subroutine called DOPATH
HOM11              ; Move both axes to the home position
                  ; (absolute counters set to zero)
A50,50            ; Set up the acceleration
V3,3              ; Set up the velocity
DATPTR1,1,1       ; Select data program 1 (DATP1) as the current active
                  ; data program, and set the data pointer to the first
                  ; data element. Increment the data pointer one element
                  ; after every data assignment with the DAT command.
                  ; If you wanted to move only axis 1 down the taught
                  ; path, you would set the increment (third integer)
                  ; to a 2, thus accessing only the axis 1 stored
                  ; positions.
REPEAT            ; Set up a repeat/until loop
D(DAT1), (DAT1)  ; The position of axis 1 and axis 2 are recalled into
                  ; the distance command
GO11              ; Move to the position
T.5              ; Wait for 0.5 seconds
UNTIL (DPTR=1)   ; Repeat the loop until the data pointer wraps around
                  ; to data element 1 (all data elements have been read)
HOM11            ; Move both axes back to the home position
END              ; End definition of the subroutine called DOPATH
```

Step 5 Define the MAIN Program (Include SETUP, TEACH, and DOPATH).

```
DEF MAIN          ; Begin definition of the program called MAIN
SETUP             ; Execute the subroutine called SETUP
TEACH            ; Execute the subroutine called TEACH
DOPATH           ; Execute the subroutine called DOPATH
END              ; End definition of the program called MAIN
```

Step 6 Run the MAIN Program and Teach the Positions with the Joystick.

1. Enter the MAIN command to execute the teach application program and set the joystick's *axis select* input to high.
2. Use the joystick to move to the position to be taught.
3. Once in position, activate the *joystick release* input to teach the positions. Two positions (one for each axis) are taught each time you activate the joystick release input.
4. Repeat steps 2 and 3 for the remaining four teach locations. After triggering the joystick release input the fifth time, the controller will home the axes, repeat the path that was taught, and then return both axes to the home position.

CHAPTER FOUR

Product Control Options

IN THIS CHAPTER

This chapter explains various options for controlling your 6K product:

- Safety features 100
- Overview of product control options 101
- Programmable I/O (*switches, thumbwheels, PLCs, PLC Scan Mode, etc.*) 102
- RP240 remote operator panel 107
- Joystick and analog input interface (*requires ANI SIM on expansion I/O brick*) 114
- Host computer interface 118

Safety Features



WARNING



The 6K Product is used to control your system's electrical and mechanical components. Therefore, you should test your system for safety under all potential conditions. Failure to do so can result in damage to equipment and/or serious injury to personnel.

To help ensure a safe operating environment, you should take advantage of the safety features listed below. These features must not be construed as the only methods of ensuring safety. *See Also* refers you to where you can find more in-depth information about the feature (system connections and/or programming instructions).

Feature	Description	See Also
Enable Input	The ENABLE input, found on the 6K product's screw-terminal connector, is provided as an emergency stop input to the controller. If the ENABLE input is opened (disconnected from GND), output to the drives is inhibited. For stepper axes, step pulses to the drive are immediately cut off. For servo axes, the analog output voltage between CMD+ and CMD- is clamped to almost zero, and the shutdown outputs are activated on all axes. (The clamping circuit is also connected to the watchdog timer; if the controller's microprocessor fails, the analog output voltage will be clamped.)	6K Product's <i>Installation Guide</i>
Shutdown Outputs	The controller uses the shutdown outputs to disable the attached drive if it detects a problem. Two types of relay outputs are found on the DRIVE connectors— SHTNC for drives that require a closed contact to disable the drive, and SHTNO for drives that require an open contact to disable the drive. The shutdown relay outputs are essential for smooth power-up and power-down of the system. The shutdown relay is active (disabling the drive) when no power is applied to the controller. When the controller is powered up, the shutdown relay remains active until you issue the DRIVE1111 command. CAUTION: When shut down, the drive cuts all control to the motor and allows the load to freewheel to a stop.	6K Product's <i>Installation Guide</i>
Drive Fault Inputs	The drive fault (DFT) inputs, found on the product's DRIVE connectors, allows the drives to tell the controller if they encounter a fault condition. When a drive fault occurs, the controller stops motion (at the rate set with the LHAD and LHADA commands) and terminates program execution. No drive shutdown will result unless it is initiated with an ERRORP error program. NOTE: The drive fault input state will not be checked unless you enable the drive fault input (DRFEN1) and enable the drive (DRIVE1).	6K Product's <i>Installation Guide</i>
End-of-travel Limit Inputs	End-of-travel limits prevent the load from crashing through mechanical stops, an incident that can damage equipment and injure personnel. Use hardware or software limits, as your application requires. The default hardware limits are found on the LIMITS connector. Software limits are set with the LSPOS and LSNEG commands.	<i>End-of-Travel Limits</i> (page 57)
User Fault Input	Using the INFNCi-F command or the LIMFNCi-F command, you can assign any of the programmable inputs the <i>user fault</i> function. You can then wire the input to activate when an external event, considered a <i>fault</i> by the user, occurs.	<i>Input Functions</i> (page 83)
Maximum Allowable Position Error (servos only)	A <i>position error</i> (TPER) is defined as the difference between the commanded position (TPC) and the actual position as measured by the feedback device (TFB). The maximum allowable position error is set with the SMPER command. When the maximum allowable position error is exceeded (usually due to instability or loss of position feedback), the controller shuts down the drive and sets error status bit 12 (reported by the TER command). If SMPER is set to zero (SMPER0), position error will not be monitored.	<i>Servo Setup</i> (page 67)

When any of the safety features listed above are exercised (e.g., **DFT** input is activated, etc.), the controller considers it an error condition. With the exception of the shutdown output activation, you can enable the **ERROR** command to check for the error condition, and when it occurs to branch to an assigned **ERRORP** program. Refer to *Error Handling* (page 30) for further information.

Options Overview

Stand-Alone Interface Options

After defining and storing controller programs, the controller can operate in a stand-alone fashion. A program stored in the controller can interactively prompt the user for input as part of the program (input via I/O switches, thumbwheels, RP240, joystick). A joystick can be used for situations requiring manual manipulation of the load.

Option	Application Example
RP240 (see page 107)	Grinding: Program the RP240 function keys to select certain part types, and program one function key as a GO button. Select the part you want to grind, then put the part in the grinding machine and press the GO function key. The controller will then move the machine according to the predefined program assigned to the function key selected.
Joystick (see page 114)	X-Y scanning/calibration: Enter the joystick mode and use the 2-axis joystick to position an X-Y table under a microscope to arbitrarily scan different parts of the work piece (e.g., semi-conductor wafer). You can record certain locations to be used later in a motion process (e.g., for drilling, cutting, or photographing the work piece). The <i>Variable Arrays</i> section on page 94 provides an example using the joystick to teach positions.
ANI Analog Inputs (see page 117)	Injection Molding: Use for feedback from a pressure sensor to maintain constant, programmable force. (NOTE: ANI control requires that you install an analog input SIM on an expansion I/O brick.)
Programmable inputs scanned in PLC Scan Mode (see page 104)	The PLC Scan feature allows you to create a pre-compiled program that mimics PLC functionality by scanning through the I/O faster than in a normal program run. Because the functions of PLC programs are pre-compiled, delays associated with command processing are eliminated during profile execution, allowing more rapid sequencing of actions than would be possible with programs that are not compiled. Command processing is then free to monitor other activities.

Programmable Logic Controller

The controller's programmable I/O can be connected to most PLCs. After defining and storing controller programs, the PLC typically executes programs, loads data, and manipulates inputs to the controller. The PLC instructs the controller to perform the motion segment of a total machine process.

EXAMPLE (X-Y point-to-point): A PLC controls several tools to stack and bore several steel plates at once. The controller is programmed to move an X-Y table in a pre-programmed sequence. The controller moves the load when the inputs are properly configured, signals the PLC when the load is in position, and waits for the signal to continue to the next position.

Host Computer Interface

A computer can be used to control a motion or machine process. A PC can monitor processes and orchestrate motion by sending motion commands to the controller or by executing motion programs already stored in the controller. This control might come from a BASIC or C program. A BASIC program example is provided on page 101.

Programmable I/O Devices

Programmable I/O Functions

Programmable inputs and outputs are provided to allow the controller to detect and respond to the state of switches, thumbwheels, electronic sensors, and outputs of other equipment such as drives and PLCs. Listed below are the programmable functions that can be assigned to the programmable I/O.

Programmable I/O offering differs by product. The total number of onboard inputs and outputs (trigger inputs, limit inputs, digital outputs) depends on the product. The total number of expansion inputs and outputs (analog inputs, digital inputs and digital outputs) depends on your configuration of expansion I/O bricks. To determine I/O bit pattern for your product, see page 76.

NOTE

Refer to page 75 for instructions on establishing programmable input and output functions. Instructions for connecting to I/O devices are provided in your product's *Installation Guide*.

Input Functions

Input functions can be assigned to two basic groups of programmable inputs. LIMFNC assigns functions to the limit inputs found on the "LIMITS/HOME" connector. INFNC assigns functions to the trigger inputs (on the "TRIGGERS/OUTPUTS" connector) and to the digital inputs installed on expansion I/O bricks. The syntax, LIMFNC_i-c or INFNC_i-c, requires a letter designator ("c") that corresponds to an input function; options for the input functions are listed in the table below.

Virtual Inputs can be established to provide programmable input functionality for data or external events that are not ordinarily represented by inputs. See page 79 for details.

Letter Designator	Function
A.....	General-purpose input (default function for triggers & inputs on I/O bricks)
B.....	BCD program select
C.....	Kill
<a>D.....	Stop (axis designator "a" is optional)
E.....	Pause/Continue
F.....	User fault
G.....	<RESERVED>
H.....	Trigger Interrupt for position capture or registration (trigger inputs only). Special trigger functions can be assigned with the TRGFN command (see page 162).
I.....	Cause alarm event (requires Ethernet interface in Communications Server)
aJ.....	Jog in the positive-counting direction (axis designator is required)
aK.....	Jog in the negative-counting direction (axis designator is required)
aL.....	Jog velocity select (axis designator is required)
M.....	Joystick release
N.....	Joystick axis select
O.....	Joystick velocity select
P.....	One-to-one program select
Q.....	Program security
aR.....	End-of-travel limit for positive-counting direction (axis designator is required) *
aS.....	End-of-travel limit for negative-counting direction (axis designator is required) *
aT.....	Home limit (axis designator is required) *

* The limit inputs are factory-set to their respective end-of-travel or home limit function (see page 76).

Output Functions

Command	Function
OUTFNC _i -A.....	General-purpose output (default function)
OUTFNC _i -<a>B.....	Moving/not moving (axis designator optional)
OUTFNC _i -C.....	Program in progress
OUTFNC _i -<a>D.....	Hardware or software end-of-travel limit encountered (axis designator optional)
OUTFNC _i -<a>E.....	Stall indicator (axis designator optional) — stepper axes only
OUTFNC _i -F.....	Fault indicator (indicates drive fault input or user fault input is active)
OUTFNC _i -G.....	Position error exceeds maximum limit set with SMPER — servo axes only
OUTFNC _i -H.....	Output on position

* The "i" in the command syntax represents the number of the programmable input (e.g., OUTFNC3-H assigns onboard output 3 as an "output on position" function).

Thumbwheels

You can connect the controller's programmable I/O to a bank of thumbwheel switches to allow operator selection of motion or machine control parameters.

The commands that allow for thumbwheel data entry are:

```
INSTW..... Establish thumbwheel data inputs
OUTTW..... Establish thumbwheel data outputs
TW..... Read thumbwheels or PLC inputs
INPLC..... Establish PLC data inputs
OUTPLC..... Establish PLC data outputs
```

Thumbwheel Setup

The controller's programming language allows direct input of BCD thumbwheel data via the programmable inputs. Use the steps below to set up and read the thumbwheel interface. Refer to the *6K Series Command Reference* for descriptions of the commands used below.

- Step 1* Wire your thumbwheels to the 6K according to the I/O connection instructions provided in your product's *Installation Guide*.
- Step 2* Set up the inputs and outputs for operation with thumbwheels. The data valid input will be an input that the operator holds active to let the controller read the thumbwheels. This input is not necessary; however, it is often used when interfacing with PLCs.

```
OUTPLC1,1-4,0,12 ; Config PLC output set 1:
                  ; onboard outputs 1-4 are strobe outputs,
                  ; no output enable bit,
                  ; 12 ms strobe time per digit read.
INPLC1,1-8,9 ; Configure PLC input set 1:
              ; onboard inputs 1-8 are data inputs,
              ; onboard input 9 is a sign input,
              ; no data valid input.
INLVL000000000 ; Onboard inputs 1-9 configured active low
```

- Step 3* The thumbwheels are read sequentially by outputs 1-4, which strobe two digits at a time. The sign bit is optional. Set the thumbwheels to **+12345678** and type in the following commands:

```
VAR1=TW5 ; Assign data from all 8 thumbwheel digits to VAR1
VAR1 ; Displays the variable (*VAR1=+0.12345678).
      ; If you do not receive this response, return to
      ; step 1 and retry.
```

PLCs

The controller's programmable I/O can be connected to most PLCs. After defining and storing controller programs, the PLC typically executes programs, loads data, and manipulates inputs to the controller. The PLC instructs the controller to perform the motion segment of a total machine process.

Refer to your product's *Installation Guide* for instructions on connecting to I/O devices. For higher current or voltages above 24VDC, use external signal conditioning such as OPTO-22 compatible I/O signal conditioning racks. Contact your local distributor or automation technology center for information on these products.

PLC Scan Mode

The PLC feature allows you to create a pre-compiled program that mimics PLC functionality by scanning through the I/O faster than in a normal program run. Because the functions of PLC programs are pre-compiled, delays associated with command processing are eliminated during profile execution, allowing more rapid sequencing of actions than would be possible with programs that are not compiled. Command processing is then free to monitor other activities.


Scan Time

To check how much time (in 2 ms increments) the last scan took to complete, issue the `TSCAN` command or use the `SCAN` operand for variable assignments and `IF` conditions.

For example, if the last PLC program took 3 system updates (2 ms each) to scan, then `TSCAN` would report `*TSCAN6`, indicating that it took 6 ms to complete the scan. Each pass, if taking the same path through the conditional branches (`IF` statements), will always report the same `TSCAN` value.

The PLC program is scanned/ executed at the beginning of the 2-ms update period. The scan will stop after 30 segments have been executed and resume at the next 2-ms update. PLCP programs, when compiled, comprise a linked list of PLC segments. During a scan, each segment is counted until the total number of segments executed exceeds 30.

If the 30-segment limit occurs while executing a multi-segment statement, then that statement will finish no matter how many segments it executes. For example, if 29 segments have executed, then the next segment will cause the scan to pause until the next 2-ms update. If that next statement is `VARI1=1PE`, which executes 2 segments, then `VARI1=1PE` will complete its operations before pausing the scan.



To Implement a PLC Program ...


1. Define the PLC program (`DEF PLCPi` statement, followed by commands from the list below, followed by `END`). Up to 99 PLC programs can be defined, identified as `PLCP1`, `PLCP2`, `PLCP3`, and so on. Only these commands are allowed in a PLC program:
 - `IF`, `ELSE`, and `NIF` (conditional branching) —The PLC program uses the non-scaled integer (“raw”) operand values (e.g., `PE` value is not scaled by `SCLD` or `ERES`; `PANI` value is ADC counts, not volts). The only operands that are not allowed are: `SIN`, `COS`, `TAN`, `ATAN`, `VCVT`, `SQRT`, `VAR`, `TW`, `READ`, `DREAD`, `DREADF`, `DAT`, `DPTR`, and `PI`.
 - `L` and `LN` (loops)
 - `HALT` — as of OS revision 5.1
 - If the PLC program is executed with `SCANP`, `HALT` will terminate the current PLC program and kill the `SCANP` mode
 - If the PLC program is executed with `PRUN`, `HALT` will stop the PLC program (and the program that executed the `PRUN` statement) running in that task.
 - `BREAK` — as of OS revision 5.1
 - If the PLC program is executed with `SCANP`, `BREAK` will end only the current scan loop. At the next 2-millisecond update, the scan will restart at the first line of the PLC program.
 - If the PLC program is executed with `PRUN`, `BREAK` will stop the PLC program and execution will continue in the program from which the `PRUN` was executed (resuming at the command immediately following the `PRUN` command).
 - `TIMST` and `TIMSTP` (start and stop the timer) — available as of OS revision 5.1
 - `OUT` (turn on a digital output)

- ANO (set an analog output voltage – requires an extended I/O brick with on an analog output SIM) — available as of OS revision 5.1
 - EXE (execute a program in a specific task — e.g., 2%EXE MOVE)
 - PEXE (execute a compiled program in a specific task — e.g., 3%PEXE PLCP4)
 - VARI (integer variables). A VARI assignment expression is limited to one math function — either addition (+) or subtraction (-). The operands can be any of the monitored integer assignment operators (e.g., PE, PC, etc.).
NOTE: The PLC program uses the non-scaled (“raw”) operand values.
 - VARB (binary variables). Bitwise operations are limited to Boolean And (&), Boolean Inclusive Or (|), and Boolean Exclusive Or (^). The operands can be any of the monitored binary assignment operators (e.g., IN, LIM, AS, VARB, etc.).
2. Compile the PLC program (PCOMP PLCPi). A compiled program runs much faster than a standard program. After the PLCP program is compiled, it is placed in the 6K controller’s “compiled” memory partition (see MEMORY command). To verify which PLC programs are compiled, type in the TDIR command; compiled PLC programs are identified as “COMPILED AS A PLC PROGRAM”.
 3. Execute the PLC program (SCANP PLCPi). When the PLC program is launched with the SCANP command, it is executed in the “PLC Scan Mode”. The advantage of the PLC Scan Mode is that the PLC program is executed within a dedicated 0.5 ms time slot during every 2 ms system update period. This gives the PLCP program faster throughput for monitoring and manipulating I/O.

An alternative execution method is to use the PRUN command (PRUN PLCPi). This method is similar to the SCANP PLCPi method, but will only run through the PLCP program once.

Technical Notes About PLC Programs

- **Controller Status** bit 3 is set when a PLCP program is being executed in Scan Mode. To check the controller status, use SC, TSC, or TSCF.
- **Launching programs external to the scan:** Using the EXE command or the PEXE command, a scan program can launch another program in a specified task. EXE launches a standard, non-compiled program; PEXE launches a compiled program.
- **Stopping the scan:** The scan program can be stopped in either of two ways: using the !K command, or clearing the scan program by issuing a SCANP CLR command.
- **Timing the PLC program outputs:** It is not possible to control where the PLC program will pause if the scan takes more than the allowed time. This means that there can be a time lag of several update periods before the outputs, analog outputs, and/or variables affected by the PLC program are updated. The order in which the scan takes place should be considered when creating PLC programs to minimize the effects of such a lag. One way to avoid the lag is to create a binary variable as a temporary holding place for the desired output states. The last commands before the END statement of the PLC program can set the outputs according to the final status of the variable, such that all output states are written at the same time, just as the scan completes. This method is demonstrated in the example program below.
- **Memory Requirements:** Most commands allowed in a PLC program consume one segment of compiled memory after the program is compiled with PCOMP; the exceptions are VARI and VARB (each consume 2 segments) and IF statements. Each IF conditional evaluation compounded with either an AND or an OR operator consumes an additional segment (e.g., IF (IN.1=b1 AND 1AS.1=b0) consumes three segments of compiled memory). The number of compounds is limited only by the memory available.
- **Order of Evaluation for Conditional Expressions:**
Because only one level of parenthesis is allowed, the order of evaluation of IF conditionals is from left to right. Refer to the flowchart below for the evaluation logic.




Programming Example

```

DEF PLCP3
; Binary states of outputs 1-6 represented by VARB1 bits 1-6.
; Outputs 1-6 set at the end of program.
VARB1=b000000      ; Initialize binary variable 1
IF(IN.1=b1)        ; If onboard input 1 is ON, turn output 1 ON
  VARB1=VARB1 | b100000 ; Set binary bit for output 1 only to ON
NIF
IF(IN.2=b1)        ; If onboard input 2 is ON, turn output 2 ON
  VARB1=VARB1 | b010000 ; Set binary bit for output 2 only to ON
NIF
IF(IN.3=b1)        ; If onboard input 3 is ON, turn output 3 ON
  VARB1=VARB1 | b001000 ; Set binary bit for output 3 only to ON
NIF
IF(IN.4=b1)        ; If onboard input 4 is ON, turn output 4 ON
  VARB1=VARB1 | b000100 ; Set binary bit for output 4 only to ON
NIF
IF(IN.5=b1)        ; If onboard input 5 is ON, turn output 5 ON
  VARB1=VARB1 | b000010 ; Set binary bit for output 5 only to ON
NIF
IF(IN.6=b1)        ; If onboard input 6 is ON, turn output 6 ON
  VARB1=VARB1 | b000001 ; Set binary bit for output 6 only to ON
NIF
OUT(VARB1)         ; Turn on appropriate onboard outputs
END


PCOMP PLCP3        ; Compile program PLCP3
SCANP PLCP3        ; Run compiled program PLCP3 in Scan mode. See diagram.

```



RP240 Remote Operator Panel

6K Series products are directly compatible with the Compumotor RP240 Remote Operator Panel. This section describes how to use your 6K product with the RP240. Instructions for connecting the RP240 are provided in the *6K Hardware Installation Guide*. Refer to the *Model RP240 User Guide* (p/n 88-012156-01) for information on RP240 hardware specifications, mounting guidelines, environmental considerations, and troubleshooting.



Configuration

NOTE

As shipped from the factory, your 6K product is configured to operate an RP240 from the **RS-232/485** connector (referred to as the "COM 2" port). This should be appropriate for the majority of applications requiring RP240 interface.

For more information on controlling your product's multiple serial ports, see page 37.

Every 6K Series product has two serial ports. The **RS-232** connector is referenced as the "COM1" serial port, and the **RS-232/485** connector is referenced as the "COM2" serial port.

To configure the 6K product's serial ports for use with the RP240 and/or 6K language commands, use the `DRPCHK` command. Be sure to select the affected serial port (**COM 1** or **COM 2**) with the `PORT` command before you execute the `DRPCHK` command. Once you issue the `DRPCHK` command, it is automatically saved in non-volatile memory. The configuration options are:

- `DRPCHK0`Use the serial port for 6K commands only (default for **COM 1**)
- `DRPCHK1`Check for RP240 on power up or reset. If detected, initialize RP240. If no RP240, use serial port for 6K commands.
- `DRPCHK2`Check for RP240 every 5-6 seconds. If detected, initialize RP240. Do not use port for 6K commands.
- `DRPCHK3`Check for RP240 on power up or reset. If detected, initialize RP240. If no RP240, use serial port for `DWRITE` command only. The `DWRITE` command can be used to transmit text strings to remote RS-232C devices. (default setting for **COM 2**)

Example **COM 2** is to be used for RS-485; **COM 1** is to be used for RP240, but the RP240 will be plugged in on an as-needed basis. The set-up commands for such an application should be executed in the following order:

```
PORT1           ; Select COM1 serial port for setup
DRPCHK2        ; Configure COM1 for RP240, periodic check
PORT2           ; Select COM2 serial port for setup
DRPCHKØ        ; Configure COM2 for 6K commands only
```

Operator Interface Features

The RP240 can be used as your product's *operator interface*, not a program entry terminal. As an operator interface, the RP240 offers the following features:

- Displays text and variables
- 8 LEDs can be used as programmable status lights
- Operator data entry of variables: read data from RP240 into variables and command value substitutions (see *Command Value Substitutions* on page 7).

Typically the user creates a program in the 6K controller to control the RP240 display and RP240 LEDs. The program can read data and make variable assignments via the RP240's keypad and function keys.

The 6K Series software commands for the RP240 are listed below. Detailed descriptions are provided in the *6K Series Command Reference*. The example below demonstrates the majority of these 6K Series commands for the RP240.

```
DCLEAR.....Clear The RP240 Display
DJOG.....Enter RP240 Jog Mode
[DKEY].....Numeric value of RP240 Key
DLED.....Turn RP240 LEDs On/Off
DPASS.....Change RP240 Password
DPCUR.....Position The Cursor On The RP240 Display
[DREAD] .....Read RP240 Data
[DREADF] .....Read RP240 Function Key
DREADI.....RP240 Data Read Immediate Mode
DRPCHK.....Check for RP240
DSTP.....Enable/Disable the RP240 Stop Key
DVAR.....Display Variable On RP240
DWRITE.....Display Text On The RP240 Display
```


*Programming
Example*

```
DEF panell ; Define program panell
REPEAT ; Start of repeat loop
DCLEAR0 ; Clear display
DWRITE"SELECT A FUNCTION KEY" ; Display text "SELECT A FUNCTION KEY"
DPCUR2,2 ; Move cursor to line 2 column 2
DWRITE"DIST" ; Display text "DIST"
DPCUR2,9 ; Move cursor to line 2 column 9
DWRITE"GO" ; Display text "GO"
DPCUR2,35 ; Move cursor to line 2 column 35
DWRITE"EXIT" ; Display text "EXIT"
VAR1 = DREADF ; Input a function key
IF (VAR1=1) ; If function key 1 hit
GOSUB panel2 ; GOSUB program panel2
ELSE ; Else
IF (VAR1=2) ; If function key 2 hit
DLED1 ; Turn on LED 1
GO1 ; Start motion on axis 1
DLEDO ; Turn off LED 1
NIF ; End of IF (VAR1=2)
NIF ; End of IF (VAR1=1)
UNTIL (VAR1=6) ; Repeat until VAR1=6 (function key 6)
DCLEAR0 ; Clear display
DWRITE"LAST FUNCTION KEY = F" ; Display text "LAST FUNCTION KEY = F"
DVAR1,1,0,0 ; Display variable 1
END ; End of panell

DEF panel2 ; Define prog panel2
DCLEAR0 ; Clear display
DWRITE"ENTER DISTANCE" ; Display text "ENTER DISTANCE"
D(DREAD) ; Enter distance number from RP240
END ; End of panel2
```

Using the Default Menus

On power-up, the 6K product will automatically default to a mode in which it controls the RP240 with the menu-driven functions listed below.


The flow chart below illustrates the RP240's menu structure in the default operating mode (when no 6K product user program is controlling the RP240). Press the **Menu Recall** key to back up to the previous screen. The menu functions are described in detail below.

- Run a stored program (run, stop, pause and continue functions)
- Jog the load
- Display the status of:
 - System (TSS), for each task
 - Axis (TAS)
 - Extended Axis (TASX)
 - I/O (TIN and TOUT)
 - Limits (TLIM) and ENABLE input (TINO bit 6)
 - Position: Commanded (TPC), Encoder (TPE)
 - Firmware revision levels for the 6K product (TREV) and the RP240
- Enable or disable the internal drive (DRIVE)
- Access RP240 menu functions with a security password (set with DPASS)
- Reset the 6K product (equivalent to the Reset command)


NOTE: To disable these menus, the start-up program (the program assigned with the STARTP command) must contain the DCLEARØ command.

Default
Power-up
Menu

- If you change the password with the DPASS command, the menu marked with [ALT] becomes the power-up menu. The default password is '8000' for the 6K controller.
- Arrows indicate the menu path when you press the corresponding function key below the menu item.
- To back up to the previous menu item, press the MENU RECALL button.



Running a Stored Program



After accessing the RUN menu, press **F1** to “find” the names of the programs stored in the 6K product’s memory; pressing **F1** repeatedly displays subsequent programs in the order in which they were stored in BBRAM. To execute the program, press the **ENTER** key.

To type in a program name at the location of the cursor, first select alpha or numeric characters with the **F2** function key (characters will be alpha if an asterisk appears to the right of ALPHA, or numeric if no asterisk appears). If alpha, press the up (2) or down (8) keys to move through the alphabet, if numeric, press the desired number key. Press **F3** to move the cursor to the left, or **F4** to move the cursor to the right.


Only user programs defined with DEF and END can be executed from this menu. Compiled profiles (contouring and GOBUF profiles) cannot be executed from this menu; they must be executed from the terminal emulator with the PRUN command, or you can place the PRUN (name of path) command in a user program and then execute that program from this menu.

When a program is RUN and TRACE is selected (TRACE*), the RP240 display will trace all program commands as they are executed. This is different from the TRACE command in that the trace output goes to the RP240 display, not to a terminal via the serial port.

When a program is RUN and STEP is selected, step mode has been entered. This is similar to the STEP command, but when selected from the RUN menu the step mode allows single stepping by pressing the ENTER key. Both RP240 trace mode and step mode are exited when program execution is terminated.

⇒ **HINT:** If you wish to display each command as it is executed, select **STEP** and **TRACE** and press the **ENTER** key to step through the program.

Jogging



You can jog individual axes by pressing the arrow keys on the RP240’s numeric keypad. Pressing an arrow key on the numeric keypad will start motion and releasing the arrow key will stop motion. The up and down arrows keys are for selecting the axis to jog. The left and right arrow keys are for jogging the selected axis in the negative and positive direction, respectively.


The HI and LO values in the jog menu represent the velocity in units of revs/sec (or volts/sec for ANI feedback). If scaling is enabled, the value is multiplied by the programmed SCLV value.

To edit the jog velocity* values:

1. Press the **F5** function key under EDIT (edit mode indicated with an asterisk).
2. Press the **F1** function key to select the HI and LO values (cursor appears under the first digit of the value selected).
3. Using the numeric keyboard, enter the value desired.
4. Repeat steps 2 and 3 for all values to be changed.
5. Press **ENTER** when finished editing.
6. To jog with the new velocity values, first press the **F6** function key (under JOG) to enable the arrow keys again.

Jog accel and decel values are specified by the JOGA and JOGAD commands, respectively.


Status Reports:
System & Axis



After accessing the desired status menu, you can ascertain the function and status of each system (TSS, for each task) or axis (TAS and TASX) status bit by pressing the arrow keys on the numeric keypad.

To view a more descriptive explanation of each status bit (includes a text description), press the left or right arrow keys on the numeric keypad.

Status Reports:
I/O, Limits, Position



INPUTS Menu: This menu displays the TIN bit patterns for programmable inputs (onboard triggers and digital inputs on expansion I/O bricks). Remember that I/O bit patterns vary by product (see page 76 to find the bit patterns for your product). The initial menu show the trigger inputs status; use the up and down arrows to select the status of inputs on expansion I/O bricks.

OUTPUTS Menu: This menu displays the TOUT bit patterns for programmable outputs (onboard outputs and digital outputs on expansion I/O bricks). Remember that I/O bit patterns vary by product (see page 76 to find the bit patterns for your product). The initial menu show the onboard outputs; use the up and down arrows to select the status of outputs on expansion I/O bricks.

LIMITS Menu:

- The POS, NEG and HOME status items represent the hardware states of the limit inputs on the “LIMITS/HOME” connector, regardless of their LIMFNC input function assignments; they **do not** represent INFNC limit functions assigned to onboard trigger inputs or digital inputs on expansion I/O bricks.
- “POS” refers to the hardware end-of-travel limit imposed when counting in the positive

direction. “NEG” refers to the limit imposed when counting in the negative direction.

- A “1” indicates that the input is grounded, “0” indicates not grounded.


The end-of-travel limits (POS and NEG) must be grounded to allow motion (this is reversed if the active level is reversed with the LHLVL command).

The Enable input (ENABLE input terminal) must also be grounded before motion is allowed. When not grounded, the output (analog voltage or step pulse) to the drives is cut off and the shutdown outputs are activated.

POS Menu:

- The position values (encoder, commanded, and position error) shown are continually updated.
- The position error (“ERROR”) report is applicable only to servo axes.
- Position values are subject to the SCLD scaling factor (if scaling is enabled—SCALE1), PSET offset value, encoder polarity (ENCPOL), and commanded direction polarity (CMDDIR).

Enabling and Disabling the Drive(s)




In the DRIVE menu, the current status of the drive(s) is displayed. To enable or disable the drive, press **F1** or **F2**, respectively. This menu offers the same functionality as the DRIVE command.

WARNING

Shutting down a rotary drive system allows the load to freewheel if there is no brake installed.


Access Security




If the RP240 password is modified with the DPASS command to be other than the default (see *Changing the Password* below) the ACCESS menu then becomes the new default menu after power-up or executing a RESET. After that, the new password must then be entered to access the original default menu (see “Access Approved” path in illustration). If the operator does not know the new password, all he or she can do is run programs stored in the 6K product (RUN).

Changing the Password: The default password for 6K products is “6000”. A new password (numeric value of up to 4 characters) can be established with the DPASS command. For example, the DPASS2001 command sets the password to 2001.

Revision Levels



Resetting the 6K Product



After accessing the RESET menu, press the **F1** key to execute a reset (or press **F2** to cancel and exit the menu). The reset is identical to issuing a RESET command or cycling power to the 6K product. If a start-up program has been assigned with the STARTP command, that program will be executed.

CAUTION

Executing a reset will restore most command values (exclusions: see page 33) to their factory default setting.

Joystick Control, Analog Inputs



Refer to your
Installation Guide for
connection
procedures.

The 6K allows you to add analog input (ANI) SIMs to the expansion I/O bricks (sold separately). Each ANI SIM provides 8 analog inputs. The default voltage range for these input is -10VDC to +10VDC, but other ranges are selectable with the ANIRNG command. ANI inputs can be used in a variety of ways:

- Control an axis with a joystick (see *Joystick Control*)
- Position feedback for servo axes. The position of the ANI inputs can be read using the PANI or TPANI commands.
- Use the voltage value to control other events. The voltage value on the ANI inputs can be read using the ANI or TANI commands.

Joystick Control

The 6K controller supports joystick operation with digital inputs and analog inputs. The digital inputs include the onboard limit inputs and trigger inputs, as well as digital input SIMs on an external I/O brick. The 12-bit analog inputs are available only if you install an analog input SIM on an external I/O brick (default voltage range is -10V to +10V, selectable with ANIRNG).

To Set Up Joystick Operation

(refer also to the example code below)

1. Select the required digital inputs and analog inputs required for joystick operation. Connect the joystick as instructed in your controller's *Installation Guide*.
2. Assign the appropriate input functions to the digital inputs used for joystick's operation:
 - Release Input: `INFNCi-M` for triggers & I/O brick inputs, or `LIMFNCi-M` for limit inputs.
 - Axis Select Input: `INFNCi-N` for triggers & I/O brick inputs, or `LIMFNCi-N` for limit inputs. **NOTE:** If you're not using this input, assign the analog inputs to the axes with the `JOYAXH` command.
 - Velocity Select Input: `INFNCi-O` for triggers & external inputs, or `LIMFNCi-O` for limit inputs.
3. (optional) Use the `ANIRNG` command to select the voltage range for the analog inputs you will use. The default range is -10VDC to +10VDC (other options are 0 to +5V, -5 to +5V, and 0 to +10V).
4. Assign analog inputs to control specific axes, using:
 - `JOYAXH`: Standard analog input-to-axis assignment.
 - `JOYAXL` (optional). Analog input-to-axis assignment when the Axis Select Input is low.
5. Define the joystick motion parameters:
 - Maximum Velocity when Velocity Select input switch is open/high (`JOYVH` command). If the Velocity Select input is not used, joystick motion always uses the `JOYVH` velocity.
 - Maximum Velocity when Velocity Select input switch is closed/low (`JOYVL` command).
 - Accel (`JOYA` command).
 - Accel for s-curve profiling (`JOYAA` command).
 - Decel (`JOYAD` command).
 - Decel for s-curve profiling (`JOYADA` command).
6. Define the usable voltage zone for your joystick:
(make sure you have first assigned the analog inputs – see step 3 above)
 - End Deadband (`JOYEDB`): Defines the voltage offset (from the -10V & +10V endpoints) at which maximum velocity occurs. Default is 0.1V, maxing voltage at -9.9V and +9.9V.
 - Center Voltage (`JOYCTR` or `JOYZ`): Defines the voltage when the joystick is at rest to be the zero-velocity center. Default `JOYCTR` setting is 0V.
 - Center Deadband (`JOYCDB`): Defines the zero-velocity range on either side of the Center Voltage. Default is 0.1V, setting the zero-velocity range at -0.1V to +0.1V.
7. To jog the axes:
 - a. In your program, enable Joystick Operation with the `JOY` command (Joystick Release input must be closed in order to enable joystick mode). When the `JOY` command enables joystick mode for the affect axes, program execution stops on those axes (assuming the Continuous Command Execution Mode is disabled with the `COMEXCØ` command).
 - b. Move the load with the joystick.
 - c. When you are finished, open the Joystick Release input to disable joystick mode. This allows program execution to resume with the next statement after the initial `JOY` command that started the joystick mode.

Joystick Programming Example
(refer also to the illustration below)

Application Requirements: This example represents a typical two-axis joystick application in which a high-velocity range is required to move to a region, then a low-velocity range is required for a fine search. After the search is completed it is necessary to record the load positions, then move to the next region. A digital input can be used to indicate that the position should be read. The Joystick Release input is used to exit the joystick mode and continue with the motion program.

Hardware Configuration:


- An analog input SIM is installed in the 3rd slot of I/O brick 1. The eight analog inputs (1-8) are addressed as input numbers 17-24 on the I/O brick. Analog input 17 will control axis 1, and analog input 18 will control axis 2.
- A digital input SIM is installed in the 1st slot of I/O brick 1. The eight digital inputs (1-8) are addressed as input numbers 1-8 on the I/O brick. Digital input 6 will be used for the Joystick Release function, and input 7 will be used for the Joystick Velocity Select input. Input 8 will be used to indicate that the position should be read.

Setup Code (the drawing below shows the usable voltage configuration):

```

1INFC7-M           ; Assign Joystick Release f(n) to brick 1, input 7
1INFC8-O           ; Assign Joystick Velocity Select f(n) to brick 1, input 8
JOYAXH1-17,1-18   ; Assign analog input 17 to control axis 1,
                  ; Assign analog input 18 to control axis 2
JOYVH1,1          ; Max. velocity on axes 1 & 2 is 10 units/sec when the
                  ; Velocity Select input (1IN.7) is open (high)
JOYVL10,10        ; Max. velocity on axes 1 & 2 is 1 unit/sec when the
                  ; Velocity Select input (1IN.7) is closed (low)
JOYA100,100       ; Set joystick accel to 100 units/sec/sec on both axes
JOYAD100,100      ; Set joystick decel to 100 units/sec/sec on both axes
;**** COMMANDS TO SET UP USABLE VOLTAGE: ****
1JOYCTR.17=+1.0   ; Set center voltage for analog input 17 (controls axis 1)
1JOYCTR.18=+1.0   ; and 18 (controls axis 2) to+1.0V. The +1.0V value was
                  ; ascertained by checking the voltage of the both
                  ; inputs (with the 1TANI.17 and 1TAIN.18 commands)
                  ; when the joystick was at rest.
1JOYCDB.17=0.5    ; Set center deadband to compensate for the fact that
1JOYCDB.18=0.5    ; when the joystick is at rest, the voltage received on
                  ; both analog inputs can fluctuate +/- 0.5V on either
                  ; side of the +1.0V center.
1JOYEDB.17=2.0    ; Set end deadband to compensate for the fact that the
1JOYEDB.18=2.0    ; joystick can produce only -8.0V to +8.0V.
;*****
JOY11             ; Enable joystick mode for axes 1 & 2

```



Analog Input Interface

*Refer to your product's
Installation Guide for
ANI connection
information.*

Using analog (ANI) inputs on expansion I/O bricks, your 6K Series controller can use analog voltage as position feedback (servo axes only) and simply as a means to control the program based on external conditions.

Each ANI SIM on an expansion I/O brick provides eight analog inputs. The 12-bit analog inputs have a default voltage range of -10VDC to +10VDC. Other ranges are selectable with the ANIRNG command (0 to +5VDC, 0 to +10VDC, and -5 to +5VDC). The voltage value of the ANI inputs can be transferred to the terminal with the TANI command, or used in an assignment or comparison operation with the ANI operator (e.g., `IF (1ANI < 2.4)`).

When used for position feedback, the position counter resolution is 205 counts/volt (under the default ANIRNG setting). The position value of the ANI inputs can be transferred to the terminal with the TPANI command, or used in an assignment or comparison operation with the PANI operator (e.g., `WAIT (1PANI > 421)`).

Three common applications of the ANI inputs are:

- Position command to the control loop (e.g., as a master axis in Following mode)
- Position feedback to the control loop (see page 67 to select ANI input feedback for servo axes)
- A force or torque feedback signal

Programming Example

The portion of 6K code below (for two axes of control) demonstrates how to read the analog inputs into the controller and set the commanded analog output of each axis to that value. If you have a torque drive, this provides open-loop torque control.

```
SGP0,0          ; Turn off servo proportional feedback gain
SGI0,0          ; Turn off servo integral feedback gain
SGV0,0          ; Turn off servo velocity feedback gain
SGAF0,0         ; Turn off servo acceleration feedforward gain
SGVF0,0         ; Turn off servo velocity feedforward gain
SOFFS0,0        ; Set offset to zero (analog output will be 0 volts)
L              ; Enter an infinite loop
  VAR1=2ANI.17  ; Read value of 1st analog input on SIM slot 3
                ; (I/O point 17) on I/O brick 2 on into VAR variable 1
  VAR1=2ANI.18  ; Read value of 2nd analog input on SIM slot 3
                ; (I/O point 18) on I/O brick 2 on into VAR variable 2
  SOFFS(VAR1), (VAR2) ; Assign voltages from 2ANI.17 and 2ANI.18 to the
                ; analog output for axes 1 & 2, respectively
  T.01         ; Set time delay to 10 milliseconds
LN            ; End loop
```

ANI as a Feedback Device

The ANI analog inputs, when selected as a feedback source with the SFB command, is assumed to provide position information. With this feedback it is possible to solve applications that require positioning to a voltage, rather than positioning to a known position. Some example applications are as follows:

- Using a potentiometer as feedback (mechanical motion is mimicked by the 6K controller)
- Maintaining a force while position changes due to fluid evacuating a chamber
- Opening or closing a valve as another process changes

Host Computer Interface

Another choice for product control is to use a host computer and execute a motion program using the serial interface (RS-232 or RS-485). A host computer can be used to run a motion program interactively from a BASIC or C program (high-level program controls the 6K product and acts as a user interface). A BASIC program example (for the 6K2 product) is provided below.

```
10 '      6K Series Serial Communication BASIC Routine
12 '
14 '
16 ' *****
18 '
20 ' This program will set the communications parameters for the
22 ' serial port on a PC to communicate with a 6K series
24 ' stand-alone product.
26 '
28 ' *****
30 '
100 '*** open com port 1 at 9600 baud, no parity, 8 data bits, 1 stop bit
110 '*** activate Request to Send (RS), suppress Clear to Send (CS), suppress
120 '*** DATA set ready (DS), and suppress Carrier Detect (CD) ***
130 OPEN "COM1:9600,N,8,1,RS,CS,DS,CD" FOR RANDOM AS 1
140 '
150 '*** initialize variables ***
160 MOVE$ = ""      ' *** commands to be sent to the product ***
170 RESPONSE$ = ""  ' *** response from the product ***
180 POSITION$ = ""    ' *** feedback position reported ***
190 SETUP$ = ""     ' *** setup commands ***
200 '
210 '*** format the screen and wait for the user to start the program ***
220 CLS : LOCATE 12, 20
230 PRINT "Press any key to start the program"
240 '
250 '*** wait for the user to press a key ***
260 PRESS$ = INKEY$
270 IF PRESS$ = "" THEN 260
280 CLS
290 '
300 '*** set a pre-defined move to make ***
310 SETUP$ = "ECHO1:ERRLVLO:LH0,0:"
320 MOVE$ = "A100,100:V2,2:D50000,50000:GO11:TFB:"
330 '
340 '
400 '*** send the commands to the product ***
410 PRINT #1, SETUP$
420 PRINT #1, MOVE$
430 '
500 ' *** read the response from the TFB command ***
510 ' *** the controller will send a leading "+" or "-" in response to the TFB command to
520 ' *** indicate which direction travel has occurred. ***
530 WHILE (RESPONSE$ <> "+" AND RESPONSE$ <> "-") ' *** this loop waits for the "+"
540     RESPONSE$ = INPUT$(1, #1) ' *** or "-" characters to be returned
550 WEND ' *** before reading the position ***
560 '
570 WHILE (RESPONSE$ <> CHR$(13)) ' *** this loop reads one character at a time
580     POSITION$ = POSITION$ + RESPONSE$ ' *** from the serial buffer until a carriage
590     RESPONSE$ = INPUT$(1, #1) ' *** return is encountered ***
600 WEND
610 '
620 '*** print the response to the screen ***
630 LOCATE 12, 20: PRINT "Position is " + POSITION$
640 '
650 'END
```

CHAPTER FIVE

5 Custom Profiling

IN THIS CHAPTER

This chapter explains how to use these custom profiling features:

- S-Curve Profiling 120
- Linear Interpolation..... 123
- Contouring (circular interpolation) 124
- Compiled Motion Profiling..... 136
- On-the-Fly Motion (pre-emptive GOs)..... 151
- Registration 155
- Synchronizing Motion..... 159


For basic motion (accel/velocity/distance), see page [53](#).

For homing profiles, see page [59](#).

For Following profiles, see page [166](#).

S-Curve Profiling

6K controllers allow you to perform *S-curve* move profiles, in addition to the usual trapezoidal profiles. S-curve profiling provides smoother motion control by reducing the *jerk* (rate of change) in acceleration and deceleration portions of the move profile (see drawing below). Because S-curve profiling reduces jerk, it improves position tracking performance, especially in linear interpolation applications (not contouring).



S-Curve Programming Requirements

To program an S-curve profile, you must use the *average accel/decel* commands provided in the 6K Series programming language. For every maximum accel/decel command (e.g., A, AD, HOMA, HOMAD, JOGA, JOGAD, etc.) there is an *average* command for S-curve profiling (see table below).

Maximum Accel/Decel Commands		Average ("S-Curve") Accel/Decel Commands	
Command	Function	Command	Function
A	Acceleration	AA	Average Acceleration
AD	Deceleration	ADA	Average Deceleration
HOMA	Home Acceleration	HOMAA	Average Home Acceleration
HOMAD	Home Deceleration	HOMADA	Average Home Deceleration
JOGA	Jog Acceleration	JOGAA	Average Jog Acceleration
JOGAD	Jog Deceleration	JOGADA	Average Jog Deceleration
JOYA	Joystick Acceleration	JOYAA	Average Joystick Acceleration
JOYAD	Joystick Deceleration	JOYADA	Average Joystick Deceleration
LHAD	Hard Limit Deceleration	LHADA	Average Hard Limit Deceleration
LSAD	Soft Limit Deceleration	LSADA	Average Soft Limit Deceleration
PA	Path Acceleration	PAA	Average Path Acceleration
PAD	Path Deceleration	PADA	Average Path Deceleration

Determining the S-Curve Characteristics

The command values for average accel/decel (AA, ADA, etc.) and maximum accel/decel (A, AD, etc.) determine the characteristics of the S-curve. To smooth the accel/decel ramps, you must enter average accel/decel command values that satisfy the equation $\frac{1}{2} A \leq AA < A$, where A represents maximum accel/decel and AA represents average accel/decel. Given this requirement, the following conditions are possible:

Acceleration Setting	Profiling Condition
AA > ½ A, but AA < A.....	S-curve profile with a variable period of constant acceleration. Increasing the AA value above the pure S-curve level (AA > ½ A), the time required to reach the target velocity and the target distance is decreased. However, increasing AA also increases jerk.
AA = ½ A	Pure S-curve (no period of constant acceleration—smoothest motion).
AA = A	Trapezoidal profile (but can be changed to an S-curve by specifying a new AA value less than A).
AA < ½ A; or AA > A.....	When you issue the GO command, the move will not be executed and an error message, *INVALID CONDITIONS FOR S_CURVE ACCELERATION-FIELD n, will be displayed.
AA = zero.....	S-curve profiling is disabled. Trapezoidal profiling is enabled. AA tracks A. (Track means the command's value will match the other command's value and will continue to match whatever the other command's value is set to.) However, if you enter an average decel command (e.g., ADA, HOMADA, etc.) equal to zero, you will receive the "INVALID DATA-FIELD n" error.
AA ≠ zero and AA ≠ A	S-curve profiling is enabled only for standard moves (e.g., not for contouring, compiled motion, or on-the-fly motion changes). All subsequent standard moves for that axis must comply with this equation: $\frac{1}{2} A \leq AA < A$.
AA > ½ A	Average accel/decel is raised above the pure S-curve level; this decreases the time required to reach the target velocity and distance. However, increasing AA also increases jerk. After increasing AA, you can reduce jerk by increasing A, but be aware that increasing A requires a greater torque to achieve the commanded velocity at the mid-point of the acceleration profile.
No AA value ever entered	Profile will default to trapezoidal. AA tracks A.

If you never change the A or AA deceleration commands, AA deceleration will track AA acceleration. However, once you change A deceleration, AA deceleration will no longer track changes in AA acceleration. For example, if you never change the AD or ADA command values, ADA will track the AA command value. But once you change AD, the ADA command value will no longer track the changes in the AA command value.

The calculation for determining S-curve average accel and decel move times is as follows (calculation method identical for S-curve and trapezoidal moves):

$$\text{Time} = \frac{\text{Velocity}}{A_{\text{avg}}} \quad \text{or} \quad \text{Time} = \sqrt{\frac{2 * \text{Distance}}{A_{\text{avg}}}}$$

Scaling affects the AA average acceleration (AA, ADA, etc.) the same as it does for the A maximum acceleration (A, AD, etc.). See page 48 for details on scaling.


NOTE: Equations for calculating jerk are provided on page 122.

Programming Example


```

; In this example, axis 1 executes a pure S-curve and takes 1 second
; to reach a velocity of 5 rps; axis 2 executes a trapezoidal profile
; and takes 0.5 seconds to reach a velocity of 5 rps.
SCALE0      ; Disable scaling
DEF SCURV   ; Begin definition of program SCURV
@MA0        ; Select incremental positioning mode
@D40000     ; Set distances to 40,000 positive-
            ; direction steps
A10,10      ; Set max. accel to 10 rev/sec/sec
            ; on axes 1 and 2
AA5,10      ; Set avg. accel to 5 rev/sec/sec on
            ; axis 1, & 10 rev/sec/sec on axis 2
AD10,10     ; Set max. decel to 10 rev/sec/sec
            ; on axes 1 and 2
ADA5,10     ; Set avg. decel to 5 rev/sec/sec on
            ; axis 1, & 10 rev/sec/sec on axis 2
V5,5        ; Set velocity to 5 rps on axes 1 & 2
GO11        ; Execute motion on axes 1 and 2
END         ; End definition of program

```



Calculating Jerk



Rules of Motion:

$$\text{Jerk} = \frac{da}{dt}$$

$$a = \frac{dv}{dt}$$

$$v = \frac{dx}{dt} \quad (x = \text{distance})$$

Assuming the accel profile starts when the load is at zero velocity and the ramp to the programmed velocity is not compromised:

$$\text{Jerk} = J_A = \frac{A^2 * AA}{V (A-AA)}$$

- A = programmed acceleration (A, AD, HOMAD, etc.)
- AA = average acceleration (AA, ADA, HOMAA, etc.)
- V = programmed velocity (V, HOMV, etc.)

$$t_1 = \frac{A}{J_A}$$

$$t_2 = \frac{V}{AA} - \frac{A}{J_A}$$

$$t_3 = \frac{V}{AA}$$

NOTE: $t_3 - t_2 = t_1$

$$V_1 = \frac{J_A * t_1^2}{2} = \frac{A^2}{2 * J_A}$$

$$V_2 = V - \frac{A^2}{2 * J_A}$$

Ⓐ $t_1 \geq t \geq 0$

$$a(t) = J_A * t$$

$$v(t) = \frac{J_A * t^2}{2}$$

$$d(t) = \frac{J_A * t^3}{6}$$

a(t) = acceleration at time t
v(t) = velocity at time t
d(t) = distance at time t

Ⓑ $t_2 \geq t > t_1$

$$a(t) = A$$

$$v(t) = \frac{A^2}{2J_A} + A * (t - t_1)$$

$$d(t) = \frac{J_A * t_1^3}{6} + \left(\frac{A * (t - t_1)^2}{2} \right) + \left(V_1 * (t - t_1) \right)$$

Ⓒ $t_3 \geq t > t_2$

$$a(t) = A - (J_A * (t - t_2))$$

$$v(t) = V - \left(\frac{J_A * (t_3 - t)^2}{2} \right)$$

$$d(t) = \frac{V^2}{2AA} + \left(\frac{J_A * (t_3 - t)^3}{6} \right) - \left(V * (t_3 - t) \right)$$

Starting at a Non-Zero Velocity: If starting the acceleration profile with a non-zero initial velocity, the move comprises two components: a constant velocity component, and an s-curve component. Typically, the change of velocity should be used in the S-curve calculations. Thus, in the calculations above, you would substitute “(V_F - V_O)” for “V” (V_F = final velocity, V_O = initial velocity). For example, the jerk equation would be:

$$\text{Jerk} = J_A = \frac{A^2 * AA}{(V_F - V_O) (A-AA)}$$

Linear Interpolation

NOTE
2-axis products can accommodate only 2-axis (X & Y) linear interpolation.

The controller allows you to perform *linear interpolation*, the process of moving two or three orthogonal (right angle) linear axes to achieve linear (straight line) motion; a fourth axis can also participate in the move profile. The task is to derive appropriate move parameters to move from a current location to a new location, where each position is specified by a set of *Cartesian coordinates*. All axes must start, accelerate, decelerate, and stop in a synchronized manner.


The Initiate Linear Interpolated Motion (GOL) command initiates linear interpolation moves based on the parameters set with the D, PA, PAD, and PV commands. You simply enter the desired path acceleration (PA), the path deceleration (PAD), and the path velocity (PV) to arrive at the point in space (*end point*) specified with the distance (D) command; the controller internally calculates each axis' actual move profiles to achieve a straight-line path with these parameters.

You can scale the acceleration, velocity, and distance with the SCLD command (see example below).


The GOL command starts motion on either or both axes. If the GOL command is issued without any arguments, motion will be started on both axes.

Code Sample

```
SCALE1 ; Enable scaling
@SCLD4000 ; Set distance, accel/decel, and velocity scale factor
          ; to 4000 steps/unit
PA25 ; Set the path acceleration to 25 units/sec/sec
PAD20 ; Set the path deceleration to 20 units/sec/sec
PV2 ; Set the path velocity to 2 units/sec
D10,5 ; Set the distance to 10 & 5 units on axes 1 & 2
GOL11 ; Initiate linear interpolated motion on axes 1 & 2
      ; (see drawings below)
```



Contrasting Motion Profiles of Axes 1 & 2 to Achieve the Linear Interpolated Path



Contouring (Circular Interpolation)

NOTE

2-axis products can accommodate only 2-axis (X & Y) contouring.

6K Series controllers allow you to define and execute two-dimensional motion paths. A *path* refers to the path traveled by the load in an X-Y plane, and must be defined before any motion takes place along that path. The X and Y axes can be specified as any of the controller's two axes

Controllers with ≥ 4 axes: A third axis, labeled the C axis, can be included to keep an angular position that changes linearly with the path direction. The path direction is the vector addition of the travel of axes X and Y. A fourth axis labeled the P axis can be included to keep a position that is proportional to the distance traveled along the path described by X and Y. The X, Y, C and P axes can be specified as any of the controller's four axes.

A *path* consists of one or more line or arc segments whose end-points are specified in terms of X and Y positions. The end-point position specifications can be made using either absolute or incremental programming. The segments can be lines or arcs, both of which are described in greater detail in the following sections. Each path segment is determined by the end-point coordinates, and in the case of arcs, by the direction and radius or center. It is possible to accelerate, decelerate or travel at constant velocity (feedrate) during any type of segment, even between segments. For each segment, the user can also specify an output pattern that can be applied to the programmable outputs at the beginning of that segment.

All paths are continuous paths, (i.e., the motion will not stop between path segments, but must stop at the end of a path). It is not possible to define a path that stops motion within the path definition and then continues that path. To achieve this result, two individual paths must be defined and executed. A path can, however, be stopped and resumed by using a *Pause/Continue input* (see page 83) while the path is executing. In this case, motion will be decelerated and resumed along the path without loss of position. If one axis is stopped due to any other reason, the other axis will stop abruptly, and motion cannot be resumed. Causes for motion being stopped can include encountering an end-of-travel limit, issuing a Kill (!K) command, detecting a stall (stepper axes), exceeding the maximum allowable position error (servo axes), etc.

Path Definition

Contouring paths are defined like programs (using the DEF and END commands), but are compiled with the PCOMP command and executed with the PRUN command. Programs intended to be compiled as paths are stored in *Program* memory. After they are compiled with the PCOMP command, they remain in program memory and the *segments* (PARCM, PARCOM, PARCOP, PARCP, and PLIN statements) from the compiled profile are stored in *Compiled* memory. The TDIR command reports which programs are stored as a compiled profile.



Compiled *GOBUF* segments and *PLCP* programs are also stored in compiled memory (see page 11).

The amount of RAM allocated for storing contouring path segments is determined by the MEMORY command setting. The list below identifies memory allocation defaults and limits for 6K Series products. Further details on re-allocating memory are provided on page 11.

Total memory (bytes)	300,000
Default allocation (program,compiled)	MEMORY150000, 150000
Maximum allocation for compiled profiles	MEMORY1000, 299000
Maximum No. of compiled profiles	300
Maximum No. of compiled profile segments	2069

CAUTION

Issuing a memory allocation command (e.g., MEMORY70000, 80000) will erase all existing programs and compiled contouring path segments. However, issuing the MEMORY command by itself (i.e., MEMORY—to request the status of how the memory is allocated) will not affect existing programs or path segments.

You can store the maximum number of paths possible (see table above) as long as each path has at least one segment, and the sum of all the segments of all the paths does not exceed the controller's *compiled* memory limitation. All path definitions can be compiled and ready to execute at any time. Paths defined using G commands are specified with a path name. Once a path definition is compiled, it can be executed repeatedly without being re-compiled.

Deleting (DEL) an existing path name will automatically delete the existing path compilation with that name. The PUCOMP command only deletes (“uncompiles”) the path compilation, not the path program.

Example Code

In the example commands below, storage space is made available for the definition of path WID3 by first deleting the compiled version of paths WID1 and WID2. The DEF statement begins the definition of the path WID3.

```
PUCOMP WID1 ; Remove compilation of WID1
PUCOMP WID2 ; Remove compilation of WID2
DEF WID3 ; Begin definition of WID3
```

Participating Axes

Units of Measure; Scaling

- If no scaling (SCALE0): Path acceleration, velocity, and distance are based on the resolution (DRES for steppers, ERES for servos) of axis 1. If multi-tasking is used, path motion units are based on the resolution of the first (lowest number) axis associated with the task (TSKAX).
- If scaling (SCALE1): The units used for path distance, acceleration, and velocity is determined by the SCLD value. For example, suppose you have 2 servo axes (axes 1 & 2) involved in contouring, both axes use encoder feedback with a resolution of 4000 counts/rev, axis 1 uses a 10:1 (10 turns per inch) leadscrew and axis 2 uses a 5:1 (5 turns per inch) lead screw, and you want to program in inches. For this application you would use the SCLD40000,20000 command to establish path motion units in inches: distance is inches, acceleration is inches/sec/sec, and velocity is inches/sec.

2-Axis Contouring

You can change the X-Y plane to an Y-X plane by using the PAXES command. A path definition default is PAXES1, 2. For any path that uses axis 2 as the X axis and axis 1 as the Y axis, the path definition must start with PAXES2, 1 (see example below).

Example Code


```
DEF DRAW1 ; Begin definition of DRAW1
PAXES2,1 ; Set contouring axes (axis 2 is X axis, axis 1 is Y axis)
```

4-Axis Contouring

Some contouring applications can require the execution of more than one path to complete a part or finish an operation. The application can require that different paths take place in different planes of a three dimensional work area. In addition, some of the paths can require a third axis to move either tangent, or proportional to the path. For these reasons, a four-axis controller offers great flexibility in the specification of participating axes.

You may want to begin your path definition with the PAXES command; this will ensure that you have specified the appropriate axes to participate in the path. The X, Y, tangent (C) and proportional (P) axes can be specified as any of the four axes, and this specification must be made before any of the path travel specifications are made. The X and Y axes must be specified, the third (tangent) axis labeled C and the fourth (proportional) axis labeled P are optional.

The C axis will maintain an angular position that changes linearly with the direction of travel in the X-Y plane. This allows the C axis to control an object, which must stay tangent (or normal) to the direction of travel such as a cutting tool. The C axis must also be specified by its signed resolution. The magnitude of the resolution is the number of C axis motor steps in 360 degrees of an arc drawn by the X and Y axes. The sign of the resolution specifies the direction of rotation of the C axis. Refer to the PTAN command.



The P axis will keep a position that is proportional to the distance traveled along the X-Y path as the path is executed. This allows the P axis to act as the Z axis in *helical interpolation* (see drawing at left), or to control the motion of any object that moves with distance and velocity proportional to the path. The P axis must also be specified by the signed ratio of P axis travel to path travel. The magnitude of this ratio can range from 0.001 to 1000. The sign of this ratio specifies the direction of rotation of the P axis. Refer to the PPRO command.

A sewing machine application can require all four axes (X, Y, C, and P). The X and Y axes would direct the sewing head along the required path. The C axis would keep the sewing head pointed into the direction of travel. The P axis would control the speed of the needle, so that an even stitch is made, regardless of path speed.

Example Code

The following example begins the definition of a path named DRAW1. The X and Y axes are specified to be axes 4 and 2. The path includes the C axis to be axis 1, with a resolution of 100,000 steps. It also includes the P axis to be axis 3, with a ratio of P axis travel to path travel specified as 2.5:1.

```
DEF DRAW1      ; Begin definition of DRAW1
PAXES4,2,1,3  ; Set contouring axes
PTAN100000    ; Define C axis resolution
PPRO2.5       ; Define P axis ratio
```

Path Acceleration, Deceleration, and Velocity

A path can be composed of many segments, each with their own motion parameters. The path velocity, acceleration, and deceleration specifications currently in effect at the time a segment is defined will apply to that segment. This allows construction of a path that moves at one velocity for a section of the path, then moves at a different velocity for another section.

In most cases, it will be desirable to maintain a constant velocity throughout the path, but it is easy to define a path in which each segment has its own velocity. For example, this can be useful when a tool needs to slow down to round a corner, or to allow the rate of glue application to be controlled by the path speed. Acceleration and deceleration can also be specified separately.

Example Code

The short code example below illustrates the specification of velocity, acceleration, and deceleration in that order. Note that the scaling commands cannot be placed inside a program.

```
PV0.5         ; Path velocity 10,000 counts/sec
PA16         ; Path acceleration 400,000 counts/sec/sec
PAD28        ; Path deceleration 700,000 counts/sec/sec
```


Path Final Velocity

The PVF command allows a line or arc segment to terminate with a final segment velocity (PVF) that can be different from the velocity traveled for the majority of that segment (specified with PV). PVF must be smaller than or equal to PV, and the path velocity change will take place at the PAD deceleration rate. Like the other path motion parameters (e.g., PV, PA, PAD), the PVF velocity is applied to the next line or arc compiled; however, unlike these other commands, the PVF command applies only to the next line or arc compiled. All subsequent lines and arcs terminate at the PV value currently in effect. For each line or arc that needs to terminate at a velocity different than PV, a new PVF command must be issued, even if the PVF value has not changed.

The most common use for the PVF command will be to cause a preceding line segment to decelerate to the path velocity at which the next line or arc needs to travel. In this case, the PVF value for the preceding line would be the same as the PV value of the reduced speed segment. This feature eliminates the need to create a special deceleration segment in the path in order to have the entire subsequent line or arc travel at the reduced speed.

Example Code


In the example below, segments 2 and 4 must travel at a path velocity of 1, while the remainder to the path travels at a path velocity of 5.



Conditional Path Execution

The PGOWHN command allows a fixed or conditional delay in path travel to occur as part of the contouring motion profile, without requiring program execution to monitor the PGOWHN conditions. Combined with the PVF command, PGOWHN provides a convenient method of imbedding a dwell within a contour.

PGOWHN (expression)



The PGOWHN expression can be specified as a time (dwell) in milliseconds (e.g., PGOWHN (T=2000)), or as inputs or limits matching the specified binary pattern (e.g., PGOWHN (LIM. 3=B1) or PGOWHN (2IN. 6=B0)). All participating axes will be at rest during a dwell, even if the previous segment had not ended in zero path velocity. In the latter case (limit or input condition), there will be an abrupt change to zero path velocity, until the PGOWHN condition is satisfied.

When the PGOWHN condition is satisfied, path velocity will ramp to the next segment's PV value. Although no motion occurs during a PGOWHN segment, it occupies one segment of compiled memory. Like the line and arc segments, an output pattern can be asserted for the duration of the PGOWHN dwell by preceding the PGOWHN statement with a POUT statement (see example below).

Example Code

In the example below, the total path travel is six inches. At five inches, motion must stop until input 3 goes active. During this time, output 2 must be asserted. When input 3 goes active, output 2 must go off and motion then resumes for the final inch.

```
DEF BISEG
PAB1                ; Use absolute positions
PA10                ; Path acceleration of 10
PAD10               ; Path deceleration of 10
PV5                 ; Starting path velocity of 5
PVF0                ; Ending segment velocity of 0
POUT.2-0            ; Start with onboard output 2 off
PLIN5,0             ; 5 units right
POUT.2-1            ; Output 2 on during dwell
PGOWHN(IN.3=B1)    ; Dwell until onboard input 3 is active
POUT.2-0            ; Output 2 off during motion
PLIN6,0             ; Another unit right to finish
END
```

Segment End-point Coordinates

Stepper axes: All end-point position specifications are in units of commanded counts.

The end-point position specifications of lines and arcs can be either absolute or incremental. The controller stores the end-point data for all of its compiled segments internally as incremental, relative to the start of the segment. But in order to ease the programming task, absolute coordinates and multiple coordinate systems can be used.

When incremental coordinates are used to specify an end-point, the X and Y end-point values represent the distances from the X and Y start point of the segment being specified. Center specifications of an arc are always incremental (i.e., relative to the start of that arc segment). When absolute coordinates are used to specify an end-point, the X and Y end-point values represent that segment's position in the specified coordinate system. Incremental and absolute programming are specified with the PAB command. Incremental programming is the default state at the beginning of a path definition.

Coordinate systems allow the assignment of an arbitrary X-Y position as a reference position for subsequent absolute end-point specifications. The controller allows the use of two coordinate systems for use with absolute coordinate programming. These are called the *Work* coordinate system and the *Local* coordinate system. These are specified with the PWC and PLC commands. Neither coordinate system needs to represent the actual absolute position of the axes when the path actually executes.

The Work and Local coordinate systems are provided to allow absolute end-point definition of a segment without needing to know the actual position of each axis when the segment is executed. If no PWC command precedes the first segment command when a path definition begins, the controller will place the start of the first segment at location (0,0) in the Work coordinate system. By using the PWC *xpos, ypos* command, the programmer defines subsequent absolute end-points to refer to the Work coordinate system, and also locates that coordinate system such that the starting position of the next segment is at (xpos, ypos) of the Work coordinate system.

The Local coordinate system is provided so that if a section of a path is to appear in multiple locations along the path, the segments that compose that section can be programmed in absolute coordinates. By using the PLC *xpos, ypos* command, the programmer defines subsequent absolute end-points to refer to the Local coordinate system, and also locates that coordinate system such that the starting position of the next segment is at (xpos, ypos) of the Local coordinate system.

A single path definition can include both absolute and incremental programming, and be required to switch between Work and Local coordinates several times. At any point along a path definition, coordinates can be switched from absolute to incremental, or from incremental to absolute. When switching to absolute, all subsequent end-point specifications are assumed to be absolute with respect to the coordinate system in effect at that time. This


remains true until the reference system is switched to incremental, or to a new absolute reference.

When switching from Work coordinates to Local coordinates, the Local X and Y start positions of the following segment must be specified with the PLC command. When starting a path definition with Work coordinates, or when switching to Work coordinates, the starting position of the next segment can either be specified or assumed. The controller toggles between the Work coordinate system and the Local coordinate system with the PL command.

Ease of programming results from the ability to switch between absolute and incremental, and to re-define the coordinate systems between sections of a path. This allows individual sections of path definition to have Local coordinate systems, yet still be integrated into the complete path.

Line Segments


Lines are the simpler of the two path segment types. The placement, length, and orientation of the line is completely specified by the end-point of the line segment and the end-point of the previous segment. As described above, end-points can be specified with absolute or incremental coordinates.



The example below is specified with incremental coordinates and results in a line segment 10,000 steps in length, at 30 degrees in the X-Y plane.

`PLIN8660,5000 ; Line segment to (8660,5000) – see illustration at left`

Arc Segments




Arcs are more complex to specify than lines, because there are four possible ways to get from the start point to the end point. The radius of an arc can either be specified directly or implied by the center specification. In the controller, all path descriptions refer to the X-Y plane. The general convention describing the X-Y plane, as viewed from a drawing, is as follows. The X axis is shown as the left-right axis, with left being negative and right being positive. The Y axis is the up-down axis with down being negative and up being positive. Angles start at zero and increase in the CCW direction of rotation. A line segment, or the radius of an arc is at zero degrees if the incremental end-point has a positive X component and zero Y component. The angle is 90 degrees if the end-point has a positive Y component and zero X component.

Radius Tolerance Specifications

All arcs have an associated radius. In the controller, the radius can either be specified explicitly, or implied by a center specification. In both cases, it is possible that the radius cannot be consistent with the specified end-point of the arc. This could be a result of improper specification, user calculation error, or of round-off error in the internal arithmetic of the controller. For this reason, the controller allows the specification of a radius tolerance (PRTOL). The radius tolerance is specified in the same units as the radius and X and Y data.

The radius tolerance has a factory default of \pm one step, which is just enough to overcome round-off errors. The radius tolerance can be specified at any point along the path definition, and can be changed between one arc and the next. Each arc definition will be compared to the most recently specified radius tolerance. The radius tolerance should be about the same as the dimension tolerances of the finished product. The following paragraphs explain how the radius tolerance is used for the two types of arc specifications, and gives syntax examples for the radius tolerance specification.

Radius Specified Arcs




Specification of an arc using the radius method requires knowledge of the start point, the end point, and the sign and magnitude of the radius. The controller knows the start point to be either the start of the path, or the end of the previous segment. The end point and radius are provided by the user's program. It is possible to specify an impossible arc by specifying an end point that is more than twice the radius away from the start point (see drawing at left). In this case, the controller will automatically extend the radius to reach the end-point, provided that the automatic radius change does not exceed the user specified radius tolerance. If the required radius extension exceeds the radius tolerance, the controller will respond with an execution error, and no arc will be generated.


Example

The following illustration shows the four possible ways to move from the start point to the end point using an arc of radius 1000. Arc 1 and 2 both travel in the CW direction, arc 3 and 4 both travel in the CCW direction. Arc 1 and 3 are both less than 180 degrees. An arc of 180 degrees or less is specified with a positive radius. Arc 2 and 4 are both greater than 180 degrees. An arc of more than 180 degrees is specified with a negative radius. The example code below shows the radius tolerance specification and the specifications of arcs 1, 2, 3, and 4 respectively.

```
DEF arcs          ; Begin definition of path arcs
PRTOL5          ; 5 steps of radius tolerance
PARCP866,500,1000 ; Arc 1, CW < 180 degrees
PARCP866,500,-1000 ; Arc 2, CW > 180 degrees
PARCM866,500,1000 ; Arc 3, CCW < 180 degrees
PARCM866,500,-1000 ; Arc 4, CCW > 180 degrees
END              ; End path definition
;*****
;* To compile the arcs path, type "PCOMP arcs" *
;* To run the arcs path, type "PRUN arcs" *
;*****
```



Center Specified Arcs



Specifying an arc, using the center method, requires knowledge of the start point, the end point, and the center point of the arc. The X coordinate of the center is referred to with the letter I, and the Y coordinate of the center is referred to with the letter J. When an arc is specified with the center, another potential problem arises.


It is possible to specify the center of an arc such that the radius implied by the start point does not equal the radius implied by the end point (see illustration on left). In this case, the controller will re-locate the center so that the resulting arc has a uniform radius and the starting and ending angles come as close as possible to those implied by the user's center specification. This automatic center relocation will take place only if the start point and end point radius difference does not exceed the user specified radius tolerance. If the radius tolerance is exceeded, an execute error will result, and the arc will not be included in the path.

While automatic center relocation will ensure a continuous path, it can result in an abrupt change in path direction. This happens because a new location for the center results in a new tangent direction for an arc about that center.

Example

The example code below shows the specifications of arcs 1, 2, 3, and 4 for the drawing on the right. In the 6K commands, the order of the data is X, Y, I, J from left to right.

```
DEF arcs2        ; Begin definition of path
PARCOP866,500,866,-500 ; Arc 1, CW < 180 degrees
PARCOP866,500,0,1000 ; Arc 2, CW > 180 degrees
PARCOM866,500,0,1000 ; Arc 3, CCW < 180 degrees
PARCOM866,500,866,-500 ; Arc 4, CCW > 180 degrees
END              ; End path definition
;*****
;* To compile the arcs2 path, type "PCOMP arcs2" *
;* To run the arcs2 path, type "PRUN arcs2" *
;*****
```




Circles

A circle is a special case of an arc whose end-point is the same as the starting point. Because these two points are the same, it is impossible to determine the location of the circle's center from a radius specification. For this reason, an arc that is a complete circle must be specified using the arc center specification method. An arc with identical starting and ending points specified with the radius method will be ignored. The circle shown below is specified with the example below.

Example

```
DEF circle      ; Begin definition of path circle
PARCOP0,0,0,500 ; Circle with center at (0,500)
END            ; End path definition
;*****
;* To compile the circle path, type "PCOMP circle" *
;* To run the circle path, type "PRUN circle"      *
;*****
```



Segment Boundary

So far, all the examples given have shown isolated line or arc segments. Most paths will consist of many segments put together. The point at which the segments are connected is called a *segment boundary* in this text. The controller automatically ensures that the path is continuous, in that segments are placed end-to-end.

The path velocity can either be constant or change from segment to segment, according to user specification. Velocity changes use the specified acceleration and deceleration and can take place even across segment boundaries.

The programmer should ensure that direction of travel is also continuous across segment boundaries (see Figure A). If the direction change is abrupt (as shown in Figure B) the X and Y axes will suffer abrupt acceleration or deceleration. The controller ensures that there will be no abrupt direction change within a segment, but the programmer is responsible for ensuring that the direction is continuous across segment boundaries. At low speeds, some motor and mechanical configurations will tolerate such abrupt changes, and the controller will accept such a program; however, it is generally good practice to design paths with smooth direction changes. This can be done by designing a path using arcs to round corners.




Figure A (Segment Example)




Figure B (Stall Example for stepper axis)

Using the C Axis *(products with ≥ 4 axes)*

The *C axis* is an axis whose position changes in a manner linearly related to the direction of travel in X and Y (i.e., the path direction). The C axis would be used in applications that require a work piece or tool to remain tangent or perpendicular to the path direction. Examples would be: a knife always pointing into the cut, or a welding head staying normal to the weld.

The magnitude of the C axis resolution refers to the number of steps of C axis position change for 360 degrees of direction change in the X-Y plane. This number can be the same as, or different from the C axis motor resolution, allowing any gearing that is convenient for the mechanics. If the C axis load is to be driven directly, the C axis resolution should be the same as the C axis motor resolution. This will cause the C axis motor and load to rotate once when a circle is drawn by the X and Y axes. If the C axis load is to be geared (e.g., 5:1), the C axis resolution specifications should be five times the C axis motor resolution. This will cause the actual motor to rotate five times and the load to rotate once when a circle is drawn by the X and Y axes.

The number can be positive or negative, allowing greater flexibility in C axis motor mounting orientation. If the sign is positive, the C axis will rotate in the positive direction when CCW arcs are drawn. If the sign is negative, the C axis will rotate in the negative direction when counter-clockwise arcs are drawn.

The C axis is assumed to be in the proper position when path execution begins. It will change position only as the direction of travel changes. The program must position the C axis before the path is executed. This can be done with the HOM command or a GO to a position.

Because the C axis position changes linearly with the direction of X-Y travel, it is important to avoid path definitions that result in an abrupt direction change between segments. The segment boundary considerations for the C axis are similar to those for the X and Y axes, except that abrupt direction changes will result in abrupt C axis position changes. The X and Y axis would only suffer large accelerations, which can cause a stall in stepper axes or exceed the maximum position error (SMPER value) in servo axes. The C axis will suffer impossibly high velocity commands, causing stall and position loss in steppers or position error in servos.

Using the P Axis *(products with ≥ 4 axes)*

The *P axis* is an axis whose position and velocity are proportional to the position and velocity traveled by the load along the path generated by X and Y. It can be used as the Z axis in helical interpolation, or to control other motion that must be proportional to the X-Y path motion. The proportionality of the P axis is specified as a ratio, with a range of ± 0.001 to ± 1000 . The sign of the ratio determines which direction the motor will turn. The magnitude specifies the ratio of P axis travel to path travel, regardless of path direction or segment type. This ratio is essentially a position ratio, but because the ratio is maintained at every instant it also becomes a velocity ratio.

The P axis only responds to the distance traveled along the path, and is not affected by direction changes in the path. The only caution that must be observed comes when a high ratio is specified. In this case, path velocity and acceleration are amplified, which can result in impossible velocities or stalls (stepper axes) or excessive position error (servo axes).

Outputs Along the Path


For each segment, you can also specify an output pattern (POUT), which is to be applied to the programmable outputs at the beginning of that segment and remains throughout that segment. These segment-defined output patterns are stored as part of the compiled path definition. These outputs will change state at some time between 1.5 ms before the beginning of the segment and 0.5 ms after the beginning of the segment. The programmable outputs cannot be controlled more precisely than this, because the controller updates its path position every 2 ms.

The path segment defined programmable outputs are provided so that plotting applications can raise and lower the pen, laser cutters can turn the laser on and off, glue applicators can be turned on and off, all at prescribed positions along the path. The output specification is stated before the segment definition, which holds that output state. In the example below, programmable outputs 2 and 4 are changed during the path segments.

```

Example Code
DEF prog1      ; Begin definition of path program prog1
POUT1001      ; Output pattern during first arc
PARCM5,5,5    ; Specify incremental X-Y endpoint position and
               ; radius arc <180° for 1/4 circle CCW arc
POUT1100      ; Output pattern during second arc
PARCM5,-5,-5  ; Specify incremental X-Y endpoint
               ; position and radius arc >180° for
               ; 3/4 circle CW arc
END           ; End definition of prog1
PCOMP prog1   ; Compile path program prog1
PRUN prog1   ; Execute path program prog1
OUT0000      ; Turn off programmable outputs 1-4

```



Paths Built Using 6K Series Commands

When defining a path, the commands that specify all of the path definitions must be contained in a named block defining that path. Each path definition block has a unique name that is used to distinguish one path from another. Because the path definition is stored as a program, many different paths can be stored, each defined with a unique name. A path definition block begins with a DEF command (containing its name) and ends with an END command.

The controller offers a command to compile (PCOMP) a named path definition block, and a separate command to execute (PRUN) a named path. Once a named path is compiled, it can be executed repeatedly without delay.

Compiling the Path

A PCOMP command will cause the controller to find the named path definition block and compile the path described by those commands, even if that pathname had been previously compiled. The use of variables (VAR) as parameters in path definition statements allow the same basic path to be re-defined with slightly different sizes and shapes. They can also be used to conditionally include or omit sections of the path.

Designed to allow compile-time determination of path parameters, there can be cases when the controller should prompt the operator or host computer for the value to be used for path velocity or segment end-points. Alternatively, these values can be read with the READ or DAT commands, allowing multiple calls of a single subroutine to define similar path sections with different data values. Commands that retrieve this data would be placed within the path definition, and would only prompt for the information when the path is compiled (e.g., PV (READ1)).

*Example
Code*

```

VARS1="PATH VELOCITY ? " ; Create message string
DEF path1                ; Begin definition of path1
PAXES1,2                 ; Set path X & Y axes
PAB1                     ; Absolute path mode
PA100                   ; Path acceleration
PV(READ1)                ; Path velocity, to be read in when compiling
PLIN25000,25000         ; Move in a line
PLIN(VAR2),(VAR3)       ; Move in a line, to be read in when compiling
END                      ; End definition of path1
PCOMP path1             ; Compile path1

```

Executing the Path

A PRUN command will cause the controller to find the named path definition block and execute the path described by those commands, if that pathname has already been compiled (PCOMP).

The use of variables as parameters in the path definition statement is a method of allowing segment parameters to take new values each time the path is compiled. When the path is executing, the values of the variables do not affect the path parameters. If a change in a variable value is intended to affect the path parameters, that path must be re-compiled. The PRUN command performs the equivalent of a GOSUB to the named path definition block.

Possible Programming Errors

It is possible to create a situation in which the segment statements are interrupted. This could occur if an enabled ON condition becomes true. If an enabled ON condition (ONCOND) becomes true while running a compiled path, the branch to the ONP program will result. Motion from the path that was being executed will continue at the last segment velocity until it is stopped. Within the ONP program, a Stop command should be issued for all axes to stop the path from executing. For more information on program interrupts (ON conditions), see page 29.

Programming Examples

Figure A and Figure B show two simple paths that illustrate most of the controller segment types. For both figures, axis 1 is X and axis 2 is Y. The C and P axes are not included.

Figure A specifies the end-points with absolute coordinates. The default Work coordinate system with start point of (0,0) is used, so no `PLØ` statement is needed.

Figure B specifies the end-points with incremental coordinates. The state of the programmable outputs needs to be different for Handles than for Knobs. No other controller actions take place during these paths.

```
6K Code  DEF HANDLE      ; Begin HANDLE path definition
          PAXES1,2    ; Set X axis as axis 1, and
                    ; set Y axis as axis 2
          PAB1       ; Use absolute coordinates
          POUT1100   ; Programmable pattern for
                    ; next segments
          PARCOM10,10,0,10 ; CCW quarter circle
          PLIN10,20  ; Vertical LINE segment
          PARCP20,10,-10 ; CW 3/4 circle
          PARCM20,0,5 ; CCW half circle
          END        ; End of HANDLE path definition
```




Figure A (HANDLE Example)

```
DEF KNOB      ; Begin KNOB path definition
PAXES1,2    ; Set X axis to be axis 1, and
            ; set Y axis to be axis 2
PAB0       ; Use incremental coordinates
POUT0011   ; Programmable pattern for next
            ; segments
PLIN30,0   ; Long LINE into circular knob
PARCOM0,0,0,10 ; CCW circle for the knob
PLIN10,0   ; Short LINE out of knob
END        ; End of KNOB path definition
```




Figure A (KNOB Example)


The third path consists of two pairs of the first two (see drawing below). Each pair is placed at variable locations within the Work coordinate system and the two pairs are connected with a Line segment. The Line leading into the first pair starts at (20,20) in the Work coordinate system. The first pair starts at (VAR1, 2Ø) and the second pair starts at (VAR2, 2Ø) in the Work coordinate system. Handle is defined using the Local coordinate system. Even though Handle is defined in absolute coordinates and appears in two different places along the path in PARTS, the statements describing it appear only once, in a path definition using local coordinates.

6K Code

```

DEF PARTS          ; Begin PARTS path definition
PAXES1,2          ; Set X axis to be axis 1, Y axis to be axis 2
PAB1              ; Use absolute coordinates
PWC20,20         ; Establish WORK coordinates
PLO              ; Enable WORK coordinates
PLIN(VAR1),20    ; LINE to (VAR1,20)
PLC0,0           ; Specify LOCAL coordinate system
PL1              ; Enable LOCAL coordinate system
PAB1              ; Use absolute coordinates
POUT1100         ; Programmable pattern for next segments
PARCOM10,10,0,10 ; CCW quarter circle
PLIN10,20        ; Vertical LINE segment
PARCP20,10,-10   ; CW 3/4 circle
PARCM20,0,5      ; CCW half circle
PAB0              ; Use incremental coordinates
POUT0011         ; Programmable pattern for next segments
PLIN30,0         ; Long LINE into circular knob
PARCOM0,0,0,10  ; CCW circle for the knob
PLIN10,0         ; Short LINE out of knob
PAB1              ; Use absolute coordinates
PLO              ; Return to WORK coordinates
PLIN(VAR2),20    ; LINE to (VAR2,20)
PLC0,0           ; Specify LOCAL coordinate system
PL1              ; Enable LOCAL coordinate system
PAB1              ; Use absolute coordinates
POUT1100         ; Programmable pattern for next segments
PARCOM10,10,0,10 ; CCW quarter circle
PLIN10,20        ; Vertical LINE segment
PARCP20,10,-10   ; CW 3/4 circle
PARCM20,0,5      ; CCW half circle
PAB0              ; Use incremental coordinates
POUT0011         ; Programmable pattern for next segments
PLIN30,0         ; Long LINE into circular knob
PARCOM0,0,0,10  ; CCW circle for the knob
PLIN10,0         ; Short LINE out of knob
END              ; End of PARTS path definition

PCOMP PARTS      ; Compile PARTS path definition
    
```



Compiled Motion Profiling

6K Series products allow you to construct complex motion profiles for each individual axis. The profiles can contain:

- Sequences of motion
- Loops
- Programmable output changes
- Embedded dwells
- Direction changes
- Trigger functions

Related Commands: Brief descriptions of related commands are found on page 136. For detailed descriptions, see the *6K Series Command Reference*.

⇒
Contouring path segments and *PLCP* programs are also stored in compiled memory (see page 11).

Compiled motion profiles are defined like programs (using the `DEF` and `END` commands); the commands used to construct the motion profile segments are stored in a program (stored in *Program* memory). This program is then compiled (using the `PCOMP` command) and the compiled profile *segments* (`GOBUF`, `PLOOP`, `GOWHEN`, `TRGFN`, `POUTA`, `POUTB`, `POUTC`, and `POUTD` statements) from the program are stored in *Compiled* memory. (**HINT:** The `TDIR` command reports which programs are compiled as a compiled profile.) You can then execute the compiled profile with the `PRUN` command.

The amount of RAM allocated for storing compiled profile segments is determined by the `MEMORY` command setting. The list below identifies memory allocation defaults and limits for 6K Series products. Further details on re-allocating memory are provided on page 11.

Total memory (bytes)	300,000
Default allocation (program,compiled)	<code>MEMORY150000</code> , 150000
Maximum allocation for compiled profiles	<code>MEMORY1000</code> , 299000
Maximum No. of compiled profiles	300
Maximum No. of compiled profile segments	2069

CAUTIONS

- Issuing a memory allocation command (e.g., `MEMORY70000`, `230000`) will erase all existing programs and compiled path segments. However, issuing the `MEMORY` command by itself (i.e., `MEMORY`—to request the status of how the memory is allocated) will not affect existing programs or segments.
- After compiling (`PCOMP`) and running (`PRUN`) a compiled profile. The profile segments will be deleted from *compiled* memory if you cycle power or issue a `RESET` command.

After compiling (`PCOMP`), you can execute the profiles with the `PRUN` command, and all of the motion and functions compiled into the profile are executed without any further commands during profile execution.

For multi-axis products, profiles on any combination of axes can be launched simultaneously with a single `PRUN` command. This provides a very powerful method of synchronizing the action of multiple axes with very simple programming. For example, in a four-axis product, one axis could be running a complex Following profile, while two other axes are contouring, and the fourth could be performing a multi-tiered velocity motion profile.

Because the motion and functions are *pre-compiled*, delays associated with command processing are eliminated during profile execution, allowing more rapid sequencing of actions than would be possible with programs that are not compiled. Command processing is then free to monitor other activities, such as I/O and communications.

NOTES

- During compilation (PCOMP), most commands are executed the same as if no profile were being defined, even those that are not relevant to the construction of a profile. This is also true of non-compiled motion commands embedded in a compiled motion program during PCOMP. For this reason, it's good to limit commands between DEF and END to those that actually assist in the construction of the profile. Even for those that do actually assist in the construction of the profile, such as A, V, and D, it is important to remember that the command is executed and data actually changes, and it is not restored after compilation is completed.
- If your compiled motion program contains variables, the variables are evaluation only at compile time.

Each motion segment in a compiled motion profile can have its own distance, velocity, acceleration, and deceleration, as shown in the program example below:


Programming Example

```

DEF simple          ; Begin definition of program simple
MCO                 ; Preset positioning mode (disable continuous mode)
D50000              ; Distance is 50000
A10                 ; Acceleration is 10
AD10                ; Deceleration is 10
V5                  ; Velocity is 5
GOBUF1             ; Store the first motion segment for axis 1.
                   ; Profile attributes are: MCO, A10, AD10, V5, D50000
D30000              ; Distance is 30000
V2                  ; Velocity is 2
GOBUF1             ; Store the second motion segment for axis 1
                   ; Profile attributes are: MCO, A10, AD10, V2, D30000
D40000              ; Distance is 40000
V4                  ; Velocity is 4
GOBUF1             ; Store the third motion segment for axis 1
                   ; Profile attributes are: MCO, A10, AD10, V4, D40000
                   ; Because this is the last segment in a preset profile,
                   ; the velocity will automatically end at zero.
END                 ; End program definition

PCOMP simple        ; Compile simple
PRUN simple         ; Run simple
  
```

The resulting profile from the above program:



STATUS COMMANDS

Use these commands to check the status of compiled profiles.

System Status (TSSF, TSS, & SS):

- Bit 29 is set if compiled memory is 75% full.
- Bit 30 is set if compiled memory is 100% full.
- Bit 31 is set if a compile (PCOMP) failed; this bit is cleared on power-up, reset, or after a successful compile. Possible causes include:
 - Errors in profile design (e.g., change direction while at non-zero velocity, distance & velocity equate to <1 count/system update, preset move profile ends in non-zero velocity).
 - Profile will cause a Following error (see TFS, TFSF & FS status).
 - Out of memory (see system status bit 30)
 - Axis already in motion at the time of the PCOMP command
 - Loop programming errors (e.g., no matching PLOOP or PLN, more than 4 embedded PLOOP/END loops)

Axis Status (TASF, TAS, & AS): Bit 31 is set while compiled a GOBUF profile is executing.

Rules for Using
Velocity in Preset
Compiled Motion


TSEG & SEG: Reports the number of available segments in compiled memory.

TDIR: Identifies programs that are “compiled as a path” (compiled with the PCOMP command) and reports the percentage of remaining compiled memory.

When defining preset mode (MC0) compiled profiles there are several rules that govern the velocity.


Rule 1: The last segment in the compiled profile will automatically end at zero velocity (only if not in a PLOOP/PLN loop).

```
DEF PROF5 ; Begin definition of profile 5
MC0 ; Select preset positioning
V1 ; Set velocity to 1 rev/sec
D4000 ; Set distance to 4000
GOBUF1 ; First motion segment (V1, D4000)
V2 ; Set velocity to 2 (second segment)
GOBUF1 ; Second motion segment (V2, D4000)
END ; End definition of profile 5
PCOMP ; Compile profile 5
; When you execute PRUN PROF5, the resulting profile is:
```



Rule 2: If you wish intermediate segments to end in zero velocity, use the VF0 command in the respective GOBUF segment.

```
DEF PROF6 ; Begin definition of profile 6
MC0 ; Select preset positioning
V1 ; Set velocity to 1 rev/sec
VF0 ; End this segment at zero velocity
D4000 ; Set distance to 4000
GOBUF1 ; First motion segment (V1, D4000, VF0)
V2 ; Set velocity to 2 (second segment)
VF0 ; End this segment at zero velocity
GOBUF1 ; Second motion segment (V2, D4000, VF0)
END ; End definition of profile 6
PCOMP ; Compile profile 6
; When you execute PRUN PROF6, the resulting profile is:
```



Rule 3: CAUTION: With compiled loops (PLOOP and PLN), the last segment within the loop must end at zero velocity or there must be a final segment placed outside the loop. Otherwise, when the profile is compiled with PCOMP you’ll receive the “ERROR: MOTION ENDS IN NON-ZERO VELOCITY-AXIS n” error message and system status bit 31 will be set. after the final segment is completed, the motor will continue moving at the last segment’s velocity.


```
DEF PROF7 ; Begin definition of profile 7
MC0 ; Select preset positioning
D3000 ; Set distance to 3000
PLOOP4 ; Loop (between PLOOP & PLN) 4 times
V1 ; Set velocity to 1 rev/sec
GOBUF1 ; First motion segment
PLN1 ; End loop
END ; End definition of profile 7
PCOMP ; Compile profile 7, but instead of compile, you receive
; an error message
```

To fix the profile, reduce the PLOOP count by one and add a GOBUF statement after the PLN command:

```

DEF PROF7 ; Begin definition of profile 7
MCO ; Select preset positioning
D3000 ; Set distance to 3000
PLOOP3 ; Loop (between PLOOP & PLN) 3 times
V1 ; Set velocity to 1 rev/sec
GOBUF1 ; Looped motion segment
PLN1 ; End loop
GOBUF1 ; Last motion segment (end at zero velocity)
END ; End definition of profile 7
PCOMP ; Compile profile 7
; When you execute PRUN PROF7, the resulting profile is:

```




Rule 4: With compiled loops (PLOOP and PLN), if you wish the velocity at the end of each loop to end at zero, use a VF0 command.

```

DEF PROF8 ; Begin definition of profile 8
MCO ; Select preset positioning
D3000 ; Set distance to 3000
PLOOP4 ; Loop (between PLOOP & PLN) 4 times
V1 ; Set velocity to 1 rev/sec
VF0 ; End each segment at zero velocity
GOBUF1 ; Looped motion segment
PLN1 ; End loop
END ; End definition of profile 8
PCOMP ; Compile profile 8
; When you execute PRUN PROF8, the resulting profile is:

```



Compiled Following Profiles

More details on Following are found in Chapter 6 (page 166).

The new FOLRNF command designates that the motor will move the load the distance designated in a preset GOBUF segment, completing the move at the specified final ratio. The only allowable value for FOLRNF is zero (0). FOLRNF is allowed for a segment only if the starting ratio is also zero, i.e., it must be the first segment, or the previous segment must have ended in zero ratio. FOLRNF is only useful with compiled preset Following moves because the starting and final ratios are already zero for motion initiated with GO.

Compiled motion profiles can be constructed with any combination of preset or continuous motion segments. A continuous (MC1) Following segment will start with the final ratio of the previous segment, and end with the ratio given by FOLRN and FOLRD. The motion segment will consist of one ramp from the starting ratio to the final ratio. Just as with continuous Following ramps outside of a compiled profile, the master travel over which the ramp takes place is specified with FOLMD. The slave travel over which the ramp takes place is simply the product of master travel and average ratio. Because the slave travel is not specified explicitly, it is possible for arithmetic round-off errors to cause actual slave travel during a ramp to differ

from theoretical calculations. For applications in which slave distance is important, preset segments should be used.

A preset (MCØ) Following segment will also start with the final ratio of the previous segment, but can end in one of two ways. FOLRNF specifies the final ratio of a preset Following segment. As previously described, the only valid value for FOLRNF is zero (0). If FOLRNFØ is given before the GOBUF, the resulting motion segment will be constructed exactly as preset Following moves are outside of compiled profiles. In this case, the starting ratio must be zero, the final ratio will be zero, and the maximum intermediate ratio will be given by FOLRN and FOLRD. The relationships between ratio, master distance, and slave distance for this case are given on page 195 under the heading *Master and Follower Distance Calculations*. The FOLRNF command affects only the immediately subsequent preset Following segment, and must be given explicitly for each preset segment that is to end in zero ratio.


If FOLRNFØ is not given before the GOBUF, the segment will end with the ratio given by FOLRN and FOLRD, and need not start with zero ratio. This type of motion segment is constrained, however, to intermediate ratios that fall between the starting and final ratios.

Compiled profiles are built from motion segments created with the GOBUF command. For each individual axis, all motion segments in a compiled profile must use the same state of Following. That is, the motion segments can be all Following or all non-Following, but not a mixture of Following and non-Following (but at any point in time, separate axes can have different Following mode states).

The GOBUF command builds the appropriate type of motion segment based on the values of FOLMAS and FOLEN during compilation. These parameters cannot be changed inside a compiled program after a GOBUF. The choice of zero or non-zero FOLMAS must be the same during PRUN as during PCOMP (if non-zero, the value can be changed, but still must be non-zero). If a non-zero FOLMAS is given, the value of FOLEN must be the same during PRUN as during PCOMP.

Distance Calculations For Compiled Following Moves

The graph below shows 6 possibilities of ratio change profiles for preset segments, with legal FOLMD and “D” values constrained by the requirement that the average ratio (given by “D”/FOLMD) is between R1 and R2. If the distance is outside these ranges, in the profile used to get from R1 to R2 over FOLMD (covering “D” slave distance), an error message will be generated during the PCOMP command. For the graphs shown, the constraints are expressed by:



The two graphs above show the cases of $R1 < R2$ or $R1 > R2$, but the distance calculations of the ramp and constant ratio portions are the same for the two cases. For each graph, the heavy lined profile (first case) of these mimics the shape of the corresponding preset velocity change (FOLMD) segments in that the ramp takes place before the constant ratio portion. The second case occurs only if the distance specified exactly matches the start and end ratios and FOLMD1. In the third case, the ramp takes place after the constant ratio portion. In the first and third cases, only two segments are built, and the slave and master distances traveled in each segment are easily calculated with the simple formulas shown below. These formulas are based on positive ratios and master and slave distances. In the construction of Following profiles, ratios and master distances are always positive, with direction implied by the sign of the slave distance. For calculations with negative slave distances, simply use the magnitude of "D" in the formulas below, and invert the sign of the resulting slave distances.

Case 1 (Ramp first)	$MD1 = [D - (R2 * FOLMD)] / ((R1 - R2) / 2)$ $MD2 = FOLMD - MD1$ $D1 = .5 * (R1 + R2) * MD1$ $D2 = D - D1$	where MD1 = master distance during ramp where MD2 = master distance during flat where D1 = slave distance during ramp where D2 = slave distance during flat
Case 2 (Ramp only)	$MD1 = FOLMD$ $D1 = D$	where MD1 = master distance during ramp where D1 = slave distance during ramp
Case 3 (Ramp last)	$MD1 = [D - (R1 * FOLMD)] / ((R2 - R1) / 2)$ $MD2 = FOLMD - MD1$ $D1 = .5 * (R1 + R2) * MD1$ $D2 = D - D1$	where MD1 = master distance during ramp where MD2 = master distance during flat where D1 = slave distance during ramp where D2 = slave distance during flat

Dwells and Direction Changes

Compiled profiles can incorporate changes in direction only if the preceding motion segment has come to rest. This can be achieved for non-Following segments either by creating a continuous segment with a goal velocity of zero, or by preceding a preset segment with VFØ. It can be achieved for Following segments either by creating a continuous or preset segment with a goal ratio of zero, or by preceding a preset segment with FOLRNFØ. In all cases, motion within the profile comes to rest, although the profile is not yet complete. Even though the motor is not moving, the axis status bit 1 (AS . 1) will remain set, indicating a profile is still underway. Only then can you change direction (using the D+ or D- command, D~ is not allowed) within a profile. An attempt to incorporate changes in direction if the preceding motion segment has not come to rest will result in a compilation error.

In many applications, it can be useful to create a time delay between moves. For example, a machine cycle can require a move out, dwell for 2 seconds, and move back. To create this dwell, a compiled GOWHEN can be used between the two moves. The code within a compiled program can look like:

```

MCO           ; Preset incremental positioning used
D(VAR1)      ; Target position is in VAR1
VF0          ; Motion comes to rest at end of move
GOBUF1       ; Create move out segment
GOWHEN(T=2000) ; Profile delays for 2 seconds
D-           ; Return position is home (direction reversed)
VF0          ; Motion comes to rest at end of move
GOBUF1       ; Create move back home segment

```

In Following applications, it can be more useful to create a master travel delay between moves. For example, a machine cycle replacing a cam can require a move out, dwell for 2000

master counts, and move back. To create this dwell, a compiled GOBUF of zero slave distance can be used between the two moves. The code within a compiled program can look like:

```

MC0           ; Preset incremental positioning used
D(VAR1)      ; Target position is in VAR1
FOLMD4000    ; Move takes place over 4000 master counts
FOLRNFO      ; Motion comes to rest at end of move
GOBUF1       ; Create move out segment
D0           ; No change in target position
FOLMD2000    ; Dwell takes place over 2000 master counts
FOLRNFO      ; Motion comes to rest at end of "move" (dwell)
GOBUF1       ; Create dwell segment
D(VAR1)      ; Return position is home (direction change implied)
D-           ; Return position is home (direction reversed)
FOLMD4000    ; Move takes place over 4000 master counts
FOLRNFO      ; Motion comes to rest at end of move
GOBUF1       ; Create move back home segment

```

Compiled Motion Versus On-The-Fly Motion

The two basic ways of creating a complex profile are with compiled motion or with on-the-fly pre-emptive GO commands. With compiled motion, portions of a profile are built piece by piece, and stored for later execution. Compiled motion is appropriate for profiles with motion segments of pre-determined velocity, acceleration and distance. Compiled motion profiles allow for shorter motion segments, which results in faster cycle times because there is no command processing and execution delay. The axes can perform their own motion control and coordination, freeing program flow for other tasks, such as I/O, machine control, and host requests. The disadvantages to pre-defined compiled motion profiles are the amount of memory use and limited run-time decision making and I/O processing.

With pre-emptive GO moves, the motion profile underway is pre-empted with a new profile when a new GO command is issued. The new GO command constructs and launches the pre-empting profile. Pre-emptive GOs are appropriate when the desired motion parameters are not known until motion is already underway.

The table below summarizes the differences between the use of compiled motion and on-the-fly motion.

Command/Issue	Compiled Motion	On-The-Fly Motion
GOBUF	Constructs motion segment and appends to previously constructed segment	N/A
PRUN	Used to launch previously compiled motion	N/A
GO	GO causes move during PCOMP	GO Constructs & launches profile, even if moving
Direction changes	Only if previous motion segment comes to rest (MCØ & VFØ or MC1 & VØ), else compile error	Not allowed during motion, else AS. 3Ø, ER. 1Ø
Insufficient room for AD (decel) value	Same as on-the-fly	Decel is modified (steppers); Motion is killed, AS. 3Ø (servos)

Related Commands

GOBUF

Store a Motion Segment in Compiled Memory:

The GOBUF command creates a motion segment as part of a profile and places it in a segment of compiled memory, to be executed after all previous GOBUF motion segments have been executed. An individual axis profile is constructed by sequentially appending motion segments using GOBUF commands. Each motion segment can have its own distance to travel, velocity, acceleration, and deceleration.


The end of a GOBUF motion segment in preset mode is determined by the distance or position specified. The end of a GOBUF motion segment in continuous mode is determined by the goal velocity specified. In both cases, the final velocity and position achieved by a segment will be the starting velocity and position for the next segment. If either type of segment is followed by

	a GOWHEN command, the segment's final velocity will be maintained until the GOWHEN condition becomes true.
PLOOP & PLN	<p><i>Loop Start & Loop End (Compiled Motion only):</i></p> <p>The PLOOP and PLN commands specify the beginning and end of an axis-specific profile loop, respectively. All segments defined between the PLOOP and PLN commands are included within that loop.</p>
VF & FOLRNF	<p><i>Final Velocity & Numerator of Slave-to-Master Final Ratio:</i></p> <p>The VF and FOLRNF commands are used to designate that the motor will move the load the distance designated in a preset GOBUF motion segment, completing the move at a final speed of zero. The VF command is used when the Following mode is disabled (FOLENØ). The FOLRNF command is used when the Following mode is enabled (FOLEN1).</p>
GOWHEN	<p><i>Conditional GO:</i></p> <p>When GOWHEN is compiled in a profile, the GOWHEN condition is stored as part of that profile instead of being executed immediately. When progress through the profile reaches the compiled GOWHEN, AS . 26 is set, and the next segment's execution will be suspended until the GOWHEN condition becomes true. This allows subsequent GOWHEN and GOBUF combinations to be issued and stored, instead of overriding each other.</p>
TRGFN	<p><i>Trigger Functions:</i></p> <p>When TRGFN is compiled in a profile, the TRGFN condition is stored as part of that profile instead of being executed immediately. When progress through the profile reaches the compiled TRGFN, the embedded trigger functions are assigned to that trigger. AS . 26 is set if the GOWHEN function has been assigned to the trigger, and the next segment's execution will be suspended until the specified trigger input goes active. This allows subsequent TRGFN, GOWHEN, and GOBUF combinations to be issued and stored, instead of overriding each other.</p>
PCOMP, PRUN & PUCOMP	<p><i>Compile a Program, Run a Compiled Program, & Un-Compile a Compiled Program:</i></p> <p>The PCOMP, PRUN, and PUCOMP commands allow you to incorporate individual axis profiles within compiled motion profiles. Compiled motion for the 6K series allows you to construct complex motion programs using an individual contour (a series of arcs and lines), individual axis profiles (a series of GOBUF commands), or a path (combination of contours and individual axis profiles).</p>
PEXE	<p><i>Execute Compiled GOBUF Profile from PLC Program:</i></p> <p>You can place a PEXE command inside a compiled PLCP program. When the PLCP program is scanned in the PLC Scan Mode (SCANP), the PEXE command launches the specified compiled profile in another task. For details on the PLC Scan Mode, see page 104.</p>
POUTA through POUTH	<p><i>Output During Compiled Motion Profile — Axes Specific:</i></p> <p>The POUTA, POUTB, POUTC, POUTD, POUTE, POUTF, POUTG, and POUTH commands turn the programmable output bits on and off for axes 1, 2, 3, 4, 5, 6, 7 and 8, respectively.</p>
TSEG & SEG	<p><i>Transfer/Display (TSEG) or Assign (SEG) the Number of Free Segment Buffers:</i></p> <p>The TSEG command returns the number of free segment buffers in compiled memory. The SEG command is used to assign the number of free segment buffers in compiled memory to a variable or to make a comparison against another value.</p>

Compiled Motion — Sample Application 1

A manufacturer has an application where wire is being wrapped onto a spindle. There is a motor controlling the rotational speed of the spindle. Every application of the spindle requires that the motor runs at a fast speed with a slow acceleration for the first few revolutions, a medium speed for the next couple of revolutions, and a slower speed as the spindle gets fuller to maintain somewhat of a constant velocity off the feed wire. The technician would like to

use an RP240 to enter the velocity and number of revolutions for each stage of winding. Programmable outputs 1, 2 and 3 are wired to status LEDs, and should go on for the respective stages of winding (output 1 for stage 1, etc.).



```

Program  DEF PROFIL          ; Define motion profile program
        VAR10 = 4000 * VAR4  ; Get distance of first stage
        ; (assuming 4000 steps/revolution)
        D(VAR10)            ; Set distance
        V(VAR1)             ; Set velocity of first stage
        POUTA.1-1          ; Turn output 1 on
        GOBUF1              ; Build motion
        VAR10 = 4000 * VAR5  ; Get distance of second stage
        D(VAR10)            ; Set distance
        V(VAR2)             ; Set velocity of second stage
        POUTA01            ; Turn output 1 off and output 2 on
        GOBUF1              ; Build motion
        VAR10 = 4000 * VAR6  ; Get distance of third stage
        D(VAR10)            ; Set distance
        V(VAR3)             ; Set velocity of third stage
        POUTAx01           ; Turn output 2 off and output 3 on
        GOBUF1              ; Build motion
        POUTA.3-0          ; Turn off output 3
        END                  ; End motion profile program


        DEF EXMPL1          ; Define program example 1
        L                    ; Continual loop of program execution
        DCLEAR0             ; Clear all lines on RP240 display
        DPCUR1,1            ; Position cursor at line 1, column 1
        DWRITE"ENTER VELOCITY STAGE 1"; Prompt user
        VAR1 = DREAD         ; Get 1st velocity from RP240 entry
        DCLEAR1             ; Clear line 1 on RP240 display
        DPCUR1,1            ; Position cursor at line 1, column 1
        DWRITE"ENTER VELOCITY STAGE 2" ; Prompt user
        VAR2 = DREAD         ; Get 2nd velocity from RP240 entry
        DCLEAR1             ; Clear line 1 on RP240 display
        DPCUR1,1            ; Position cursor at line 1, column 1
        DWRITE"ENTER VELOCITY STAGE 3" ; Prompt user
        VAR3 = DREAD         ; Get 3rd velocity from RP240 entry
        DCLEAR1             ; Clear line 1 on RP240 display
        DPCUR1,1            ; Position cursor at line 1, column 1
        DWRITE"ENTER REVOLUTIONS STAGE 1" ; Prompt user
        VAR4 = DREAD         ; Get # of windings 1st stage from RP240 entry
        DCLEAR1             ; Clear line 1 on RP240 display
        DPCUR1,1            ; Position cursor at line 1, column 1
        DWRITE"ENTER REVOLUTIONS STAGE 2" ; Prompt user
        VAR5 = DREAD         ; Get # of windings 2nd stage from RP240 entry
        DCLEAR1             ; Clear line 1 on RP240 display
        DPCUR1,1            ; Position cursor at line 1, column 1
        DWRITE"ENTER REVOLUTIONS STAGE 3" ; Prompt user
        VAR6 = DREAD         ; Get # of windings 3rd stage from RP240 entry
        PCOMP PROFIL        ; Re-compile profile with new vel/dist info
        $AGAIN              ; Label for repeating same profile
        PRUN PROFIL         ; Execute profile
        DCLEAR1             ; Clear line 1 on RP240 display
        DPCUR1,1            ; Position cursor at line 1, column 1
        DWRITE"SAME DATA (1=YES,2=NO)" ; Prompt user if perform again with old data
        VAR7 = DREAD         ; Get response
        IF(VAR7=1)          ; If user wants to perform same profile
            GOTO AGAIN       ; perform again
        NIF                  ; End conditional
        LN                  ; End command execution loop
        END                  ; End definition program example 1

        ; *****
        ; * To begin, execute the EXMPL1 program *
        ; *****


```

Compiled Motion — Sample Application 2

Here's an example of replacing a mechanical cam using a compiled Following profile. There is evenly spaced product coming in on a feeder belt. The feeder belt can vary in speed. The cam that you are replacing controls a push arm that will push the product into a box for shipping. You would also like the arm to retract at a faster rate than it extends. In other words, you would like to have a smooth push to load and a fast retract to set up for the next product. Since this is a cam, this profile must repeat continuously for each product or master cycle but won't start until the first product is detected.



The feeder belt is the master and the master cycle length (space from the front of one product to the front of the next) is 12000 master (encoder) counts on the feeder belt. The push of the product will start 2000 counts into the master cycle. The push will take place over 6K master counts, and the retract over 2000 master counts. The distance the push arm (slave) must travel is 4000 counts. Assume the detector is wired to trigger 1A (onboard trigger input 1). Below is a graph of this Following profile.



Program

```

; Setup code
FOLMAS21      ; Master is coming in on encoder 2
FOLEN1       ; Enable Following
INFNC1-H     ; Assign onboard input 1 (TRG-1A) as trigger interrupt

; Motion program
DEL EXPL2    ; Delete program (in case it already exists in memory)
DEF EXPL2    ; Begin definition of program example 2
1TRGFNA1    ; Launch axis 1 profile upon receiving TRG-1A
             ; (1st product detected)
PLOOP0      ; Loop continuously to mimic a mechanical cam

; Program first move - dwell
FOLRN1      ; Set up ratios - numerator
FOLRD1      ; and denominator
FOLMD2000   ; Over a distance of 2000 master steps
D0          ; slave will not move
FOLRNF0     ; and end at zero ratio
GOBUF1     ; Build motion
    
```

```

; Program second move - positive slave move
FOLMD6000      ; Over a distance of 6000 master steps
D4000          ; slave will move 4000 steps
FOLRNFO        ; and end at zero ratio
GOBUF1         ; Build motion

; Program third move - negative slave move
FOLRN3         ; New ratio to accommodate larger distance of slave travel
FOLMD2000     ; Over a distance of 2000 master steps
D-4000        ; slave will move -4000 steps
FOLRNFO        ; and end at zero ratio
GOBUF1         ; Build motion

; Program last move - dwell
FOLMD2000     ; Over a distance of 2000 master steps
D0             ; slave will not move
FOLRNFO        ; and end at zero ratio
GOBUF1         ; Build motion
PLN1          ; Close cam loop
END            ; End program example 2

PCOMP EXPL2    ; Compile program EXPL2

; ** To execute the program, enter the PRUN EXPL2 command **

```

**Program
Modification**

Let's now modify the constraints of the system. Let's say that the product will be spaced roughly 12000 master counts apart. It may or may not be exactly 12000, but it will never be less than 10000 (just to make sure the retraction finishes before the next product is detected). We can then modify the program to wait for the product to be detected each cycle. We can also take the extra "dwell" or zero distance move out of the end of the profile. See program below:

```

; Setup code
FOLMAS21       ; Master is coming in on encoder 2
FOLEN1         ; Enable Following mode
INFNC1-H       ; Assign onboard input 1 (TRG-1A) as trigger interrupt

; Motion program
DEL EXPL2B     ; Delete program (in case it already exists in memory)
DEF EXPL2B     ; Begin definition of program example 2b
PLOOP0        ; Loop continuously to mimic a mechanical cam
1TRGFNA1      ; Pause axis 1 profile until TRG-1A is activated
               ; (detect next product)

; Program first move - dwell
FOLRN1         ; Set up ratios - numerator
FOLRD1         ; and denominator
FOLMD2000     ; Over a distance of 2000 master steps
D0             ; slave will not move
FOLRNFO        ; and end at zero ratio
GOBUF1         ; Build motion

; Program second move - positive slave move
FOLMD6000     ; Over a distance of 6000 master steps
D4000          ; slave will move 4000 steps
FOLRNFO        ; and end at zero ratio
GOBUF1         ; Build motion

; Program third move - negative slave move
FOLRN3         ; New ratio to accommodate larger distance of slave travel
FOLMD2000     ; Over a distance of 2000 master steps
D-4000        ; slave will move -4000 steps
FOLRNFO        ; and end at zero ratio
GOBUF1         ; Build motion
PLN1          ; Close cam loop
END            ; End program example 2b


PCOMP EXPL2B   ; Compile program EXPL2B

; *****
; * To execute the program, enter the PRUN EXPL2B command *
; *****

```

Compiled Motion — Sample Application 3

In this application, there is a wheel that stamps a logo onto the product. The product is assumed to be entering at a constant and fixed spacing, each product is 4 inches in length with 2 inches separating each unit. The stamp wheel has a circumference of 9 inches, and must be traveling at a 1 to 1 ratio with the product at the time of stamping. The stamp wheel must then travel five inches in just 2 inches of master travel. There is a sensor wired to trigger A of the 6K controller to detect the first product and start the cycling. At the time of the trigger the product is 1 inch away from contact with the stamp wheel. Assume that the home position of the slave is 0.5 inches away from a stamp. The mechanics of the system give 3000 steps of master travel per inch and 1500 steps of slave travel per inch.



As you can see above, we have a multi-tiered Following profile. By multi-tiered we mean that ratio is changing from a non-zero value to another non-zero value. To program this profile effectively, we will break the profile into pieces as shown with the dotted lines in the above illustration:

```

Program FOLMAS21      ; Define the master as encoder on axis 2
FOLEN1      ; Enable Following
INFNC1-H    ; Assign onboard input 1 (TRG-1A) as trigger interrupt
SCLMAS3000  ; Set scaling of master steps per inch
SCLD1500    ; Set scaling of slave steps per inch
SCALE1      ; Enable scaling

DEF EXMPL3  ; Start definition of example program 3
1TRGFNA1    ; Launch axis 1 profile when TRG-1A is activated

; Program first ramp from ratio 0 to ratio 1
FOLRD1      ; Set Following ratio - denominator
FOLRN1      ; Set the Following ratio at 1 to 1
FOLMD1      ; Over a master distance of 1"
D0.5        ; Slave will travel 0.5"
GOBUF1      ; Build motion

PLOP0       ; Start the continuous loop

; Program constant ratio
FOLRN1      ; At a 1 to 1 ratio
FOLMD4      ; Over a master distance of 4"
D4          ; Slave will travel 4"
GOBUF1      ; Build motion

; Program ramp to new ratio
FOLRN3      ; Go to a 3 to 1 ratio
FOLMD0.5    ; Over a master distance of 0.5"
D1          ; Slave will travel 1"
GOBUF1      ; Build motion
; Program second constant ratio
FOLRN3      ; At a 3 to 1 ratio
FOLMD1      ; Over a master distance of 1"
D3          ; Slave will travel 3"
GOBUF1      ; Build motion

; Program ramp to lower ratio
FOLRN1      ; Go to a 1 to 1 ratio
FOLMD0.5    ; Over a master distance of 0.5"

```

```

D1                ; Slave will travel 1"
GOBUF1           ; Build motion
PLN1            ; Close motion loop

; Define the exit motion
FOLRN0          ; Stop slave at zero ratio (and zero velocity)
FOLMD1         ; Over a master distance of 1"
D0.5           ; And a slave distance of 0.5"
GOBUF1         ; Build motion
END            ; End definition of example program 3

PCOMP EXMPL3    ; Compile example program 3

; *****
; * To execute the program, enter the PRUN EXMPL3 command *
; *****


```

NOTE: The GOBUF command has been added to the “Define the exit motion” portion of the program despite the fact that an infinite loop has been programmed earlier in the program. This is to avoid an error message when the program is compiled.

Compiled Motion — Sample Application 4

A manufacturer of stamped molds needs to make a machine that will stamp molds into a continuous flow of extruded plastic material. The stamp must be lowered 0.5 inches into the plastic to leave the correct impression. Because the flow is continuous, the stamp must also move in synchronization with plastic in the direction of flow as it is lowered and raised. The initial design approach to the machine required two axes of motion. One was needed to lower and raise the stamp, the other to allow the stamp to follow the plastic. With the availability of complex Following cam profiles the job can be done with a single axis.

In the drawing below, the stamp is attached to a rotating arm in such a way that the stamp remains level as the arm rotates. The length of the arm at the stamp fixture, or radius of rotation, is exactly one inch. The arm is mounted above the plastic so that at the bottom of its rotation (270 degrees), the stamp will be 0.5 inches into the plastic. Using trigonometry, the horizontal and vertical positions and speeds can be calculated at other arm angles. Because the stamp must follow the flow of the plastic, we must adjust the ratio of rotational speed to plastic speed so that the horizontal velocity component of the arm stays at 1:1 with the plastic while the stamp is in the plastic.



The table below shows these relationships. The arm is directly driven with a servo motor having 4096 steps per revolution. The table shows increments of 30 degrees, which is about 341 servo motor steps, or about 0.524 slave inches measured around the circumference described by rotation of the arm. The plastic flow is measured with an encoder giving 1000 steps per inch of flow. To maintain ratios in terms of inches, FOLRD will always be 1000. The required FOLRN value is simply the inverse of the arm’s horizontal velocity component multiplied by the number of slave steps per inch. The corresponding ratio in terms of surface speeds is given in parentheses. The required FOLMD is the number of master steps corresponding to the horizontal component of slave rotation.

Arm angle, degrees	Horizontal component (in.) = $\cos(\text{deg})$	FOLMD = $1000 * \Delta \cos(\text{deg})$	Horizontal vel component = $-\sin(\text{deg})$	Required FOLRN = $-651.9/\sin(\text{deg})$
210	-0.866	n/a	0.500	1304 (2:1)
240	-0.500	366	0.866	753 (1.155:1)
270	0.000	500	1.000	652 (1:1)
300	0.500	500	0.866	753 (1.155:1)
330	0.866	366	0.500	1304 (2:1)

The profile that we construct from these number is meant to approximate the inverse sine function in the last column, but of course, will actually be a series of ramps and constant ratio segments. Let's review the Compiled Following Move Distance Calculations to determine the exact shape and error in the first motion segment(from 210 to 240 degrees). First, we need to determine if the ramp or constant ratio is first for that segment. Using ratios and distances in inches, we have:

R1 = 2 Starting ratio
R2 = 1.155 Final ratio
D = (2*pi)/12 = 0.524 Distance at stamp hinge
FOLMD= .366 Travel along plastic

We find $(R1+R2) * FOLMD / 2 = 0.577$, which is greater than D, so the "Ramp First" equations apply to this segment. Let's examine the error at the junction between the ramp and constant ratio portion of this segment.

MD1 = $[D - (R2 * FOLMD)] / ((R1 - R2) / 2) = 0.239$ master inches
D1 = $0.5 * (R1 + R2) * MD1 = 0.377$ slave inches at circumference = 21.6 degrees
 $\cos(210+21.6) - \cos(210) = -0.621 - (-0.866) = 0.245$ inches slave horizontal travel
error = horizontal slave travel - master travel = $0.245 - 0.239 = 0.006$ inches


A similar calculation can be done for the "elbow" of the next of the next segment, and symmetry indicates these errors will be the same between 270 and 330 degrees. The error along intermediate points can be found with linear interpolation of ratio and master distance. In this case, the errors fall within manufacturing tolerance. If the errors were too large, the travel could be broken into more segments, each with exactly correct positions and ratios at their boundaries.

So far, we have only discussed the portion of the profile that lowers and raises the stamp. During the remainder of the profile, the arm must continue its rotation to bring the stamp to its starting position in time for the next mold. The mold is 3 inches long, and .4 inches are needed between molds for strength at the edges. This makes the total master cycle 3.4 inches long. The total slave cycle must be 4096 steps, so the segments required to bring the arm around must complete the portions of master and slave cycles not already accounted for. We will create two segments, which divide the remaining master and slave travels in two, and are mirror images of each other. The average ratio of these two segments must simply be slave travel divided by master travel, i.e., $(D / FOLMD)$. As previously determined, the FOLRN value for the boundaries of the stamping portion of the profile is 638. From this value and the average ratio, we can calculate the peak FOLRN value.

D = $0.5 * \text{remaining slave} = 0.5 * (4096 - 4 * 341) = 1366$
FOLMD = $0.5 * \text{remaining master} = 0.5 * [1000 * (3.4 - 2 * 0.866)] = 834$
peak ratio = FOLRN/1000
 $0.5 * (FOLRN/1000 + 1304/1000) = \text{average ratio} = D / FOLMD = 1366 / 834 = 1.638$
FOLRN = 1972 (solved from above)

Finally, we need to design a segment used to create a smooth entry into the repetitive portion of the profile. We'll assume that the home position of the arm is at 180 degrees, so it needs to achieve the FOLRN ratio of 1304 in 30 degrees (341 slave steps). Using the same averaging arithmetic as above, the required master distance for the entry segment is 523 steps. A sensor is positioned with this entry segment in mind, and wired to **TRG-1A**. A function to start motion when the sensor is triggered will be imbedded inside the profile. The motion segments for the stamping portion and recovery portions of the profile must be enclosed in a loop, and can be programmed by picking the numbers from the table and equations above. Because the ratio denominators are the same for all segments, and the slave distances are the same for the entry and each of the stamping segments, these are commanded only when the values change.

Repetitive Portion of Profile



```

Program  FOLMAS21      ; Follow extra encoder
        FOLEN1       ; Enable Following mode
        INFNC1-H    ; Enable trigger 1 (TRG-1A) for interrupt function
        SCALE0      ; Parameters are in steps

        DEF STAMP   ; Start program definition
        1TRGFNA1    ; Axis 1 profile starts upon trigger 1 (TRG-1A)
        FOLRD1000   ; Ratio denominator, 1000 steps per inch
        ;define the entry segment
        D341        ; Distance of 341 steps is about 30 degrees
        FOLRN1304   ; Goal ratio for start segment
        FOLMD523    ; Master distance during ramp
        GOBUF1      ; Build start segment
        PLOOP0      ; Start the continuous loop
        ;this profile section starts 2-to-1 ratio, or a starting FOLRN1304
        FOLRN753    ; Goal ratio for segment
        FOLMD366    ; Master travel in steps for segment
        GOBUF1      ; Build motion segment
        ;the 2nd section of profile starts with the final ratio of the 1st section
        FOLRN652    ; Goal ratio for segment
        FOLMD500    ; Master travel in steps for segment
        GOBUF1      ; Build motion segment
        ;the next two sections are mirror images of the first two
        FOLRN753    ; Goal ratio for third segment
        FOLMD500    ; Master travel in steps for 3rd segment
        GOBUF1      ; Build motion segment
        FOLRN1304   ; Goal ratio for 4th segment
        FOLMD366    ; Master travel in steps for 4th segment
        GOBUF1      ; Build motion segment
        ;the next two sections complete the loop and are mirror images of each other
        D1366       ; Slave travel in recovery segments
        FOLMD834    ; Master travel in steps for recovery segments
        FOLRN1972   ; Goal ratio for ramp up segment
        GOBUF1      ; Build ramp up motion segment
        FOLRN523    ; Goal ratio for ramp down segment
        GOBUF1      ; Build ramp down motion segment
        PLN1        ; End of loop cycle
        ;finally, a segment to end motion
        D341        ; Distance of 341 steps is about 30 degrees
        FOLRN0      ; Goal ratio for end segment
        FOLMD1000   ; Master distance during ramp
        GOBUF1      ; Build end segment
        END         ; End of STAMP program definition

        PCOMP STAMP ; Compile the program

        ; *****
        ; * To execute the program, enter the PRUN STAMP command *
        ; *****

```

On-the-Fly Motion (pre-emptive GOs)

While motion is in progress, you can change these motion parameters to affect a new profile:

- Acceleration (A) — s-curve acceleration is not allowed
- Deceleration (AD) — s-curve deceleration is not allowed
- Velocity (V)
- Distance (D)
- Preset or Continuous Positioning Mode Selection (MC)
- Incremental or Absolute Positioning Mode Selection (MA)
- Following Ratio Numerator and Denominator (FOLRN and FOLRD, respectively)

The motion parameters can be changed by sending the respective command (e.g., A, V, D, MC) followed by the GO command. If the continuous command execution mode is enabled (COMEXC1), you can execute buffered commands; otherwise (COMEXC0), you must prefix each command with an immediate command identifier (e.g., !A, !V, !D, !MC, followed by !GO).

The new GO command pre-empts the motion profile in progress with a new profile based on the new motion parameter(s). On-the-fly motion changes are applicable only for motion started with the GO command, and not for motion started with other commands such as HOM, JOG, JOY, PRUN or GOL.

On-the-fly motion changes are most likely to be used to change the velocity and/or goal position of a preset move already underway. In the event that the goal position is completely unknown before motion starts, a move can be started in continuous mode (MC1), with a switch to preset mode (MC0), a distance command (D), and a GO given later. In absolute positioning mode (MA1) the new goal position given with a pre-emptive GO is explicit in the D command. In incremental positioning (MA0) the distance given with a new pre-emptive GO is always measured from the at-rest position before the original GO. If a move is stopped (with the S command), and then resumed (with the C command), this resumed motion is considered to be part of the original GO. A subsequent distance given with a new pre-emptive GO is measured from the at rest position before the original GO, not the intermediate stopped position.

<pre> Programming Example: <i>This program creates a 2-tiered profile (single-axis) that changes velocity and deceleration at specific motor positions.</i> SCALE0 ; Disable scaling DEL OTF ; Delete program (in case program is already in memory) DEF OTF ; Begin definition of program PSET0 ; Set position to zero COMEXC1 ; Enable continuous command processing mode MC0 ; Select preset positioning MA0 ; Select incremental positioning A20 ; Set accel to 20 revs/sec/sec AD20 ; Set decel to 20 revs/sec/sec V9 ; Set velocity to 9 revs/sec D500000 ; Set distance to 20 revs GO1 ; Initiate motion WAIT(PC>100000) ; Wait until commanded position > 100000 steps (4 revs) V4 ; Slow down for machine operation GO1 ; Initiate new profile with new velocity WAIT(PC>450000) ; Wait until the motor position > 450000 steps (18 revs) AD5 ; Set decel for gentle stop V1 ; Slow down for gentle stop GO1 ; Initiate new profile with new velocity END ; End program definition </pre>

The table below summarizes the restrictions on pre-emptive GOs.

Condition	Possible?
Execute GO during MC1 & FOLENØ	Yes
Execute GO during MC1 & FOLEN1	Yes
Execute GO during MCØ & FOLENØ	Yes
Execute GO during MCØ & FOLEN1	No
Change MC setting during motion	Yes (but cannot change MC1 to MCØ during FOLEN1)
Change ENC setting during motion	No
Change FOLENØ to FOLEN1 during motion	No
Change FOLEN1 to FOLENØ during motion	Only while MC1, constant ratio, and not shifting

OTF Error Conditions

The ability to change the goal position on the fly raises the possibility of several error conditions:

Further instructions about handling error conditions are provided on page 30.

Error Conditions	6K Response		
	Set axis status bit 30	Set error status bit 10	Kill motion (decelerate at the LHAD value)
The new position goal of an on-the-fly GO cannot be reached with the current direction, velocity, and decel.	YES	YES	NO
The direction of the new goal position is opposite that of current travel	YES	YES	YES
There has not yet been an overshoot, but it is not possible to decelerate to the new distance from the current velocity using the specified AD value.	YES	YES	YES

RELATED STATUS COMMANDS

Axis Status — Bit 30: (this status bit is cleared with the next GO command)

AS.30Assignment & comparison operator — use in a conditional expression (see page 25).

TASFFull text description of each status bit. (see “Preset Move Overshot” line item)

TASBinary report of each status bit (bits 1-32 from left to right). See bit 30.

Error Status — Bit 10: The error status is monitored and reported only if you enable error-checking bit 10 with the ERROR command (e.g., ERROR.1Ø-1). **NOTE:** When the error occurs, the controller will branch to the error program (assigned with the ERRORP command). (this status bit is cleared with the next GO command)


ER.10Assignment & comparison operator — use in a conditional expression (see page 25).

TERFFull text description of each status bit. (see “Preset Move Overshot” line item)


TERBinary report of each status bit (bits 1-32 from left to right). See bit 10.

Scenarios


Scenario 1: OTF change of velocity and distance, where new commanded distance (D_2) is greater than the original distance (D_1) that was pre-empted [$D_2 > D_1$]. The distances are the areas under the profiles, starting at t_0 for both. If the original move had continued, D_1 would have been reached at time t_1 . D_2 is reached at time t_2 .



Scenario 2: OTF change of distance, where new commanded distance (D_2) is less than the original distance (D_1) that was pre-empted [$D_2 < D_1$]. In this example, the position where the OTF change was entered is already beyond D_2 (or D_2 cannot be reached with the commanded deceleration). The result is an error and motion is killed (decel at the LHAD value) and TAS bit 30 and TER bit 10 are set.




Scenario 3: OTF change of velocity. Note that motion must continue for a longer time at the reduced velocity to reach the original commanded distance than if it had continued at the original velocity ($t_2 > t_1$).



On-The-Fly Motion — Sample Application

A manufacturer of three products wishes to produce a “sampler-pak” package that will contain a few of each of his products. The products all have the same width and length, but are 3, 4, and 5 inches high respectively. The 3 products are fed from individual lines into a common conveyor, and arrive at a stacking and wrapping station. At this station, a tray accepts a product and must have moved down by that product’s height by the time the next product arrives. This means that each time a new product arrives, the velocity of the tray must be changed to match the height of that product. Although product spacing will be regular, the ordering of product type on the common conveyor will be random, due to variations in the input lines. Also, a finished sampler-pak should contain 5 products or be at least 18 inches high, whichever occurs first. This means that the total move distance of the tray will be unknown until the last product arrives. When the last product is stacked, an output is asserted that will pause the conveyor and start the wrapping process. When wrapping is complete, the sampler-pak is removed from the tray, and the tray returns to the starting position.

The basic problems in this application are that the move distance is not known until near the end, and the velocity must change on the fly. As the products approach the tray, they are detected with a near vertical arrangement of three sensors. Products of heights 3, 4, and 5 inches are detected by 1, 2, or all 3 sensors respectively. Input 1 always detects a product, and switches last, so that the others will be stable. When each product is identified, the motion profile is modified accordingly.



**Program
(portion only)**

```

VAR1=0           ; Initialize product count
VAR2=0           ; Initialize move distance variable
VAR3=0           ; Initialize velocity
A10              ; Moderate acceleration
MC0              ; Start with preset move
WHILE (VAR1<5 AND VAR2<18) ; Loop until cycle complete
WAIT (IN.1=B1)   ; Wait for start of next product
                 ; (onboard input 1 is activated)
VAR1=VAR1+1     ; Update product count
IF (IN.2=B1)    ; If not a 3" product
  IF (IN.3=B1)  ; If it is a 5" product
    VAR3=5     ; Set velocity
    VAR2=VAR2+5 ; Update distance
  ELSE        ; If not 5", must be 4"
    VAR3=4     ; Set velocity
    VAR2=VAR2+4 ; Update distance
  NIF        ; End of 5" case check
ELSE        ; 3" inch case
  VAR3=3     ; Set velocity
  VAR2=VAR2+3 ; Update distance
NIF        ; End of 3" case check
V(VAR3)    ; New velocity
D(VAR2)    ; New distance
WAIT (IN.1=B0) ; Wait for end of this product
GO1        ; Implement new distance and velocity
NWHILE    ; Sampler-pak completed product detection
WAIT (AS.1=B0) ; Wait for move to complete
OUT1      ; Output to indicate stacking complete

```

Registration

A “registration input” is a trigger input assigned the “trigger interrupt” function with the `INFNCi-H` command.

When a *registration input* is activated, the motion profile currently being executed is replaced by the registration profile with its own distance (`REG`), acceleration (`A` & `AA`), deceleration (`AD` & `ADA`), and velocity (`V`) values. The registration move can interrupt any preset, continuous, or registration move in progress.

The registration move does not alter the rest of the program being executed when registration occurs, nor does it affect commands being executed in the background if the controller is operating in the continuous command execution mode (`COMEXC1`).

Registration moves will not be executed while the motor is not performing a move, while in the joystick mode (`JOY1`), or while decelerating due to a stop, kill, soft limit, or hard limit.

How to Set up a Registration Move

Before you can initiate a registration move, you must program these elements (refer also to the programming examples below):

1. Configure one of the trigger inputs (`TRG-nA` or `TRG-nB` per axis) to function as a trigger interrupt input; this is done with the `INFNCi-H` command, where “i” is the input bit number representing the targeted trigger input. Note that the “Master Trigger” input cannot be used for registration.
2. Specify the distance of the registration move with the `REG` command. For servo axes, the distance refers to the encoder position (registration cannot be used with analog input feedback). For stepper axes, the distance refers to commanded position if `ENCCNT0` (default setting) or encoder position if `ENCCNT1`.
3. Enable the registration function with the `RE` command. Registration is performed only on the axis or axes with the registration function enabled, and with a non-zero distance specified in the respective axis-designation field of the `REG` command; the other axes will not be affected. Each trigger has a distinct move defined for its axis; for example, trigger 3 (called `TRG-2A`) can initiate a registration move for axis 2 with the specified `2REGA` distance.

NOTE: The registration move is executed using the `A`, `AA`, `AD`, `ADA`, and `V` values that were in effect when the `REG` command was entered.

⇒
ENCCNT: Encoder capture options for stepper axis are discussed on page 66.

Registration Move Accuracy (see also *Registration Move Status* below)

The accuracy of the registration move distance specified with the `REG` command is ± 1 count (servo axes: encoder count; stepper axes: commanded count if `ENCCNT0` or encoder count if `ENCCNT1`).

RULE OF THUMB: To prevent position overshoot, make sure the `REG` distance is greater than 4 ms multiplied by the incoming velocity.

The lapse between activating the registration input and commencing the registration move (this does not affect the move accuracy) is less than one position sample period (2 ms).

The `REG` distance will be scaled by the distance scale factor (`SCLD` value) if scaling is enabled (`SCALE1`). See page 51 for details on scaling.

Preventing Unwanted Registration Moves (*methods*)

- **Registration Input Debounce:** Registration Input Debounce: By default, the registration inputs are debounced for 2 ms before another input on the same trigger is recognized. (The debounce time is the time required between a trigger's initial active transition and its secondary active transition.) Therefore, the maximum rate that a registration input can initiate registration moves is 500 times per second. If your application requires a shorter debounce time, you can change it with the TRGLOT command.
- **Registration Single-Shot:** The REGSS command allows you to program the 6K controller to ignore any registration commands after the first registration move has been initiated. Refer to the REGSS command description for further details and an application example.
- **Registration Lockout Distance:** The REGLD command specifies what distance an axis must travel before any trigger assigned as a registration input will be recognized. Refer to the *Sample Application 3* below.

Registration Move Status & Error Handling

Axis Status — Bit 28: This status bit is set when a registration move has been initiated by any registration input (trigger). This status bit is cleared with the next GO command.

AS . 28 Assignment & comparison operator — use in a conditional expression (see page 25).
TASF..... Full text description of each status bit. (see “Reg Move Commanded” line item)
TAS..... Binary report of each status bit (bits 1-32 from left to right). [See bit 28.](#)

Axis Status — Bit 30: If, when the registration input is activated, the registration move profile cannot be performed with the specified motion parameters, the 6K controller will kill the move in progress and set axis status bit 30. This status bit is cleared with the next GO command.

AS . 30 Assignment & comparison operator — use in a conditional expression (see page 25).
TASF..... Full text description of each status bit. (see “Preset Move Overshot” line item)
TAS..... Binary report of each status bit (bits 1-32 from left to right). [See bit 30.](#)

Error Status — Bit 10: This status bit can be set if axis status bit 30 is set. The error status is monitored and reported only if you enable error-checking bit 10 with the ERROR command (e.g., ERROR . 10-1). **NOTE:** When the error occurs, the controller will branch to the error program (assigned with the ERRORP command). This status bit is cleared with the next GO command.

ER . 10 Assignment & comparison operator — use in a conditional expression (see page 25).
TERF..... Full text description of each status bit. (see “Preset Move Overshot” line item)
TER..... Binary report of each status bit (bits 1-32 from left to right). [See bit 10.](#)

Trigger Status — Bits 1-17: Trigger status bits are set when a registration move has been initiated by trigger inputs A or B for each axis, or with the TRIG-M (master trigger) input. This also indicates that the positions of all axes has been captured. As soon as the captured information is transferred or assigned/compared (see page 84), the respective trigger status bit is cleared (set to ∅).

TRIG..... Assignment & comparison operator — use in a conditional expression.(see page 25).
TTRIG..... Binary report of each status bit (bits 1-17 from left to right). From left to right the bits represent trigger A and B for axes 1-8, the 17th bit is master trigger M (the “MASTER TRIG” input terminal) — see page 76.


Further instructions about handling error conditions are provided on page 30.

Registration — Sample Application 1

In this example, two-tiered registration is achieved (see illustration below). While axes 1 is executing it's 50,000-unit move, trigger input 1 (TRG-1A) is activated and executes registration move A to slow the load's movement. An open container of volatile liquid is then placed on the conveyor belts. After picking up the liquid and while registration move A is still in progress, trigger input 2 (TRG-1B) is activated and executes registration move B to slow the load to gentle stop.

```

DEL REGI1      ; Delete program (in case program already resides in memory)
DEF REGI1      ; Begin program definition
INFNC1-H      ; Define trigger input 1 (TRG-1A) as trigger interrupt input
INFNC2-H      ; Define trigger input 2 (TRG-1B) as trigger interrupt input
A20           ; Set acceleration on axis 1 to 20 units/sec2
AD40          ; Set deceleration on axis 1 to 40 units/sec2
V1            ; Set velocity on axis 1 to 1 unit/sec
1REGA4000     ; Set TRG-1A's registration distance on axis 1 to 4000 units
              ; (registration A move will use the A, AD, & V values above)
A5            ; Set acceleration on axis 1 to 5 units/sec/sec
AD2           ; Set deceleration on axis 1 to 2 units/sec/sec
V.5           ; Set velocity on axis 1 to 0.5 units/sec
1REGB13000   ; Set TRG-1B's registration distance on axis 1 to 13,000 units
              ; (registration B move will use the A, AD, & V values above)
RE10         ; Enable registration on axis 1 only
A50          ; Set acceleration to 50 units/sec/sec on axis 1
AD50         ; Set deceleration to 50 units/sec/sec on axis 1
V10         ; Set velocity to 10 unit/sec on axis 1
D50000      ; Set distance to 50000 units on axis 1
GO10        ; Initiate motion on axis 1
END          ; End program definition
    
```




Registration — Sample Application 2

A user has a line of material with randomly spaced registration marks. It is known that the first mark must initiate a registration move, and that each registration move cannot be interrupted or the end product will be destroyed. Since the distance between marks is random, it is impossible to predict if a second registration mark will occur before the first registration move has finished.

```


DEL REGI2      ; Delete program (in case program already resides in memory)
DEF REGI2      ; Begin program definition
INFNC1-H      ; Trigger capture mode for trigger 1 (TRG-1A)
RE1           ; Enable registration
V2           ; Set registration move to a velocity of 2 rps
AD.5         ; a deceleration of 0.5 rev/sec/sec
1REGA20000   ; and a distance of 20000 steps for axis 1
MC1          ; Start a mode continuous
V1           ; move at a velocity of 1 rps
GO1          ; Initiate motion
END           ; End program definition
    
```



In order to stop the second registration from occurring, REGSS can be used:

```


DEL REGI2b    ; Delete program (in case program already resides in memory)
DEF REGI2b    ; Begin program definition
INFNC1-H      ; Trigger capture mode for trigger 1 (TRG-1A)
RE1           ; Enable registration
V2           ; Set registration move to a velocity of 2 rps
AD.5         ; and a distance of 20000 steps for axis 1
REGSS1        ; Enable registration single shot mode
MC1          ; Start a mode continuous
V1           ; move at a velocity of 1 rps
GO1          ; Initiate motion
END           ; End program definition
    
```



Registration — Sample Application 3

A print wheel uses registration to initiate each print cycle. From the beginning of motion, the controller should ignore all registration marks before traveling 2000 steps. This is to ensure that the unit is up to speed and that the registration mark is a valid one.

```
DEL REGI3      ; Delete program (in case program already resides in memory)
DEF REGI3      ; Begin program definition
INFNC1-H      ; Trigger capture mode for trigger 1 (TRG-1A)
RE1           ; Enable registration
V2            ; Set registration move to a velocity of 2 rps
1REGA2500     ; and a distance of 2500 steps for axis 1
REGLOD2000    ; Set registration lockout distance to 2000 steps
MC1           ; Start a mode continuous
V1            ; move at a velocity of 1 rps
GO1           ; Initiate motion
END           ; End program definition
```



Synchronizing Motion (GOWHEN and TRGFN operations)


GOWHEN and TRGFN allow you to synchronize the execution of motion on one or more axes:

- GOWHEN — synchronize execution of the subsequent start-motion command (GO, GOL, FGADV, FSHFC, or FSHFD) to:
 - Position (commanded, feedback device, motor, master, slave, Following shift)
 - Master cycle number
 - Input status
 - Time delay (dwell)
- TRGFN:
 - Suspend execution of the next start-motion command (GO, GOL, FGADV, FSHFC, or FSHFD) until the specified trigger input goes active.
 - Suspend beginning a new Following master cycle until the specified trigger input goes active.

Conditional “GO”s (GOWHEN) The GOWHEN command is used to synchronize a motion profile of an axis with a specified position count, input status, dwell (time delay), or master cycle number on that axis or other axes. Command processing does not wait for the GOWHEN conditions (relational expressions) to become true during the GOWHEN command. Rather, the motion from the subsequent start-motion command (GO, GOL, FGADV, FSHFC, and FSHFD) will be suspended until the condition becomes true.

Start-motion type commands that **cannot** be synchronized using the GOWHEN command are: HOM, JOG, JOY, and PRUN. A preset GO command that is already in motion can start a new profile using the GOWHEN and GO sequence of commands. Continuous moves (MC1) already in progress can change to a new velocity based upon the GOWHEN and GO sequence. Both preset and continuous moves can be started from rest with the GOWHEN and GO sequence.

GOWHEN
Syntax



EXAMPLES

```
GOWHEN (1PE>40000) ; suspend next GO until axis 1 encoder position > 40000
GOWHEN (IN.6=b1) ; suspend next GO until onboard input #6 is activated (b1)
GOWHEN (2PMAS>255) ; suspend next GO until the master for axis 2 has
; traveled 255 master distance units
```

SCALING

If scaling is enabled (SCALE1), the right-hand operand is multiplied by SCLD if the left-hand operand is FB, PC, PE, PSLV, or PSHF. The right-hand operand is multiplied by the SCLMAS value if the left-hand operand is PMAS. (The SCLD or SCLMAS values used correlate to the axis specified with the variable—e.g., a GOWHEN expression with 3PE scales the encoder position by the SCLD value specified for axis 3.)

GOWHEN
Status

Axis Status — Bit 26: Bit 26 is set when motion has been commanded by a GO, GOL, FGADV, FSHFC, or FSHFD command, but is suspended due to a pending GOWHEN condition. This status bit is cleared when the GOWHEN condition is true or when a stop (!S) or kill (!K or ^K) command is executed. An individual axis' GOWHEN command can be cleared using an axis-specific S or K command (e.g., !S11X0 or !K0XX1).

- AS.26 Assignment & comparison operator — use in a conditional expression (see page 25).
- TASF..... Full text description of each status bit. (see “Gowhen is Pending” line item)
- TAS Binary report of each status bit (bits 1-32 from left to right). See bit 26.

Axis Status — Bit 29: Bit 29 is set when the input state of position relationship specified in the GOWHEN expression was already true when the subsequent GO, GOL, FGADV, FSHFC or FSHFD command was executed.

- AS.29 Assignment & comparison operator — use in a conditional expression (see page 25).
- TASF..... Full text description of each status bit. (see “Gowhen Error” line item)
- TAS Binary report of each status bit (bits 1-32 from left to right). See bit 29.

Further instructions about handling error conditions are provided on page 30.

Error Status — Bit 14: Bit 14 is set if the input state or position relationship specified in the GOWHEN expression was already true when the subsequent GO, GOL, FGADV, FSHFC, or FSHFD command is issued. The error status is monitored and reported only if you enable error-checking bit 14 with the ERROR command (e.g., ERROR.14-1). **NOTE:** When the error occurs, the controller will branch to the error program (assigned with the ERRORP command).

ER.14Assignment & comparison operator — use in a conditional expression (see page 25).
 TERF.....Full text description of each status bit. (see “GOWHEN condition true” line item)
 TER.....Binary report of each status bit (bits 1-32 from left to right). See bit 14.

GOWHEN ...
On a Trigger Input

If you wish motion to be triggered with a trigger input, use the aTRGFNC1 command. The aTRGFNC1 command executes in the same manner as the GOWHEN command, except that motion is executed on specified axis “a” when the specified trigger input “c” is activated. For more information, see *Trigger Functions* below.

GOWHEN VS.WAIT

A WAIT will cause the 6K controller program to halt program flow (except for execution of immediate commands) until the condition specified is satisfied. Common uses for this function include delaying subsequent I/O activation until the master has achieved a required position or an object has been sensed.

By contrast, a GOWHEN will suspend the motion profile for a specific axis until the specified condition is met. It does **not** affect program flow. If you wish motion to be triggered with a trigger input, use the TRGFNC1 command. The TRGFNC1 command executes in the same manner as the GOWHEN command, except that motion is executed when the specified trigger input (c) is activated (see *Trigger Functions* below for details). In addition, GOWHEN expressions are limited to the operands listed above; WAIT can use additional operands such as FS (Following status) and VMAS (velocity of master).

Factors Affecting GOWHEN Execution

If, on the same axis, a second GOWHEN command is executed **before** a start-motion command (GO, GOL, FSHFC, or FSHFD), then the first GOWHEN is over-written by the second GOWHEN command. (GOWHEN commands are not nested.) An error is not generated when a GOWHEN command is over-written by another GOWHEN.

While waiting for a GOWHEN condition to be met **and** a start-motion command **has** been issued, if a second GOWHEN command is encountered, then the first sequence is disabled and another start-motion command is needed to re-arm the second GOWHEN sequence.

A new GOWHEN command must be issued for each start-motion command (GO, GOL, FGADV, FSHFC, or FSHFD). That is, once a GOWHEN condition is met and the motion command is executed, subsequent motion commands will not be affected by the same GOWHEN command.

If the GOWHEN and start-motion commands are issued, the motion profile is delayed until the GOWHEN condition is met. If a second start-motion command is encountered, the second start-motion command will override the GOWHEN command and start motion. If this override situation is not desired, it can be avoided by using a WAIT condition between the first start-motion command and the second start-motion command.

It is probable that the GOWHEN command, the GO command, and the GOWHEN condition becoming true can be separated in time, and by other commands. Situations can arise, or commands can be given that make the GOWHEN invalid or inappropriate. In these cases, the GOWHEN condition is cleared, and any motion pending the GOWHEN condition becoming true is canceled. These situations include execution of the JOG, JOY, HOM, PRUN, and DRIVEØ commands, as well motion being stopped due to hard or soft limits, a drive fault, an immediate stop (!S), or an immediate kill (!K or ^K).

⇒
GOWHEN in Compiled
 Motion (Compiled
 Motion is discussed on
 page 136)

When used in a compiled program, a *GOWHEN* will pause the profile in progress (motion continues at constant velocity) until the *GOWHEN* condition evaluates true. When executing a compiled Following profile, the *GOWHEN* is ignored on the reverse Following path (i.e., when the master is moving in the opposite direction of that which is specified in the *FOLMAS* command). A compiled *GOWHEN* can require up to 4 segments of compiled memory storage.


Sample 6K Code

In the example below, axis 2 must start motion when the actual position of axis 1 has reached 4. While axis 1 is moving, the program must be monitoring inputs and serving other system requirements, so a *WAIT* statement cannot be used; instead, a *GOWHEN* and *GO* sequence will delay the profile of axis 2.

```
MC00           ; Set both axes to preset move mode
D20,20        ; Set distance end-point
COMEXC1       ; Enable continuous command execution mode
V1,1          ; Set velocity
A100,100      ; Set acceleration
GOWHEN(,1PE>4) ; Delay axis 2 profile. When expression is true (position
               ; of encoder 1 is > 4), allow axis 2 to start motion.
GO11          ; Command both axes to move. Axis 2 will not start until
               ; conditions in the GOWHEN statement are true.
               ; Command processing does not wait, so other system
               ; functions can be performed.
```

Trigger Functions (TRGFN)

The Trigger Functions command (*TRGFN*) allows you to assign additional functions to trigger inputs that have been defined as “trigger interrupt” inputs (*INFNCi-H*):



- “**Conditional GO**” Function (*aTRGFNc1x*): Suspend execution of the next start-motion command on axis “a” until specified trigger input “c” goes active. Start-motion commands are listed below. Refer to page 159 or to the *GOWHEN* command description for additional details.
 - *GO* (standard command to begin motion)
 - *GOL* (begin linear interpolated motion)
 - *FGADV* (begin geared advance – for Following motion)
 - *FSHFC* (begin continuous shift – for Following motion)
 - *FSHFD* (begin preset shift – for Following motion)

Axis status bit 26 (reported with *TASF*, *TAS*, or *AS*) is set to one (1) when there is a pending “Conditional GO” condition initiated by a *TRGFN* command; this bit is cleared when the trigger is activated or when a stop command (*S*) or a kill command (*K*) is issued. If you need execution to be triggered by other factors (e.g., input state, master position, encoder position, etc.) use the *GOWHEN* command.

- “**New Master Cycle**” Function (`aTRGFNCx1`): This is equivalent to executing the `FMCNEW` command. When specified trigger input “c” goes active, the controller begins a new Following master cycle on axis “a”. For more information on master cycles, see page 183 or to the `FMCNEW` command description.

These trigger functions are cleared once the function is complete (trigger input is activated). To use the trigger to perform a `GOWHEN` function again, the `TRGFN` command must be given again.

```

Sample  INFNC2-H ; Define trigger 2 (TRG-1B) as a trigger interrupt input
6K Code INFNC4-H ; Define trigger 4 (TRG-2B) as a trigger interrupt input
1TRGFNBx1 ; When TRG-1B goes active, axis 1 will begin a
; new master cycle
2TRGFNB1x ; When TRG-2B goes active, axis 2 will execute the move
; commanded with the GO command.
GO01 ; The move on axis 2 is commanded, but will not execute
; until trigger 2B goes active.

```


CHAPTER SIX



Following

IN THIS CHAPTER

This chapter will help you understand Ratio Following:

- Introduction to Ratio Following 166
- Implementing Ratio Following 168
- Master Cycle Concept 183
- Technical Considerations for Following 189
- Troubleshooting for Following 199
- Following Commands (list)..... 200

Ratio Following – Introduction

Compiled Profiles

You can pre-compile Following profiles (saves processing time). See page 139 for details.

As part of its standard features, the 6K Series Controller family allows you to solve applications requiring *Ratio Following*.

Ratio Following is, essentially, controlled motion based on the measurement of external motion. This includes concepts such as an electronic gearbox, trackball, follower axis feed-to-length, as well as complex changes of ratio as a function of master position. Ratio Following can include continuous, preset, and registration-like moves in which the velocity is replaced with a ratio.

The follower axis can follow in either direction and change ratio while moving, with phase shifts allowed during motion at otherwise constant ratio. Ratio changes or new moves can be dependent on master position or based on receipt of a trigger input. Also, a follower axis can perform Following moves or normal time-based moves in the same application because Following can be enabled and disabled at will. *Product cycles* (operations that repeat with periodic master travel) can be easily specified with the master cycle concept (see page 183).

In Ratio Following, acceleration ramps between ratios will take place over a user-specified master distance. Product cycles can be easily specified with the master cycle concept.

This chapter highlights the capabilities of the 6K Following features and provides application examples. If you need more details on the operation or syntax of a particular command, please see the *6K Series Command Reference*.

Before delving into the specifics of Ratio Following, read on to gain a basic understanding of how the 6K controller *follows*.

What can be a master?

Any axis on the 6K controller can be made to any of the master input (“master”) sources listed in the table below. All of the 6K controller’s axes can be following at the same time with the same or different master.

- Commanded position
- Incremental encoder. The encoder can be one of the axis-related “ENCODER” ports, or it can be the “MASTER ENCODER” port.
- Analog input (servo axes only). This requires an ANI SIM be installed on an expansion I/O brick (see your product’s *Installation Guide* for instructions). ANI SIMs and expansion I/O bricks are sold separately.
- Internal count source (a “virtual master” option)
- Internal sine wave source (a “virtual master” option)
- Integer variable (VARI)

A servo axis cannot follow its own feedback device input (encoder or analog input). A stepper axis can follow its own encoder input, as long as that axis does not use the Stall Detect feature (ESTALL1 mode).

For instructions on assigning a master for a particular follower axis, see *Define the Master and Follower Axes* (page 168), or see the FOLMAS command description in the *6K Series Command Reference*.

Following Status (TFSE, TFS & FS Commands)

Many of the Following features described in this document have associated status bits that can be displayed (with the TFSE and TFS commands) or used in assignment or comparison operations (with the FS operator). The portions of this document that describe those features also summarize the related status bits.

FS Bit Function (YES = 1; NO = 0)

- 1..... Follower in Ratio Move..... A Following move is in progress.
- 2..... Ratio is Negative The current ratio is negative (i.e., follower counts counting in the opposite direction from master).
- 3..... Follower Ratio Changing.. The follower is ramping from one ratio to another (including a ramp to or from zero ratio).
- 4..... Follower At Ratio The follower is at constant non-zero ratio.

Bits 1-4 indicate the status of the follower axis in Following motion.

- * 5..... FOLMAS Active..... A master is specified with the FOLMAS command.
- * 6..... FOLEN Active Following has been enabled with the FOLEN command.
- * 7..... Master is Moving The specified master is currently in motion.
- 8..... Master Dir Neg The current master direction is negative. (Bit must be cleared to allow Following move in preset mode—MC0).

Bits 5-8 indicate the status required for Following motion (i.e., a master must be assigned, Following must be enabled, the master must be moving, and for many features, the master direction must be positive). Unless the master is a commanded position of another axis, minor vibration of the master will likely cause bits 7-8 to toggle on and off, even if the master is nominally "at rest". These bits are meant primarily as a quick diagnosis for the absence of master motion, or master motion in the wrong direction. Many features require positive master counting to work properly.

- 9..... OK to Shift Conditions are valid to issue shift commands (FSHFD or FSHFC).
- 10..... Shifting now A shift move is in progress.
- 11..... Shift is Continuous..... An FSHFC-based shift move is in progress.
- 12..... Shift Dir is Neg..... The direction of the shift move in progress is negative.

Bits 9-12 indicate the shift status of the follower. Shifting is super-imposed motion, but if viewed alone, can have its own status. In other words, bits 10-12 describe only the shifting portion of motion.

- 13..... Master Cyc Trig Pend..... A master cycle restart is pending the occurrence of the specified trigger.
- 14..... Mas Cyc Len Given A non-zero master cycle length has been specified with the FMCLN command.
- 15..... Master Cyc Pos Neg..... The current master cycle position (PMAS) is negative. This could be by caused by a negative initial master cycle position (FMCP), or if the master is moving in the negative direction.
- 16..... Master Cyc Num > 0..... The master position (PMAS) has exceeded the master cycle length (FMCLN) at least once, causing the master cycle number (NMCY) to increment.

Bits 13-16 indicate the status of master cycle counting. If a Following application is taking advantage of master cycle counting, these bits provide a quick summary of some important master cycle information.

- 17..... Mas Pos Prediction On..... Master position prediction has been enabled (FPPEM).
- 18..... Mas Filtering On A non-zero value for master position filtering (FFILT) is in effect.
- 19..... <RESERVED>
- 20..... <RESERVED>

Bit 17 and 18 indicate the status of master position measurement features.

- 21..... <RESERVED>
- 22..... <RESERVED>
- 23..... OK to do FGADV move..... OK to do Geared Advance move (master assigned with FOLMAS, Following enabled with FOLEN, and follower axis is either not moving, or moving at constant ratio in continuous mode).
- 24..... FGADV move underway Geared Advance move profile is in progress.

Bits 23 and 24 indicate the status of a Geared Advance move.

- 25..... <RESERVED>
- 26..... FMAXA/FMAXV limited..... The present Following move profile is being limited by FMAXA or FMAXV.
- 27..... <RESERVED>
- 28..... <RESERVED>

Bits 23 and 24 indicate the status of a Geared Advance move.

* All these conditions must be true before Following motion will occur.

Implementing Ratio Following

This section covers the basic elements of implementing Ratio Following:

- Applying Following setup parameters
- Move profiles
- Performing phase shifts (FSHFC and FSHFD)
- Geared advanced (FGADV)
- Application scenarios:
 - Electronic gearbox
 - Trackball

Ratio Following Setup Parameters

Prior to executing a Following move, there are several setup parameters that must be specified. These parameters can be established:

⇒
Programming examples — see application examples later in this chapter.

- Define the *master* and *follower axes* (FOLMAS)
- Define master & follower scaling factors (SCLMAS, SCLA, SCLD, and SCLV) — *if required*
- Define the follower-to-master Following ratio (FOLRN and FOLRD)
- Define the master distance (FOLMD) — *define scaling first*
- Enable the Following Mode (FOLEN)

Following Status
 (see TFSF, TFS and FS commands)


Following Status bits 5-8 (see table below) are meant to indicate the status required for Following motion (i.e., a master must be assigned, Following must be enabled, the master must be moving, and for many features, the master direction must be positive).

Bits 7-8 represent master motion and master direction respectively. Unless the master is a commanded position of another axis, it is likely that minor vibration of the master will cause these bits to toggle on and off, even if the master is nominally “at rest”. These bits are meant primarily as a quick diagnosis for the absence of master motion, or master motion in the wrong direction. Many features require positive master counting to work properly.

Bit No.	Function (YES = 1; NO = 0)
5	FOLMAS Active A master is specified with the FOLMAS command.
6	FOLEN Active Following has been enabled with the FOLEN command.
7	Master is Moving The specified master is currently in motion.
8	Master Dir Neg The current master direction is negative. (bit must be cleared to allow Following move in preset mode—MCØ).

Define the Master and Follower Axes (FOLMAS)

The FOLMAS command defines the masters and the followers. The command syntax is:



- **Sign bit** (\pm): Specifies the count direction of the master source that will result in positive master travel counts. The sign bit is not meant to be used simply to change the direction of follower motion. That function can be done with the sign of the `D` command. Rather, the sign bit is used to allow forward motion of the physical master (e.g., conveyor belt, rotating wheel, or the continuous feed of material or product) to result in positive counts. Several features described later in this document require increasing master counts for proper operation. These include Following motion in preset positioning mode (`MCØ`), master cycle counting, and executing `GOWHEN` based on master cycle position.
- **Master source axis number** (1st `i`): Selects the axis number of the master source. This number is not required when selecting the Master Encoder as the master source. If the master source is “8” (`VARI`), this represents the integer variable (`VARI`) number.
- **Master source selection** (2nd `i`): Selects the master source (according to the master source axis number). The options, selected by their respective number, are:
 - 1.... Incremental encoder connected to one of the axis-related “ENCODER” ports, or the “MASTER ENCODER” port. If the master encoder is selected, the master source input number must be omitted from the syntax.
 - 2.... Analog input (servo axes only). This requires an ANI SIM be installed on an expansion I/O brick (see your product’s *Installation Guide* for instructions), and the ANI input must be designated as a master input source with the `ANIMAS` command. ANI SIMs and expansion I/O bricks are sold separately.
 - 4.... Commanded position
 - 5.... Internal count source (see “Following a Virtual Master” below for details)
 - 6.... Internal sine wave source (see “Following a Virtual Master” below for details)
 - 8.... `VARI` variable (see “Following an Integer Variable” below for details)

NOTES

- Servo controllers: The follower axis cannot use its own commanded position or its currently selected feedback device (encoder or ANI) as the master input.
- Stepper controllers: The follower axis cannot use its own commanded (motor) position as the master input. Also, a follower axis that is using the Stall Detect mode (`ESTALL1`) cannot use its own encoder as the master input.
- Multiple axes can follow the same count source (e.g., encoder) from the same master. However, multiple axes cannot follow different count sources (e.g., encoder and commanded position) from the same master.
- If scaling is enabled (`SCALE1`), the measurement of the master is scaled by the `SCLMAS` value.

As an example, suppose the **ENCODER 3** input is to be the master input for follower axis 2, and forward travel of the physical master (e.g., conveyor belt) results in negative counts on **ENCODER 3**. Given these operating constraints, you would use the `FOLMAS, -31` command.

The default setting is that all axes are disabled from being follower axes (@FOLMAS+Ø). If you do not want a particular axis to be a follower, simply leave it not configured (e.g., FOLMAS,+31,, command configures only axis 2 as a follower to encoder 3; the rest of the axes are left in the default state—not follower axes). If an axis is currently configured as a follower, you can disable its follower status by putting a zero (Ø) in the parameter field (e.g., the FOLMAS,Ø,, command disables axis 2 from being a follower axis).

As soon as the master/follower configuration is specified with the FOLMAS command, a continuously updated relationship is maintained between the follower's position and the master's position. The update period is 2 ms.

FOLMAS Setting Not Saved in Non-Volatile Memory

The FOLMAS configuration is not saved in non-volatile memory. Therefore, consider including it in the power-up program (STARTP).

Following a Virtual Master

The 6K controller allows two “Virtual Master” options for applications that require the synchronization features of Following, but have no external master to measure.

- Internal count source For example, this feature could be used in an application in which multi-axis electronic cams may need to start, stop and run backward together, under control of an internally generated “machine speed”, not an externally measured master encoder.
- Internal sine wave. Other applications require a sinusoidal trajectory, which may be achieved by following a sinusoidal master.

Internal Count Source

The internal count source is intended to mimic the counts that might be received on an external encoder port. Just as can be encountered with an external encoder, this count source can speed up, slow down, stop, or count backwards. There is one count source per axis, each with a user definable and variable count frequency. The count frequency, specified in counts per second with FVMFRQ, is a signed value, allowing the master to move forward or backwards. The rate at which the count frequency can change is specified in counts per second per second with the FVMACC command. This allows smooth changes in master velocity and direction. Neither of these commands are scaled or have associated report backs. The accumulated raw count and count rate have no report back, but can be accessed via TPMAS and TVMAS respectively if the internal count source is specified as master.

The associated commands are:

FVMFRQi,i,i,i,i,i,i,i..... Where “i” is the count frequency in counts/sec
(range is 0-1,000000)

FVMACCi,i,i,i,i,i,i,i..... Where “i” is the count accel in counts/sec²
(range is 0-9,999,999)

The count sources are always enabled, counting at the signed rate specified with the FVMFRQ command. There are no start or stop commands, no modes, distances, or limit inputs. To stop and start the count source, specify zero or non-zero values respectively for the FVMFRQ command. To add or subtract a “preset” number of counts (i.e., move the master forward or backward a “preset distance”), you must calculate the time required for that distance, (using the frequency and acceleration values), and command the appropriate value of FVMFRQ for that duration.

Internal Sine Wave

The internal sine wave is generated using the internal count source as a frequency input. By designating the internal sine wave as a master (e.g., FOLMAS+16), you can produce a sinusoidally oscillating motion, with control of the phase (angle), amplitude, and center of oscillation. There is one sine wave per axis, each using the variable count frequency (FVMFRQ) of that axis to increase or decrease the angle from which the sine is calculated.

Each count of the count frequency changes the angle by one tenth (0.1) of a degree. For example, a FVMFRQ value of 3600 would create an angular frequency of 3600 tenths degrees per second, or 1 cycle per second. When used as a source for the sine wave, the maximum value for FVMFRQ is 144000. This results in a maximum of 40 Hz angular frequency. Higher frequencies are not allowed because they can be subject to aliasing.

The associated commands are:

```
SINANGi,i,i,i,i,i,i,i..... Where "i" is the new angle (range is 0.0-360.0 degrees)
SINAMPi,i,i,i,i,i,i,i..... Where "i" is the amplitude (range is 0-9,999,999 —
                             maximum peak-to-peak is 16384))
SINGObbbbbbbb..... Where "b" is the binary start/stop for each master axis:
                             1 = restart from zero degrees
                             0 = stop the sine wave
```

The SINAMP command is included in the specification in order to allow a change in slave amplitude without changing the center of oscillation. Changing the ratio (with FOLRN) will also change the slave amplitude, but unless the command is given at exactly the master zero crossing, it will also change the center of slave oscillation. The center of oscillation can be changed by a controlled amount by using the FSHFD command. The SINAMP command affects the sine wave immediately, without any built in ramp in amplitude. If a gentle change is desired, a user program should be written that repeatedly issues the command with small changes in value, until the desired value is reached.

Using SINGO with a "0" parameter abruptly stops the sine wave, without changing its current magnitude. Using SINGO with a "1" parameter abruptly starts the sine wave, also without changing its current magnitude. To gently pause the slave output, use an FVMFRQ value of zero, with a moderate FVMACC value; to resume, restore the FVMFRQ value.

The SINGO with a "1" parameter always starts at the previous angle, which might not be the desired start of oscillation. The SINANG command will instantly change the angle and corresponding sine of the angle. This represents an abrupt change in master position. If the slave is still following when this occurs, there will be an abrupt change in commanded slave position. To start the slave properly, move the slave to the desired start position first (using MC0, D, GO), then issue SINANG, then MC1, GO1, and finally SINGO. If SINANG is issued without any parameters, the current angle is reported, not the most recent user SINANG command value.

Sinewave Example

In the example below, an analog input (ANI) is used for feedback on axes 1 and 2, without scaling, so distance is in ANI counts of 205 counts/volt. The ANI voltage range (ANIRNG) is left at its default of -10V to +10V. Axis 1 is supposed to oscillate at 1 Hz, centered around -4096, with a peak-to-peak amplitude of 2048. Axis 2 is supposed to oscillate at 0.1 Hz, centered around 7000, with a peak-to-peak amplitude of 2000. Because both the master axis and the follower axis use the same units, we can use a Following ratio of 1:1, and control the amplitude with the SINAMP command. In order to provide a gentle start, the oscillation is started at the bottom of the cycle, where the velocity is zero.

```
D-3072,6000      ; Establish desired bottom of oscillation
MC00            ; Put axes into preset move mode
GO11           ; Move axes to desired center locations
FOLMAS16,26    ; Axis 1 follows sine 1, axis 2 follows sine 2
FOLRN1,1       ; Set both axes to 1:1 ratio
FOLRD1,1
FOLEN11        ; Put axes into following mode
MC11           ; Put axes into continuous following
SINAMP1024,1000 ; Establish center to peak amplitudes
FVMFRQ3600,360 ; Establish frequencies
@FVMACC999999  ; Reach frequencies rapidly
SINANG270,270  ; Start angles at bottom of cycle
GO11           ; Lock follower axes to master (not started yet)
SINGO11        ; Start sine waves (and hence follower axis motion)
```

In observing operation, it is determined that for axis 2, the bottom of the cycle is correct

(minimum value 6000), but the top of cycle needs to change from 8000 to 8192. In order to correct this, both the center and amplitude need to increase by 96 ($192/2 = 96$):

```
FSHFD,96 ; Shift center of axis 2 only
SINAMP,1096 ; Increase amplitude of axis 2 only
```

Following an Integer Variable

Syntax is FOLMASn8. This option allows an axis to follow the integer variable (VARI) specified with “n”; that is, VARIn. The range for “n” is 1-8 (VARI1 – VARI8). For example, FOLMAS, 48 assigns axis 2 to follow VARI4.

This option is particularly useful in conjunction with the INVARI (Map Inputs to a VARI Variable) feature. INVARI continuously updates a specified VARI variable with the value of a specified group of digital inputs, allowing an axis to follow a binary input pattern. Another useful way to update the value of the VARI variable is to calculate its value in a PLCP program (launched with the SCANP command).

The INVARI and SCANP options for updating VARI are good choices, because both are performed every system update, thus facilitating smooth Following motion. It is also possible to use an extra task (multi-tasking) to calculate VARI values, but the resulting updates will not be as fast (not perfectly periodic); consequently, Follow motion will be less smooth.

Define the Master and Follower Scaling Factors (SCLMAS) ... if required

If you will be scaling your motion parameters (distance, velocity, acceleration/deceleration), be aware that the only variance from non-Following scaling is that the master source (distance) is scaled by the SCLMAS value. Virtual master sources are not scaled.

Typically, the master and follower scale factors are programmed so that master and follower units are the same, but this is not required. Consider the scenario below as an example.

The master is a 1000-line encoder (4000 counts/rev post-quadrature) mounted to a 50 teeth/rev pulley attached to a 10 teeth/inch conveyor belt, resulting in 80 counts/tooth (4000 counts/50 teeth = 80 counts/tooth). To program in inches, you would set up the master scaling factor with the SCLMAS800 command (80 counts/tooth * 10 teeth/inch = 800 counts/inch).

The follower axis is a servo motor with position feedback from a 1000-line encoder (4000 counts/rev). The motor is mounted to a 4-pitch (4 revs/inch) leadscrew. Thus, to program in inches, you would set up the follower scaling factor with the SCLD16000 command (4000 counts/rev * 4 revs/inch = 16K counts/inch).

NOTE: Additional details on scaling and non-scaled units of measure are presented on page 48.

Define the Follower-to-Master Following Ratio (FOLRN & FOLRD)

The FOLRN and FOLRD commands establish the goal ratio between the follower and master travel, just as the V command establishes the goal velocity for a typical non-Following move. The FOLRN command specifies the ratio's numerator (follower travel), and the FOLRD command specifies the ratio's denominator (master travel). If the denominator (FOLRD) is not specified, it is assumed to be 1.

FOLRNF can be used to define a final ratio for compiled Following profiles (see page 139).

FOLRN and FOLRD are specified with two positive numbers, but the resulting ratio applies to moves in both directions; the actual follower direction will depend on the direction commanded with the D command and master direction. Numeric variables (VAR) can be used with these commands for follower and/or master parameters (e.g., FOLRN (VAR1) : FOLRD3). The maximum value of the resulting quotient is 127 to 1.

For a preset Following move (MCØ mode), the FOLRN/FOLRD ratio represents the maximum allowed ratio. For a continuous move (MC1 mode), it represents the final ratio reached by the follower axis.

Example

As an example, assume the follower-to-master ratio is set to 5-to-3 for an axis (FOLRN5 : FOLRD3). The first parameter (5) is scaled by the SCLD value to give follower steps. The second parameter (3) is scaled by the SCLMAS value to give master steps. If the SCLD setting is 25000 and the SCLMAS setting is 4000, the follower-to-master step ratio would be $5 * 25000$

to 3 * 4000, or 125 follower steps for every 12 master steps.

Define the Master Distance (FOLMD)

The “master distance” for moves in the Following mode (FOLEN1) is analogous to the move time for normal time-based moves with Following disabled (FOLENØ). For time-based moves, the time required to ramp to a new velocity (MC1 mode) or move to a new position (MCØ mode) is determined indirectly by the acceleration (A), deceleration (AD), and velocity (V) command values. For Following mode moves, a ramp to a new ratio (MC1 mode) or a move to a new position (MCØ mode) takes place over a specific master distance, not over a specific time. This distance is defined directly by the user with the FOLMD command.

In other words, the FOLMD command defines the master distance over which a preset follower move will take place, or the master distance over which a continuous follower move will change from its current ratio (including zero) to the commanded ratio (ratio established by FOLRN and FOLRD).

By carefully specifying a master distance (FOLMD), a precise position relationship between master and follower during all phases of the profile is ensured.

⇒ **HINT:** If the follower axis is in continuous mode (MC1) and the master is starting from rest, setting FOLMD to Ø will ensure precise tracking of the master's acceleration ramp.

If scaling is enabled (SCALE1), the FOLMD value is scaled by the SCLMAS parameter.

Examples and more information on this topic can be found below in the section titled *Follower vs. Master Move Profiles*.

Enable the Following Mode (FOLEN1)

When an axis is configured as a follower with the FOLMAS command, it will continuously monitor the position and motion of its master, even if the follower is at rest. This allows subsequent motion to be related to the motion of the master via ratios (FOLRN/FOLRD) and ramping over master distances (FOLMD). Such moves are done with Following enabled (FOLEN1).

It is also possible, and sometimes desirable, to have the follower axis motion independent of master axis motion, yet still “aware” of master position. For example, a move might need to start at a specified master position, yet finish in a fixed time, independent of the master speed. This move would be performed with Following disabled (FOLENØ).

Following can be enabled or disabled between moves, as needed, without affecting the monitoring of the master.

If a move is performed with Following disabled, its motion profile is determined by the acceleration, deceleration, and velocity specified with the A, AD, and V commands. Its motion is the same as if the axis were not configured as a follower, but the axis does monitor the master.

If a move is performed with Following enabled, its profile is determined by the specified master distance (FOLMD) and Following ratio (FOLRN/FOLRD). The next section describes such profiles.

Follower vs. Master Move Profiles

Following Status (TFSE, TFS, and FS) bits 1-4 indicate the status of follower axis in Following motion. They mimic the meaning and organization of Axis Status (TASF and AS) bits 1-4, except that each bit indicates the current state of the ratio, rather than the current state of the velocity:


Bit No.	Function (YES = 1; NO = \emptyset)
1	Follower in Ratio Move A Following move is in progress
2	Ratio is Negative The current ratio is negative (i.e., the follower axis counts are counting in the opposite direction from the master counts).
3	Follower Ratio Changing .. The follower axis is ramping from one ratio to another (including a ramp to or from zero ratio).
4	Follower At Ratio The follower axis is at constant non-zero ratio.

Continuous Positioning Mode Moves

For Following moves in the continuous positioning mode (MC1), FOLMD specifies the exact master travel distance over which the follower axis ratio changes. This will be required for any application that uses multiple ratios and continuous moves for the construction of precisely defined multi-segment moves.

⇒ **HINT:** If the follower is in continuous mode (MC1) and the master is starting from rest, setting FOLMD to \emptyset will ensure precise tracking of the master's acceleration ramp.

In the profile below, the first two moves each change ratio over one master inch, and the final ramp to zero takes place over two master inches.



Example

In the sample 6K code below, assume the follower has a 1000-line encoder on axis 1, connected to a 2-pitch leadscrew. This gives 8000 follower axis steps per inch. The master is a toothed belt with a pulley connected to encoder 2, such that there are 800 master steps per inch.

```

SCALE1           ; Enable scaling
SCLD8000         ; Set axis 1 scaling so that follower commands are in inches
SCLMAS800        ; Set axis 1 scaling so that master commands are in inches
COMEXC1         ; Allow commands during motion
FOLMAS21         ; Define axis 1 master to be encoder input 2
FOLEN1          ; Enable Following on axis 1 (will follow encoder 2)
FOLMD1          ; Follower to change ratio over 1 inch of the master travel
FOLRD1          ; Set Following ratio denominator to 1 for subsequent ratios
D+              ; Set direction positive
MC1             ; Mode set to continuous clockwise moves
FOLRN1          ; Set Following ratio numerator to 1 (ratio set to 1:1)
FMCNEW1         ; Restart master cycle counting
GO1             ; Start axis 1 from rest to reach velocity of master
                ; (encoder 2)

WAIT(1FS.4=B1)  ; (for stepper axes) Wait until follower axis is at ratio
FOLRN3          ; Set Following ratio numerator to 3 (ratio set to 3:1)
GOWHEN (1PMAS>=2) ; Enable motion pre-processing so that the next ramp
                ; begins at master position 2
GO1             ; Follower starts ratio change to 3 to 1 at master position 2
FOLRN0          ; Set Following ratio numerator to zero (ratio is 0 to 1)
FOLMD2          ; Follower axis changes ratio over 2 inches of master travel
WAIT(1AS.26=b0) ; Wait until the previous ramp is started
                ; (GOWHEN bit in axis status register is cleared)
WAIT(1FS.3=b0)  ; Wait until the previous ramp is finished
GOWHEN(1PMAS>=5) ; Enable motion pre-processing so that follower motion
                ; begins at master position 5
GO1             ; Wait for master to reach 5 revolutions before
                ; follower axis starts ratio change to 0 (zero)

```

Preset Positioning Mode Moves


For preset positioning mode (MCØ) moves, the FOLMD parameter is the master distance over which the entire follower axis move is to take place.

As an example, a follower axis is to move 20 inches over a master distance of 25 inches with a maximum ratio of 1:1 (ratio set with the FOLRN1 and FOLRD1 commands). The program and a diagram of the move profiles are provided below.

```
FOLMAS31      ; Define axes 1 master to be encoder input port 3
FOLMD25      ; Define follower to perform the move over 25 inches
              ; of the master (encoder 3)
MC0          ; Set positioning mode to preset
MA0         ; Set preset positioning mode to incremental
D20         ; Set follower distance to 20 inches
FOLRN1      ; Set Following ratio numerator to 1
FOLRD1      ; Set Following ratio denominator to 1 (ratio is 1:1)
GO1         ; Perform the follower move
```



If the master distance specified is too large for the follower distance and ratio (FOLRN and FOLRD) commanded, the follower will never actually reach the commanded ratio, and the move profile will look similar to that below. Here, the FOLMD is 25 inches and the follower is commanded to move 10 inches:



If the master distance is too small for the follower distance and ratio commanded, the 6K controller will not perform the move at all. For example, if the FOLMD is 25, the ratio is 1:1, and the follower is commanded to move 30 inches, the move will not even be attempted. The error message “INVALID DATA” will be displayed (depending on the ERRVLV setting) and program execution will continue.

Performing Phase Shifts

Following Status (TFSF, TFS and FS) bits 9-12 indicate the shift status of the follower axis. Shifting is super-imposed motion, but if viewed alone, can have its own status. In other words, bits 10-12 describe only the shifting portion of motion.

Bit No.	Function (YES = 1; NO = 0)
9	OK to Shift Conditions are valid to issue shift commands (FSHFD or FSHFC).
10	Shifting now A shift move is in progress.
11	Shift is Continuous..... An FSHFC-based shift move is in progress.
12	Shift Dir is Neg..... The direction of the shift move in progress is negative.

When a follower axis is following a master continuously, it might be necessary to adjust, or *shift*, the Following *phase* (follower's position with respect to the master) independent of motion due to ratio moves. The FSHFC and FSHFD commands allow time-based follower moves to be superimposed upon ratio Following moves. Because phase shifts are time-based, they are independent of master motion; in fact, the master can be at rest and a shift can still be performed.

Use the FSHFD command to perform a preset shift move with a specific change in follower phase. The FSHFD distance value will be scaled by SCLD if scaling is enabled (SCALE1).

Use the FSHFC command to superimpose a continuous shift move in the positive (FSHFC1) or negative (FSHFC2) direction. The FSHFC parameters stop (0) and kill (3) can be used to halt a continuous FSHFC move or a preset FSHFD move without affect the ratio motion.

The most recently defined velocity and acceleration (i.e., the V and A values) for the follower will determine the basis for the superimposed shift move profile for both FSHFC and FSHFD moves. The commanded velocity of the FSHFC or FSHFD move will be added to the current velocity at which the follower is performing the Following move. For example, assume a follower is traveling at 1 rps in the positive direction as a result of following a master. If a FSHFC move is commanded in the positive direction at 2 rps, the follower's actual velocity (after acceleration) will be 3 rps.

For servos, shifting can be performed whenever Following is enabled (FOLEN1). For steppers, this can only be done while Following is enabled and the follower is either not in a move, or is in continuous positioning mode (MC1) and moving at constant ratio. For both products, TFS/FS bit 9 indicates when a shift is allowed.

The current follower position (TPSLV value) and the net follower shift accumulated since the most recent FOLEN1 command (TPSHF value) can be read into numeric variables (VAR) using the PSLV and PSHF commands, respectively (e.g., VAR6=2PSLV). They can also be used for subsequent decision making (e.g., IF (3PSHF<6), GOWHEN (1PSLV>VAR2), etc.). The TPSHF and PSHF values are set to zero each time the Following mode is enabled (FOLEN1), even if the follower is already in Following mode. This provides a way of clearing these values for programming convenience.

Note that the distance traveled during the time-based deceleration due to stop, kill, or limits is included in the PSHF value. By comparing "before and after" values of PSHF, a 6K program can calculate how much shift was required to perform visual- or sensor-based alignment of a master/follower phase relationship.

Phase Shift Examples

An FSHFC or FSHFD move can be needed to adjust the follower position *on the fly* because of a load condition that changes during the continuous Following move. Below are programming examples to demonstrate both shift methods.

FSHFC Example

An operator is visually inspecting the follower's continuous Following motion with respect to the master. If he notices that the master and follower are out of synchronization, it might be desirable to have an interrupt programmed (e.g., activated by pressing a push-button switch) that will allow the operator to move the follower at a superimposed correction speed until the operator chooses to have the follower start tracking the master again (by releasing the push-button). The programming example below illustrates this.

Assume all scale factors and set-up parameters have been entered for the master and follower. In this example, the follower (axis 1) is continually following the master at a 1:1 ratio. If the operator notices some mis-alignment between master and follower, he can press 1 of 2 pushbuttons (connected to onboard trigger inputs 1 and 2) to shift the follower in the positive or negative direction until the button is released. After the adjustment, the program continues on as before.

```
DEL SHIFT          ; Delete program before defining
DEF SHIFT          ; Begin definition of program called SHIFT
COMEXS1           ; Continue command execution after stop
COMEXC1           ; Continue command execution during motion
FOLMAS21          ; Axis 2 encoder input is the master for axis 1
FOLRN1            ; Set follower-to-master Following ratio numerator to 1
FOLRD1            ; Set follower-to-master Following ratio denominator to 1
                  ; (ratio set to 1:1)
FOLEN1            ; Enable Following mode on axis 1
A25               ; Set acceleration
AD18              ; Set deceleration
V5               ; Set velocity
D+                ; Set direction to positive
MC1               ; Select continuous positioning mode
GO1               ; Start following master continuously
VARB1=b10         ; Define onboard input pattern 1 and assign to VARB
VARB2=b01         ; Define onboard input pattern 2 and assign to VARB
$TESTIN           ; Define label called TESTIN
IF(IN=VARB1)      ; IF statement (if input 1 is activated, do the jump)
JUMP SHIFTP       ; Jump to shift follower axis in the positive direction
                  ; when pattern 1 active
NIF               ; End of IF statement
IF(IN=VARB2)      ; IF statement (if input 2 is activated, do the jump)
JUMP SHIFTN       ; Jump to shift follower axis in the negative direction
                  ; when pattern 2 active
NIF               ; End of IF statement
JUMP TESTIN       ; Return to main program loop
$SHIFTP           ; Define label called SHIFTP (subroutine to shift in
                  ; the positive direction)
FSHFC1            ; Start continuous follower shift in positive direction
WAIT(IN.1=B0)     ; Continue shift until input bit 1 is deactivated
FSHFC0            ; Stop shift move
WAIT(1FS.10=B0)  ; (stepper axes only) Wait until the shift is completed
JUMP TESTIN       ; Return to main program loop
$SHIFTN           ; Define label called SHIFTN (subroutine to shift
                  ; in the negative direction)
FSHFC2            ; Start continuous follower axis shift move in the
                  ; negative direction
WAIT(IN.2=B0)     ; Continue shift until bit 2 is deactivated
FSHFC0            ; Stop shift move
WAIT(1FS.10=B0)  ; (stepper axes only) Wait until the shift is completed
JUMP TESTIN       ; Return to main program loop
END               ; End definition of program called SHIFT
```

In this example, the follower axis follows a master that moves in a continuous cycle. Once each cycle, the master and follower both pick parts. The master's part is detected by a sensor connector to trigger 1B, and the follower's part is detected by a sensor connected to trigger 1A. After both parts are detected, they must be aligned. The sensors are mounted 2 inches apart from each other, so that proper alignment would result in 2 inches of follower axis travel between detection of the master's part and detection of the follower's part.

The follower axis position is sampled when each of the sensors activates. The difference between the follower axis positions is compared to the required 2 inches. If the measured difference is greater than or less than 2 inches, then a shift move to correct the alignment is made. At that point, the follower axis will then start tracking the master again. The follower axis (axis 1) is continually following the master at a 1:1 ratio.

```

DEL ALIGN          ; Delete program before defining
DEF ALIGN          ; Begin definition of program called ALIGN
COMEXC1           ; Allow continuous command execution during motion
FOLMAS31          ; Axis 3 Encoder input is the master for follower axis 1
FOLRN1            ; Set follower-to-master ratio numerator to 1
FOLRD1            ; Set follower-to-master ratio denominator to 1
                  ; (ratio set to 1:1)
FOLEN1            ; Enable Following mode on axis 1
MC1               ; Enable continuous positioning mode
D+                ; Set direction to positive
GO1               ; Start Following master continually
INFNC1-H          ; Enable trigger input 1A to latch position of follower
                  ; when the follower's part is detected
INFNC2-H          ; Enable trigger input 1B to latch position of follower
                  ; when the master's part is detected
$SYNCLP           ; Main loop where synchronizing moves occur
WAIT(TRIG.1=b1 AND TRIG.2=b1)
                  ; Wait for both follower and master inputs to occur
VAR10=1PCCA       ; Load VAR10 with the follower commanded position due
                  ; to follower input activation
VAR11=1PCCB       ; Load VAR11 with the follower commanded position due
                  ; to master input activation
VAR12=VAR10-VAR11 ; Load VAR12 with the offset distance
VAR13=VAR12-2     ; Calculate the required shift
FSHFD(VAR13)      ; Perform synchronization move of distance in VAR13
JUMP SYNCLP       ; Return (jump) to main program loop
END                ; End of program

```

Geared Advance Following

The FGADV command provides the ability to super-impose an advance or retard on Following motion. This is the same ability provided by the FSHFD command (see *Performing Phase Shifts* above), except that the super-imposed motion is also geared to master motion. The FGADV command has the positive or negative “advance” distance as a parameter, but it initiates motion instead of simply setting up the distance. The shape of the super-imposed profile is determined by the FOLMD, FOLRN, and FOLRD commands (just as a normal preset Following move).

The FGADV command profile can be delayed with the GOWHEN command.

A FGADV move can be performed only while the conditions below exist (Following status bit 23, reported with the FS, TFS, and TFSF commands, indicates that it is “OK to do FGADV move”):

- Master is specified with a FOLMAS command
- Following is enabled with the FOLEN command
- The follower axis is either not moving, or moving at constant ratio in continuous mode (MC1)

A FGADV move cannot be performed:

- During a preset (MC0) move
- In a compiled profile or program Following Status (FS, TFS, and TFSF) bit 24 reports if a “FGADV move is underway”.

Example

```

COMEXC1      ; All command processing during motion
FOLRN25     ; Set numerator of follower-to-master Following ratio
FOLRD10     ; Set denominator of follower-to-master Following ratio
FOLMD1000   ; Set master distance to 1000 units
MC1         ; Enable continuous positioning mode
D+          ; Set direction to positive
FOLEN1      ; Enable Following
GO          ; Ramp up to a 2.5:1 ratio over 1000 master distance units
FOLMD500    ; Set master distance to 500 units
FOLRN13     ; Superimposed ratio will be 1.3 (added to 2.5 = 3.8 total)
WAIT(FS.23=B1) ; Wait for OK to do geared advance
              ; (in this case, ramp is complete)
FGAVD400    ; Advance the follower axis 400 counts over a distance
              ; of 500 master counts
WAIT (FS.23=B1) ; Wait for OK to do geared advance (in this case,
              ; FGADV400 super-imposed profile is complete)
FGADV-400   ; Retard the follower axis 400 counts over a distance of
              ; 500 master counts (2.5 - 1.3 = 1.2 net ratio)

```

Summary of Ratio Following Commands

ANIMAS.....Assigns an analog input to be used as a master in a FOLMAS assignment (requires a ANI SIM located on an expansion I/O brick)

FGADV.....Defines the geared advance distance

FOLEN.....Enables or disables Following mode

FOLMAS.....Defines masters for follower axes

FOLMD.....Defines the master distance over which follower acceleration or moves are to take place

FOLRN and FOLRD.....Establishes the maximum follower-to-master ratio for a preset move or the final ratio for a continuous move (FOLRN for the numerator and FOLRD for the denominator)

FSHFD.....Initiates preset advance or retard (shift) of follower position during continuous Following moves

FSHFC.....Initiates continuous advance or retard (shift) of follower position (or kills or stops the shift portion of motion) during continuous Following moves

FVMACC.....Establishes the rate at which the virtual master count frequency (FVMFRQ) can change for an axis.

FVMFRQ.....Defines the frequency of the virtual master count.

SCLD.....Sets the follower distance scale factor

SCLMAS.....Sets the master distance scale factor

SINAMP.....Defines the amplitude of the internal sine wave

SINANG.....Defines the phase angle of the internal sine wave

SINGO.....Initiates the internal sine wave

TPSHF or [PSHF]Transfers or assigns the net position shift since constant ratio

TPSLV or [PSLV]Transfers or assigns the current follower position

TVMAS or [VMAS]Transfers or assigns the velocity of the master axis

Electronic Gearbox Application for Ratio Following

An electronic gearbox is a classic application for Ratio Following. Suppose we need a three-output gearbox, with all three outputs geared off the same input. Also, each gear ratio must be individually programmed. In this example, a 1000-line encoder is mounted to the input shaft of a master motor, giving 4000 master counts per revolution after quadrature. This encoder is fed into the encoder input on axis 4 (**ENCODER 4** connector) of the 6K controller. The motors on axes 1, 2, and 3 have resolutions of 2000, 4000, and 5000 steps/revolution.

In this example, a precise position relationship is not required between master and followers, but a ratio change during motion is required. The ratio change will take place over one master revolution in order to avoid abrupt acceleration of the follower. The followers will accelerate to their initial ratios (in terms of revolutions), and after 10 seconds the gear ratio on each axis will change to their final ratios.

In this example, **ENCODER 4** is specified as the master. This means that this *external* master encoder is wired to the 6K controller's axis 4 encoder input.

Program (code portion)

```
*****  
; execute scaling before the program is executed  
SCALE1          ; Enable scaling  
SCLD2000,4000,5000 ; Set follower scale factors equal to the  
                  ; motor resolutions  
SCLA2000,4000,5000 ; Set acceleration scale factors equal to the  
                  ; motor resolutions  
SCLMAS4000,4000,4000 ; Master scale factor to number of pulses per rev  
*****  
COMEXC1        ; Allow continuous command execution during motion  
FOLMAS+41,+41,+41 ; Encoder 4 is master axis for follower axes 1-3.  
                  ; The + sign indicates that the master input is not  
                  ; inverted before it is read as master counts.  
  
FOLEN111       ; Enable followers to follow  
FOLMD1         ; Change to new ratio over one master revolution  
FOLRN1,3,2     ; Set follower-to-master ratio numerators to 1, 3 & 2  
FOLRD1,1,1     ; Set all follower-to-master ratio denominators to 1  
                  ; (initial Following ratio for axis 1 is 1:1, axis 2  
                  ; is 3:1, and axis 3 is 2:1)  
  
MC111         ; Enable continuous mode  
GO111         ; Begin follower continuous Following move  
TIMST0        ; Reset and start the timer  
FOLRN10,6,1   ; Set follower-to-master ratio numerators to 10, 6 & 1  
FOLRD1,7,2    ; Set follower-to-master ratio denominators to 1, 7 & 2  
                  ; (change Following ratios: axis 1 is 10:1,  
                  ; axis 2 is 6:7, axis 3 is 1:2)  
WAIT(TIM>=10000) ; Wait 10 seconds to change to new ratio  
GO111         ; Start moving to new ratio
```


Trackball Application for Ratio Following Motion

A trackball is a two-axis, two-dimensional positioning device; just as a mouse is used to position the cursor on a computer screen, a trackball could be used to position an X-Y stage.

In this example, a two-axis trackball is needed that can do fine and coarse positioning of an X-Y stage. The fine or coarse setting is selected by the user with a two-position switch connected to onboard trigger input 1 on the 6K controller. Onboard trigger input 2 on the 6K controller is used to switch back and forth from trackball to standard point-to-point positioning mode. *Unlocking* the stage from the trackball is necessary because of other point-to-point move requirements elsewhere in the 6K controller program.

The trackball housing has two encoders mounted at 90 degrees to each other that are driven by rubber wheels in contact with the ball. The stage is driven by motors and leadscrews.

For one inch of trackball motion to result in one inch of stage motion, the follower-to-master ratio must be 10-to-1; this will be the ratio for coarse positioning. The fine positioning ratio will be one tenth of that, or 1-to-1. When programmable input 1 is low, coarse positioning is selected, and when trigger input 2 goes low, the stage becomes locked to the trackball. Each change of state of trigger inputs 1 and 2 calls a different subroutine in the 6K controller program; however, the ratios can only change if the stage is locked to the trackball positioning mode.

The trackball is initially unlocked and fine positioning is selected.

Program

```
SCALE1                ; Enable & define scale factors before loading program
SCLD4000,4000          ; Follower axes 1 and 2 have 4000 counts per rev
                       ; resolution post-quadrature
SCLV4000,4000          ; Set velocity scaling factors
SCLA4000,4000          ; Set acceleration scaling factors
SCLMAS200,200          ; Master axis 3 and 4 have 200 counts per rev
                       ; resolution post-quadrature
DEL UNLOCK             ; Delete program before defining
DEF UNLOCK             ; Program that unlocks the stage from the trackball
S11                   ; Stop moves
WAIT(1AS.1=B0 AND 2AS.1=B0) ; (for steppers only)
                       ; Wait for motion to stop on both axes
ONIN.2-1              ; Set up onboard input 2 to lock trackball to stage
FOLEN00              ; Stop Following mode
ONP LOCK              ; Select LOCK as an ON program
JUMP WAITLP          ; Return to main loop
END                   ; End program definition

DEL LOCK
DEF LOCK              ; Program that locks the stage to the trackball
FOLEN11              ; Enable Following on both axis
IF(VAR1=0)           ; If in the FINE mode, set ratio to 0.5:1
FOLRN.5,.5
ELSE
FOLRN1.5,1.5         ; If in the COARSE mode, set ratio to 1.5:1
NIF
ONIN.2-0              ; Set up input 2 to unlock trackball from stage
GO11                 ; Start following the trackball
ONP UNLOCK           ; Select UNLOCK as ON program
JUMP WAITLP          ; Return to main loop
END                   ; End program definition

DEL COARSE
DEF COARSE           ; Declare COARSE label
FOLRN1.5,1.5         ; Coarse positioning ratio of 1.5 to 1
GO11                 ; Move to begin travel at new ratio
VAR1=1               ; Flag to indicate we are in coarse mode
END                   ; Return to main loop
```

(Continued on next page)

Trackball Program (Continued from previous page)

```
DEL FINE
DEF FINE          ; Subroutine to assign fine positioning
FOLRN.5,.5       ; Fine positioning ratio is 0.5:1
GO11             ; Move to begin travel at new ratio
VAR1=0           ; Flag to indicate we are in fine mode
END              ; Return to main loop

DEL TRACK
DEF TRACK        ; Main track ball program
IF(IN.1=b1 AND VAR1=0) ; If input 1 is set to 1 and we are
                    ; currently in fine mode, then enter coarse mode
    GOSUB COARSE  ; Set high ratio
NIF
IF(IN.1=b0 AND VAR1=1) ; If input 1 is set to 0 and we are
                    ; currently in coarse mode, then enter fine mode
    GOSUB FINE    ; Set low ratio
NIF
IF(LIM.1=b0 OR LIM.2=b0) ; If a limit is hit, allow track ball to move off
D~                ; Back off of the limit, axis 1
GO1
NIF
IF(LIM.4=b0 OR LIM.5=b0)
D,~              ; Back off of the limit, axis 2
GOX1
NIF
END

DEL MAIN
DEF MAIN        ; Begin definition of main program
V1,1           ; Set non-Following move parameters
A99,99
LH3,3,0,0
FOLMAS+31,+41 ; Encoder 3 is master axis for follower axes 1 and
                ; Encoder 4 is master axis for follower axes 2.
                ; The follower axes will move in the same direction as
                ; the master.

FOLRN.5,.5
INDEB250       ; Noisy switch debounce of 250 milliseconds for
                ; onboard trigger inputs
FOLRD1,1       ; Initial follower-to-master ratio is set to fine
                ; positioning (0.5:1)
VAR1=0         ; Flag set to fine positioning
MC11          ; Set both axes 1 and 2 to continuous positioning mode
FOLEN00       ; Following is initially disabled
COMEXC1       ; Continue command execution during motion.
COMEXS1       ; Continue command execution after stop
COMEXL11      ; Continue command execution after a limit is hit
SGP20,20      ; Set servo gains
SGV5,5
DRIVE11       ; Enable drives
DRFEN11       ; Enable checking for drive fault input states
DRFLVL11      ; Set drive fault level for Compumotor 670-T drives
ONP LOCK      ; Select LOCK as an ON program
ONIN.2-1      ; Trigger 1B locks trackball to stage
ONCOND1000    ; Inputs enabled for interrupts
$WAITLP       ; Main program loop
IF(IN.2=b1)   ; If trigger input 1B is set to 1 (stage locked),
                ; enter trackball mode
    GOSUB TRACK
NIF           ; End of IF statement

; *****
; * Other user programs can be added here for performing *
; * motion when the stage is not locked to the trackball. *
; *****

JUMP WAITLP   ; Return to main loop
END           ; End program definition
```

Master Cycle Concept

Ratio Following can also address applications that require precise programming synchronization between moves and I/O control based on master positions or external conditions. The concept of the master cycle greatly simplifies the required synchronization.

A master cycle is simply an amount of master travel over which one or more related follower axis events take place. The distance traveled by the master in a master cycle is called the *master cycle length*. A *master cycle position* is the master position relative to the start of the current master cycle. The value of master cycle position increases as positive-direction *master cycle counts* are received, until it reaches the value specified for master cycle length. At that point, the master cycle position becomes zero, and the *master cycle number* is incremented by one—this condition is called *rollover*.

The master cycle concept is analogous to minutes and hours on a clock. If the master cycle is considered an hour, then the master cycle length is 60 minutes. The number of minutes past the hour is the master cycle position, and current hour is the master cycle number. In this analogy, the master cycle position decrements from 59 to zero as the hour increases by one.

By specifying a master cycle length, periodic actions can be programmed in a loop or with subroutines that refer to cycle positions, even though the master can be running continuously. To accommodate applications where the feed of the product is random, the start of the master cycle can be defined with trigger inputs. Two types of *waits* are also programmable to allow suspension of program operation or follower moves based on master positions or external conditions.

Master Cycle Commands

Following Status (TFSE, TFS and FS) bits 13-16 indicate the status of master cycle counting. If a following application is taking advantage of master cycle counting, these bits provide a quick summary of some important master cycle information:

Bit No.	Function (YES = 1; NO = 0)
13	Master Cyc Trig Pend.....A master cycle restart pending the occurrence of the specified trigger.
14	Mas Cyc Len GivenA non-zero master cycle length has been specified with FMCLLEN.
15	Master Cyc Pos Neg.....The current master cycle position (PMAS) is negative. This could be by caused by a negative initial master cycle position (FMCP), or if the master is moving in the negative direction.
16	Master Cyc Num > 0.....The master position (PMAS) has exceeded the master cycle length (FMCLLEN) at least once, causing the master cycle number (NMCY) to increment.

Master Cycle Length (FMCLLEN)

The FMCLLEN command is used to define the length of the master cycle. The value entered with this command is scaled by the SCLMAS parameter to allow specification of the master cycle length in user units. This parameter must be defined before those commands that wait for periodically repeating master positions are executed.

The default value of FMCLLEN is zero, which means the master cycle length is practically infinite (i.e., 4,294,967,246 steps, after scaling). If a value of zero is chosen, the master cycle position will keep increasing until this very high value is exceeded or a new cycle is defined with the FMCNEW command (or triggered after a TRGFNCx1 command) described below. If a non-zero value for FMCLLEN is chosen, the internally maintained master cycle position will keep increasing until it reaches the value of FMCLLEN. At this point, it immediately rolls over to zero and continues to count.

The master cycle length can be changed with the FMCLLEN command even after a master cycle has been started. The new master cycle length takes affect as soon as it is issued. If the new master cycle length is greater than the current master cycle position, the cycle position will

not change, but will rollover when the new master cycle length is reached. If the new master cycle length is less than the current master cycle position, the new master cycle position becomes equal to the old cycle position minus one or more multiples of the new cycle length.

Example Code

```
FMCLen23,10,12,22 ; Set master cycle length for all four axes:
                  ; (axis 1: 23 units; axis 2: 10 units;
                  ; axis 3: 12 units; and axis 4: 22 units)
```

Restart Master Cycle Counting (FMCNEW or TRGFNCx1xxxxxx)

Once the length of the master cycle has been specified with the FMCLen command, master cycle counting can be restarted immediately with the FMCNEW command, or based on activating a trigger input as specified with the TRGFNCx1 command. The new master cycle count is started at an initial position specified with the FMCP command (see below).

When the TRGFNCx1 command is used, the restart of master cycle counting is pending activation of the specified trigger. If an FMCNEW command is issued while waiting for the specified trigger to activate, counting is restarted immediately with the FMCNEW command, and the TRGFNCx1 command is canceled.

When using TRGFNCx1

- Before the TRGFNC command can be used, you must first assign the trigger interrupt function to the specified trigger input with the INFNCi-H command, where “i” is the input number of the trigger input desired for the function (input bit assignments vary by product).
- Because the 6K controller program will not wait for the trigger to occur before continuing on with normal program execution, a WAIT or GOWHEN condition based on PMAS will not evaluate true if the restart of master cycle counting is pending the activation of a trigger. To halt program operation, the WAIT command can be used.

A new master cycle will restart automatically when the total master cycle length (FMCLen value) is reached. This is useful in continuous feed applications.

Example Code

```
FMCNEW11xx ; Restart new master cycle counting on axes 1 and 2
INFNC2-H ; Assign input 2 (TRG-1B) the trigger interrupt
          ; function (prerequisite to using the TRGFNC features)
1TRGFNBx1 ; When trigger input 2 (TRG-1B) goes active,
2TRGFNBx1 ; restart new master cycle counting on axes 1 and 2
```

Initial Master Cycle Position (FMCP)

The FMCP command allows you to assign **for the first cycle only**, an initial master cycle position to be a value other than zero. When master cycle counting is restarted with the FMCNEW command or with the trigger specified in the TRGFNCx1 command, the master cycle position takes the initial value previously specified with the FMCP command. The value for FMCP is scaled by SCLMAS if scaling is enabled (SCALE1)

FMCP was designed to accommodate situations in which the trigger that restarts master cycle counting occurs either before the desired cycle start, or somewhere in the middle of what is to be the first cycle. In the former case, the FMCP value must be negative. The master cycle position is initialized with that value, and will increase right through zero until it reaches the master cycle length (FMCLen). At that point, it will roll over to zero as usual.

The continuous cut-to-length example below illustrates the use of a negative FMCP (a trigger that senses the motion of the master is physically offset from the master position at which some action must take place). If it is desired that the first cycle is defined as already partially complete when master cycle counting is restarted, the FMCP value must be greater than zero, but less than the master cycle length.

To give a value for FMCP that is greater than master cycle length is meaningless since master cycle positions are always less than the master cycle length. The 6K controller responds to this case as soon as a new master cycle counting begins by using zero instead of the initial value specified with FMCP.

Transfer and
Assignment/
Comparison of Master
Cycle Position and
Number

The current master cycle position and the current master cycle number can be displayed with the `TPMAS` and `TNMCY` commands, respectively. These values can also be read into numeric variables (`VAR`) at any time using the `PMAS` and `NMCY` commands (e.g., `VAR6=NMCY`). If position capture is used, the master cycle position can be captured, and the value is available with the `TPCMS` and `PCMS` commands.

Very often, the master cycle number will be directly related to the quantity of product produced in a manufacturing run, and the master cycle position can be used to determine what portion of a current cycle is complete.

The master cycle number is sampled once per *position sampling period* (see note, left). If the master cycle length (`FMCLLEN`) divided by the master's velocity (`VMAS`) is less than the position sampling period (2 ms), then the sample (`TNMCY` or `NMCY` value) cannot be accurate.

Details on using `PMAS` in conditional expressions is provided below in *Using Conditional Statements with PMAS*.

Using Conditional
Statements with
Master Cycle Position
(`PMAS`)

The current master cycle position (`PMAS`) value can be used in comparison expressions, just like other position variables such as `PC`, `PE`, and `FB`. `PMAS` is a special case, however, because its value rolls over to zero when the master cycle length (`FMCLLEN`) is met or exceeded. This means that `PMAS` values greater than or equal to the master cycle length will never be reported with the `TPMAS` command, or with expressions such as (`VAR1=1PMAS`).

The other fact that makes `PMAS` special is that master cycle counting can be restarted after the command containing the `PMAS` expression has been executed. Either the `FMCNEW` command or the `TRGFNCx1` command can be used to restart counting, each with a different effect on the evaluation of `PMAS`.

The treatment of `PMAS` in comparison expressions depends on the command using the expression, as described below. `WAIT` and `GOWHEN` are treated as special cases.

`IF`, `UNTIL`, and
`WHILE`

These commands evaluate the current value of `PMAS` in the same way that `TPMAS` does (i.e., `PMAS` values will never be greater than or equal to the master cycle length). With these commands, avoid comparing `PMAS` to be greater than or equal to variables or constants that are nearly equal to the master cycle length, because rollover can occur before a `PMAS` sample is read that makes the comparison true. If such a comparison is necessary, it should be combined (using `OR`) with a comparison for master cycle number (`NMCY`) being greater than the current master cycle number.

Also, master cycle counting restart can be pending activation of a trigger, but this will not affect the evaluation of `PMAS` for `IF`, `WAIT`, and `WHILE`. It is simply evaluated based on counting currently underway.

`WAIT` and `GOWHEN`

These commands evaluate the current value of `PMAS` differently than `TPMAS` does, in such a way that it is possible to compare `PMAS` to variables or constants that are greater than or equal to the master cycle length and still have the comparison be reliably detected.

Effectively, `PMAS` is evaluated as if the master cycle length were suddenly set to its maximum value (2^{32}) at the time the `WAIT` or `GOWHEN` command is encountered. It eliminates the need to `OR` the `PMAS` comparison with a comparison for master cycle number (`NMCY`) being greater than the current master cycle number. Such multiple expressions are not allowed in the `GOWHEN` command, so this alternative evaluation of `PMAS` offers the required flexibility.

This method of evaluation of `PMAS` allows commands that sequence follower axis events through a master cycle to be placed in a loop. The `WAIT` or `GOWHEN` command at the top of the loop can execute, even though the actual master travel has not finished the previous cycle. If it is desired to `WAIT` or `GOWHEN` for a master cycle position of the next master cycle, the variable or constant specified in the command should be calculated by adding one master cycle length to the desired master cycle position.

Finally, master cycle counting restart can be pending activation of a trigger (`TRGFNCx1`), and

Synchronizing
Following Moves with
Master Positions

this will suspend the evaluation of PMAS for these commands. PMAS is not sampled, and the comparison evaluates as false. During this time, if the pending status of master cycle counting restart is aborted with FMCNEWØ, the GOWHEN condition is also cleared, and any motion profile of any axis waiting on *that* PMAS comparison will be canceled. Otherwise, when master cycle counting is restarted by a trigger, evaluation takes place as described above. This allows GOWHEN to include waiting on a trigger without explicitly including it in the GOWHEN expression.

A final special case allows perfect synchronization between the start of a Following motion profile of a follower axis and a specified position of its master. If a GOWHEN (nPMAS >= xxx) expression is used to synchronize a follower with its own master, with the operator specifically ">=", a special synchronization occurs. Although it can be impossible for the 6K product to sample the exact master position specified, the Following motion profile is calculated from master travel based on that position. This allows for the construction of profiles in which the synchronization of master and follower positions is well defined and precisely maintained. This feature requires positive travel of the master, which can be achieved with the appropriate sign for the FOLMAS specification.

Summary of Master Cycle and Wait Commands

FMCLen.....	Defines the length of the master cycle
FMCNEW.....	Immediately restart master cycle counting
FMCP.....	Defines the initial position of a new master cycle
GOWHEN.....	GOWHEN suspends execution of the next move on the specified axis or axes until the specified conditional statement (based on T, IN, LIM, FB, NMCY, PC, PE, PMAS, PSLV, or PSHF) is true
TNMCY or [NMCY]	Transfers or assigns the current master cycle number
TPCMS or [PCMS]	Transfers or assigns the captured master cycle position
TPMAS or [PMAS]	Transfers or assigns the current master cycle position
TRGFN.....	aTRGFNc1x initiates a GOWHEN, suspending execution of the next follower move on axis (a) until the specified trigger input (c) goes active. aTRGFNcx1 causes master cycle counting to restart when the specified trigger input (c) goes active.
WAIT.....	WAIT suspends program execution until the specified conditional statement (based on PMAS, FS, NMCY, PCMS, PSHF, PSLV, or VMAS) is true; WAIT (SS.i=b1) suspends program execution until a trigger input is activated. The "i" is the programmable input bit corresponding to the trigger input. (Input bit assignments vary by product; see the Programmable I/O Bit Patterns table on page 76 to determine the correct bit pattern for your product.)
AS and TAS bit 26.....	AS and TAS (and TASF) bit 26 is set when there is a profile suspended pending GOWHEN condition, initiated either by a GOWHEN command or a TRGFNc1 command; this bit is cleared when the GOWHEN condition is true or when a stop or kill command is issued.
ER and TER bit 14.....	ER, TER, and TERF bit 14 is set if the GOWHEN condition is already true when the GO, GOL, FGADV, FSHFC, or FSHFD command is given (ERROR bit 14 must first be enabled to check for this condition)




NOTE

The continuous cut-to-length application example below illustrates the use of the master cycle concept and the commands above.

Continuous Cut-to-Length Application

This application requires automobile trim to be cut to a pre-defined length. The saw is controlled by axes 1 and 2 on the 6K controller. It must be moving with the material while the cut is being made (axis 1), and also move perpendicular to the trim (axis 2) to actually make the cut. The trim comes in long stock that moves continuously under the cutting area.

The leading edge of the trim stock is detected with a sensor connected to trigger 1 that is located 4 inches from the home position of the saw. Axis 1 will be following the trim based on an encoder mounted on the trim via a friction wheel. The encoder is a 1000-line encoder and the wheel is geared to give 2 revolutions per inch of trim, resulting in 8,000 post-quadrature steps per inch of trim. Axis 1 has a resolution of 4,000 steps per rev and is connected to a 2-pitch leadscrew 24 inches in length. Axis 2 is similar in mechanics but its length is 10 inches. The travel on Axis 1 will be controlled by the speed at which axis 2 makes its cut. The travel on axis 2 is a fixed speed of 5 inches per second, with a fixed cross stroke of 5 inches. Limit switches are in place for safety.



The master cycle length will be set equal to the desired cut length (36" in the example below), which the operator can change by modifying variable VAR1. The cut cycle will be a continuous loop, but the first cut will be made 0.2 inches from the end of the stock to ensure an even first edge. Axis 1 will accelerate to the desired tracking ratio over 1 inch of master travel for all cuts. Assume that the home position of both axes is at position 0 inches.

The Cut-to-Length example takes advantage of being able to change master cycle length, while being careful to change it only at the beginning of a current cycle. This ensures that the current master cycle position will be less than the new master cycle length, and will not change as a result of a change in cycle length. In this example, the master cycle length and corresponding waits are redefined every cycle to the current value of VAR1. The value of VAR1 becomes the cut length, and can be changed via remote command during program execution. With minor modifications, the cut lengths and the number of iterations could be read from DATA commands (e.g., in a teach mode application).

Program

```

SCALE1           ; Enable scaling
SCLD8000,8000    ; Set axes 1 & 2 scale factors for programming
                 ; in inches
SCLV,8000        ; Axis 2 velocity scale factor for inches/sec
SCLA,8000        ; Axis 2 accel scale factor for inches/sec/sec
SCLMAS8000       ; Master scale factor for programming in inches

DEF CUTLEN       ; Start definition of Cut-to-Length program
COMEXC1          ; Enable continuous command execution mode
COMEXS1          ; Continue execution if stop is issued
INFNC1-H         ; Enable trigger input 1 (TRG-1A) for TRGFN use
A20,20           ; Set acceleration
V5,5             ; Set velocity
MA11             ; Absolute positioning mode for non-Following moves
VAR1=36          ; Desired cut length is 36"
VAR2=4           ; Sensor is 4" from home position of axis 1
VAR2=VAR2+0.2    ; 1st cut to be 0.2" from end of stock
VAR3=1           ; FOLMD to be set to 1"
VAR4=VAR3/2      ; Follower will travel 1/2" when accelerating to
                 ; 1:1 ratio while master travels 1"
VAR2=VAR4-VAR2   ; Take distance follower travels during accel into
                 ; account so we'll be up to speed at position = 0.2"
                 ; from end of stock. Then the cut will be made.
                 ; Initial master cycle position will be the negative
                 ; of the distance traveled during follower wait and
                 ; accel.
FOLMAS31         ; Encoder 3 is the master for follower axis 1
FMCP(VAR2)       ; Set initial master cycle position to wait length
FOLMD(VAR3)      ; Acceleration to constant ratio will take place
                 ; over VAR3" (1" here) of master travel

FOLRN1
FOLRD1           ; Following ratio is 1 to 1
1TRGFNA X1       ; Define a new master cycle on axis 1 when trigger
                 ; input 1 (TRG-A) is activated
WAIT(IN.1=b1)    ; Suspend program execution until stock is sensed
OUT.6-1          ; Turn on output for saw blade to move into position
GOWHEN(1PMAS>=0) ; Wait on first move for start of master cycle.
                 ; This will ensure being at 1:1 ratio at exactly
                 ; 0.2" from end of stock.
$NEWCUT          ; Subroutine DEF for continuous cutting
D,5              ; Axis 2 will move 5 inches across the stock
MC1              ; Axis 1 into continuous move mode.
FOLEN1          ; Enable Following on axis 1
VAR5=VAR1        ; Set VAR5 = VAR1 (Snapshot of VAR1)
FMCLN(VAR5)      ; New master cycle length is cut length
GO1              ; Start Following move on follower axis 1

```

(Continued on next page)

Continuous Cut-to-Length Program (Continued from previous page)

```
WAIT(1FS.4=b1)      ; Wait for axis 1 to be in sync with the moving stock
GOx1                ; Once axis 1 is up to speed, move axis 2 across
                    ; stock to make the cut
WAIT(2AS.1=b0)     ; Wait for axis 2 cut to finish
S1                  ; Stop Following move on axis 1
WAIT(MOV=b0)       ; Wait until the move is complete on axis 1
FOLENO             ; Exit Following mode
OUT.6-0            ; Raise the saw blade
MCO                ; Axis 1 into preset move mode.
D0,0               ; Move both axes back to home positions
GO11               ; Execute moves on axes 1 and 2 (execution will not
                    ; occur until motion from previous move is complete)
WAIT(MOV=b00)      ; Wait until the moves are complete on axes 1 and 2
OUT.6-1            ; Move saw blade into position for next cut
GOWHEN(1PMAS>=VAR5) ; Synchronize next move with next master cycle
GOTO NEWCUT        ; Repeat the cut cycle
END                 ; End program definition
```

Technical Considerations for Following

In the introduction to Following (see page 166), the algorithm for 6K controller Following was briefly discussed. Here we will address some of the more technical aspects of Following:

Keep in mind that in all cases, the follower position is calculated from a sampled master position.

- Performance
- Master Position Prediction
- Master Position Filtering
- Following error
- Maximum acceleration and velocity (stepper axes only)
- Factors affecting Following accuracy
- Preset vs. Continuous Following moves
- Master and follower axis distance calculations
- Using other features with Following

Performance Considerations

When a follower axis is following a master, the 6K controller does not simply measure the master velocity to derive follower axis velocity. Instead, the 6K controller samples the master position (*position sampling period = 2 ms*) and calculates the corresponding follower axis position command. This is true even if the follower axis is in the process of changing ratios. A follower axis is not simply following velocity, but rather position. With this algorithm, the master and follower position or phase relationship is maintained indefinitely, without any drift over time due to velocity measurement errors.

The 6K controller also measures master velocity by measuring the change in master position over a number of sample periods. The present master velocity and position can be used to calculate the next commanded follower position, so the follower has no velocity-dependent phase delay. This concept is known as *Master Position Prediction* and can be enabled or disabled as needed with the `FPPEN` command.

The 6K controller's default Following algorithm should work well for most applications; however, you can change the Following algorithm to meet application-specific needs. For instance, suppose that the speed of the master is very slow, or has some vibration. For a case like this, the 6K controller allows you to filter the master position signal to generate a smooth follower position command. This is known as *Master Position Filtering* and is programmed with the `FFILT` command.

Master Position Prediction

Master Position Prediction is a technique used to compensate for the fact a follower's position command cannot be calculated and implemented infinitely fast.

The master position prediction mode is enabled by default (FPPEN1) in the Following algorithm, but can be turned off as desired with the FPPENØ command.

The 6K controller measures master position once per *position sampling period* (2 ms), and calculates a corresponding follower position command. This calculation and achieving the subsequent follower commanded position requires 2 sample periods (4 ms).

If master position prediction mode is disabled (FPPENØ), waiting 2 sample periods results in a follower position lag. That is, by the time the follower reaches the position that corresponds to the sampled master position, 2 sample periods have gone by, and the master can be at a new position. Measured in time, the lag is 2 sample periods. Measured in position, the lag is 2 sample periods * current follower velocity.

For example, suppose the follower is traveling at a speed of 25000 counts per second. If master position prediction mode is disabled (FPPENØ), the follower will lag the master by 100 counts (25000 counts/sec * 4 ms = 100 counts).

By measuring the change in master position over sequential sample periods, the master's present velocity is calculated. The present master velocity and position are used to predict future master position. If master position prediction mode is enabled (FPPEN1, the predicted future master position is used to determine the follower's position command. In this case the follower has no velocity-dependent phase delay. The follower's velocity for a given sample will always be the velocity required to move from its current position to the next calculated position command.

If the master motion is fairly smooth and velocity is not very slow, the measurement of its recent velocity will be very accurate, and a good way of predicting future position. But the master motion can be rough, or the measurements can be inaccurate if there is no filtering (see *Master Position Filtering* below). In this case, the predicted master position and the corresponding follower position command will have some error, which can vary in sign and magnitude from one sample to the next. This random variation in follower position command error results in rough motion. The problem is particularly pronounced if there is vibration on the master.

It can be desirable to disable the master position prediction mode (FPPENØ) when maximum follower smoothness is important and minor phase delays can be accommodated.

If master filtering is enabled (FFILT_Ø), then the prediction algorithm would be used on the filtered master position, resulting in a smoother follower position command. However, due to the delay introduced by the filtering, the prediction algorithm would not compensate for the total delay in the follower's tracking command. (See also *Master Position Filtering* below.)

Following Status (TFSE, TFS, and FS) bit 17 indicates the status of where or not the master position prediction mode is enabled.

Master Position Filtering

The follower axis' position command is calculated at each *position sample period* (2 ms). This calculation is a function of the master position and the master velocity estimated from the change in master position over 2 position sample periods.

The *Master Position Filter* feature allows you to apply a low-pass filter to the measurement of master position. Master position filtering is used in these situations:

- Measurement of master position is contaminated by either electrical noise (when analog input is the master) or mechanical vibration.
- Measurement noise is minimal, but the motion that occurs on the master input is oscillatory. In this case, using the filter can prevent the oscillatory signal from

propagating into the follower axis (i.e., ensuring smoother motion on the follower axis). The bandwidth of the low-pass filter is controlled with the `FFILT` command:

<code>FFILT</code> Setting	Low pass Filter Bandwidth
∅	infinite (no filtering) – <i>default setting</i>
1	120 Hz
2	80 Hz
3	50 Hz
4	20 Hz

When considering whether or how much master position filtering to use, consider the application requirement itself. The application requirements related to filtering can be categorized into these three types:

- Type I: If an application requires smooth motion but also high follower tracking accuracy, then a heavy filtering should **not** be used. It should not be used because it can introduce too much velocity phase lag, although the motion can be smooth. In other words, the master axis in the first place should produce very smooth motion and low sensor measurement noise such that a higher level of master filtering is not needed.
- Type II: If follower axis velocity tracking error is not critical but smooth follower axis motion is desired, then you can use a higher level of master filtering to deal with sensor noise or master vibration problems.
- Type III: If it is determined that under certain dynamic conditions the master position's oscillatory measurement is purely caused by its vibration motion (noise is insignificant), and it is necessary for the follower to follow such motion, then the filter command should not be used or only use the highest bandwidth (`FFILT1`).

Following Status (`TFSF`, `TFS`, and `FS`) bit 18 indicates the status of master position filtering.

Following Error

As soon as an axis becomes configured as a follower, the follower's position command is continuously updated and maintained. At each update, the position command is calculated from the current master position and velocity, and the current ratio or velocity of the follower.

Whenever the commanded position is not equal to the actual follower position, a *Following error* exists. This error, if any, can be positive or negative, depending on both the reason for the error and the direction of follower travel. Following error is defined as the difference between the commanded position and the actual position.

$$\text{Following Error} = \text{Commanded position} - \text{Actual position}$$

If the follower is traveling in the positive direction and the actual position lags the commanded position, the error will be positive. If the follower is traveling in the negative direction and the actual position lags the commanded position, the error will be negative. This error is always monitored, and can be read into a numeric variable (`VAR`) at any time using the `PER` command. The error value in follower steps is scaled by `SCLD` for the axis. This value can be used for subsequent decision making, or simply storing the error corresponding to some other event.

Maximum Velocity and Acceleration *(Stepper Axes Only)*

The follower's attempt to faithfully follow the master can command velocities and accelerations that the follower axis is physically not able to complete. Therefore, the `FMAXV` and `FMAXA` commands are provided to set the maximum velocity and acceleration at which the follower will be allowed to move.

If the follower is commanded to move at rates beyond the defined maximums, the follower will begin falling behind its commanded position. If this happens, a correction velocity will be applied to correct the position error as soon as the commanded velocity and acceleration fall within the limitation of `FMAXV` and `FMAXA`.

The `FMAXA` and `FMAXV` commands should be used only to protect against worst case conditions, and should be avoided altogether if they are not needed. If an axis is not able to follow its profile because of limitations imposed by these commands, some correction motion will occur. If the maximum acceleration (`FMAXA` value) is set very low, some oscillation about the commanded position can occur because the follower is not allowed to decelerate fast enough to prevent overshoot.

Factors Affecting Following Accuracy

There are additional accuracy requirements of Following applications beyond those of standard positioning. The follower axis must maintain positioning accuracy while in motion, not just at the end of moves, because it is trying to stay synchronized with the master.

Assuming parameters such as master and follower scaling and ratios have been specified correctly, the overall positioning accuracy for an application depends on several factors:

- Resolution of the master
- Resolution of the follower axis
- Position sampling accuracy
- Accuracy of the follower axis motor and drive
- Accuracy of load mechanics
- Master position prediction
- Master velocity relative to master position prediction & master position filtering
- Tuning (servo axes only)
- Repeatability of the trigger inputs and sensors

Just as with a mechanical arrangement, the accuracy errors can build up with every link from the beginning to the end. The overall worst case accuracy error will be the sum of all the sources of error listed below. The errors fall into two broad categories, namely, master measurement errors and follower errors. These both ultimately affect follower accuracy, because the commanded follower position is based on the measured master position.

It is important to understand how master measurement errors result in follower position errors. In many applications, master and follower units will be the same (e.g., inches, millimeters, degrees). These applications will require linear speeds or surface speeds to be matched (i.e., a 1:1 ratio). For example, suppose that in a rotary knife application, there were 500 master steps per inch of material, so an error in master measurement of one encoder step would result in 0.002 inches of follower position error.

If the master and follower units are not the same, or the ratio is not 1:1, the master error times the ratio of the application gives the follower error. An example would be a rotary master and a linear follower. For instance, suppose one revolution of a wheel gives 4000 master counts, and results in 10 inches of travel on the follower. The ratio is then 10 inches/revolution. The follower error that results from one step of master measurement error is $(1/4000) * 10$ inches/revolution = 0.0025 inches.

Resolution of the Master	The best case master measurement precision is the inverse of the number of master steps per user's master unit. For example, if there are 100 master steps/inch, then the master measurement precision is 0.01 inches. Even if all other sources of error are eliminated, follower accuracy will only be that which corresponds to 1 step of the master (e.g., 0.01 inches in the previous example).
Resolution of the Follower	The best case follower axis precision is the inverse of the number of follower steps per user's position unit. For example, if there are 1000 follower steps/inch, then the follower resolution is 0.001 inches. Even if all other sources of error are eliminated, follower positioning accuracy will only be that which corresponds to 1 step of the follower. This must be at least as great as the precision required by the application.
Position Sampling Accuracy	<p>The position sampling rate for the 6K controller depends on whether it is a servo or a stepper. The sample period for is 2 ms.</p> <p>The repeatability of the sampling rate, from one sample to the next, can vary by as much as 100 μs. This affect can be eliminated by using non-zero master position filter (<code>FFILT</code>) command values. Otherwise, measurement of master position can be off by as much as (20 to 100 microseconds * master speed). This can appear to be a significant value at high master speeds, but it should be noted that this error changes in value (and usually sign) every sample period. It is effectively like a noise of 200-600 Hz; if the mechanical frequency response of the motor and load is much less than this frequency, the load cannot respond to this error.</p>
Accuracy of the Follower Motor and Drive	<p>The precision also depends on how accurately the drive follows its commanded position while moving. Even if master measurement were perfect, if the drive accuracy is poor, the precision will be poor.</p> <p>In the case of stepper drives, this amounts to the specified motor/drive accuracy.</p> <p>In the case of servo drives, the better the drive is tuned for smoothness and zero Following error, the better the precision of the positioning. Often, this really only matters for a specific portion of the profile, so the drive should be tuned for zero Following error at that portion.</p>
Accuracy of the Load Mechanics	The accuracy (not repeatability) of the load mechanics must be added to the overall build up of accuracy error. This includes backlash for applications that involve motion in both directions.
Master Position Prediction	<p>The master position prediction mode can be enabled or disabled with the <code>FPPEN</code> command, but each state contributes a different error.</p> <p>Disabled (<code>FPPEN0</code>): The follower position command is based on a master position that is 2 sample periods (4 ms) old. This means that master measurement error due to disabling the position prediction mode will be (2 sample periods * master speed).</p> <p>Enabled (<code>FPPEN1</code>): If the position prediction mode is enabled (default setting), its accuracy is also affected by position sampling accuracy, master speed, and master position filtering. The error due to enabling the position prediction mode is about twice that due to sampling accuracy (i.e., 40 to 200 microseconds * master speed). As with the error due to position sampling accuracy, the error due to the position prediction mode being enabled is like a noise on the order of 200-600 Hz, which is not noticed by large loads.</p>

Master Velocity Relative to Master Position Prediction

Variation in Master Velocity: Although increasing master position filtering (increasing the `FFILT` command value) eliminates the error due to sampling accuracy, it increases the error due to variations in master speed when the master position prediction mode is enabled (`FPPEN1`).

Most applications maintain a constant master speed, or change very slowly, so this effect is minimal. But if the master is changing rapidly, there can be a significant master speed measurement error. Because predicted master positions are in part based on master speed measurement, they can result in an error in master position prediction mode (`FPPEN1`). This effect will always be smaller than that due to the master position prediction mode being disabled (`FPPEN0`).

Tuning (Servo Axes Only)

A servo system's tuning has a direct impact on how well the follower axis can track the master input. Overshoot, lag, oscillation, etc., can be devastating to following performance. The best tool to use for tuning the 6K series controller is Motion Planner's Servo Tuner utility.

Repeatability of the Trigger Inputs and Sensors

Some applications can use the trigger inputs for functions like registration moves, `GOWHENS`, or new cycles. For these applications, the repeatability of the trigger inputs and sensors add to the overall position error.

Refer to page 84 for accuracy specifications on the trigger input position capture function. Refer to your sensor manufacturer's documentation for the sensor repeatability.

Preset vs. Continuous Following Moves

When a follower performs a preset (`MC0`) move in Following mode (`FOLEN1`), the commanded position is either incremental or absolute in nature, but it does have a commanded endpoint. The direction traveled by the follower will be determined by the commanded endpoint position, and the direction the master is counting.

Let's illustrate this with an example. Assume all necessary set-up commands have been previously issued for our follower (axis 1) and master so that distances specified are in revolutions:

```
FOLRN3      ; Set Following follower-to-master ratio numerator to 3
FOLRD4      ; Set Following follower-to-master ratio denominator to 4
              ; (ratio is 3 revs on the follower to 4 revs on the master)
FOLEN1      ; Enable Following on axis 1
FOLMD10     ; Set preset move to take place over 10 master revolutions
MC0         ; Set follower to preset positioning mode
MA1         ; Set follower to absolute positioning mode
PSET0       ; Set current absolute position reference to zero
D5          ; Set move distance to absolute position 5 revolutions
GO1         ; Initiate move to absolute position 5
```

If the master is stationary when the `GO1` command is executed, the follower will remain stationary also. If the master begins to move and master pulses are positive in direction, the follower will begin the preset move in the positive direction. If the master pulses stop arriving before 10 master revolutions have been traveled, the follower will also stop moving, but that `GO1` command will not be completed. If the master then starts to count in the negative direction, the follower will follow in the negative direction, but only as far as its starting position. If the master continues to count negative, the follower will remain stationary. The `GO1` command will not actually be completed until the master has traveled at least 10 revolutions in the positive direction from where it was at the time the `GO1` command was executed. If the master oscillates back and forth between its position at the start of the `GO1` command to just under 10 revolutions, the follower will oscillate back and forth as well.

The master must be counting in the positive direction for any preset (`MC0`) `GO1`s commanded

on the follower to be completed. If mechanics of the system dictate that the count on the source of the master pulses is negative, a minus (-) sign should be entered in the FOLMAS command so that 6K controller sees the master counts as positive.

Continuous follower moves (MC1) react much differently to master pulse direction. Whereas a preset move will only start the profile if the master counts are counting in the positive direction, a continuous move will begin the ramp to its new ratio following the master in either direction. As long as the master is counting in the positive direction, the direction towards which the follower starts in a continuous move is determined by the argument (sign) of the D command. The follower direction is positive for D+ and negative for D-.

If the master is counting in the negative direction when follower begins a continuous move, the direction towards which the follower moves is opposite to that commanded with the D command. The follower direction is positive for D- and negative for D+.

If the master changes direction during a continuous follower move, the follower will also reverse direction. As with standard continuous moves, the GO1 will continue until terminated by S, K, end-of-travel limits, stall condition, or command to go to zero velocity. As with preset moves, the sign on the FOLMAS command determines the direction of master counting with respect to the direction of actual counting on the master input.

Master and Follower Distance Calculations

The formulas below show the relationship between master move distances and the corresponding follower move distances. These relationships can be used to assist in the design of Following mode moves in which both the position and duration of constant ratio are important.

In such calculations, it is helpful to use SCLMAS and SCLD values that allow the master and follower distances to be expressed in the same units (e.g., inches or millimeters). In this case, many applications will be designed to reach a final ratio of 1:1, and the distances in these figures can be easily calculated.

⇒ **HINT:** For a trapezoidal preset follower axis move with a maximum ratio of 1:1, the master and follower distances during the constant ratio portion will be the same. The follower travel during acceleration will be exactly half of the corresponding master travel, and it will also occur during deceleration.

Master Distance (FOLMD)

If the follower axis is in continuous positioning mode (MC1), FOLMD is the master distance over which the follower axis is to accel or decel from the current ratio to the new ratio. If the follower axis is in preset positioning mode (MC0), FOLMD is the master distance over which the follower's entire move will take place.

When the Follower is in Continuous Positioning Mode (MC1)

$$D = \frac{\text{FOLMD} * (R_2 + R_1)}{2}$$

where:

FOLMD = Master distance

R₂ = New ratio (FOLRN ÷ FOLRD)

R₁ = Current ratio (FOLRN ÷ FOLRD)

D = Follower distance traveled during ramp

When the Follower is in Preset Positioning Mode (MCØ)


Trapezoidal Follower Moves

$D_{max} = (FOLMD * R_{max})$ $D_1 = \frac{(D_{max} - D)}{2}$ $MD_1 = \frac{2 * D_1}{R_{max}}$ $D_2 = D - (2 * D_1)$ $MD_2 = \frac{D_2}{R_{max}}$ $FOLMD = 2 * MD_1 + MD_2$	<p>where:</p> <p>FOLMD = Master distance</p> <p>MD₁ = Master distance during accel & decel ramps</p> <p>MD₂ = Master distance during constant ratio</p> <p>D = Total follower axis preset distance commanded</p> <p>D₁ = Follower travel during accel and decel ramps</p> <p>D₂ = Follower travel during constant ratio</p> <p>D_{max} = Maximum follower distance possible (assuming no accel or decel)</p> <p>R_{max} = Maximum ratio = FOLRN ÷ FOLRD</p>
---	---

Trapezoidal profile if:

$$D = (D_2 + 2 * D_1) < D_{max}$$

These Profiles depict ratio vs. distance




Rectangular profile if:

$$D_2 = D$$

$$D_1 = \text{zero}$$

$$MD_2 = FOLMD$$

$$MD_1 = \text{zero}$$




Triangular Follower Moves

$D = \frac{R_{peak} * FOLMD}{2}$	<p>where:</p> <p>FOLMD = Master distance</p> <p>R_{peak} = Peak ratio reached during move</p> <p>D = Total follower distance</p>
----------------------------------	--

Triangular profile if:

$$D < 1/2 D_{max}$$

This Profile depicts ratio vs. distance



Distance Calculation Example

In the example below, the desired travel during constant ratio is already contained in numeric variable 1 (VAR1), and can have been read from thumbwheels or a DATA command. The corresponding follower move distance (D) and FOLMD are calculated as shown:

```

VAR2=2           ; Desired follower travel during accel and decel combined
VAR3=2 * VAR2   ; Required master travel during these ramps
VAR4=VAR1 + VAR2 ; Move distance is constant ratio portion plus ramps
VAR5=VAR1 + VAR3 ; Master travel for entire follower move
FOLMD(VAR5)     ; Establish calculated master travel
D(VAR4)         ; Establish calculated follower travel
GO1             ; Make desired follower move
    
```

Similar calculations can be done for a series of continuous move ramps to ratios, separated by GOWHEN for master cycle positions. These ramps can be repeated in a loop to create a continuous cyclical follower profile.

Beware of Roundoff Error (Scaling only)

Some potential for roundoff error exists if the scaling of a move distance or master distance by `SCLD` and `SCLMAS` does not result in an integer number of steps. Some additional care must be taken in the segment by segment construction of profiles using ramps to continuous ratio. The 6K controller maintains a follower position command that is calculated from the commanded constant ratios, the ramps to the new ratios, and the master travel over which these take place. At the end of each ramp or constant ratio portion, this commanded position is calculated to the nearest integer follower step. If the ratios and master travel result in a non-integer follower travel for a segment, the fractional part of that segment's calculated travel will be lost. In a cyclical application, repeated truncations could build up to a significant error. This can be avoided through careful attention to design of the profile.

Using Other Features with Following

The 6K controller has many features that can be used in the same application as its Following features. In some cases, having configured an axis as a follower with the `FOLMAS` command will affect, or be affected by, the operation of other features, as described below.

Setups used by `FOLMAS` (Stepper Axes Only)

The `FOLMAS` command uses the drive resolution (`DRES`) and the velocity range (`PULSE`) data to configure an axis as a follower. In order for this data to be used correctly, these commands must be given before `FOLMAS`. These commands are not allowed after `FOLMAS` is given. After `FOLMAS` is executed, the `MC` command can be used to change from incremental to absolute positioning and back.

`S` (Stop) & `K` (Kill) Commands

Stop (`S`) and Kill (`K`) commands cause the follower to do a non-Following decel, even if the follower is in Following mode. A stop or a kill, buffered or immediate, will clear a pending `GOWHEN` condition (clears `AS` bit 26).

Kill Conditions

Under default operation (`FOLK0`), certain error conditions (i.e., drive fault input active, or maximum position error limit exceeded) will cause the 6K controller to disable the drive and kill the Following profile (follower's commanded position loses synchronization with the master).

If you enable Following Kill (`FOLK1`), these error conditions will still disable the drive (`DRIVE0`), but will not kill the Following profile. Because the Following profile is still running, the controller keeps track of what the follower's position should be in the Following trajectory. To resume Following operation, resolve the error condition (drive fault, excessive position error), enable the drive (`DRIVE1`), and command the controller to impose a shift to compensate for the lapse/shift that occurred while the drive was disabled and the follower was not moving. To impose the shift, assign the negative of the internally monitored shift value (`PSHF`) to a variable (e.g., `VAR1 = -1 * PSHF`) and command the shift using a variable substitution in the `FSHFD` command (e.g., `FSHFD (VAR1)`).

The `FOLK` command only preserves Following profiles; normal velocity-based profiles will be killed regardless of the `FOLK` command.

`GO` Command

If a follower axis is in Following mode (`FOLEN1`), moves will ramp to a ratio (set with `FOLRN` and `FOLRD`). If it is not in Following mode, moves will ramp to a velocity (`V`). Switching in and out of Following mode does not change the value for final ratio or final velocity goals, but simply changes which parameter is used as the goal.

Registration Moves (see page 155)

Registration inputs can be enabled with the `INFCi-H` command while an axis is a follower, and registration moves can interrupt either a Following mode move or a time-based move. The registration move itself, however, is always a time based move, and implements the registration velocity with respect to a stationary reference. Any trigger input can be used as a registration input or for any Following feature that uses triggers, even at the same time.

Enter/Exit Following Mode While Moving

The `FOLENØ` command can be executed while a follower axis is moving at constant ratio. In this case, the current velocity becomes the constant velocity, and the follower can accelerate or decelerate to other velocities. The `FOLEN1` command cannot be executed while the follower axis is moving in the non-Following mode. Attempting to do so will result in the error response “MOTION IN PROGRESS”.

Pause and Continue

A program can be paused and continued, even if one or more axes is configured as a follower axis. Those axes do not lose track of the master input, even though motion is stopped. As usual, if a program finishes normally, or if `COMEXS` is set to zero (`COMEXSØ`), the program cannot be continued. If a program is resumed, partially completed Following moves will be completed; however, the remainder of the move is completed over the entire original master distance (`FOLMD` value).

`TVEL` and `TVELA` Commands

The `TVEL` and `VEL` commands have always reported an unsigned value (i.e. magnitude), consistent with the fact that the `V` command is always positive, even if the move direction is negative. When Following is enabled (`FOLEN1`), `TVEL` and `VEL` report the net magnitude of commanded velocity due to following and/or shifting. For example, if the follower axis is Following in the positive direction at 1 rps, `TVEL` reports 1.000. If a shift in the negative direction of 1.5 rps is then commanded, `TVEL` will report 0.5 – still positive, even though the net direction is negative.

By contrast, `TVELA` and `VELA` have always been signed. In the above example, `TVELA` will report -0.5.

`TASF`, `TAS` & `AS` Axis Status Bits

Axis Status (`TASF`, `TAS` and `AS`) bits 1-4 represent the motion status of an axis. Bits 1 and 2 represent the moving and direction status of the net motion of an axis, including the combination of following and shifting.

Bits 3 and 4 represent acceleration and velocity, respectively. With Following disabled (`FOLENØ`), the accel and velocity can only be due to a commanded time-based profile. With Following enabled (`FOLEN1`), the net commanded velocity and accel could be due to following the master and/or a simultaneous shift (time-based profile). Bits 3 and 4 only reflect the acceleration and velocity status of the time-based profile, not the combined command.

For example, if the follower axis is Following in the positive direction at 1 rps, `TAS` reports 1ØØØ. If a continuous shift (`FSHFC2`) of 0.8 rps in the negative direction is then commanded, `TAS` will report 1Ø1Ø, while the shaft is decelerating to 0.2 rps. When the continuous shift velocity is reached, `TAS` will report 1ØØ1.

Changing Feedback Sources (Servo Axes only)

Changing feedback sources (`SFB`) can result in a follower axis Following its own feedback. For this reason, changing feedback sources is not allowed while a master is specified (`FOLMAS`).

Following and Other Motion

Following motion is initiated with the `GO` command, just like normal motion. Other motion, that does not depend on the motion of an external master, cannot be used while a follower axis is in Following mode (`FOLEN1`). These motion types include jog mode, joystick mode, contouring, homing, streaming mode, and linear interpolation (`GOL`). To use these motion types, Following must be disabled (`FOLENØ`) — see *Enter/Exit Following Mode While Moving* above for precautions.

Conditional Statements Using `PMAS`

The master cycle position (`PMAS`) value can be used in the comparison argument of these commands:

- **WAIT & GOWHEN:** If it is desired to `WAIT` or `GOWHEN` on a master cycle position of the next master cycle, one master cycle length (value of `FMCLEN`) should be added to the master cycle position specified in the argument. This allows commands that sequence

follower axis events through a master cycle to be placed in a loop. The `WAIT` or `GOWHEN` command at the top of the loop could execute, even though the actual master travel had not finished the previous cycle. This is done to allow a `PMAS` value that is equal to the master cycle length to be specified and reliably detected.

- `IF`, `UNTIL`, & `WHILE`: These arguments use the instantaneous `PMAS` value. Be careful to avoid specifying `PMAS` values that are nearly equal to the master cycle length (`FMCLEN`), because rollover can occur before a `PMAS` sample is read.

Compiled Motion Following profiles can be pre-compiled to save processing time. For details, see page 139.

Troubleshooting for Following (also see Chapter 8)

The table below offers some possible reasons for troubles that can be encountered in achieving the desired follower motion.

Symptom	Possible Causes
Follower axes do not follow master	<ul style="list-style-type: none"> • Improper <code>FOLMAS</code> • Poor connection if master is encoder • Master running backward • No encoder power (when the encoder is selected as the master)
Follower motion is rough	<ul style="list-style-type: none"> • <code>FFILT</code> command value too low • Unnecessary <code>FPPEN</code> amplifies master roughness
Ratio seems wrong	<ul style="list-style-type: none"> • <code>FOLRN</code> and <code>FOLRD</code> follower-to-master ratio values are inaccurate, possibly reversed • <code>SCLD</code> or <code>SCLMAS</code> wrong • Following limited by <code>FMAXV</code> or <code>FMAXA</code> (steppers only)
Follower profile wrong, or un-repeatable	<ul style="list-style-type: none"> • <code>WAIT</code> used where <code>GOWHEN</code> should be • Too little master travel between <code>GOWHEN</code> and <code>GO1</code>, desired <code>PMAS</code> is missed
Master/follower alignment drifts over many cycles	<ul style="list-style-type: none"> • Roundoff error due to fractional steps resulting from <code>SCLD</code> or <code>SCLMAS</code> and user's parameters • Ratios and master distances specified result in fractional follower steps covered during ramps, constant ratio
Follower lags Following position (steppers only)	<ul style="list-style-type: none"> • Inhibited by <code>FMAXV</code> • <code>FMAXA</code> clips acceleration peaks resulting from attempt to follow rough master

Error Messages

If an illegal programming condition is discovered while programming or executing programs, the 6K controller responds with an error message. If a program execution error is detected, the program is aborted.

The table below lists all the error messages that relate to Following, and indicates the command and cause that can generate them. These error messages are displayed only if the error level is set to level 4 with the `ERRLVL4` command (this is the default setting).

Error Message	Cause
FOLMAS NOT SPECIFIED	No FOLMAS for the axis is currently specified. It will occur if FMCNEW, FSHFC, or FSHFD commands are executed and no FOLMAS command was executed, or FOLMASØ was executed.
INCORRECT DATA	Velocity (V), acceleration (A), or deceleration (AD) command is zero. (used by FSHFC & FSHFD)
INVALID CONDITIONS FOR COMMAND	The FOLMD command value is too small to achieve the preset distance and still remain within the FOLRN/FOLRD ratio. A command phase shift cannot be performed: FSHFD.....Error if already shifting or performing other time based move. FSHFC.....Error if currently executing a FSHFD move, or if currently executing another FSHFC move in the opposite direction. The FOLEN1 command was given while a profile was suspended by a GOWHEN.
INVALID DATA	The parameter supplied with the command is invalid. FFILT.....Error if: smooth number is not 0-4 FMCLLEN.....Error if: master steps > 999999999 or negative EMCPError if: master steps > 999999999 or <-999999999 FOLMD.....Error if: master steps > 999999999 or negative FOLRD.....Error if: master steps > 999999999 or negative FOLRN.....Error if: follower steps>999999999 or negative FSHFC.....Error if: number is not 0-3 FSHFD.....Error if: follower steps>999999999 or <-999999999 GOWHEN.....Error if: position > 999999999 or <-999999999 WAIT.....Error if: position > 999999999 or <-999999999 Error if a GO command is given in the preset positioning mode (MCØ) and: FOLRN = zero FOLMD = zero, or too small (see <i>Preset Positioning Mode Moves</i> on page 175)
INVALID FOLMAS SPECIFIED	An illegal master was specified in FOLMAS. A follower can never use its own commanded position or feedback source as its master.
INVALID RATIO	Error if the FOLRN:FOLRD ratio after scaling is > 127 when a GO is executed.
MASTER SLAVE DISTANCE MISMATCH	Attempting a preset Following move with a FOLMD value that is too small.
MOTION IN PROGRESS	The FOLEN1 command was given while that follower was moving in a non-Following mode.
NOT VALID DURING FOLLOWING MOTION	A GO command was given while moving in the Following mode (FOLEN1) and while in the preset positioning mode (MCØ).
NOT VALID DURING RAMP	A GO command was given while moving in a Following ramp and while in the continuous positioning mode (MC1). Following status (FS) bit 3 will be set to 1.
SYSTEM UPDATE OVERRUN, USE SYSPER4	The system update service has overrun the time allotted with the default 2-millisecond period. Use the SYSPER4 command to increase the system update period to 4 milliseconds.

Following Commands

Detailed information about these commands is provided in the *6K Series Command Reference*.

- ANIMAS Assigns an analog input to be used as a master in a FOLMAS assignment (requires a ANI SIM located on an expansion I/O brick).
- ERROR..... Enable bit 14 to check for when a GOWHEN condition is already true when a subsequent GO, GOL, FGADV, FSHFC, or FSHFD command is given.
- ERRORP If ERROR bit 14 is enabled, a GOSUB branch to the error program occurs if a GOWHEN condition is already true

when a subsequent GO, GOL, FGADV, FSHFC, or FSHFD command is given.

FFILT..... Sets the bandwidth for master position filtering.

FGADV..... Defines the geared advance distance.

FMAXA..... Stepper axes only: Sets the maximum acceleration a follower can use while Following.

FMAXV..... Stepper axes only: Sets the maximum velocity at which a follower can travel.

FMCLEN..... Defines the length of the master cycle.

EMCNEW..... Restarts new master cycle counting immediately. To make this a trigger-based operation instead of issuing the EMCNEW command, use the TRGFNCx1 command.

FMCP..... Defines the initial position of a new master cycle.

FOLEN..... Enables or disables Following mode.

FOLK..... Allows drive fault or maximum position error to disable drive without killing the Following profile.

FOLMAS..... Defines masters for follower axes.

FOLMD..... Defines the master distance over which ratio changes or moves are to take place.

FOLRD..... Establishes the DENOMINATOR ONLY for the maximum follower-to-master ratio for a preset move or the final ratio for a continuous move (use in combination with the FOLRN command).

FOLRN..... Establishes the NUMERATOR ONLY for the maximum follower-to-master ratio for a preset move or the final ratio for a continuous move (use in combination with the FOLRD command).

FPEN..... Allows master position prediction to be enabled or disabled.

FSHFC..... Allows continuous advance or retard (shift) of follower position during continuous Following moves.

FSHFD..... Allows preset advance or retard (shift) of follower position during continuous Following moves.

FVMACC..... Establishes the rate at which the virtual master count frequency (FVMFRQ) can change for an axis.

FVMFRQ..... Defines the frequency of the virtual master count.

GOWHEN..... A GOWHEN command suspends execution of the next follower move until the specified conditional statement (based on T, IN, LIM, PC, PE, PMAS, PSLV, or PSHF) is true. To make this a trigger-based operation instead of issuing the GOWHEN command, use the TRGFNC1x command.

SCLD..... Sets the follower distance scale factor.

SCLMAS..... Sets the master scale factor.

SINAMP..... Defines the amplitude of the internal sine wave.

SINANG..... Defines the phase angle of the internal sine wave.

SINGO..... Initiates the internal sine wave.

TRGFN..... aTRGFNC1x initiates a GOWHEN. Suspends execution of the next follower move on follower axis (a) until the specified trigger input (c) goes active.
aTRGFNCx1 allows master cycle counting to be restarted on axis (a) when the specified trigger input (c) goes active.

Status and Assignment Commands

TASF, TAS & [AS] Bit 26 of each axis status is set (1) if a motion profile suspended by a GOWHEN (including TRGFNC1x) is pending on that axis. The bit is cleared when the GOWHEN is true, or when a stop (S) or kill (K) command is executed.

TERF, TER & [ER] Bit 14 is set if the GOWHEN condition is already true when a subsequent GO, GOL, FGADV, FSHFC, or FSHFD command is given. (The corresponding error-checking bits must be enabled with the ERROR command before the error will be detectable.)

TFSF, TFS & [FS] Transfers or assigns/compares the Following status or each axis.

TNMCY and [NMCY] Transfers or assigns the current master cycle number.

TPCMS and [PCMS] Transfers or assigns the current captured master cycle position.

TPMAS and [PMAS] Transfers or assigns the current master cycle position.

TPSHF and [PSHF] Transfers or assigns the net position shift since constant ratio.

TPSLV and [PSLV] Transfers or assigns the follower's current commanded position.

TVMAS and [VMAS] Transfers or assigns the current velocity of the master axis.

WAIT..... A WAIT command suspends program execution until the specified conditional statement (based on PMAS, FS, NMCY, PCMS, PSHF, PSLV, or VMAS) is true;
WAIT(SS.i=b1) suspends program execution until a trigger input is activated ("i" is the input bit number corresponding to the trigger input—see the 6K Series Command Reference).



CHAPTER SEVEN

Multi-Tasking

IN THIS CHAPTER

- | | |
|---|-----|
| IN THIS CHAPTER | |
| • Introduction to Multi-Tasking | 204 |
| • Using 6K Resources While Multi-Tasking..... | 213 |
| • Multi-Tasking Performance Issues | 217 |
| • Multi-Tasking Application Examples | 219 |

Introduction to Multi-Tasking

What is Multi-Tasking? Multi-tasking is the ability of the 6K to run more than one program at the same time. This allows users to manage independent sets of axes for multiple machines or unrelated parts of a single machine.

Why use Multi-Tasking?

- Multiple independent *tasks* can act on the same process or same set of axes.
- A supervisory program can control and coordinate multiple processes or axes sets.

What is a Task? A system task is a program execution environment, not a program. Each task runs independently. Each task can be used to run independent programs. Any task can run any program. Multiple tasks could even be running the same program simultaneously. Each task can either be:

- Running a program
- Monitoring ON, ERROR, or INSELP conditions
- Inactive (**not** running a program or monitoring conditions)

Using Multi-Tasking to Run Programs

Use the Wizard

Motion Planner provides a Multi-Tasking wizard, accessed from the Editor. The wizard leads you, step by step, through the process of setting up for multi-tasking.

Multi-tasking is initiated by the *Task Supervisor*. The supervisor is the 6K controller's main program execution environment — it runs the STARTP program and contains the command buffer and parser. If the multi-tasking feature is not being used, the supervisor is the lone program execution environment of the 6K controller, as shown in Figure 1. When multi-tasking is in operation, the supervisor is referred to as “Task 0”.




Figure 1: 6K Supervisor, with no Multi-Tasking

The 6K can have a maximum of 10 tasks, in addition to the Task Supervisor (Task 0). Each task acts as an individual program execution environment. The boxes shown under Resources in Fig. 1, and the following Figures, represent the resources that the supervisor and tasks

monitor and manipulate (see list below). These resources can be shared with other tasks.

- I/O..... Inputs and Outputs (onboard I/O and expansion I/O bricks)
- Communication ports ... “RS-232”, “RS-232/485”, and “ETHERNET”
- Axes..... Axes available with the 6K
- Variables Real (VAR), binary (VARB), integer (VARI), and string (VARS)

“Program Memory” is the 6K’s non-volatile memory where programs are stored. Any task can run any program. Multiple tasks could even be running the same program simultaneously. Programs in multi-tasking are defined as they typically are with the 6K

6K8




Figure 2: 6K8 - Multi-Tasking with 10 tasks.

The Task Identifier (%) prefix is used to specify that the associated command will **affect** the indicated task number. For most simple multi-tasking applications, the % prefix will only be used to start a program running in a specific task. Multi-tasking programs can be started through the communication ports (see Figs. 3a-3c), or from a program (see Figs. 4a-4d). Note that the programs are run in the tasks specified with the % prefix.

Starting Tasks from a Communications Port




Figure 3a: Multi-Tasking initiated from a computer terminal.

6K8




Figure 3b: Multi-Tasking initiated from a computer terminal (cont'd).

6K8




Figure 3c: Multi-Tasking initiated from a computer terminal (cont'd).

Starting Tasks from a Program

6K8




Figure 4a: Multi-Tasking initiated from a program.

6K8




Figure 4b: Multi-Tasking initiated from a program (cont'd).

6K8




Figure 4c: Multi-Tasking initiated from a program (cont'd).

6K8




Figure 4d: Multi-Tasking initiated from a program (cont'd).

Interaction Between Tasks

A new task is initiated by identifying the task number with the Task Identifier (%) prefix, followed by the name of the program to be run in the specified task. Because the % prefix specifies the task number that the associated command will **affect**, new tasks can be started from within other tasks. Fig. 5b shows the `move1` program in task 1 being started by the main program in the supervisor. Fig. 5c shows the `fill` program in task 3 being started by the `move1` program in task 1 with the `3%fill` command. Fig. 5d shows the `inout` program in task 2 being started by the `fill` program in task 3 with the `2%inout` command.

Program execution in a task is controlled by commands executed from the program the task is running. In the example shown in Figs 5a-5d, program execution in Task 1 is controlled by commands executed from the `move1` program, program execution in Task 2 is controlled by commands executed from the `inout` program, and program execution in Task 3 is controlled by commands executed from the `fill` program.




Figure 5a: Initiating multi-tasking.




Figure 5b: Task initiated from another task (cont'd).

6K8




Figure 5c: Task initiated from another task (cont'd).

6K8




Figure 5d: Task initiated from another task (cont'd).

Axes & Tasks

Refer to page 213 for more details about associating axes with tasks.

The default condition in multi-tasking is that each task is associated with all controller axes, as shown in Fig. 6a. This means that when an axis being used in a task hits an end-of-travel limit, program execution will be killed within that task, and in all other tasks, because they all share that axis. It can therefore be necessary to assign a set of axes to a given task to allow a multi-axis controller to be used as more than one independent program execution environment.

The TSKAX command allows you to assign axes to specific tasks, thus constraining task response and control to a smaller set of axes. A task is allowed to control only its associated axes. This axis association covers all interaction between axes commands, conditions or inputs and task program flow. For example, if a 6K controller is controlling two independent machines that do not share common axes, with control of each machine as a separate task, a limit hit by an axis in one machine can kill the task running that machine, but will not kill the task running the other machine.




Figure 6a: Each task is associated with all controller axes in default condition.

The TSKAX command syntax identifies the first and last axis numbers (range) associated with the task. Thus, the axes associated with a task will always be consecutive. For example, the following commands will associate axes 1-3 with Task 1, axes 4-6 with Task 2, and axes 7 and 8 with Task 3. These associations are illustrated in Figures 6b-6d below. If axis 3 in task 1 hits a limit, program execution in task 1 will be killed, but task 2 and task 3 can continue to run because they are independent and do not share axis 3.

```
DEF main          ; Begin definition of program called "main"
1%TSKAX1,3       ; Associate axes 1-3 with Task 1 (see Fig 6b)
2%TSKAX4,6       ; Associate axes 4-6 with Task 2 (see Fig 6c)
3%TSKAX7,8       ; Associate axes 7 & 8 with Task 3 (see Fig 6d)
1%move1          ; Execute the "move1" program in Task 1 (affects axes 1-3)
2%inout          ; Execute the "inout" program in Task 2 (affects axes 4-6)
3%fill           ; Execute the "fill" program in Task 3 (affects axes 7 & 8)
END              ; End definition of program called "main"
```

6K8




Figure 6b: Executed from the “main” program, the `1%TSKAX1,3` command assigns axes 1-3 to Task 1.

6K8




Figure 6c: Executed from the “main” program, the `2%TSKAX4,6` command assigns axes 4-6 to Task 2.

6K8




Figure 6d: Executed from the “main” program, the 3%TSKAX7,8 command assigns axes 7 and 8 to Task 3.

How a “Kill” Works While Multi-Tasking

The general rule of command execution within a task is that the command affects only the task in which it was executed or to which it was directed via the % prefix. This includes almost all motion commands when tasks have associated (TSKAX) axes. The exception is the Kill command. A “K” or “!K” without prefix or parameters will kill all controller axes, and programs running in all tasks. This exception is made to allow one short, familiar command to effectively stop all controller processes. As usual, a “K” with parameters (e.g., Kx11) will kill motion only on the specified axes, and will not kill the program. A “K” prefixed with a task specifier but without parameters (e.g., 3%K) will kill the program and motion of all axes associated with that task.

Certain inputs can be used to kill programs and motion. These inputs and their results under multi-tasking are:

- **Drive Fault input.** Kills program execution and associated axes for all tasks that are associated with the faulted axis.
- **Kill input** (INFNCi-C or LIMFNCi-C). If prefixed with the task identifier (e.g., 2%INFNC3-C), it will kill the designated task, its program and associated axes. If not prefixed with a task identifier, it will kill all controller axes, and programs running in all tasks. It will also cause a branch to the task’s error program if the task’s error-checking bit 6 is enabled (n%ERROR.6-1).
- **User fault input** (INFNCi-F or LIMFNCi-F). This input functions the same as the kill input noted above, with the exception that it will also cause a branch to the task’s error program if the task’s error-checking bit 7 is enabled (n%ERROR.7-1).

Associating Axes with Tasks

The default condition in multi-tasking is that each task is associated with all controller axes. The `TSKAX` command allows you to assign axes to specific tasks, thus constraining task response and control to a smaller set of axes. The `TSKAX` command allows you to specify the first and last axis numbers associated with the task; thus, the axes associated with a task will always be consecutive. This association covers all interaction between axes commands, conditions or inputs and task program flow, including the following:

- **Axis data commands** (e.g., A, V, D). These commands will affect only the associated axes. If data is supplied in the fields of non-associated axes, it will be ignored. To alter the data of an axis associated with another task, that task number must prefix the command (e.g., if axis 3 is associated with task 2 but not task 1, then to change axis 3 velocity to 5 units/sec from task 1, the command `2%3V5` can be issued).
- **Stop, pause, and continue commands and inputs**. These commands will affect motion only on the associated axes of the task receiving the command: `S` (stop) command — without parameters, `PS` (pause) command, and `C` (continue) command. Inputs programmed with these functions will affect motion only on the associated axes of the task specified in the input function assignment (with the `n%` prefix): Kill input (`n%INFNCi-C` or `n%LIMFNCi-C`), stop input (`n%INFNCi-D` or `n%LIMFNCi-D`), pause/continue input (`n%INFNCi-E` or `n%LIMFNCi-E`), and user fault input (`n%INFNCi-F` or `n%LIMFNCi-F`).
- **Drive fault and limit inputs**. If a drive fault or end-of-travel limit occurs on an axis, only tasks that include that axis as an associated axis will be killed.
- **ON conditions**. If user status information includes axis status bits, and `ONUS` is enabled via `ONCOND`, then only bits of an associated axis will be monitored by that task.
- **ERROR conditions**. Each task has its own error status register (`ER`, `TER`, `TERF`), error-checking bits (`ERROR`), and error program (`ERRORP`). If an axis-related error occurs, only the task that is associated (`TSKAX`) with the axis is affected.
- **Command buffer control**:
 - `COMEXC`. Pauses command processing of that task until no associated axes are moving.
 - `COMEXL`. Allows specified associated axes to not kill that task's program. (`COMEXL` applies to axes, and any task that includes an axis will be affected by that axis' `COMEXL` status. An axis can't be enabled for one task and disabled for another.)
 - `COMEXR`. Motion on only the associated axes will also pause if a task-specific pause input becomes active.
- **OUTFNC bits**. Output bits defined without an axis specifier will become active if the condition becomes true on any associated axis.

Sharing Common Resources Between Multiple Tasks

Controller resources other than processing time must also be shared between multiple tasks. All physical inputs and outputs are shared (i.e., each task can read all inputs and write to all outputs). Some of the functions associated with that I/O (defined with LIMFNC, INFNC and OUTFNC commands) are unique for each task. All variables (VAR, VARI, VARB, VARS), DATA programs, and the DATPTR are shared. If one task modifies a variable, a DATA program, or DATPTR, the new value is the same for all tasks. There are no “private” variables. The serial ports are shared (i.e., any task can read from, or write to, any serial port). When a task writes to a serial port, the characters are all sent to the output buffer at once, but execution proceeds to the next command without waiting for those characters to be transmitted.

The data assignment functions READ, DREAD, or DREADF, and TW are also shared between tasks, but in these cases, the task is not allowed to execute the next command until the data has been received and assigned. This requires waiting for human or host input, or thumbwheel strobe time. During this time, that task is “blocked”, and that data assignment function (READ, DREAD, or DREADF, or TW) is owned by the blocked task. If another task is active, it will continue to execute commands. If this second task attempts to access a data assignment function that is still owned by the first task, the second task becomes blocked also. This situation persists until the first task receives and assigns its data. At that point, ownership of the data assignment function passes to the second task, until it too receives and assigns its data. All this blocking and ownership is automatic, not requiring coordination by the user.

Locking Resources to a Specific Task

Examples:

```
LOCK1,1 locks COM1
LOCK1,0 unlocks COM1
LOCK2,1 locks COM2
LOCK2,0 unlocks COM2
LOCK3,1 locks swapping
LOCK3,0 unlocks swapping
```

The LOCK command can be used by a system task to gain or release exclusive ownership of a resource. This will allow that task to complete a sequence of commands with that resource while preventing another task from using the resource in between commands. Any other task attempting to access or LOCK that resource will become blocked (i.e., become temporarily totally inactive) until the resource is released by the task that owns it. Resources that can be LOCKed are:

- COM1 — the “RS-232” connector or the “ETHERNET” connector
- COM2 — the “RS-232/485” connector
- Task Swapping — When task swapping is locked to a specific task, command statements in all other tasks will not be executed until the task swapping is again unlocked. For more information on task swapping, see page 218.

NOTE: A resource can be locked by a task only while that task is executing a program. If program execution is terminated for any reason (e.g., stop, kill, limit, fault, or just reaching the END of a program), all resources locked by that task will become unlocked.

For example, to report the current position of a robotic arm, one might program:

```
VAR10 = 2PM ; position of axis two
LOCK1,1 ; lock COM1 ("RS-232" port) resource
WRITE "Arm Position is" ; write string
WVAR10 ; write position
WRITE "inches\13" ; write string and carriage return
LOCK1,0 ; release COM1 to other tasks
; Between the LOCK commands, other tasks will run unless they
; attempt to access COM1, in which case they become
; temporarily blocked. The same concept applies to COM2 and task
; swapping. In the extreme, the LOCK command may be used to prevent
; other tasks from doing anything, allowing one task all command
; processing resources. This might be done to maximize the speed
; of a group of commands, or to protect a sequence which is not
; otherwise covered with the LOCK options.
```

How Multi-tasking and the % Prefix Affect Commands and Responses

Multi-tasking affects many, but not all, of the 6K commands and features. The table below lists the commands that are affected by multi-tasking and the task-identifier (%) prefix. Any command that is not listed can be considered unaffected by multi-tasking. Any command that has axis data (e.g., A, V, D) is only affected if the axes have been associated with a task via the TSKAX command. Any command listed below as affected by the % prefix can also accept the @ character as a task number; in this case, all tasks will be affected by the command.

The response (if any) sent to the terminal by the command will be prefixed with the task number and % sign if the command had been executed by any task other than Task 0, the Supervisor Task. For commands executed in Task 1, if the command itself had the 1% prefix, then the response will also have the prefix. Otherwise, the response will not be prefixed. Therefore, if no multi-tasking is used, no responses will have task prefixes. If multi-tasking is used, however, you can determine which task originated the response. A response could be the result of a transfer command (e.g., TER), a command with no parameters (e.g. MC), trace output, or an error message.

Command(s)	Effect of % Prefix	Effect of Multi-tasking
GOTO, IF, ELSE, NIF, WHILE, NWHILE, REPEAT, UNTIL, L, LN, LX	None (ignored)	These commands direct program flow only on the task from which they are executed.
GOSUB, RUN, <programe>, JUMP, HALT, BP, PS, T, WAIT, C	Effectively inserts command into numbered task's program	These commands initiate, interrupt or continue program flow only on implicitly or explicitly specified task.
COMEXC, COMEXR, COMEXS	Affects mode on numbered task	These commands affect program flow only on implicitly or explicitly specified task.
S, K	Specifies affected task and axes, or axes only	These commands affect program flow and/or associated axes (depending on parameters given) only on implicitly or explicitly specified task. A "K" with no prefix or parameters kills all tasks.
ERROR, ERRORP, TER, TERF, ER	Affect/report on numbered task	These commands affect/report error conditions and programs only on implicitly or explicitly specified task (each task has its own error status register and error program).
TCMDER, TSS, TSSF, SS, TSTAT	Report on numbered task	These commands report command errors and status only on implicitly or explicitly specified task.
TTIM, TIMINT, TIMST, TIMSTP, TIM	Command refers to timer of numbered task	Each task has an independent timer. Also, TIMST0,# resets the timer to # msec., TIMST1,# restarts the timer with the TIM value of task #.
TRACE, TRACEP, TEX, STEP, #	Command refers to numbered task	Each task has its own trace and step mode. This allows tracing on a single task, or combined tasks commands.
ONCOND, ONIN, ONP, ONUS, ONVARA, ONVARB	Command refers to numbered task	Each task has its own set of ON conditions and its own ONP program.
LIMFNCi-C, LIMFNCi-D,	Command refers to	These functions are task specific.

LIMFNCi-E, LIMFNCi-F, LIMFNCi-P, INFNCi-C, INFNCi-D, INFNCi-E, INFNCi-F, INFNCi-P, INSELP, OUTFNCi-C	numbered task	All others affect the entire controller and cannot be affected by the % prefix.
--	---------------	---

Input and Output Functions and Multi-tasking

The 6K has inputs and outputs (onboard and on external optional I/O bricks) that can be assigned various I/O functions with these function assignment commands:

- `limfnc` Assigns input functions to the dedicated limit inputs on the “LIMITS/HOME” connectors (factory default functions are the respective R, S, and T limit input functions).
- `INFNC`..... Assigns input functions to the onboard digital inputs (trigger input on the “TRIGGERS/OUTPUTS” connectors) and to the digital inputs on external I/O bricks.
- `OUTFNC` Assigns output functions to the onboard digital outputs (outputs on the “TRIGGERS/OUTPUTS” connectors) and to the digital outputs on external I/O bricks.

The 6K’s I/O and events involving programmed I/O are related to tasks only if:

- The input or output function assignment is associated with a specific task. For example, because of the 1% prefix, the 1%`INFNC3-F` command assigns the “user fault” function to onboard input 3 and directs its function to be specific to Task 1.
- An input or output is assigned an axis-specific function and the axis is associated with a specific task. For example, if axes 2 and 3 are associated with Task 1 (1%`TSKAX2, 3`) and onboard input 4 is assigned as a “stop” input for axis 2 (`INFNC4-2D`), then when onboard input 4 goes active axis 2 is stopped; thus Task 1 is affected by input 4.

Each input or output group (`LIMFNC`, `INFNC`, and `OUTFNC`) is limited to a maximum of 32 function assignments at one time. Exceptions are: function A, `LIMFNC` functions R, S, and T, and `INFNC` function H. A given input or output can be assigned only one function, although for task-specific functions, this I/O point can perform the same function for multiple tasks (by using the % prefix). This only counts as one function against the maximum total of 32, even though it is shared by multiple tasks. A given I/O point cannot perform different functions for different tasks. Re-assigning a I/O point’s function in any (same or different) task will result in removing the assignment of the previous function in the previous task(s). For example:

```
1%2INFNC4-C ; module 2's 4th input will kill task 1
2%2INFNC4-C ; module 2's 4th input now kills tasks 1 & 2
3%2INFNC4-D ; module 2's 4th input will stop all axes in task 3,
              ; it no longer has a kill function for tasks 1 & 2
```

Axis-Specific I/O Functions

The table on page 215 shows the LIMFNC, INFNC and OUTFNC functions that can be shared by multiple tasks. A special case is the “stop” input function (INFNCi-aD or LIMFNCi-aD). Here, “a” is the optional axis number. If it is not included, the function stops the program and all associated (via TSKAX) axes of a task. In this case, the function is task specific, and can be shared by multiple tasks. If an axis number is included, it simply stops motion on the specified axis, and does not affect program flow. In this case, the function is not task specific; it associates an input with only one physical axis. The same is true for any INFNC or OUTFNC function that can accept (or require) an axis identifier. An I/O function can be associated with only one physical axis. The actual physical axis associated with the input or output is determined at the time the LIMFNC, INFNC or OUTFNC command is issued, in the context of current value of TSKAX for the current or % designated task. That association does not change if TSKAX changes later. As with all commands, if the specified axis is not part of the associated axes group (via TSKAX) of the task, the command will be ignored. Refer to the example below.

Example TSKAX1,4 ; task 1 associated with physical axes 1-4
 2%TSKAX5,8 ; task 2 associated with physical axes 5-8

Multi-Tasking Performance Issues

When is a Task Active?

Tasks are always ready to become active if commanded to do so. No special command is required to allow a task to do something. A task is active if it is:

- Executing a program (SS.3=B1)
- Executing a T or WAIT command (even if not running a program)
- Monitoring drive faults conditions (DRFEN1)
- Monitoring ONCOND conditions (SS.15=B1)
- Waiting in Program Select Mode (INSELP1 and SS.18=B1)
- Monitoring ERROR conditions (ERROR has any non-zero bit)

A task becomes active when it receives a command to perform something from the list above. A task that is not active does not create any overhead (delays) in command processing for tasks that are active. Once a task becomes active, however, it takes its turn in the sequence of swapping (see below), and checks for all of the conditions listed above. This adds a processing burden that will slow the command execution rate of programs running in other tasks.

A task becomes inactive if nothing from the above list is occurring. There is no special command “kill task” to disable all these modes/conditions/activities at once. The standards methods for terminating these (S, INSELP0, ERROR0, etc.) are needed to make a task completely inactive, and therefore not creating command processing overhead. Task 0, the Task Supervisor, will always be active, even if nothing from the above list is occurring, because Task 0 always checks the input command buffer for commands to execute.

The TSWAP command reports a binary bit pattern indicating the tasks that are currently active. Bit 1 represents task 1, bit 2 represents task 2, etc. A “1” indicates that the task is active, and a “0” indicates that the task is inactive. The SWAP assignment operator allows the same information to be assigned to a binary variable, or evaluated in a conditional statement such as IF or WAIT. This is useful for determining which tasks have any activity, whereas the system status (SS) and error status (ER) states reveal exactly what activity a given task has at that time.

Task Swapping

The 6Kn controller has only one processor responsible for executing programs, therefore, multiple tasks are not actually executing simultaneously. Tasks take turns executing when they are active. A task's "turn" consists of executing one command and checking its input, output, ON, ERROR and INSELP conditions before relinquishing control to the next task. The process of changing from one task to the next is called **task swapping**. The 6K controller determines when to swap tasks. The user is not required (or allowed) to determine how long a task should run, or when to relinquish control to another task.

Although the user does not determine how long a task should run, or when to relinquish control to another task, the number of "turns" a task gets before swapping can be set with the TSKTRN command. The default value is one for all active tasks. Thus, each task has equal weight, swapping after every command. If a task needs a larger share of processing time however, the TSKTRN value for that task can be increased. For example, if task 2 issued a TSKTRN6 command, while the others stayed at 1, programs running in task 2 would execute six commands before relinquishing. The TSKTRN value for a task can be changed at any time, allowing a task to increase its weight for an isolated section of program statements.

The TTASK command reports to the display the task number of the task that executed the command. This could be used for diagnostic purposes, as a way to indicate which task is executing a given section of program. The corresponding TASK assignment allows the program itself to determine which task is executing it. The current task number TASK can be assigned to a variable or evaluated in a conditional statement such as IF. This allows a single program to be used as a subroutine called from programs running in all tasks, yet this routine could contain sections of statements that are executed by some tasks and not others.

Task Execution Speed

Two terms describe the execution speed of tasks in multi-tasking environments.

Performance

Performance is a measure of how fast a task executes commands, and could be described in terms of commands per second. Because tasks must take turns executing, performance will decrease when tasks are added. For example, the performance of a task sharing the controller with two other tasks will be just one third of its performance if it were running by itself. Using the TSKTRN command described above, the relative performances of tasks can be altered.

Determinism

Determinism is a measure of how independent the performance of one task is from the commands and conditions involved in another task. If task swapping were done via a periodic interrupt (time slicing), task performance would be completely determinate, i.e., each task would run exactly for its time slice, not more or less. In the 6K products, task swapping is not time sliced, rather each task is allowed to execute one command and check its input, output, ON, ERROR and INSELP conditions before relinquishing control to the next task. For this reason, the performance of each task is somewhat determined by the commands and conditions underway in the other tasks. Most commands execute in approximately the same time. The others (some math commands, and line and arc commands) are broken into sections with durations that approximate those of the average command (approximately 2 ms). Swapping also takes place between these sections, allowing all task performance to be reasonably determinate regardless of which commands are being executed by other tasks.

Although time slicing would give completely determined task performance, the task swapping would need to include additional task save and restore functions to completely protect the task from the interrupt. This additional overhead would effectively rob processor time from the time slice, resulting in lower task performance. Task swapping in the 6K products does not add this overhead, and is therefore extremely efficient, taking less than 0.5% of task execution time.

Multi-Tasking Application Example

One machine multi-tasking application

A machine must perform three processes to a product. They are:

1. Fill the bottle with product. (axes 1,2)
2. Put a cap on the bottle. (axes 3,4)
3. Put the bottle in a box. (axes 5,6)

Each process must operate independently, because they wait on inputs that are not synchronized with each other. Even so, if one process slows too much, the others must also slow, to accommodate overall product flow. If a drive fault or limit occurs on any axis of any process, the entire machine must stop.

Solution

Create programs CAP, FILL, BOX, SETUP, and MAIN. The first three will control the respective processes, and will each be run from their own task. The STARTP program will be SETUP. SETUP will initialize all I/O and motion parameters, launch the tasks that run CAP, FILL and BOX, then jump to MAIN, which monitors the overall product flow. The TSKAX command is not used, with the result that all tasks are affected by limits or faults on any axis.

```
DEF SETUP
INFNC1-A           ; set up I/O (assign onboard inputs 1-7 as
INFNC2-A           ; "general-purpose" inputs)
INFNC3-A           ;
INFNC4-A           ;
INFNC5-A           ;
INFNC6-A           ;
INFNC7-A           ;
OUT011001         ; initialize outputs
@A100              ; set up all accelerations
V4,5,7,6,32,12    ; set up all velocities
VARB1=B1          ; process 1 (filler) flag
VARB2=B1          ; process 2 (capper) flag
VARB3=B1          ; process 3 (boxer) flag
2%FILLER          ; start filler in task 2
3%CAPPER          ; start capper in task 3
4%BOXER           ; start boxer in task 4
JUMP MAIN
END

DEF MAIN
WHILE(IN.1=B1)     ; while process is running
  IF (IN.5=B1)     ; If filling too fast (high-flow input on)
    VARB1=B0
  ELSE
    VARB1=B1
  NIF
  IF (IN.6=B1)     ; If capping too fast (high-flow input on)
    VARB2=B0
  ELSE
    VARB2=B1
  NIF
  IF (IN.7=B1)     ; If boxing too fast (high-flow input on)
    VARB3=B0
  ELSE
    VARB3=B1
  NIF
NWHILE
END
```

(continued on next page)

(continued from previous page)

```
DEF FILLER
WHILE(IN.1=B1)           ; while process is running
  IF(VARB1=B1)           ; if allowed by MAIN
    WAIT(IN.2=B1)        ; fill input
    D4000,6000
    GO11
    WAIT(IN.2=B0)
    D-4000,-6000
    GO11
  NIF
NWHILE
END

DEF CAPPER
WHILE(IN.1=B1)           ;while process is running
  IF(VARB2=B1)           ;if allowed by MAIN
    WAIT(IN.3=B1)        ;cap input
    D,,7000,5000         ;could write "3D7000,5000"
    GOXX11               ;could write "3GO11"
    WAIT(IN.3=B0)
    D-,,7000,-5000      ;could write "3D7000,-5000"
    GOXX11               ;could write "3GO11"
  NIF
NWHILE
END

DEF BOXER
WHILE(IN.1=B1)           ;while process is running
  IF(VARB3=B1)           ;if allowed by MAIN
    WAIT(IN.4=B1)        ;cap input
    D,,,7000,5000       ;could write "5D7000,5000"
    GOXXX11             ;could write "5GO11"
    WAIT(IN.4=B0)
    D-,,,7000,-5000    ;could write "5D7000,-5000"
    GOXXX11             ;could write "5GO11"
  NIF
NWHILE
END

STARTP SETUP
```


CHAPTER EIGHT

Troubleshooting

IN THIS CHAPTER

• Troubleshooting basics	222
• Solutions to common problems (problem/cause/remedy table).....	222
• Program debug tools	
- Status commands	226
- Error messages	232
- Trace mode.....	236
- Single-step mode.....	237
- Simulating programmable I/O activation.....	238
- Simulating analog input activation.....	240
- Motion Planner's Panel Gallery	240
• Technical support.....	241
• Operating system upgrades	241
• Product return procedure	241

Troubleshooting Basics

When your system does not function properly (or as you expect it to operate), the first thing that you must do is identify and isolate the problem. When you have accomplished this, you can effectively begin to resolve the problem.

The first step is to isolate each system component and ensure that each component functions properly when it is run independently. You can have to dismantle your system and put it back together piece by piece to detect the problem. If you have additional units available, you can want to exchange them with existing components in your system to help identify the source of the problem.

Determine if the problem is mechanical, electrical, or software-related. Can you repeat or recreate the problem? Random events can appear to be related, but they are not necessarily contributing factors to your problem. You can be experiencing more than one problem. You must isolate and solve one problem at a time.

Log (document) all testing and problem isolation procedures. Also, if you are having difficulty isolating a problem, be sure to document all occurrences of the problem along with as much specific information as possible. You can need to review and consult these notes later. This will also prevent you from duplicating your testing efforts.

Once you isolate the problem, see the problem solutions contained in this chapter. If the problem persists, contact your local technical support resource (see *Technical Support* below).

Electrical Noise

If you suspect that the problems are caused by electrical noise, see your 6K product's *Installation Guide* for help.

Solutions to Common Problems

NOTES

- Some hardware-related causes are provided because it is sometimes difficult to identify a problem as either hardware or software related.
- Refer to other sections of this manual for more information on controller programming guidelines, system set up, and general feature implementation. You can also see the command descriptions in the *6K Series Command Reference*. Refer to your product's *Installation Guide* for hardware-related issues.

Problem	Cause	Solution
Communication (Ethernet) errors.	1. Ethernet card not installed correctly.	1. Refer to the user instructions that came with your Ethernet card.
	2. Ethernet IP address conflict.	2. Change IP address with the <code>NTADDR</code> command.
	3. Connection to Ethernet port is compromised or miswired.	3. Refer to the connection instructions in the <i>Installation Guide</i> .
Communication (serial) not operative, or receive garbled characters.	1. Improper interface connections or communication protocol.	1. See troubleshooting section in your product's <i>Installation Guide</i> .
	2. COM port disabled.	2.a. Enable serial communication with the <code>E1</code> command. 2.b. If using RS-485, make sure the internal jumpers are set accordingly (see <i>Installation Guide</i>). Make sure COM 2 port is enabled for sending 6K language commands (execute the <code>PORT2</code> and <code>DRPCHKØ</code> commands).
	3. In daisy chain, unit cannot be set to proper address.	3. Verify DIP switch settings (see <i>Installation Guide</i>), verify proper application of the <code>ADDR</code> command.

Problem	Cause	Solution
Direction is reversed. (stepper axes only)	1. Direction connections to the drive are reversed.	1. Switch DIR+ with DIR- connection to drive.
	2. Phase of step motor reversed (motor does not move in the commanded direction).	2. Switch A+ with A- connection from drive to motor. SOFTWARE ALTERNATIVE: If the motor (and the encoder if one is used) is reversed, use the <code>CMDDIR1</code> command to reverse the polarity of both the commanded direction and the polarity of the encoder counts).
	3. Phase of encoder reversed (reported <code>TPE</code> direction is reversed).	3. Swap the A+ and A- connection at the ENCODER connector.
Direction is reversed, servo condition is stable. (servo axes only)	1. Command output (CMD) connections and feedback device connections or mounting are reversed.	1. Software remedy: Issue the <code>CMDDIR1</code> command to the affected axis. This reverses the polarity of the commanded direction and the feedback direction so that servo stability is maintained. Hardware remedy: Switch CMD- with the CMD+ connection to drive or valve (if your drive or valve does not accept differential outputs this will not work). You will also have to change the feedback device wiring or mounting so that it counts in same direction as the commanded direction.
Direction is reversed, servo condition is <u>un</u> stable. (servo axes only)	1. Not tuned properly.	1. Refer to tuning instructions in your product's <i>Installation Guide</i> .
	2. Phase of encoder reversed or mounting of ANI input is such that it counts in the opposite direction as the commanded direction.	2. Software remedy for encoder feedback only: For the affected axis, issue <code>ENCPOL1</code> . Hardware remedy: If using encoder feedback, swap the A+ and A- connections to the 6K product. If using ANI feedback, change the mounting so that the counting direction is reversed.
Distance, velocity, and accel are incorrect as programmed.	1. Incorrect resolution setting.	1.a. Stepper axes: Set the resolution on the to match the 6K product's <code>DRES</code> command setting (default <code>DRES</code> setting is 4,000 steps/rev). 1.b. Match the 6K product's <code>ERES</code> command setting (default <code>ERES</code> setting is 4,000 counts/rev) to match the post-quadrature resolution of the encoder. <u>ERES values for Compumotor encoders:</u> Stepper axes: <ul style="list-style-type: none"> • RE, -RC, -EC, & -E Series Encoders:..... <code>ERES4000</code> • HJ Series Encoders:..... <code>ERES2048</code> Servo axes (SM, N or J Series Servo Motors): <ul style="list-style-type: none"> • SM/N/JxxxxD-xxxx:..... <code>ERES2000</code> • SM/N/JxxxxE-xxxx:..... <code>ERES4000</code> Dynaserv (stepper and servo): <ul style="list-style-type: none"> • DR10xxB <code>ERES507904</code> • DR1xxxE <code>ERES614400</code> • DR1xxxA <code>ERES819200</code> • DR5xxxB <code>ERES278528</code> • DR5xxxA <code>ERES425894</code> • DM10xxB <code>ERES655360</code> • DM1xxxA <code>ERES1024000</code> • DM1004x <code>ERES655360</code>
	2. Pulse width too narrow. (stepper axes)	2. Set pulse width to drive specifications using the <code>PULSE</code> command. See page 47 for Parker drive <code>PULSE</code> settings.
	3. Wrong scaling values.	3. Check the scaling parameters (<code>SCALE1</code> , <code>SCLA</code> , <code>SCLD</code> , <code>SCLV</code> , <code>SCLMAS</code>) – see also page 48.
Erratic operation.	1. Electrical Noise.	1. Reduce electrical noise or move product away from noise source.
	2. Improper shielding.	2. Refer to the instructions in your product's <i>Installation Guide</i> .
	3. Improper wiring.	3. Check wiring for opens, shorts, & mis-wired connections.
Feedback device (encoder or ANI) counts missing.	1. Improper wiring.	1. Check wiring.
	2. Feedback device slipping.	2. Check and tighten feedback device coupling.
	3. Encoder too hot.	3. Reduce encoder temperature with heatsink, thermal insulator, etc.
	4. Electrical noise.	4a. Shield wiring. 4b. Use encoder with differential outputs.
	5. Encoder frequency too high.	5. Peak encoder frequency must be below 12 MHz post-quadrature. Peak frequency must account for velocity ripple.

Problem	Cause	Solution
Following problems — see page 199.		
Joystick mode: Motor does not move.	1. Joystick Release input not grounded.	1.a. If an input is not assigned the “Joystick Release” input function, do so with the <code>INFNCi-M</code> command (see page 86). 1.b. Ground the Joystick Release input.
	2. Improper wiring.	2. Check wiring for opens, shorts, and mis-wired connections.
LEDs:	<i>All other LED states indicate hardware errors.</i>	
“POWER” LED is off.	1. No power.	1. Check 24VDC power connection and restore power.
“POWER” LED is red.	1. General fault. 2. ENABLE input not grounded.	1. Reset the controller by one of these methods: <ul style="list-style-type: none"> • Cycle power • Issue the <code>RESET</code> command 2. Ground the ENABLE input.
An “AXIS” LED is on (red).	1. Drive was commanded to shut down (<code>DRIVE0</code>). If Disable Drive on Kill mode is enabled (<code>KDRIVE1</code>), a kill command or kill input will also disabled the drive. 2. Servo Axes: Maximum position error (<code>SMPER</code> value) exceeded. Could be caused by disconnected or mismatched feedback device.	1. Re-enable the drive by sending a <code>DRIVE1</code> command to the affected axis. 2. (verify position error by checking to see if <code>TAS/TASF</code> bit 23 is set) Check feedback device connection and mounting and re-enable drive by sending <code>DRIVE1</code> command to the affected axis.
Motion does not occur.	1. “AXIS” LED is red, or “POWER” LED is off or red. 2. End-of-travel limits are active. 3. Step pulse too narrow for drive to recognize (stepper axes only). 4. Drive fault level incorrect. 5. Improper wiring. 6. ENABLE input is not grounded. 7. Load is jammed. 8. No torque from motor. 9. Maximum position error (<code>SMPER</code> value) exceeded. (servo axes only) 10. Drive has activated the drive fault input.	1. See LED troubleshooting as noted above. 2.a. Move load off of limits or disable limits by sending the <code>LH0</code> command to the affected axis. 2.b. Software limits: Set <code>LSPOS</code> to a value greater than <code>LSNEG</code> . 3. Set pulse width to drive specifications using the <code>PULSE</code> command (see page 47). 4. Set drive fault level using the <code>DRFLVL</code> command (see page 46). 5. Check drive fault & limit connections. Stepper Axes: check step and direction connections. Servo Axes: check command and shutdown connections. 6. Ground the ENABLE input connection. 7. Remove power and clear jam. 8. See problem: <i>Torque, loss of.</i> 9. Check to see if <code>TAS/TASF</code> bit 23 is set, and issue the <code>DRIVE1</code> command to the axis that exceeded the position error limit. 10. Check to see if <code>TAS/TASF</code> bit 14 is set, and check the drive fault level (<code>DRFLVL</code>) — see page 46 for appropriate <code>DRFLVL</code> settings.
Power-up Program does not execute.	1. ENABLE input is not grounded. 2. <code>STARTP</code> program is not defined.	1. Ground the ENABLE input to GND and reset the product. 2. Check the response to the <code>STARTP</code> command. If no program is reported, define the <code>STARTP</code> program and reset (see page 13, or see the <code>STARTP</code> command description).
Program access denied: receive the message *ACCESS DENIED when trying to use the <code>DEF</code> , <code>DEL</code> , <code>ERASE</code> , <code>LIMFNC</code> , <code>INFNC</code> , or <code>MEMORY</code> commands.	1. Program security function has been enabled (<code>INFNCi-Q</code> or <code>LIMFNCi-Q</code>) and the program access input has not been activated	1.a. Activate the assigned program access input, perform your programming changes, then deactivate the program access input. 1.b. Refer to the instructions on page 89, or to the <code>INFNC</code> or <code>LIMFNC</code> command descriptions.
Program execution: the first time a program is run, the move distances are incorrect. Upon downloading the program the second time, move distances are correct.	1. Scaling parameters were not issued when the program was downloaded; or scaling parameters have been changed since the program was defined.	1. Issue the scaling parameters (<code>SCALE1</code> , <code>SCLA</code> , <code>SCLD</code> , <code>SCLV</code> , <code>PSCLA</code> , <code>PSCLD</code> , <code>PSCLV</code> , <code>SCLMAS</code>) before saving any programs.

Problem	Cause	Solution
Program execution: stops at the DRFEN1 command	1. DRFEN1 enables drive fault monitoring, but the drive fault level (DRFLVL) command is set incorrectly for the drive being used.	1. Issue the correct DRFLVL command for your drive (see the DRFLVL command or to page 46).
Runaway (SERVOS ONLY)	1. Direction connections reversed. (if encoder counts positive when turned clockwise or extended).	1. Switch CMD- with the CMD+ connection to drive or valve. NOTE: The CMD+/- Connection is not differential. Do not connect CMD+ to ground on your drive or valve.
Torque, loss of.	1. Improper wiring.	1. Check wiring to the drive, as well as other system wiring.
	2. No power to drive .	2. Check power to drive.
	3. Drive failed.	3. Check drive status.
	4. Drive faulted.	4. Check drive status.
	5. Shutdown issued to drive.	5. Re-enable drive by sending the DRIVE1 command to the affected axis.
Velocity & acceleration is incorrect as programmed.	See <i>Distance</i> problem noted above.	

Program Debug Tools After creating your programs, you can need to debug the programs to ensure that they perform as expected. The 6K controller provides several debugging tools. Detailed descriptions are provided on the following pages.

- **Status Commands:** Use the “Transfer” commands (e.g., TAS, TSS, TIN) to display various controller status information. Multi-Tasking: System (TSS) and Error (TER) status information is task specific; to check the status for a specific task, you must prefix the status command with the task identifier (e.g., 2%TSS to check the system status for task 2).
- **Error Messages:** You can enable the 6K controller to display error messages when it detects certain programming errors as you enter them or as the program is run. When the controller detects an error with a command, you can issue the TCMDER command to find out which command caused the error.
- **Trace mode:** Trace a program as it is executing.
- **Single-Step mode:** Step through the program one command at a time.
- **Simulate Programmable I/O Activation:** You can set the desired state of the 6K controller’s inputs and outputs via software commands.
- **Simulate Analog Input Activation:** Without an actual voltage present, you can simulate a specific voltage on the 6K controller’s analog input channels using the ANIEN command.
- **Motion Planner’s Panel Gallery:** Motion Planner’s Panel Gallery provides an assortment of test panels you can use to verify various system I/O and operating parameters.

Status Commands

Status commands are provided to assist your diagnostic efforts. These commands display status information such as, axis-specific conditions, general system conditions, error conditions, etc.

Checking Specific Setup Parameters

One way to check the conditions that are established with a specific setup command is to simply type in the command name without parameters. For example, type “ERES” to check the encoder resolution setting; the response would look something like: *ERES4000.

Refer to page 44 for a list of most setup parameters and their respective commands.

⇒ **HINT:** To send a status command to the 6K product during program execution, prefix the command with an “!” (e.g., !TASF).

Below is a list of the status commands that are commonly used for diagnostics. Additional status commands are available for checking other elements of your application (see *List of All Status Commands* below). For more information on each status command, see the respective command description in the *6K Series Command Reference*.

SPECIAL NOTATIONS

- * The command has a binary report version (just leave the “F” off when you type it in—e.g., TAS). This is used more by experienced 6K programmers. Using the binary report command, you can check the status of one particular bit (e.g., The 2TAS.1 command reports “1” if axis 2 is moving or “0” if it is not moving.). In the binary report the bits are numbered left to right, 1 through *n*. A “1” in the binary report correlates to a “YES” in the full text report, and a “0” correlates to a “NO” in the full text report.
- † The command has an assignment/comparison operator that uses the bit status for conditional expressions and variable assignments. For example, the WAIT (2AS.1=b0) command pauses program execution until axis 2’s status bit 1 (2AS.1) reports a binary zero value (indicates that the axis is not-moving). See page 7 and page 25 for more information on using assignment and comparison operators in conditional expressions and variable assignments.

TASF	Reports axis-specific conditions.	* (TAS)	† (AS)
1. Axis is in motion (commanded)	17. Positive-direction software limit (LSPOS) encountered		
2. Direction is negative	18. Negative-direction software limit (LSNEG) encountered		
3. Accelerating (n/a to deceleration)	19. RESERVED		
4. At velocity	20. RESERVED		
5. Home Successful (HOM)	21. RESERVED6. In absolute positioning mode (MA)		22.
RESERVED7. In continuous positioning mode (MC)	23. Position error limit is exceeded (SMPER) — servos		
8. In Jog Mode (JOG)	24. Load is within Target Zone (STRGTD & STRGTV)		
9. In Joystick Mode (JOY)	25. Target Zone timeout occurred (STRGTT) — servos		
10. RESERVED	26. Motion suspended, pending GOWHEN		
11. RESERVED	27. RESERVED		
12. Stall detected (ESTALL) — steppers	28. Registration move occurred since last GO		
13. Drive shutdown occurred	29. GOWHEN error		
14. Drive fault occurred (enable DRFEN1 first)	30. Pre-emptive (OTF) GO or Registration profile not possible		
15. Positive-direction hardware limit hit	31. Executing profile		
16. Negative-direction hardware limit hit	32. RESERVED		

TASXF

Reports extended axis-specific conditions.

* (TASK)

† (ASX)

1. RESERVED
2. RESERVED
3. RESERVED
4. Drive Fault input is active (hardware state is always recognized, regardless of DRIVE and DRFEN)
5. Encoder failure detected (encoder failure detection must first be enabled with the EFAIL1 command)
6. Z-Channel input (on the encoder connector) is active.
7. Drive Stall Active

TSTAT

Reports general system setup and current conditions.

Sample response for the 6K8:

```

*6K8 (8-axis controller)
*6K revision: 92-XXXXXX-01-5.0 6K 92-XXXXXX-XX-NOP2.5 DSP
*Ethernet address: xxxxxxxxxx; IP address: 192.168.10.30
*Axis definition: Servo,Servo,Servo,Servo,Stepper,Stepper,Stepper,Stepper
*Power-up program assignment (STARTP): SETUP
*ENABLE input OK: Yes
*Drive status (DRIVE): 0000_0000
*Drive Fault input states (ASX.4 for each axis): 0000_0000
*Drive Fault input checking - enabled (DRFEN1): 0000_0000
*Drive resolution (DRES): -, -, -, -, 25000, 25000, 25000, 25000
*Encoder resolution (ERES): 4000, 4000, 4000, 4000
*Encoder failure detection enabled (EFAIL1): 0000_0000
*Hard Limit enable: LH3, 3, 3, 3, 3, 3, 3, 3
*Soft Limit enable: LS0, 0, 0, 0, 0, 0, 0, 0
*Current Motion Attributes:
* Scaling enabled (SCALE1): 0
* Acceleration scaler (SCLA): 4000, 4000, 4000, 4000, 4000, 4000, 4000, 4000
* Distance scaler (SCLD): 1, 1, 1, 1, 1, 1, 1, 1
* Velocity scaler (SCLV): 4000, 4000, 4000, 4000, 4000, 4000, 4000, 4000
* Continuous/Preset (MCL/MC0) positioning mode: 0, 0, 0, 0, 0, 0, 0, 0
* Absolute/Incremental (MAL/MA0) positioning mode: 0, 0, 0, 0, 0, 0, 0, 0
* Feedback position (TFB or TPE): +0, +0, +0, +0, -, -, -, -
* Commanded position (TPC): +0, +0, +0, +0, +0, +0, +0, +0
* A10.0000, 10.0000, 10.0000, 10.0000, 10.0000, 10.0000, 10.0000, 10.0000
* AA10.0000, 10.0000, 10.0000, 10.0000, 10.0000, 10.0000, 10.0000, 10.0000
* AD10.0000, 10.0000, 10.0000, 10.0000, 10.0000, 10.0000, 10.0000, 10.0000
* ADA10.0000, 10.0000, 10.0000, 10.0000, 10.0000, 10.0000, 10.0000, 10.0000
* V1.0000, 1.0000, 1.0000, 1.0000, 1.0000, 1.0000, 1.0000, 1.0000
* D+4000, +4000, +4000, +4000, +4000, +4000, +4000, +4000
*I/O Status:
* Onboard limit inputs:
* Hardware state (TLIM): 000_000_000_000_000_000_000_000
* Prog. function (LIMFNC): RST_RST_RST_RST_RST_RST_RST_RST
* Onboard trigger inputs:
* Hardware state (TIN): 0000_0000_0000_0000_0
* Prog. function (INFNC): AAAA_AAAA_AAAA_AAAA_A
* Onboard digital outputs:
* Hardware state (TOUT): 000_000
* Prog. function (OUTFNC): AAA_AAA
* Expansion I/O bricks: See TIO response
*Axis Status (see TASF for full text report of all axes):
* Axis 1 (1TAS): 0010_0000_0000_1000_0000_0001_0000_0000
* Axis 2 (2TAS): 0010_0000_0000_1000_0000_0001_0000_0000
* Axis 3 (3TAS): 0010_0000_0000_1000_0000_0001_0000_0000
* Axis 4 (4TAS): 0010_0000_0000_1000_0000_0001_0000_0000
* Axis 5 (5TAS): 0010_0000_0000_1000_0000_0001_0000_0000
* Axis 6 (6TAS): 0010_0000_0000_1000_0000_0001_0000_0000
* Axis 7 (7TAS): 0010_0000_0000_1000_0000_0001_0000_0000
* Axis 8 (8TAS): 0010_0000_0000_1000_0000_0001_0000_0000
*System Status (This is Task 0 status if using multi-tasking.):
* Assoc. axes (TSKAX): 1, 2, 3, 4, 5, 6, 7, 8
* System status (TSSF): 1000_1100_0000_0000_0000_0100_0000_0000
* Error checking (ERROR): 1000_0100_1000_0001_0000_0000_0000_0000
* Error status (TERF): 0000_0000_0000_0000_0000_0000_0000_0000
* Error program (ERRORP): ERRPRG
* On conditions (ONCOND): 0000
*Multi-Tasking Status:
* Currently active tasks (TSWAP): 0000_0000_00
*Following Conditions:
* Master-Follower assignment (FOLMAS): +0, +0, +0, +0, +0, +0, +0, +0
* Master scaling (SCLMAS): 4000, 4000, 4000, 4000, 4000, 4000, 4000, 4000
* Following status (TFSF): 0000_0000_0000_0000_0000_0000_0000_0000

```

TSSF	Reports current system conditions. * (TSS) † (SS) <u>Multi-tasking</u> : Each task has its own system status; therefore, to check the system status for a specific task, prefix the TSSF command (e.g., 2%TSSF).
1. System is ready	17. Loading Thumbwheel Data (TW operator)
2. RESERVED	18. In External Program Select Mode (INSELP)
3. Executing a Program	19. Dwell in Progress (T command)
4. Last command was immediate	20. Waiting for RP240 Data (DREAD or DREADF)
5. In ASCII Mode	21. RP240 Connected
6. In Echo Mode (ECHO)	22. Non-volatile Memory Error
7. Defining a Program (DEF)	23. Gathering servo data
8. In Trace Mode (TRACE, TRACEP)	24. RESERVED
9. In Step Mode (STEP)	25. RESERVED
10. RESERVED	26. RESERVED
11. Command error (check with TCMER)	27. RESERVED
12. Break Point Active (BP)	28. RESERVED
13. Pause Active (PS or pause input)	29. Compiled memory partition is 75% full
14. Wait Active (WAIT)	30. Compiled memory partition is 100% full
15. Monitoring On Conditions (ONCOND)	31. Compile operation (PCOMP) failed
16. Waiting for Data (READ)	32. RESERVED

TINOF	Reports the status of the ENABLE input. * (TINO) † (INO)
1-5. RESERVED	
6. ENABLE input OK (motion not inhibited)	
7-8. RESERVED	

TFSF	Reports Following Mode conditions (details on page 167). * (TFS) † (FS)
1. Slave is in a Following ratio move	17. Master Position Prediction Mode enabled (FPPEN)
2. Current ratio is negative	18. Master Position Filtering Mode enabled (FFILT)
3. Slave is changing ratio	19. RESERVED
4. Slave at ratio (constant non-zero ratio)	20. RESERVED
5. FOLMAS Active	21. RESERVED
6. Following Mode enabled (FOLEN)	22. RESERVED
7. Master is moving	23. OK to do a geared advance (FGADV) move
8. Master direction is negative	24. Geared advance (FGADV) move is underway
9. OK to Shift	25. RESERVED
10. Shifting now	26. Following profile is limited (FMAXA/FMAXV)
11. FSHFC-based shift move is in progress	27. RESERVED
12. Shift direction is negative	28. RESERVED
13. Master cycle trigger input is pending	29. RESERVED
14. Mas cycle length (FMCLN) given	30. RESERVED
15. Master cycle position is negative	31. RESERVED
16. Master cycle number is > 0	32. RESERVED

TERF

Reports error conditions. **

* (TER) † (ER)

Multi-tasking: Each task has its own error status; therefore, to check the error status for a specific task, prefix the TERF command (e.g., 2%TERF).

1. Stall detected. 1st: Enable Stall Detection (ESTALL).
2. Hardware end-of-travel limit encountered. 1st: Enable hard limits (LH).
3. Software end-of-travel limit encountered. 1st: Enable hard limits (LH).
4. Drive Fault input is active. 1st: enable (DRFEN) & set fault level (DRFLVL).
5. Stop or Kill Issued
6. A programmable input, defined as a “kill” input, is active.
7. A programmable input, defined as a “user fault” input, is active.
8. A programmable input, defined as a “stop” input, is active.
9. ENABLE input not grounded.
10. Pre-emptive (OTF) GO or Registration profile not possible.
11. Target Zone settling timeout period (STRGTT) is exceeded. — servo only
12. Maximum position error (SMPER value) is exceeded. — servo only
13. RESERVED
14. GOWHEN condition already true.
15. RESERVED
16. Bad command detected (use TCMDEP to identify the bad command).
17. Encoder failure detected (1st: enable failure detection with EFAIL1).
18. Expansion I/O brick is disconnected or has lost power.
19. Option Card Fault
20. RESERVED
21. RESERVED
22. Ethernet Failure
23. Client Connect Error
24. Client Polling Error
- 25–32. RESERVED

** The error condition will not be reported until you enable the respective error-checking bit with the ERROR command (for details, see page 30 or the ERROR command description).

NOTE: When the error-checking bit is enabled and the error occurs, the controller will branch to the “error” program that you assigned with the ERRORP command.

Other status commands commonly used for diagnostics:

TDIR.....	Identifies the name and number of all programs residing in the 6K product's memory. Also reports percent of available memory for programs and compiled path segments.
TCMDER....	Identifies the bad command that caused the error prompt (?). (see page 235 for details)
TEX.....	Execution status (and line of code) of the current program in progress. Task specific.
TIN.....	Binary report of all programmable and trigger inputs ("1" = active, "Ø" = inactive). <i>INFNC</i> also reports the state and programmed function of each input. (see page 76 for bit assignments)
TOUT.....	Binary report of all programmable and auxiliary outputs ("1" = active, "Ø" = inactive). <i>OUTFNC</i> also reports the state and programmed function of each output. (see page 76 for bit assignments)
TLIM.....	Binary report of all limit inputs ("1" = active, "Ø" = inactive). <i>LIMFNC</i> also reports the state and programmed function of each limit input. (see page 76 for bit assignments)
TIO.....	Reports current contents on all expansion I/O bricks connected to the 6K controller. Includes current state and function of the digital inputs and outputs, as well as voltage of analog inputs.
TPER.....	(servo axes) Reports the difference between the commanded position and the actual position as measure by the feedback device.
TPC.....	Current commanded position.
TPE.....	Current position of the encoder.
TFB.....	(servo axes) Current position of the feedback device selected with the last <i>SFB</i> command.
TPMAS.....	Current position of the Following master axis.
TPSLV.....	Current position of the Following slave axis.
TNMCY.....	Current master cycle number.
TSCF.....	Full-text report of the current "Controller Status" register.
TNT.....	Report the current Ethernet status.

List of All Status Commands

SPECIAL NOTATIONS

- * The command responds with a binary report. This is used more by experienced 6K programmers. Using the bit select operator (.), you can check the status of one particular bit (e.g., The *2TAS.1* command reports "1" if axis 2 is moving or "Ø" if it is not moving.). In the binary report, the bits are numbered left to right, 1 through *n*. A "1" in the binary report correlates to a "YES" in the full text report, and a "Ø" correlates to a "NO" in the full text report.
- Δ The command has a full-text report version (just add an "F" when you type it in—e.g., *TASF*). This makes it easier to check status information without having to look up the purpose of each status bit. (see full-text descriptions on pages 226-230)
- † The command has an assignment/comparison operator that uses the bit status for conditional expressions and variable assignments. For example, the *WAIT (2AS.1=bØ)* pauses progress execution until axis 2's status bit 1 (*2AS.1*) reports a binary zero value (indicates that the axis is not-moving). See page 7 and page 25 for more information on using assignment and comparison operators in conditional expressions and variable assignments.

COMMAND STATUS SUBJECT

TANI	Voltage of ANI inputs (<i>servo products with ANI option</i>) †
TANO	report the value of an analog output channel †
TAS	Binary Report of Axis Status * Δ †
TASX	Binary Report of Axis Status – extended * Δ †
TCMDER	Command Error (view command that caused the error prompt)
TDAC	Digital-to-Analog (DAC) Voltage (Servos) †
TDIR	Program Directory and Available Memory
TDPTR	Data Pointer Status †
TER	Error Status * Δ †
TEX	Program Execution Status †
TFB	Position of Selected Feedback Devices †
TFS	Binary Report of Following Status * Δ †
TGAIN	Current Value of Active Servo Gains
TIN	Binary Report of Status of Programmable Inputs * †
TINO	Status of the ENABLE input (bit 6) * Δ †
TIO	Report of all I/O on expansion I/O bricks
TLABEL	Defined Labels (names of)
TLIM	Binary Report of Hardware Status of All Limit Inputs †
TMEM	Memory Usage (partition and available memory)
TNMCY	Master Cycle Number †
TNT	Reports the current Ethernet conditions
TNTMAC	Ethernet Address
TOUT	Binary Report of Status of Programmable Outputs * †
TPANI	Position of ANI Inputs †
TPC	Commanded Position †
TPCC	Captured Commanded Position †
TPCE	Captured Encoder Position †
TPCME	Captured Master Encoder Position †
TPCMS	Captured Master Cycle Position †
TPE	Position of Encoder †
TPER	Position Error †
TPMAS	Position of Master Axis †
TPME	Position of Master Encoder †
TPROG	Contents of a Program
TPSHF	Net Position Shift †
TPSLV	Current Commanded Position of the Slave Axis †
TREV	Firmware Revision Level
TSC	Current "Controller Status" register.
TSCAN	Scan Time of Last PLC Program * Δ †
TSGSET	Servo Gain Sets
TSEG	Number of Free Segment Buffers †
TSS	Binary Report of System Status * Δ †
TSTAT	Statistics
TSTLT	Settling Time
TSWAP	Identify Currently Active Tasks (in multi-tasking) * †
TTASK	Task Number of the program that executes this command †
TTIM	Time Value †
TTRIG	Status of "Trigger Interrupt" Activation * †
TUS	User Status * †
TVEL	Current Commanded Velocity †
TVELA	Current Actual Velocity †
TVMAS	Current Velocity of the Master Axis †

Error Messages

Depending on the error level setting (set with the `ERRLVL` command), when a programming error is created, the 6K controller will respond with an error message and/or an error prompt. A list of all possible error messages is provided in a table below. The default error prompt is a question mark (?), but you can change it with the `ERRBAD` command if you wish.

At error level 4 (`ERRLVL4`—the factory default setting) the 6K controller responds with both the error message and the error prompt. At error level 3 (`ERRLVL3`), the 6K controller responds with only the error prompt.

Error Response	Possible Cause
ACCESS DENIED	Program security feature enabled, but program access input (<code>INFNCi-Q</code>) not activated.
ALREADY DEFINED FOR THUMBWHEELS	Attempting to assign an I/O function to an I/O that is already defined as a thumbwheel I/O.
alternative task not allowed	Attempting to execute a <code>LOCK</code> command directed to another task.
AXES NOT READY	Compiled Profile path compilation error.
COMMAND NOT IMPLEMENTED	Command is not applicable to the 6K Series product.
COMMAND NOT ALLOWED IN PROGRAM	Command is not allowed inside a program definition (between <code>DEF</code> and <code>END</code>).
COMMAND/drive mismatch	The command (or \geq one field in the command) is not appropriate to the <code>AXSDEF</code> configuration (e.g., attempting to execute a servo tuning command on a stepper axis)
ERROR: MOTION ENDS IN NON-ZERO VELOCITY - AXIS N	Compiled Motion: The last <code>GOBUF</code> segment within a <code>PLOOP/PLM</code> loop does not end at zero velocity, or there is no final <code>GOBUF</code> segment placed outside the loop.
EXCESSIVE PATH RADIUS DIFFERENCE	Contouring path compilation error.
FOLMAS NOT SPECIFIED	No <code>FOLMAS</code> for the axis is currently specified. It will occur if <code>FMCNEW</code> , <code>FSHFC</code> , or <code>FSHFD</code> commands are executed and no <code>FOLMASØ</code> command was executed, or <code>FOLMAS0</code> was executed.
INCORRECT AXIS	Axis specified is incorrect.
INCORRECT BRICK NUMBER	Attempted to execute a command that addresses an I/O brick that is not connected to your 6K controller.
INCORRECT DATA	Incorrect command syntax. Following: Velocity (<code>v</code>), acceleration (<code>A</code>) or deceleration (<code>AD</code>) command is zero (used by <code>FSHFC</code> & <code>FSHFD</code>).
INPUT(S) NOT DEFINED AS JOYSTICK INPUT	Attempted to execute <code>JOYCDB</code> , <code>JOYCTR</code> , <code>JOYEDB</code> , or <code>JOYZ</code> before executing <code>JOYAXH</code> or <code>JOYAXL</code> to assign the analog input to an axis.
INSUFFICIENT MEMORY	Not enough memory for the user program or compiled profile segments. This can be remedied by reallocating memory (see <code>MEMORY</code> command description).
INVALID COMMAND	Command is invalid because of existing conditions

Error Response	Possible Cause
INVALID CONDITIONS FOR COMMAND	<p>System not ready for command (e.g., LN command issued before the L command).</p> <p>Following (these conditions can cause an error during Following):</p> <ul style="list-style-type: none"> • The FOLMD value is too small to achieve the preset distance and still remain within the FOLRN/FOLRD ratio. • A phase shift cannot be performed: <ul style="list-style-type: none"> FSHFD Error if already shifting or performing other time based move. FSHFC Error if currently executing a FSHFD move, or if currently executing another FSHFC move in the opposite direction. • The FOLEN1 command was given while a profile was suspended by a GOWHEN.
INVALID CONDITIONS FOR S_CURVE ACCELERATION—FIELD n	Average (AA) acceleration or deceleration command (e.g., AA, ADA, HOMAA, HOMADA, etc.) with a range that violates the equation $\frac{1}{2}A \leq AA \leq A$ (A is the maximum accel or decel command—e.g., A, AD, HOMA, HOMAD, etc.)
INVALID DATA	<p>Data for a command is out of range.</p> <p>Following (these conditions can cause an error during Following):</p> <ul style="list-style-type: none"> • The parameter supplied with the command is valid. <ul style="list-style-type: none"> FFILT Error if: smooth number is not 0-4 FMCLEN .. Error if: master steps > 999999999 or negative FMCP..... Error if: master steps > 999999999 or < -999999999 FOLMD Error if: master steps > 999999999 or negative FOLRD Error if: master steps > 999999999 or negative FOLRN Error if: follower steps > 999999999 or negative FSHFC Error if: number is not 0-3 FSHFD Error if: follower steps > 999999999 or < -999999999 GOWHEN .. Error if: position > 999999999 or < -999999999 WAIT..... Error if: position > 999999999 or < -999999999 • Error if a GO command is given in the preset positioning mode (MCØ) and: <ul style="list-style-type: none"> FOLRN = zero FOLMD = zero, or too small (see Following chapter on page 166)
INVALID FOLMAS SPECIFIED	Following: An illegal master was specified in FOLMAS. A follower can never use its own commanded position or feedback source as its master.
INVALID RATIO	Following: Error if the FOLRN:FOLRD ratio after scaling is > 127 when a GO is executed
INVALID TASK IDENTIFIER	Attempting to launch a PEXE or EXE command into the supervisor task (task 0).
MASTER, SLAVE DISTANCE MISMATCH	Attempting a preset Following move with a FOLMD value that is too small.
LABEL ALREADY DEFINED	Defining a program or label with an existing program name or label name
MAXIMUM COMMAND LENGTH EXCEEDED	Command exceeds the maximum number of characters
MAXIMUM COUNTS PER SECOND EXCEEDED	Velocity value is greater than 1,600,000 counts/sec

Error Response	Possible Cause
MOTION IN PROGRESS	Attempting to execute a command not allowed during motion (see <i>Restricted Commands During Motion</i> on page 17). Following: The FOLEN1 command was given while that follower was moving in a non-Following mode.
NEST LEVEL TOO DEEP	IFs, REPEATs, WHILEs, or GOSUBs nested greater than 16 levels (for each type)
NO MOTION IN PROGRESS	Attempting to execute a command that requires motion, but motion is not in progress
NO PATH SEGMENTS DEFINED	Compiled Profile compilation error
NO PROGRAM BEING DEFINED	END command issued before a DEF command
NOT ALLOWED IF SFBØ	Changes to tuning commands (SGILIM, SGAF, SGI, SGP, SGV, and SGVF) and SMPER are not allowed if SFBØ is selected
NOT ALLOWED IN PATH	Compiled Profile path compilation error
NOT DEFINING A PATH	Executing a compiled profile or contouring path command while not in a path
NOT VALID DURING FOLLOWING MOTION	A GO command was given while moving in the Following mode (FOLEN1) and while in the preset positioning mode (MCØ).
NOT VALID DURING RAMP	A GO command was given while moving in a Following ramp and while in the continuous positioning mode (MC1). Following status (FS) bit 3 will be set to 1. A FOLEN command was given during one of these conditions: <ul style="list-style-type: none"> • During a shift (FSHFC or FSHFD) • During a change in ratio (FOLRN/FOLRD) • During deceleration to a stop
OUTPUT BIT USED AS OUTFNC	Attempted to change an output that is not an OUTFNCi-A output.
PATH ALREADY MOVING	Compiled Profile path compilation error
PATH NOT COMPILED	Attempting to execute a individual axis profile or a multiple axis contouring path that has not been compiled
PATH RADIUS TOO SMALL	Contouring path compilation error
PATH RADIUS ZERO	Contouring path compilation error
PATH VELOCITY ZERO	Contouring path compilation error
STRING ALREADY DEFINED	A string (program name or label) with the specified name already exists
STRING IS A COMMAND	Defining a program or label that is a command or a variant of a command
SYSTEM UPDATE OVERRUN, USE SYSPER4	The system update service has overrun the time allotted with the default 2-millisecond period. Use the SYSPER4 command to increase the system update period to 4 milliseconds.

Error Response	Possible Cause
UNDEFINED LABEL	Command issued to product is not a command or program name
WARNING: POINTER HAS WRAPPED AROUND TO DATA POINT 1	During the process of writing data (DAT TCH) or recalling data (DAT), the pointer reached the last data element in the program and automatically wrapped around to the first datum in the program
WARNING: ENABLE INPUT INACTIVE	ENABLE input is no longer connected to ground (GND)
WARNING: DEFINED WITH ANOTHER TW/PLC	Duplicate I/O in multiple thumbwheel definitions

Identifying Bad Commands

To simplify program debugging, the Transfer Command Error (TCMDER) command allows you to display the first command that the controller detects as an error. This is especially useful if you receive an error message when running or downloading a program, because it catches and remembers the command that caused the error.

Using Motion Planner:

If you are typing the command in a live terminal emulator session, the controller will detect the bad command and respond with an error message, followed by the ERRBAD error prompt (?). If the bad command was detected on download, the bad command is reported automatically (see example below).

NOTE: If you are not using Motion Planner, you'll have to type in the TCM DER command at the error prompt to display the bad command.

Once a command error has occurred, the command and its fields are stored and system status bit 11 (reported in the TSSF, TSS and SS commands) is set to 1. The status bit remains set until the TCM DER command is issued.

Example Error Scenario

1. In Motion Planner's program editor, create and save a program with a programming error:

```

DEL badprg      ; Delete a program before defining and downloading
DEF badprg      ; Begin definition of program called badprg
MA11            ; Select the absolute preset positioning mode
A25,40          ; Set acceleration
AD11,26         ; Set deceleration
V5,8            ; Set velocity
VAR1=0          ; Set variable 1 equal to zero
GO11           ; Initiate move on both axes
IF(VAR1<)16    ; MISTYPED IF STATEMENT - should be typed as "IF(VAR1<16)"
VAR1=VAR1+1    ; If variable 1 is < 16, increment the counter by 1
NIF            ; End IF statement
END            ; End programming of program called badprg

```

2. Using Motion Planner's terminal emulator, download the program to the 6K Series product. Notice that an error response identifies the bad command as an "INCORRECT DATA" item and displays it:

```

> *NO ERRORS
*INCORRECT DATA
> *IF(VAR1<)16
>

```

Trace Mode

You can use the Trace mode to debug a program. The Trace mode allows you to track, command-by-command, the entire program as it runs. The 6K controller will display all of the commands as they are executed. **NOTE:** Program tracing is also available on the RP240 display (see page 111).

The example below demonstrates the Trace mode.

Step 1 Create a program called prog1:

```
DEF prog1          ; Begin definition of program prog1
A10                ; Acceleration is 10
AD10               ; Deceleration is 10
V5                 ; Velocity is 5
L3                 ; Loop 3 times
GOSUB prog3        ; Gosub to program 3 (prog3)
LN                 ; End the loop
END                ; End definition of program prog1
```

Step 2 Create a program prog3:

```
DEF prog3          ; Begin definition of program prog3
D50000             ; Sets the distance to 50,000
GO1                ; Initiates motion
END                ; End definition of program prog3
```

Step 3 Enable the Trace Mode:

```
TRACE1            ; Enables the Trace mode
```

Step 4 Execute the program prog1: (each command in the program is displayed as it is executed)

```
EOT13,10,0        ; Set End-of-Transmission characters to <cr>,<lf>
RUN prog1          ; Run program prog1
```

The response will be:

```
*PROGRAM=PROG1      COMMAND=A10.0000
*PROGRAM=PROG1      COMMAND=AD10.0000
*PROGRAM=PROG1      COMMAND=V5.0000
*PROGRAM=PROG1      COMMAND=L3
*PROGRAM=PROG1      COMMAND=GOSUB PROG3 LOOP COUNT=1
*PROGRAM=PROG3      COMMAND=D50000 LOOP COUNT=1
*PROGRAM=PROG3      COMMAND=GO1 LOOP COUNT=1
*PROGRAM=PROG3      COMMAND=END LOOP COUNT=1
*PROGRAM=PROG1      COMMAND=LN LOOP COUNT=1
*PROGRAM=PROG1      COMMAND=GOSUB PROG3 LOOP COUNT=2
*PROGRAM=PROG3      COMMAND=D50000 LOOP COUNT=2
*PROGRAM=PROG3      COMMAND=GO1 LOOP COUNT=2
*PROGRAM=PROG3      COMMAND=END LOOP COUNT=2
*PROGRAM=PROG1      COMMAND=LN LOOP COUNT=2
*PROGRAM=PROG1      COMMAND=GOSUB PROG3 LOOP COUNT=3
*PROGRAM=PROG3      COMMAND=D50000 LOOP COUNT=3
*PROGRAM=PROG3      COMMAND=GO1 LOOP COUNT=3
*PROGRAM=PROG3      COMMAND=END LOOP COUNT=3
*PROGRAM=PROG1      COMMAND=LN LOOP COUNT=3
*PROGRAM=PROG1      COMMAND=END
```

The format for the Trace mode display is:

```
Program Name ... Command ... Loop Count or
Program Name ... Command ... Repeat Count or
Program Name ... Command ... While Count
```

Step 5 Exit the Trace Mode.

```
TRACE0            ; Disables the Trace mode
```


Tracing Program Flow

Using the TRACEP command, you can monitor the entry and exit of programs and their associated nest levels.

For example, let's assume these four programs are defined:

```
DEF PICK1
GOSUB PICK2
GOTO PICK3
END
```

```
DEF PICK2
GOSUB PICK4
END
```

```
DEF PICK3
END
```

```
DEF PICK 4
END
```

Now we'll enable the TRACEP mode and launch the calling program (PICK1) to start tracing the program flow:

```
>TRACEP1
>PICK1
*INITIATE PROGRAM:    PICK1    NEST=1
*INITIATE PROGRAM:    PICK2    NEST=2
*INITIATE PROGRAM:    PICK4    NEST=3
*END:                 PROGRAM NOW: PICK2    NEST=2
*END:                 PROGRAM NOW: PICK1    NEST=1
*INITIATE PROGRAM:    PICK3    NEST=1
*END:                 PROGRAM EXECUTION TERMINATED
>TRACEP0
```

Single-Step Mode

The Single-Step mode allows you to execute one command at a time. Use the STEP command to enable Single-Step mode. To execute a command, you must use the !# sign. By entering a !# followed by a delimiter, you will execute the next command in the sequence. If you follow the !# sign with a number (*n*) and a delimiter, you will execute the next *n* commands. The Single-Step mode is demonstrated below (using the programs from the Trace mode above).

Step 1 Enable the Single-Step Mode:

```
STEP1          ; Enables Single Step Mode
```

Step 2 Enable the Trace Mode and begin execution of program prog1:

```
TRACE1        ; Enables the Trace mode
RUN prog1     ; Run program called prog1
```

Step 3 Execute one command at a time by using the !# command:

```
!#           ; Executes one command
```

The response will be:

```
*PROGRAM=PROG1          COMMAND=A10.0000
```

Step 4 To execute more than one command at a time, follow the !# sign with the number of commands you want executed:

```
!#3          ; Executes three commands
```

The response will be:

```
*PROGRAM=PROG1          COMMAND=AD10.0000
*PROGRAM=PROG1          COMMAND=V5.0000
*PROGRAM=PROG1          COMMAND=L3
```

To complete the sequence, use the # sign until all the commands are completed (!#16 would complete the example).

Step 5 To exit Single-Step mode, type:

```
STEP0        ; Disables Single Step Mode
```

Breakpoints

The Break Point (BP) command allows the programmer to set a place in the program where command processing will halt and a message will be transmitted to the PC. There are 32 break points available, BP1 to BP32, all transmitting the message *BREAKPOINT NUMBER x<cr> where x is the break point number.

After halting at a break point, command processing can be resumed by issuing a continue (!C) command.

The break point command is useful for stopping a program at specific locations in order to test status for debugging or other purposes.

Example

```
DEF prog1          ; Begin definition of program named prog1
D50000,1000        ; Set distance to 50000 units on axis 1, and 1000 units
                  ; on axis 2
MA1100            ; Absolute mode for axes 1 and 2
GO1100            ; Initiate motion on axes 1 and 2
IF(1PC>40000)     ; Compare axis 1 commanded position to 40000
BP1               ; If the motor position is > 40000 units, set break
                  ; point 1
NIF               ; End IF statement
D80000,2000       ; Set distance to 80000 units on axis 1, and 2000 units
                  ; on axis 2
GO1100            ; Initiate motion on axes 1 and 2

BP2               ; Set break point 2
END               ; End program definition
RUN prog1         ; Execute program prog1
```

If the IF statement evaluates true, the message *BREAKPOINT NUMBER 1 will be transferred out. A !C command must be issued before processing will continue. Once processing has continued, the second break point command will be encountered, again the message *BREAKPOINT NUMBER 2 will be transferred out, and processing of commands will pause until a second !C command is received.

Simulating I/O Activation

If your application has inputs and outputs that integrate the 6K controller with other components in your system, you can simulate the activation of these inputs and outputs so that you can run your programs without activating the rest of your system. Thus, you can debug your program independent of the rest of your system.

There are two commands that allow you to simulate the input and output states desired. The INEN command controls the inputs and the OUTEN command controls the outputs.

NOTE

The INEN command has no effect on the trigger inputs when they are configured as *trigger interrupt* (position latch) inputs with the INFNCi-H command.

The OUTEN command has no effect on the onboard outputs when they are configured as *output-on-position* outputs with the OUTFNCi-H command.

You will generally use the INEN command to cause a specific input pattern to occur so that a program can be run or an input condition can become true. Use the OUTEN command to simulate the output patterns that are needed, and to prevent an external portion of your system from being initiated by an output transition. When you execute your program, the OUTEN command overrides the outputs and holds them in a defined state.

Outputs

The following steps describe the use and function of the OUTEN command

Step 1

Display the state of the outputs with the TOUT command:

```
TOUT ; Displays the state of the outputs
```

The response will be:

```
*TOUT0000_0000_0000_0000_0000_0000_00
```

Display the function of the outputs with the OUTFNC command:

```
OUTFNC ; Displays the state of the outputs
```

The response will be:

```
*OUTFNC1-A PROGRAMMABLE OUTPUT - STATUS OFF
*OUTFNC2-A PROGRAMMABLE OUTPUT - STATUS OFF
*OUTFNC3-A PROGRAMMABLE OUTPUT - STATUS OFF
.
.
*OUTFNC26-A PROGRAMMABLE OUTPUT - STATUS OFF
```

Step 2

Disable outputs 1 - 4, leave them in the ON state.

```
OUTEN1111 ; Disable outputs 1-4, leave them in ON state
OUTFNC ; Displays the state of the outputs
```

The response will be:

```
*OUTFNC1-A PROGRAMMABLE OUTPUT - STATUS DISABLED ON
*OUTFNC2-A PROGRAMMABLE OUTPUT - STATUS DISABLED ON
*OUTFNC3-A PROGRAMMABLE OUTPUT - STATUS DISABLED ON
.
.
*OUTFNC26-A PROGRAMMABLE OUTPUT - STATUS OFF
```

Step 3

Change the output state using the OUT command. The status of all outputs, including auxiliary outputs, is displayed. The output bit pattern varies by product. To determine the bit pattern for your product, see the OUTEN command description.

```
OUT1010 ; Activates outputs 1 and 3, deactivates outputs 2 and 4
```

Display the state of the outputs with the OUTFNC command.

```
OUTFNC ; Displays the state of the outputs
```

The response will be:

```
*OUTFNC1-A PROGRAMMABLE OUTPUT - STATUS DISABLED ON
*OUTFNC2-A PROGRAMMABLE OUTPUT - STATUS DISABLED ON
*OUTFNC3-A PROGRAMMABLE OUTPUT - STATUS DISABLED ON
.
.
*OUTFNC28-A PROGRAMMABLE OUTPUT - STATUS OFF
```

Notice that output 2 and output 4 have not changed state because the output (OUT) command has no effect on disabled outputs.

Step 4

To re-enable the outputs, use the OUTEN command.

```
OUTENEEEE ; Re-enables outputs 1-4
```

Inputs

The steps below describe the use and function of the `INEN` command. You can use it to cause an input state to occur. The inputs will not actually be in this state but the 6K controller treats them as if they are in the given state and will use this state to execute its program.

Step 1 This program will wait for an input state to occur and will then make a preset move:

```
INFNC1-A      ; Onboard input 1 is has no function
INFNC2-A      ; Onboard input 2 is has no function
INLVL00       ; Set input 1 and 2 active level to low
DEF prog8     ; Begin definition of program prog8
A100          ; Acceleration is set to 100
AD100         ; Deceleration is 100
V5            ; Velocity is 5
D25000        ; Distance is 25,000
WAIT(IN=b11)  ; Waits for the input state to be 11
GO1           ; Initiate motion
END           ; End definition of program prog8
```

Step 2 Enable the Trace mode so that you can view the program as it is executed:

```
TRACE1        ; Enables the trace mode
```

Step 3 Execute the program:

```
RUN prog8     ; Runs program prog8
```

Step 4 The program will execute until the `WAIT (IN=b11)` command is encountered. The program will then pause, waiting for the input condition to be satisfied. Simulate the input state using the `INEN` command. Inputs with an E value are not affected. **NOTE** that the input bit pattern varies by product. To determine the bit pattern for your product, see the `INEN` command description.

```
!INEN11      ; Disables inputs 1 and 2, leaving them in the ON state
```

The motor will now move for 25000 steps.

Step 5 Deactivate the input simulation:

```
INENEE       ; Re-enables inputs 1 and 2
```

Simulating Analog Input Channel Voltages

Without actually applying any voltage, you can test any command or function that references the voltage on an analog input (located on an expansion I/O brick). For example, `2ANIEN.1=1.2,1.6,1.8` overrides I/O brick 2's hardware analog input 1 through 3 as follows: 1.2V on input 1, 1.6V on input 2, and 1.8V on input 3.

Another application for the `ANIEN` command can be to use it in an `ERRORP` program to override the analog input voltage in response to a fault.

Motion Planner's Panel Gallery

Motion Planner's Panel Gallery provides diagnostic panels for testing your programs and monitor the following:

- I/O (programmable I/O, analog I/O, limits)
- Motion (motor and feedback device position, velocity)
- Status (axis, system, interrupt, user-defined, Following)
- Terminal (direct communication with the product, to check for error messages, etc.)

Technical Support

For solutions to your questions about implementing 6K product software features, first look in this manual. Other aspects of the product (command descriptions, hardware specs, I/O connections, graphical user interfaces, etc.) are discussed in the respective manuals listed in *Reference Documentation* on page ii.

If you cannot find the answer in this documentation, contact your local Automation Technology Center (ATC) or distributor for assistance.

If you need to talk to our in-house application engineers, please contact us at the numbers listed on the inside cover of this manual. (The phone numbers are also provided when you issue the `HELP` command to the 6K controller.) **NOTE**

Operating System Upgrades

You can obtain an upgraded 6K operating system from our web site at www.compumotor.com. Instructions for downloading and upgrading the operating system are provided on the website.

Product Return Procedure

If you must return your 6K Series product to affect repairs or upgrades, use this procedure:

- Step 1* Get the serial number and the model number of the defective unit, and a purchase order number to cover repair costs in the event the unit is determined by the manufacturers to be out of warranty.
- Step 2* Before you return the unit, have someone from your organization with a technical understanding of the 6K Series product and its application include answers to the following questions:
- What is the extent of the failure/reason for return?
 - How long did it operate?
 - Did any other items fail at the same time?
 - What was happening when the unit failed (e.g., installing the unit, cycling power, starting other equipment, etc.)?
 - How was the product configured (in detail)?
 - What, if any, cables were modified and how?
 - With what equipment is the unit interfaced?
 - What was the application?
 - What was the system environment (temperature, enclosure, spacing, unit orientation, contaminants, etc.)?
 - What upgrades, if any, are required (hardware, software, user guide)?
- Step 3* Call for a return authorization. Refer to the Technical Support phone numbers provided on the inside cover of this manual. The support personnel will also provide shipping guidelines.

Index

- absolute position
 - absolute positioning mode 55
 - absolute zero position 55
 - establishing 55
 - status 55
- acceleration
 - change on the fly 54, 151
 - contouring 126
 - maximum (Following) 192
 - scaling 50
 - s-curve profiling 120
 - units of measure 53, 54
- access to RP240 functions 113
- accuracy
 - Following, factors affecting. 192
 - position capture 85, 155
- address
 - daisy chain (RS-232) 38
 - Ethernet
 - conflict 224
 - multi-drop (RS-485) 41
- advance, geared (Following) ... 178
- alarm events
 - trigger with an input 86
- analog inputs
 - interface 117
 - override voltage 242
- analog output (servos)
 - offset 72
 - setting limits 72
- application examples
 - cam profiling (using compiled
 - Following) 145, 148
 - continuous cut-to-length 187
 - continuous phase shift 177
 - contouring 134
 - electronic gearbox 180
 - multi-tasking 220
 - packaging (using on-the-fly
 - motion) 153
 - PLC 101
 - PLC scan mode 101
 - preset phase shift 178
 - registration 157, 158, 159
 - scaling setup 52
 - servo setup 72
 - spindle (using compiled motion)
 - 143
 - stamping (using compiled
 - Following) 147
 - teaching data points 96
 - trackball 181
 - using a joystick 101
 - using an RP240 101
 - using analog inputs 101
 - using programmable I/O 101
- arc segments 124, 129
- assignment & comparison
 - operators 7
 - used in conditional expressions
 - 25
- assignment of master and following 168
- assumptions, skills required to implement features ii
- axis moving status 228
- axis scaling 48
- axis status 228
 - extended 229
 - relative to Following 198
 - RP240 display 112
- BCD program select input 82
- before you start programming ... iii
- binary value identifier (b) 6
- binary variables (VARB) ... 18, 22
- bit patterns, programmable I/O . 76
- bit select operator (.) 6, 8
- bitwise operations (and, or, not, etc.) 22
- Boolean operations 21
- branching 23
 - conditional 25
 - unconditional 23
- buffers
 - buffered commands
 - control execution of 15
 - executed during motion ... 56, 151
 - stored in a program 9
 - command 56
- C (tangent) axis, contouring... 124, 125, 131
- cam profiling example 145, 148
- capture positions 84
- carriage return, command delimiter 6
- case sensitivity 6
- center specified arcs 130
- change summary i
- characters
 - command delimiters 6
 - comment delimiter 6
 - field separators 6
 - limit per line 6
 - neutral (spaces) 6
- circles 131
- closed-loop operation, steppers.. 64
- COM ports, controlling 37
- commanded direction polarity
 - servos 71
 - steppers 66
- commanded position
 - absolute position reference ... 55
 - follower, tracking error 191
 - status 232
- commands
 - buffer 56
 - after pause 83
 - after stop 83
 - command buffer execution
 - after end-of-travel limit (COMEXL) 15
 - after pause/continue input (COMEXR) 16
 - after stop (COMEXS) 16
 - continuous (COMEXC) 15
 - command value substitutions ... 7
 - delimiters 6
 - errors in programming 237
 - executed during motion 151
 - Following (list of) 200
 - immediate 3, 56
 - restricted execution during
 - motion 17
 - setup command list 44
 - status 228
 - syntax 3
- comment delimiter 6
- communication 35
 - controlling multiple serial ports
 - 37
 - lock port during multi-tasking
 - 214
 - Motion Planner iii
 - options 36
 - problems 224
 - RS-232C daisy-chaining 38
 - RS-485 multi-drop 41
 - via RP240 terminal 107
- compiled motion 136

compare with on-the-fly motion changes	142	C (tangent) axis ...	124, 125, 131	delimiters	
Following profiles.....	139	circles	131	command.....	6
related commands	142	compiling a path	133	comment.....	6
sample applications.....	143, 145, 147, 148	deceleration	126	detecting a stall	64
compiling a contouring path	133	deceleration scaling	51	stall indicator output.....	92
conditional branching	25, 28	defining a path	124	device address	See address
conditional expression examples	25	distance scaling.....	51	direction	
conditional go	159	end points	128	"positive" vs "negative"	53
conditional GO		executing a path.....	133	direction, changes in compiled motion	141
pending trigger input.....	85, 162	conditionally	127	distance	
conditional looping	25, 28	helical interpolation.....	126, 132	calculations, Following	195
conditional path execution	127	line segments	129	compiled motion	140
conditional statement using PMAS	185	local coordinates.....	128	change on the fly	54, 151
configuration		memory allocation	11	registration	155
DAC output limits.....	72	outputs along path	132	units of measure	53, 54
disable drive on kill	48	P (proportional) axis... ..	124, 125, 132	drive	
drive fault level	46	participating axes (PAXES)	125	fault input	
drive resolution	47	programming errors	133	active level (DRFLVL)	46
drive type (AXSDEF)	46	scaling	48	as safety feature.....	100
encoder-based stepper setup ..	64	segment boundary.....	131	enable	46
end-of-travel limits	57	stall condition (stepper axes)	131	status	229
feedback device polarity	70	velocity	126	resolution	47, 225
Following setup	168	velocity scaling.....	51	effect on Following	197
joystick.....	114	work coordinates	128	selection (AXSDEF)	46
memory allocation	11	controlling multiple serial ports.	37	shutdown	
position modes	53	count source (internally generated)		LED status.....	226
programmable inputs	79	170	on kill	48, 83
programmable outputs	90	creating programs	9	stall detection	47
scaling.....	48	DAC output, limiting.....	72	status on RP240.....	113
servo control signal offset.....	72	daisy-chaining	38, 40	dwells & direction changes,	
servo setup	67	with RP240s	41	compiled motion	141
setup commands, list.....	44	data		electrical noise	See installation
setup program	13	fields, in command syntax.....	5	guide	
step pulse (steppers).....	47	read from serial or Ethernet port	26	electronic gearbox application .	180
continuous command execution mode (COMEXC)		read from the RP240.....	26	electronic I/O devices.....	103
effect in continuous positioning mode	56	teach to variable arrays.....	94	electronics concepts	ii
continue		deadband for stall detection.....	64	enable input	
effect on Following motion..	198	debounce time		as safety feature.....	100
continue (!C).....	16, 83	position capture	84	status	230
continue execution on		program select input.....	82	enable or disable Following	173
pause/continue (COMEXR)..	16, 83	programmable inputs.....	81	status	167
83		debugging tools	227	while moving	198
continue execution on stop (COMEXS).....	16, 83	analog input voltages,		encoder	
continue input	83	simulating.....	242	capture/counter enable	
continue key on RP240	107	error messages	234	(steppers).....	65
continuous cut-to-length		I/O activation.....	240	failure detection	66
application	187	identify bad commands	237	status	229
continuous positioning mode	53, 56	problem/cause/solution table	224	feedback for steppers	64
Following.....	174, 194	RP240 menus.....	111	polarity reversal	
distance calculations	195	single-step mode.....	239	servos	70
contouring	124	status commands.....	228	steppers	65
acceleration	126	trace mode	238	position	
acceleration scaling.....	51	deceleration		RP240 display	112
arc segments.....	129	change on the fly	54, 151	resolution	64, 225
		contouring.....	126	setup example	
		scaling	50	servos	72
		s-curve profiling	120	steppers	65
		units of measure.....	53, 54	Z-channel	59
				end point	

- contouring 128
 - linear interpolation 123
- end-of-move settling 74
- end-of-travel limits See limits, end-of-travel
- error
 - clearing 31
 - error handling 30
 - error level for daisy chains 38
 - related to safety 101
 - error message
 - Following specific 199
 - error messages 234
 - Following 191
 - on-the-fly motion errors 152
 - program, assignment 30
 - status 231
- example programs ii
- executing programs... see program, execution options
- expansion I/O 78
- fault output 92
- field separator 6
- filtering, master position See master, master position filtering
- final velocity of a path 126
- follower
 - commanded position 176
 - Following error 191
 - conditional go 159
 - definition of 168
 - distance
 - scaling 172
 - motor/drive accuracy 193
 - move profiles 173
 - ratio to master 172
 - status 167
 - resolution 193
 - scaling 172
 - shift See shift
- following
 - distance
 - move calculations 195
- Following 165
 - cam profiling example . 145, 148
 - commands, list of 200
 - compiled Following profiles 139
 - conditions used in conditional expressions 27
 - distance
 - scaling 51
 - enable or disable 173
 - status 167
 - while moving 198
 - error 191
 - geared advance 178
 - master cycle concept 183
 - maximum acceleration (steppers) 192
 - maximum velocity (steppers) 192
 - performance considerations. 189
 - prerequisites to Following
 - motion 168
 - ratio Following introduction 166
 - set-up parameters 168
 - status 167, 230
 - technical considerations 189
 - virtual master 170
- geared advance (Following) ... 178
- general purpose input function .. 81
- general purpose output function 91
- global command identifier (@) ... 6
- GOSUB 23
- GOTO 23
- GOWHEN 159
 - cleared by stop or kill 197
 - error condition 231
 - using PMAS 185
 - using PMAS 198
 - via trigger input 85, 162
- hard limit. See limits, end-of-travel
- helical interpolation 126, 132
- help (tech support services) iv, 243
- hexadecimal value identifier (h). 6, 22
- homing
 - home See limits, home
 - status 228
 - zeroing the absolute position. 59
- host computer operation 118
- I/O activation (simulation) 240
- I/O device interface 102
- IF25
 - using PMAS 185
 - using PMAS 198
- immediate commands 3, 56
 - not stored in programs 9
- immediate data read from RP240 27
- immediate stop 16, 56
- in position, output function 92
- incremental positioning mode ... 55
- inputs
 - analog 117
 - application example 101
 - drive fault 100
 - active level (DRFLVL) 46
 - status 229
 - enable 100
 - status 230
 - encoder See encoder
 - end-of-travel limits .. 56, 57, 100
 - home limits 59
 - joystick 114
 - PLC 103
 - programmable 75, 102
 - alarm event 86
 - bit pattern 76
 - debounce time 81
- end-of-travel limits 89
- function assignments 79, 90
- functions (INFNC), effect on system performance 34
- functions (LIMFNC), effect on system performance .. 34
- general purpose function ... 81
- home limits 89
- jogging 86
- joystick 87
 - kill 56, 83
 - one-to-one program select. 88
 - operand (IN) 25
 - pause/continue 83
 - effect on command buffer 16
 - polarity 81
 - program security 14, 89
 - program select 82
 - simulating activation 240
 - status 80
 - status on RP240 112
 - stop 16, 56, 83
 - update rate 75
 - user fault 84, 100
- stop 16
- thumbwheel 103
- triggers
 - debounce time 81
 - position capture 84
 - programmed functions (TRGFN) 85
 - update rate 75
 - virtual inputs 79
- interface options 101
- interpolation
 - circular/contouring See contouring
 - linear See linear interpolation
- interrupts
 - program (ON conditions) 29
- jerk (acceleration), reducing 120
- jogging
 - input functions 86
 - RP240 jog mode 111
 - setup 86
 - status on RP240 111
- joystick
 - application example 96, 101
 - axis select input 87
 - interface 114
 - problems 226
 - release input 87
 - velocity select input 87
 - voltage override 242
- JUMP 23
- kill
 - assigned input function 83
 - effect on drive 48, 83
 - effect on Following 197

effect on multi-tasking.....	212		
kill on stall	64		
labels (\$).....	23		
last motion segment, compiled			
motion.....	138		
LEDs.....	226		
LEDs on RP240.....	107		
left-to-right math.....	6		
length, master cycle.....	183		
limit to DAC output.....	72		
limits			
end-of-travel	57		
as safety feature	100		
effect on command buffer and			
program execution	15		
programmed functions	89		
status	228		
used as basis to activate			
output.....	92		
home	59		
programmed functions	89		
status on RP240	112		
line feed, command delimiter	6		
line segments	124, 129		
linear interpolation.....	123		
acceleration scaling.....	51		
distance scaling.....	51		
velocity scaling	51		
local coordinate system.....	128		
lockout distance for registration			
.....	156		
logical operators.....	25		
loops			
conditional	27		
unconditional	23		
master			
definition of	168		
status	167		
direction, status of.....	167		
distance			
move calculations	195		
programming (FOLMD) ..	173		
master cycle			
counting	183		
restart	184		
status	183		
length	183		
number.....	185		
position	183		
assignment/comparison		185	
initial.....	184		
rollover.....	183, 198		
status	185		
synchronizing.....	186		
status	167		
master cycle concept.....	183		
master input (A.K.A.).....	166		
master position filtering.....	189, 190		
effect on accuracy	194		
effect on position accuracy			
.....	193		
status.....	167		
master position prediction ..	189,		
190			
effect on accuracy.....	193		
status.....	167		
move profiles.....	173		
moving, status of	167		
ratio to follower.....	172		
status.....	167		
resolution.....	193		
scaling	51, 172		
velocity.....	189		
virtual.....	170		
master/slave daisy-chain.....	38		
mathematical operations.....	19		
maximum position error			
output to indicate exceeded ..	92		
mechanical cam replacement..	145,		
148			
memory			
allocation	11		
compiled motion.....	136		
contouring.....	124		
locking.....	14, 89		
non-volatile.....	33		
status.....	12		
menus, RP240.....	110		
messages, error	234		
motion			
Following motion status	168		
motion control concepts	ii		
parameters used in conditional			
expressions	25		
pre-compiled profiles	See		
compiled motion			
restrictions while in Following			
.....	198		
rough	199		
synchronize			
conditional GOs.....	159		
registration.....	155		
triggered conditional GOs		159	
triggered start of master cycle			159
with PMAS.....	186		
Motion Planner.....	2		
communication features.....	36		
programming wizards.....	10		
setup program tool.....	13		
move completion criteria.....	74		
moving/not moving status .	92, 228		
multi-drop, RS-485.....	41		
multiple serial ports, controlling		37	
multi-tasking.....	203		
affected by kill.....	212		
application example.....	220		
conditions used in conditional			
expressions	27		
performance considerations.	218		
programmed I/O functions ..	217		
sharing system resources.....	213		
task identifier (%).....	6, 208, 215		
task-specific resources	215		
negative-direction end-of-travel			
limits	See limit, end-of-travel		
neutral characters	6		
noise, electrical	See installation		
guide			
numeric variables	18		
in conditional expression	25		
NWHILE.....	28		
on conditions (program interrupts)			
.....	29		
effect on system performance		34	
one-to-one program select input.	88		
on-line help for Windows	2		
on-line manuals.....	ii		
on-the-fly motion changes .	54, 151		
compare with compiled motion			
.....	142		
operating system upgrades	243		
operator interface			
host computer operation.....	118		
RP240 remote panel.....	107		
operators			
assignment & comparison.....	7		
correlated to status			
commands	232		
used in conditional			
expressions.....	25		
bit select	8		
bitwise	9		
logic	9		
math	9		
relational	9		
outputs			
activate on position	93		
contouring path	132		
output on position	93		
programmable	75, 102		
bit pattern	76		
fault output	92		
function assignments.....	90		
functions (OUTFNC), effect			
on system performance ..	34		
general purpose function....	91		
limit encountered.....	92		
max position error exceeded			
.....	92		
moving/not moving	92		
operand (OUT).....	25		
output on position.....	93		
polarity	91		
program in progress	92		
simulating activation	240		
stall indicator.....	92		
status	90		
status on RP240.....	112		
update rate	75		

shutdown.....	100	positioning modes	53	programmable	
update rate	75	change on the fly	54, 151	programming	
P (proportional) axis, contouring	124, 125, 132	sampling period.....	189	contouring errors.....	133
participating axes in contouring	125	effect on Following accuracy	193	contouring examples	134
partitioning memory	11	status		creating programs	9
password, RP240	113	RP240 display	112	debug tools.....	227
paths.....	See contouring	used to active an output.....	93	debugging via RP240.....	111
pause active, status	230	zeroed after homing.....	59	error messages.....	234
pause key on RP240	107	positive-direction end-of-travel limits.....	See limit, end-of-travel	error programs.....	32, 101
pause, effect on Following motion	198	power-up start program (STARTP)	13	examples, using.....	ii
pause/continue input.....	83	clear RP240 menus.....	109	executing programs	
effect on motion & program execution.....	16	Following setup commands.	170	options.....	13
performance, effects on	34	will not execute	226	preparing to program	iii
performance, Following.....	189	prediction of master position..	190.	program example	10
performance, multi-tasking.....	218	See master, master position		program security	89
phase, shift.....	176	prediction		program selection	
PLC interface.....	103	pre-emptive GOs	See on-the-fly	BCD	82
application example.....	101	motion changes		one-to-one	88
PLC scan mode.....	104	preset positioning mode	55	sample programs provided.....	ii
point-to-point move	55	Following	175, 194	scan programs in PLC mode	104
polarity		distance calculations.....	196	set-up program	13, 45
commanded direction		profiling, custom	119	skills required.....	ii
causes reversed direction	225	program		storing programs	11
servos.....	71	branch		proportional axis, contouring ..	124, 125, 132
steppers	66	conditionally.....	25	pulse width.....	47
encoder		unconditionally.....	23	radius specified arcs.....	130
servos.....	70	comments	6	radius tolerance specifications .	129
steppers	65	creating.....	9	ratio of follower to master.....	172
feedback device, servos	70	debug tools	227	status	167
programmable inputs	81	editing in Motion Planner.....	2	reading thumbwheel data	103
programmable outputs	91	error handling.....	30	reference documentation.....	ii
position		error responses	234	registration	155
absolute.....	55	examples, using.....	ii	effect on Following.....	197
establish	55	execution		lockout distance	156
accuracy, Following.....	193	controlling	15	sample application 157, 158, 159	
analog inputs.....	117	from RP240 menu	111	status	156
capture	84	options	13	related documentation.....	ii
commanded.....	65	execution status	230	relational operators	25
encoder	65	flow control.....	23	REPEAT	25
registration.....	155	interrupts	29	repeatability, Following	
commanded		labels (\$).....	23	position sampling rate.....	193
capture	84	loop		sensors.....	194
RP240 display.....	112	conditionally.....	25	trigger inputs.....	194
commanded position		unconditionally.....	23	resetting the controller	45
calculation, Following	191	memory allocation.....	11	via the RP240 menu	114
encoder	26	multi-tasking	204	resolution	
capture	84	power-up program	13	drive	47, 225
RP240 display.....	112	program example.....	10	effect on Following.....	197
error	225	programming guidelines.....	1	encoder.....	64, 225
exceeded max. limit		scan programs in PLC mode	104	follower axis	193
status	228	security	14	master axis	193
max. allowable.....	100	setup (configuration) program	13	resources used by multi-tasking	
RP240 display.....	112	storage	11	213
follower axis	176	program in progress.....	92	responses, error	234
incremental	55	programmable inputs....	See inputs,	restart master cycle counting	85, 162, 184
master	See master	programmable		restricted commands during	
		programmable outputs	See outputs,	motion	17
				return procedure.....	243

revision levels from RP240 display	114	single-step mode.....	239	assigned input function	56
revision of this manual.....	i	RP240 menu	111	effect on Following motion..	197
rollover of master cycle position	183, 185, 198	status.....	230	effect on program execution..	16, 83
rough Following motion	199	soft limit ..See limits, end-of-travel		input (INFCi-D)	16
RP240	107	space (neutral character).....	6	stop key on RP240	107
access security	113	stall deadband	64	storing programs in controller	
application example	101	stall detect		memory	11
COM port setup	37, 107	drive.....	47	storing variable data to arrays	94
connectoin verified	230	stall detection.....	64	string variables	18
data read.....	26	stall indicator output.....	92	subroutine, definition of.....	9
front panel description	107	stand-alone operation	101	substitutions, command values.....	7
in daisy chain	41	start-up program (STARTP).....	13	supervisor for multi-tasking	204
menu structure	110	examples for servos	72	support, technical	iv
send text via the connector..	107	include setup parameters	45	swapping tasks	218
RS-232C communication		will not execute	226	synchronizing motion	
daisy-chaining.....	38	statistics, controller config. &		conditional GOs (GOWHEN)	
RP240 connector.....	107	status.....	229	159
RS-485 multi-drop	41	status		Following (follower-to-master)	
runaway motor (servos)	227	absolute position.....	55	186
safety features	100	assigned to binary variable	18	registration	155
sample programs.....	ii	axis		trigger functions	
scaling.....	48, 54	extended	229	conditional GO.....	162
acceleration & deceleration ..	50	relative to Following	198	start new master cycle	162
distance	51	RP240 display.....	112	syntax	5
effect on system performance	34	command error	237	guidelines	6
follower.....	172	commands		system performance	34
master.....	51, 172	diagnostics related	228	system status	230
velocity	50	list of.....	232	RP240 display	112
scan programs (PLC scan mode)		compiled motion.....	137	system update period.....	189
.....	104	error conditions	231	tangent axis, contouring ..	124, 125, 131
security, program	14, 89	Following	167, 230	target zone.....	74
segment boundary	131	GOWHEN	160	affects moving/not moving	
segment, definition of	11	inputs		output	92
serial ports, controlling	37	enable	230	status (within zone).....	228
servo		RP240 display.....	112	timeout error.....	74
setup.....	67	LEDs	226	status	228
code examples.....	72	limits.....	228	task zero (supervisor).....	204
settling time, actual	74	RP240 display.....	112	tasks	See multi-tasking
set-up commands	44	master cycle number.....	185	teach mode	94
set-up program	13, 45	master cycle position	185	technical considerations for	
shift		motion	25, 228	Following	189
advance	178	OTF profiling conditions.....	152	technical support	iv, 243
continuous.....	176	outputs		terminal emulation	2
application example	177	RP240 display.....	112	testing	
preset.....	176	pause.....	230	program debug tools.....	227
application example	178	position	232	test panels in Motion Planner	
status	167, 176	captured	84	242
<i>shift left to right (>>)</i>	22	RP240 display.....	112	test programs, Motion Planner	2
<i>shift right to left (<<)</i>	22	program execution	230	thumbwheels	103
shutdown.....	100	programmable inputs	80	timeout, target zone.....	74
LED status	226	programmable outputs.....	90	status	228
on kill.....	48, 83	registration.....	156	trace mode.....	238
SIM modules.....	78	RP240 displays	112	RP240 menu.....	111
simulating analog input voltages		setup parameters	44	status	230
.....	242	statistics	229	trackball application.....	181
sine wave (internally generated)		system.....	230	trigger inputs	
.....	170	RP240 display.....	112	I/O bit pattern	76
single-shot registration.....	156, 158	wait.....	230	position capture.....	84
		step output pulse width.....	47		
		stop			

programmed			
conditional GO (GOWHEN)			
.....	85, 162		
restart master cycle counting			
.....	85, 162, 184		
status	167		
repeatability	194		
trigonometric operations	20		
troubleshooting	223		
command problems & solutions			
.....	224		
debug tools.....	227		
enable input status	230		
error messages	234		
Following.....	199		
general product condition report			
.....	229		
identify bad commands.....	237		
methods.....	224		
status commands.....	228		
test panels in Motion Planner			
.....	242		
truncation			
acceleration/deceleration	50		
velocity	50		
tuning			
effect on Following accuracy			
.....	194		
unconditional branching	23		
unconditional looping.....	23		
units of measurement	48		
UNTIL.....	25		
using PMAS	185		
usng PMAS	198		
update rate, programmable I/O..	75		
upgrade the 6K operating system			
.....	243		
user fault input.....	84, 92		
as safety feature.....	100		
user interface options	101		
user programs, memory allocation			
.....	11		
value substitution, command fields			
.....	7		
variables			
binary	18, 22		
in conditional expression...	25		
conversion between binary &			
numeric.....	18		
numeric.....	18		
in conditional expression...	25		
teach data.....	94		
string.....	18		
variable arrays	94		
velocity			
change on the fly	54, 151		
compiled motion	138		
contouring	126		
maximum (Following)	192		
range due to PULSE (steppers)			
.....	47		
scaling	50		
TVEL & TVELA responses			
relative to Following	198		
units of measure	53, 54		
virtual inputs	79		
virtual master	170		
WAIT	25		
compared to GOWHEN.....	161		
status	230		
using PMAS	185		
usng PMAS	198		
watchdog timer	100		
web site (www.compumotor.com)			
.....	ii		
WHILE	25, 28		
using PMAS	185		
usng PMAS	198		
work coordinate system	128		
XON/XOFF, controlling.....	37		
Z-channel	59, 63		
status	229		
zero position after homing	59		